

OVP Guide to Using Processor Models

Model Specific Information for variant ARM_ARM1156T2-S

Imperas Software Limited

Imperas Buildings, North Weston Thame, Oxfordshire, OX9 2HA, UK docs@imperas.com



Author	Imperas Software Limited
Version	0.4
Filename	OVP_Model_Specific_Information_arm_ARM1156T2-S.pdf
Created	25 August 2015

Copyright Notice

Copyright © 2015 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Table of Contents

1.0 Overview	4
1.1 Description	4
1.2 Licensing.	4
1.3 Limitations	4
1.4 Verification	5
1.5 Features	5
2.0 Configuration	5
2.1 Location	5
2.2 GDB Path	5
2.3 Semi-Host Library	5
2.4 Processor Endian-ness	5
2.5 QuantumLeap Support	5
2.6 Processor ELF Code.	
3.0 Other Variants in this Model	5
4.0 Bus Ports	
5.0 Net Ports	7
6.0 FIFO Ports	8
7.0 Parameters	8
8.0 Execution Modes	
9.0 Exceptions	10
10.0 Hierarchy of the model	
10.1 Level 1: CPU	11
11.0 Model Commands	
11.1 Level 1: CPU	
12.0 Registers	
12.1 Level 1: CPU	
12.1.1 Core	
12.1.2 Control	
12.1.3 User	
12.1.4 FIQ	
12.1.5 IRQ	
12.1.6 Supervisor	
12.1.7 Undefined.	
12.1.8 Abort	
12.1.9 Coprocessor_32_bit	
12.1.10 Coprocessor_64_bit.	
12.1.11 Integration support	16

1.0 Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms.

The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance.

Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners.

There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

1.1 Description

ARM Processor Model

1.2 Licensing

Usage of binary model under license governing simulator usage.

Note that for models of ARM CPUs the license includes the following terms:

Licensee is granted a non-exclusive, worldwide, non-transferable, revocable licence to:

If no source is being provided to the Licensee: use and copy only (no modifications rights are granted) the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

If source code is being provided to the Licensee: use, copy and modify the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

In the case of any Licensee who is either or both an academic or educational institution the purposes shall be limited to internal use.

Except to the extent that such activity is permitted by applicable law, Licensee shall not reverse engineer, decompile, or disassemble this model. If this model was provided to Licensee in Europe, Licensee shall not reverse engineer, decompile or disassemble the Model for the purposes of error correction.

The License agreement does not entitle Licensee to manufacture in silicon any product based on this model.

The License agreement does not entitle Licensee to use this model for evaluating the validity of any ARM patent.

Source of model available under separate Imperas Software License Agreement.

1.3 Limitations

Instruction pipelines are not modeled in any way. All instructions are assumed to complete immediately. This means that instruction barrier instructions (e.g. ISB, CP15ISB) are treated as NOPs, with the exception of any undefined instruction behavior, which is modeled. The model does not implement speculative fetch behavior. The branch cache is not modeled. Caches and write buffers are not modeled in any way. All loads, fetches and stores complete immediately and in order, and are fully synchronous (as if the memory was of Strongly Ordered or Device-nGnRnE type). Data barrier instructions (e.g. DSB, CP15DSB) are treated as NOPs, with the exception of any undefined instruction behavior, which is modeled. Cache manipulation instructions are implemented as NOPs, with the exception of any undefined instruction behavior, which is modeled.

Real-world timing effects are not modeled: all instructions are assumed to complete in a single cycle.

1.4 Verification

Models have been extensively tested by Imperas. ARM11 models have been successfully used by customers to simulate Linux and Nucleus on ArmIntegrator virtual platforms.

1.5 Features

Thumb-2 instructions are supported.

Trivial Jazelle extension is implemented.

PMSA address translation is implemented.

1 ITCM is implemented.

1 DTCM is implemented.

Vectored Interrupt Controller Port (VIC port) is implemented.

2.0 Configuration

2.1 Location

The model source and object file is found in the VLNV tree at: arm.ovpworld.org/processor/arm/1.0

2.2 GDB Path

The default GDB for this model is found at: \$IMPERAS_HOME/lib/\$IMPERAS_ARCH/gdb/arm-none-eabi-gdb

2.3 Semi-Host Library

The default semi-host library file is found in the VLNV tree at : arm.ovpworld.org/semihosting/armNewlib/1.0

2.4 Processor Endian-ness

This model can be set to either endian-ness (normally by a pin, or the ELF code).

2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

2.6 Processor ELF Code

The ELF code supported by this model is: 0x28

3.0 Other Variants in this Model

Table 1.

Table 1.	
Variant	
ARMv4T	
ARMv4xM	
ARMv4	
ARMv4TxM	
ARMv5xM	
ARMv5	
ARMv5TxM	
ARMv5T	
ARMv5TExP	
ARMv5TE	
ARMv5TEJ	
ARMv6	
ARMv6K	
ARMv6T2	
ARMv6KZ	
ARMv7	
ARM7TDMI	
ARM7EJ-S	
ARM720T	
ARM920T	
ARM922T	
ARM926EJ-S	
ARM940T	
ARM946E	
ARM966E	
ARM968E-S	
ARM1020E	
ARM1022E	
ARM1026EJ-S	
ARM1136J-S	
ARM1156T2-S	
ARM1176JZ-S	
Cortex-R4	
Cortex-R4F	
Cortex-A5UP	
Cortex-A5MPx1	
Cortex-A5MPx2	
Cortex-A5MPx3	
Cortex-A5MPx4	
Cortex-A8	
L	

Cortex-A9UP	
Cortex-A9MPx1	
Cortex-A9MPx2	
Cortex-A9MPx3	
Cortex-A9MPx4	
Cortex-A7UP	
Cortex-A7MPx1	
Cortex-A7MPx2	
Cortex-A7MPx3	
Cortex-A7MPx4	
Cortex-A15UP	
Cortex-A15MPx1	
Cortex-A15MPx2	
Cortex-A15MPx3	
Cortex-A15MPx4	
Cortex-A17MPx1	
Cortex-A17MPx2	
Cortex-A17MPx3	
Cortex-A17MPx4	
AArch32	
AArch64	
Cortex-A53MPx1	
Cortex-A53MPx2	
Cortex-A53MPx3	
Cortex-A53MPx4	
Cortex-A57MPx1	
Cortex-A57MPx2	
Cortex-A57MPx3	
Cortex-A57MPx4	

4.0 Bus Ports

Table 2.

Туре	Name	Bits	Description
master (initiator)	ITCM0	32	instruction TCM
master (initiator)	DTCM0	32	data TCM
master (initiator)	INSTRUCTION	32	
master (initiator)	DATA	32	

5.0 Net Ports

Table 3.

Name Type	Description
-----------	-------------

reset	input	Processor reset, active high
fiq	input	FIQ interrupt, active high (negation of nFIQ)
irq	input	IRQ interrupt, active high (negation of nIRQ)
AXI_SLVERR	input	AXI external abort type (DECERR=0, SLVERR=1)
PMUIRQ	output	Performance monitor event (active high)
VICACK	output	VIC Port acknowledge (active high)
VICADDR	input	VIC Port Address (32 bit value)

6.0 FIFO Ports

No FIFO Ports in this model.

7.0 Parameters

Table 4.

Name	Туре	Description
verbose	Boolean	Specify verbosity of output
showHiddenRegs	Boolean	Show hidden registers during register tracing
UAL	Boolean	Disassemble using UAL syntax
compatibility	Enumeration	Specify compatibility mode ISA=0 gdb=1 nopSVC=2
override_debugMask	Uns32	Specifies debug mask, enabling debug output for model components
override_fcsePresent	Boolean	Specifies that FCSE is present (if true)
override_SCTLR_V	Boolean	Override SCTLR.V with the passed value (enables high vectors)
override_SCTLR_CP15BEN_Present	Boolean	Enable ARMv7 SCTLR.CP15BEN bit (CP15 barrier enable)
override_MIDR	Uns32	Override MIDR register
override_CTR	Uns32	Override CTR register
override_MPUIR	Uns32	Override MPUIR register
override_CLIDR	Uns32	Override CLIDR register
override_AIDR	Uns32	Override AIDR register
override_PFR0	Uns32	Override ID_PFR0 register
override_PFR1	Uns32	Override ID_PFR1 register
override_DFR0	Uns32	Override ID_DFR0 register
override_AFR0	Uns32	Override ID_AFR0 register
override_MMFR0	Uns32	Override ID_MMFR0 register
override_MMFR1	Uns32	Override ID_MMFR1 register
override_MMFR2	Uns32	Override ID_MMFR2 register
override_MMFR3	Uns32	Override ID_MMFR3 register
override_ISAR0	Uns32	Override ID_ISAR0 register
override_ISAR1	Uns32	Override ID_ISAR1 register
override_ISAR2	Uns32	Override ID_ISAR2 register

override_ISAR3	Uns32	Override ID_ISAR3 register
override_ISAR4	Uns32	Override ID_ISAR4 register
override_ISAR5	Uns32	Override ID_ISAR5 register
override_ERG	Uns32	Specifies exclusive reservation granule
override_STRoffsetPC12	Boolean	Specifies that STR/STR of PC should do so with 12:byte offset from the current instruction (if true), otherwise an 8:byte offset is used
override_mpuV5ExtAP	Boolean	Specifies that ARMv5 MPU extended access permissions implemented (cp15/5/2 and cp15/5/2)
override_ignoreBadCp15	Boolean	Specifies whether invalid coprocessor 15 access should be ignored (if true) or cause Invalid Instruction exceptions (if false)
override_SGIDisable	Boolean	Override whether GIC SGIs may be disabled (if true) or are permanently enabled (if false)
override_condUndefined	Boolean	Force undefined instructions to take Undefined Instruction exception even if they are conditional
override_deviceStrongAligned	Boolean	Force accesses to Device and Strongly Ordered regions to be aligned
override_Control_V	Boolean	Override SCTLR.V with the passed value (deprecated, use override_SCTLR_V)
override_MainId	Uns32	Override MIDR register (deprecated, use override_MIDR)
override_CacheType	Uns32	Override CTR register (deprecated, use override_CTR)
override_MPUType	Uns32	Override MPUIR register (deprecated, use override_MPUIR)
override_InstructionAttributes0	Uns32	Override ID_ISAR0 register (deprecated, use override_ISAR0)
override_InstructionAttributes1	Uns32	Override ID_ISAR1 register (deprecated, use override_ISAR1)
override_InstructionAttributes2	Uns32	Override ID_ISAR2 register (deprecated, use override_ISAR2)
override_InstructionAttributes3	Uns32	Override ID_ISAR3 register (deprecated, use override_ISAR3)
override_InstructionAttributes4	Uns32	Override ID_ISAR4 register (deprecated, use override_ISAR4)
override_InstructionAttributes5	Uns32	Override ID_ISAR5 register (deprecated, use override_ISAR5)

8.0 Execution Modes

Table 5.

Code	Name
------	------

User	16
FIQ	17
IRQ	18
Supervisor	19
Abort	23
Undefined	27
System	31

9.0 Exceptions

Table 6.

Name	Code
Reset	0
Undefined	1
SupervisorCall	2
PrefetchAbort	5
DataAbort	6
IRQ	8
FIQ	9

10.0 Hierarchy of the model

A CPU core may allow the user to configure it to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy.

Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

10.1 Level 1: CPU

This level in the model hierarchy has 4 commands.

This level in the model hierarchy has 11 register groups:

Table 7.

Group name	Registers
Core	16
Control	3
User	7
FIQ	8
IRQ	3
Supervisor	3
Undefined	3
Abort	3
Coprocessor_32_bit	62
Coprocessor_64_bit	4
Integration_support	2

This level in the model hierarchy has no children.

11.0 Model Commands

11.1 Level 1: CPU

Table 8.

Name	Arguments
debugflags	
dumpTLB	
isync	specify instruction address range for synchronous execution
itrace	enable or disable instruction tracing

12.0 Registers

12.1 Level 1: CPU

12.1.1 Core

Table 9.

Name	Bits	Initial		Description
		value (Hex)		
r0	32	0	rw	
r1	32	0	rw	
r2	32	0	rw	
r3	32	0	rw	
r4	32	0	rw	
r5	32	0	rw	
r6	32	0	rw	
r7	32	0	rw	
r8	32	0	rw	
r9	32	0	rw	
r10	32	0	rw	
r11	32	0	rw	frame pointer
r12	32	0	rw	
sp	32	0	rw	stack pointer
lr	32	0	rw	
рс	32	0	rw	program counter

12.1.2 Control

Table 10.

Name		Initial value (Hex)		Description
fps	32	0	rw	archaic FPSCR view (for gdb)
cpsr	32	1d3	rw	
spsr	32	0	rw	

12.1.3 User

Table 11.

Name		Initial		Description
		value (Hex)		
r8_usr	32	0	rw	
r9_usr	32	0	rw	
r10_usr	32	0	rw	
r11_usr	32	0	rw	
r12_usr	32	0	rw	
sp_usr	32	0	rw	
Ir_usr	32	0	rw	

12.1.4 FIQ

Table 12.

Name		Initial value (Hex)		Description
		value (Hex)		
r8_fiq	32	0	rw	
r9_fiq	32	0	rw	
r10_fiq	32	0	rw	
r11_fiq	32	0	rw	
r12_fiq	32	0	rw	
sp_fiq	32	0	rw	
Ir_fiq	32	0	rw	
spsr_fiq	32	0	rw	

12.1.5 IRQ

Table 13.

Name		Initial value (Hex)		Description
sp_irq	32	0	rw	
Ir_irq	32	0	rw	
spsr_irq	32	0	rw	

12.1.6 Supervisor

Table 14.

Name		Initial value (Hex)		Description
sp_svc	32	0	rw	
Ir_svc	32	0	rw	
spsr_svc	32	0	rw	

12.1.7 Undefined

Table 15.

Name		Initial value (Hex)		Description
sp_undef	32	0	rw	
Ir_undef	32	0	rw	
spsr_undef	32	0	rw	

12.1.8 Abort

Table 16.

Name		Initial value (Hex)		Description
sp_abt	32	0	rw	
Ir_abt	32	0	rw	
spsr_abt	32	0	rw	

12.1.9 Coprocessor_32_bit

Table 17

Table 17.	1	1		I
Name	Bits	Initial		Description
		value (Hex)		
ACTLR	32	18b	rw	Auxiliary Control
CCNT	32	0	rw	Cycle Counter
CONTEXTIDR	32	0	rw	Context ID
CPACR	32	0	rw	Coprocessor Access Control
CTR	32	1d152152	r-	Cache Type
CleanDCache	32	-	-w	Clean Data Cache
CleanDCacheLineMVA	32	-	-w	Data Cache Line Clean by VA
CleanDCacheLineSW	32	-	-w	Data Cache Line Clean by Set/Way
CleanInvalDCache	32	-	-w	Data Cache Clean and Invalidate
CleanInvalDCacheLineMVA	32	-	-w	Data Cache Line Clean and Invalidate by VA
CleanInvalDCacheLineSW	32	-	-w	Data Cache Line Clean and Invalidate by Set/Way
DBGDIDR	32	0	r-	Debug ID
DCLR	32	ffffff0	rw	Data Cache Lockdown
DFAR	32	0	rw	Data Fault Address
DFSR	32	0	rw	Data Fault Status
DRACR	32	0	rw	Data Region Access Control
DRBAR	32	0	rw	Data Region Base Address
DRSR	32	0	rw	Data Region Size/Enable
DTCMRR	32	18	rw	DTCM Region
DataMemoryBarrier	32	-	-w	Data Memory Barrier
DataSynchBarrier	32	-	-w	Data Synchronization Barrier
DirtyStatus	32	0	r-	Dirty Status

FlushPrefetchBuffer	32	-	-w	Flush Prefetch Buffer
ICLR	32	fffffffO	rw	Instruction Cache Lockdown
ID_AFR0	32	0	r-	Auxiliary Feature 0
ID_DFR0	32	0	r-	Debug Feature 0
ID_ISAR0	32	141111	r-	Instruction Set Attribute 0
ID_ISAR1	32	12112111	r-	Instruction Set Attribute 1
ID_ISAR2	32	21232011	r-	Instruction Set Attribute 2
ID_ISAR3	32	1111131	r-	Instruction Set Attribute 3
ID_ISAR4	32	142	r-	Instruction Set Attribute 4
ID_ISAR5	32	0	r-	Instruction Set Attribute 5
ID_MMFR0	32	120020	r-	Memory Model Feature 0
ID_MMFR1	32	20302	r-	Memory Model Feature 1
ID_MMFR2	32	1200100	r-	Memory Model Feature 2
ID_MMFR3	32	0	r-	Memory Model Feature 3
ID_PFR0	32	131	r-	Processor Feature 0
ID_PFR1	32	1	r-	Processor Feature 1
IFAR	32	0	rw	Instruction Fault Address
IFSR	32	0	rw	Instruction Fault Status
ITCMRR	32	18	rw	ITCM Region
InvalDCache	32	-	-w	Invalidate Data Cache
InvalDCacheLineMVA	32	-	-w	Invalidate Data Cache Line by VA
InvalDCacheLineSW	32	-	-w	Invalidate Data Cache Line by Set/Way
InvallCache	32	-	-w	Invalidate Instruction Cache
InvallCacheLineMVA	32	-	-w	Invalidate Instruction Cache Line by VA
InvallCacheLineSW	32	-	-w	Invalidate Instruction Cache Line by Set/Way
InvalUnified	32	-	-w	Invalidate Unified Cache
JIDR	32	0	rw	Jazelle ID
JMCR	32	0	rw	Jazelle Main Configuration
JOSCR	32	0	rw	Jazelle OS Control
MIDR	32	410fb564	r-	Main ID
MPUIR	32	1000	r-	MPU Type
PMN0	32	0	rw	Count 0
PMN1	32	0	rw	Count 1
PMNC	32	0	rw	Performance Monitor Control
PrefetchlCacheLine	32	-	-w	Prefetch Instruction Cache Line
RGNR	32	0	rw	Region Number
SCTLR	32	50078	rw	System Control
TCMTR	32	10001	r-	ТСМ Туре
WFAR	32	0	rw	Watchpoint Fault Address
WaitForInterrupt	32	-	-W	Wait For Interrupt

12.1.10 Coprocessor_64_bit

Table 18.

Name	Bits	Initial value (Hex)		Description
CleanDCacheRange	64	-	-w	Clean Data Cache Range
CleanInvalDCacheRange	64	-		Clean and Invalidate Data Cache Range
InvalDCacheRange	64	-	-w	Invalidate Data Cache Range
InvallCacheRange	64	-	-w	Invalidate Instruction Cache Range

12.1.11 Integration_support

Table 19.

Name		Initial value (Hex)		Description
transactPL	32	1	r-	privilege level of current memory transaction
transactAT	32	0	r-	current memory transaction type: PA=1, VA=0

#