

OVP Guide to Using Processor Models

Model Specific Information for variant renesas_v850_V850E2

Imperas Software Limited

Imperas Buildings, North Weston Thame, Oxfordshire, OX9 2HA, UK docs@imperas.com



Author	Imperas Software Limited
Version	0.4
Filename	OVP_Model_Specific_Information_v850_V850E2.pdf
Created	25 August 2015

Copyright Notice

Copyright © 2015 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Table of Contents

1.0 Overview	4
1.1 Description	4
1.2 Licensing	4
1.3 Limitations	4
1.4 Verification	4
1.5 Features	4
2.0 Configuration	4
2.1 Location.	4
2.2 GDB Path	4
2.3 Semi-Host Library	4
2.4 Processor Endian-ness	5
2.5 QuantumLeap Support	5
2.6 Processor ELF Code	5
3.0 Other Variants in this Model	5
4.0 Bus Ports	5
5.0 Net Ports	5
6.0 FIFO Ports	6
7.0 Parameters	6
8.0 Execution Modes	6
9.0 Exceptions	6
10.0 Hierarchy of the model	7
10.1 Level 1:	7
11.0 Model Commands	8
11.1 Level 1:	8
12.0 Registers	8
12.1 Level 1:	8
12.1.1 User	8
12.1.2 System	9

1.0 Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms. The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance. Most models are provided as a binary shared object and also as source. This allows the

Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners.

There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

1.1 Description

V850 Family Processor Model.

1.2 Licensing

Open Source Apache 2.0

1.3 Limitations

This variant is currently under development.

1.4 Verification

Models have been extensively tested by Imperas, In addition Verification suites have been supplied by Renesas for CORE validation

1.5 Features

2.0 Configuration

2.1 Location

The model source and object file is found in the VLNV tree at: renesas.ovpworld.org/processor/v850/1.0

2.2 GDB Path

The default GDB for this model is found at: \$IMPERAS_HOME/lib/\$IMPERAS_ARCH/gdb/v850-elf-gdb

2.3 Semi-Host Library

The default semi-host library file is found in the VLNV tree at : renesas.ovpworld.org/semihosting/v850Newlib/1.0

2.4 Processor Endian-ness

This is a LITTLE endian model.

2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

2.6 Processor ELF Code

ELF codes supported by this model are: , 0x57, 0x24, 0x70f1, 0x70ff and 0x747b.

3.0 Other Variants in this Model

Table 1.

Variant	
V850	
V850E1	
V850E1F	
V850ES	
V850E2	
V850E2M	
V850E2R	

4.0 Bus Ports

Table 2.

Туре	Name	Bits
master (initiator)	INSTRUCTION	32
master (initiator)	DATA	32

5.0 Net Ports

Table 3.

Name	Туре	Description
intp	input	Interrupt Port
nmi0	input	Non-Maskable Interrupt Port
nmi1	input	Non-Maskable Interrupt Port
nmi2	input	Non-Maskable Interrupt Port
reset	input	Reset Port
mireti	output	Return from Interrupt Port
intack	output	Interrupt Acknowledge Port

6.0 FIFO Ports

No FIFO Ports in this model.

7.0 Parameters

Table 4.

Name	Туре	Description
verbose	Boolean	Specify verbose output messages
GDBSIMMODE	Boolean	GDB Simulator Compatibility Mode

8.0 Execution Modes

No execution modes.

9.0 Exceptions

Table 5.

Name	Code	Description
reset	0	Reset Signal Exception
nmi0	16	Non Maskable Interrupt(0) Exception
nmi1	32	Non Maskable Interrupt(1) Exception
nmi2	48	Non Maskable Interrupt(2) Exception
intp	65535	Maskable Interrupt Exception - Vector value = (0x0000ffff AND intp)
trap0	64	TRAP0 Exception
trap1	80	TRAP1 Exception
ilgop	96	Illegal OPCODE Exception

10.0 Hierarchy of the model

A CPU core may allow the user to configure it to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy.

Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

10.1 Level 1:

This level in the model hierarchy has 2 commands.

This level in the model hierarchy has 2 register groups:

Table 6.

Group name	Registers
User	32
System	117

This level in the model hierarchy has no children.

11.0 Model Commands

11.1 Level 1:

Table 7.

Name	Arguments
isync	specify instruction address range for synchronous execution
itrace	enable or disable instruction tracing

12.0 Registers

12.1 Level 1:

12.1.1 User

Table 8.

Name	Bits	Initial value (Hex)		Description
R0	32	0	r-	Zero Register
R1	32	0	rw	Assembler-reserved register
R2	32	0	rw	Address/data variable register (when the real-time OS to be used is not using r2)
R3	32	0	rw	Stack pointer (SP)
R4	32	0	rw	Global pointer (GP)
R5	32	0	rw	Test pointer (TP)
R6	32	0	rw	Address/data variable registers
R7	32	0	rw	Address/data variable registers
R8	32	0	rw	Address/data variable registers
R9	32	0	rw	Address/data variable registers
R10	32	0	rw	Address/data variable registers
R11	32	0	rw	Address/data variable registers
R12	32	0	rw	Address/data variable registers
R13	32	0	rw	Address/data variable registers
R14	32	0	rw	Address/data variable registers
R15	32	0	rw	Address/data variable registers
R16	32	0	rw	Address/data variable registers
R17	32	0	rw	Address/data variable registers
R18	32	0	rw	Address/data variable registers
R19	32	0	rw	Address/data variable registers
R20	32	0	rw	Address/data variable registers
R21	32	0	rw	Address/data variable registers
R22	32	0	rw	Address/data variable registers
R23	32	0	rw	Address/data variable registers
R24	32	0	rw	Address/data variable registers
R25	32	0	rw	Address/data variable registers
R26	32	0	rw	Address/data variable registers

R27	32	0	rw	Address/data variable registers
R28	32	0	rw	Address/data variable registers
R29	32	0	rw	Address/data variable registers
R30	32	0	rw	Element pointer (EP)
R31	32	0	rw	Link pointer (LP)

12.1.2 System

Table 9.

Name	Bits	Initial value (Hex)		Description
EIPC	32	0	r-	Interrupt status-saving register PC
EIPSW	32	0	r-	Interrupt status-saving register PSW
FEPC	32	0	r-	NMI status-saving register PC
FEPSW	32	0	r-	NMI status-saving register PSW
ECR	32	0	r-	Exception cause register
PSW	32	20	r-	Program status word
PID	32	0	r-	_UNIMPLEMENTED_
CFG	32	0	r-	_UNIMPLEMENTED_
SR8	32	0	r-	_UNIMPLEMENTED_
SR9	32	0	r-	_UNIMPLEMENTED_
SR10	32	0	r-	_UNIMPLEMENTED_
SCCFG	32	0	r-	_UNIMPLEMENTED_
SCBP	32	0	r-	_UNIMPLEMENTED_
EIIC	32	0	r-	El Cause Register
FEIC	32	0	r-	FE Cause Register
DBIC	32	0	r-	DB Cause Register
CTPC	32	0	r-	CALLT status-saving register PC
CTPSW	32	0	r-	CALLT status-saving register PSW
DBPC	32	0	r-	Exception/Debug trap status-saving register PC
DBPSW	32	0	r-	Exception/Debug trap status-saving register PSW
СТВР	32	0	r-	CALLT base pointer
DIR	32	0	r-	Debug Interface register
SR22	32	0	r-	_UNIMPLEMENTED_
SR23	32	0	r-	_UNIMPLEMENTED_
SR24	32	0	r-	_UNIMPLEMENTED_
SR25	32	0	r-	_UNIMPLEMENTED_
SR26	32	0	r-	_UNIMPLEMENTED_
SR27	32	0	r-	_UNIMPLEMENTED_
EIWR	32	0	r-	EIWR
FEWR	32	0	r-	FEWR
DBWR	32	0	r-	DBWR
BSEL	32	0	r-	Bank Select Register

PC	32	0	rw	Program Counter
FPVIP	32	0	r-	
SR33	32	0	r-	
SR34	32	0	r-	
SR35	32	0	r-	
VMECR	32	0	r-	
VMTID	32	0	r-	
VMADR	32	0	r-	
SR39	32	0	r-	
VPECR	32	0	r-	
VPTID	32	0	r-	
VPADR	32	0	r-	
SR43	32	0	r-	
VDECR	32	0	r-	
VDTID	32	0	r-	
SR46	32	0	r-	
SR47	32	0	r-	
SR48	32	0	r-	
SR49	32	0	r-	
SR50	32	0	r-	
SR51	32	0	r-	
SR52	32	0	r-	
SR53	32	0	r-	
SR54	32	0	r-	
SR55	32	0	r-	
SR56	32	0	r-	
SR57	32	0	r-	
SR58	32	0	r-	
SR59	32	0	r-	
MPM	32	0	r-	
MPC	32	0	r-	
TID	32	0	r-	
PPA	32	0	r-	
PPM	32	0	r-	
PPC	32	0	r-	
DCC	32	0	r-	
DCV0	32	0	r-	
DCV1	32	0	r-	
SR69	32	0	r-	
SPAL	32	0	r-	
SPAU	32	0	r-	
IPA0L	32	0	r-	

IPA0U 32 0 r-	
IPA1U 32 0 r-	
IPA2L 32 0 r-	
IPA2U 32 0 r- IPA3L 32 0 r- IPA3U 32 0 r- DPA0L 32 0 r- DPA0U 32 0 r- DPA1L 32 0 r- DPA1L 32 0 r- DPA1U 32 0 r- DPA2L 32 0 r- DPA2U 32 0 r- DPA3L 32 0 r- SR88 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR80 32 0 r- SR81 32 0 r-	
IPA3L 32 0 r- IPA3U 32 0 r- DPA0L 32 0 r- DPA0U 32 0 r- DPA1L 32 0 r- DPA1U 32 0 r- DPA2L 32 0 r- DPA3L 32 0 r- DPA3U 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
IPA3U 32 0 r- DPA0L 32 0 r- DPA0U 32 0 r- DPA1L 32 0 r- DPA1U 32 0 r- DPA2L 32 0 r- DPA2L 32 0 r- DPA3U 32 0 r- DPA3U 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR80 32 0 r- SR81 32 0 r- SR81 32 0 r- SR80 32 0 r- SR81 32 0 r-	
DPAOL 32 0 r- DPAOU 32 0 r- DPA1L 32 0 r- DPA1U 32 0 r- DPA2L 32 0 r- DPA3U 32 0 r- DPA3U 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
DPA0U 32 0 r- DPA1L 32 0 r- DPA1U 32 0 r- DPA2L 32 0 r- DPA2U 32 0 r- DPA3L 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
DPA1L 32 0 r- DPA1U 32 0 r- DPA2L 32 0 r- DPA2U 32 0 r- DPA3L 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
DPA1U 32 0 r- DPA2L 32 0 r- DPA2U 32 0 r- DPA3L 32 0 r- DPA3U 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
DPA2L 32 0 r- DPA2U 32 0 r- DPA3L 32 0 r- DPA3U 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR80 32 0 r- SR80 32 0 r- SR80 32 0 r-	
DPA2U 32 0 r- DPA3L 32 0 r- DPA3U 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
DPA3L 32 0 r- DPA3U 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
DPA3U 32 0 r- SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR80 32 0 r- SR91 32 0 r-	
SR88 32 0 r- SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
SR89 32 0 r- SR80 32 0 r- SR91 32 0 r-	
SR80 32 0 r- SR91 32 0 r-	
SR91 32 0 r-	
	I
SR92 32 0 r-	
SR93 32 0 r-	
FPSR 32 20000 r-	
FPEPC 32 0 r-	
FPST 32 0 r-	
FPCC 32 0 r-	
FPCFG 32 0 r-	
SR99 32 0 r-	
SR100 32 0 r-	
SR101 32 0 r-	
SR102 32 0 r-	
SR103 32 0 r-	
SR104 32 0 r-	
SR105 32 0 r-	
SR106 32 0 r-	
SR107 32 0 r-	
SR108 32 0 r-	
SR109 32 0 r-	
SR100 32 0 r-	
SR101 32 0 r-	
SR102 32 0 r-	
SR103 32 0 r-	
SR104 32 0 r-	

SR105

#