注意:

- (1) 任务中使用的变量应为静态变量
- (2) 线程内不能使用纯 while (1)—即含 PT_WAIT_UNTIL()等宏的 while (1)是可以的。

不能在 switch() {case…} 中调用任务 Protothreads API 带有 case 的语句(即只能单向嵌套)。

(3) 线程内可以使用:

```
for() {···}
switch() {case···}— case 与 case 之间必须是一个完整的语句或者语句段
if() {···} else {···}
含宏的 while(1) {···}
```

(4) ProtothreadS 系统可以仍然还是个大 while (1) 循环。但也可设计为根据定时器产生的恒定间隔的中断来触发和管理任务一时间触发方式的嵌入式系统,此时可更改 pt 结构体为(见《时间触发模式下的 ProtothreadS 设计应用》):

```
struct pt{
    lc_t lc;
    unsigned short count; // 每次中断都减 l
    unsigned short load; // 初始计数值
    char ready; // 任务就绪标志
```

- (5) 在 ProtothreadS 系统中延时:
 - 1) 如果 ProtothreadS 系统是基于时间触发,则延时可基于该触发一即基于系统时钟。
 - 2) 如果 ProtothreadS 系统中无系统时钟,
- (6) Protothreads 虽然提供了在各自线程内的条件阻塞机制,但对于在该线程内调用的其它函数,则无法阻塞其运行。所以,如果要在线程内调用占用时间较多的函数,为保证各个线程的实时性要求,需要将这类函数进一步划分为更小的函数,分步执行。
- (7) Protothread 的精华: 当 Protothread 程序运行到 PT_WAIT_UNTIL 时,判断其运行条件是否满足,若不满足,则阻塞。

Protothread 的阻塞其实质就是函数返回。

Protothread 仅能在程序员指定位置阻塞。

- (8)能满足系统实时性要求的条件是:(当且仅当)TaskA、TaskB、TaskC三个任务的运行时间之和要小于系统实时响应的时间要求。
- (9) 由于事件驱动模型没有阻塞机制,因此需要由程序员构造一个有限状态机来实现顺序流控制。

ProtothreadS 函数说明 1:

函数	说明	
PT_INIT(pt)	初始化任务变量,只在初始化函数中执行一次就行	
PT_BEGIN(pt)	启动任务处理,放在函数开始处	
PT_END(pt)	结束任务,放在函数的最后	
PT_WAIT_UNTIL(pt, condition)	等待某个条件(条件可以为时钟或其它变量, IO等)成立,否则直接退	
	出本函数,下一次进入本函数就直接跳到这个地方判断	
PT_WAIT_WHILE(pt, cond)	和上面一个一样,只是条件取反了	
PT_WAIT_THREAD(pt, thread)	等待一个子任务执行完成	
PT_SPAWN(pt, child, thread)	新建一个子任务,并等待其执行完退出	
PT_RESTART(pt)	重新启动某个任务执行	
PT_EXIT(pt)	任务后面的部分不执行,直接退出重新执行	
PT_YIELD(pt)	锁死任务	
PT_YIELD_UNTIL(pt, cond)	锁死任务并在等待条件成立,恢复执行	

ProtothreadS 函数说明 2:

函数	说明
struct pt {	
lc_t lc;};	
	Initialize a protothread
#define PT_INIT(pt) LC_INIT((pt)->1c)	初始化 Protothread 线程,实际上是将线程控制结构
	体里的 1c 置 0
	Declaration of a protothread
#define PT_THREAD(name_args) char name_args	声明线程
	例如: PT_THREAD(task1(struct pt *pt))
#define PT_BEGIN(pt) { char PT_YIELD_FLAG = 1;	Declare the start of a protothread
LC_RESUME((pt)->1c)	启动任务处理
#define PT_END(pt) LC_END((pt)->1c); PT_YIELD_FLAG = 0; \	Declare the end of a protothread

```
PT_INIT(pt); return PT_ENDED; }
                                                            结束任务
#define PT_WAIT_UNTIL(pt, condition)
  do {
   LC_SET((pt) \rightarrow lc);
                                                            Block and wait until condition is true
   if(!(condition)) {
                                                            等待某个条件成立
     return PT_WAITING;
 } while(0)
                                                            Block and wait while condition is true
#define PT_WAIT_WHILE(pt, cond) PT_WAIT_UNTIL((pt), !(cond))
                                                            某个条件成立则一直等待
#define PT WAIT THREAD(pt,
                              thread)
                                       PT WAIT WHILE ((pt),
                                                            Block and wait until a child protothread completes
                                                            等待一个子任务执行完成
PT SCHEDULE(thread))
#define PT_SPAWN(pt, child, thread)
  do {
                                                            Spawn a child protothread and wait until it exits
   PT_INIT((child));
                                                            新建一个子任务,并等待其执行完退出
   PT_WAIT_THREAD((pt), (thread));
 } while (0)
#define PT_RESTART(pt)
  do {
                                                            Restart the protothread
   PT INIT(pt);
                                                            线程的重新开始
   return PT_WAITING;
  } while(0)
#define PT EXIT(pt)
  do {
                                                            Exit the protothread
   PT_INIT(pt);
                                                            线程的退出
   return PT EXITED;
 } while(0)
                                                            Schedule a protothread
                                                            线程的调度。f 传递线程的状态, 当 f 为 PT_WAITING
#define PT_SCHEDULE(f) ((f) < PT_EXITED)</pre>
                                                            或 PT YIELDED 才参与调度
                                                            例如在主循环中: PT_SCHEDULE(task1(&pt_task1));
#define PT_YIELD(pt)
 do {
   PT_YIELD_FLAG = 0;
                                                            Yield from the current protothread
   LC_SET((pt) \rightarrow lc);
                                                            无条件唤醒线程。把唤醒标志设为0,接着给线程设置
    if (PT YIELD FLAG == 0) {
                                                            局部连续块,然后判断如果唤醒标志为 0 则返回
     return PT_YIELDED;
                                                            PT YIELDED 的状态
 } while (0)
#define PT_YIELD_UNTIL(pt, cond)
   PT YIELD FLAG = 0;
                                                            Yield from the protothread until a condition
   LC_SET((pt) \rightarrow lc);
                                                            occurs
   if((PT_YIELD_FLAG == 0) \mid \mid !(cond)) \{ \setminus \}
                                                            有条件唤醒线程。与无条件唤醒的区别就在于在判断
     return PT_YIELDED;
                                                            唤醒标志是否为0的同时还判断条件是否为成立
   }
 } while(0)
struct pt sem {
                                                            信号量数据结构的定义
  unsigned int count;
                                                            count 就是此信号量的值
                                                            Initialize a semaphore
\#define PT_SEM_INIT(s, c) (s) \rightarrow count = c
                                                            信号量初始化
#define PT_SEM_WAIT(pt, s)
  do {
                                                            Wait for a semaphore
   PT_WAIT_UNTIL(pt, (s)\rightarrow count > 0);
                                                            等待信号量可用
    --(s) \rightarrow count;
  } while (0)
                                                            Signal a semaphore
#define PT_SEM_SIGNAL(pt, s) ++(s)->count
                                                            信号量增加
```

此时将(s)->count 加 1, 由 PT_SEM_WAIT 程序可知, 只有当(s)->count 的值变为大于等于 0,线程才继续

简单例子:

```
#include "pt.h"
                                                           static PT THREAD(example(struct pt *pt))
static int counter:
                                                              PT BEGIN(pt);
static struct pt example_pt;
                                                              while(1) {
                                                                PT_WAIT_UNTIL(pt, counter == 1000);
int main(void)
                                                                printf("Threshold reached\n");
  counter = 0;
                                                                counter = 0;
  PT_INIT(&example_pt);
  while(1) {
                                                             PT_END(pt);
    example(&example_pt);
    counter++;
  return 0;
           PT_THREAD(example(struct pt *pt))
                                                                 char example(struct pt *pt)
            PT_BEGIN(pt);
                                                                 switch(pt->lc) { case 0:
            while(1) {
                                                                  while(1) {
             PT_WAIT_UNTIL(pt,
                                                                   pt->lc = 12; case 12:
              counter == 1000);
                                                                   if(!(counter == 1000)) return 0;
             printf("Threshold reached\n");
                                                                   printf("Threshold reached\n");
             counter = 0;
                                                                   counter = 0;
                                                                 } pt->lc = 0; return 2;
            PT_END(pt);
```

一个实时通信的例子:

```
PT THREAD(sender(struct pt *pt))
    PT_BEGIN(pt);
    do
        send packet();
        /* Wait until an ackowledgement has been received, or until the timer expires. If the timer expires,
we should send the packet again. */
        timer_set(&timer, TIMEOUT);
        PT_WAIT_UNTIL(pt, acknowledgment_received() || timer_expired(&timer));
    } while(timer_expired(&timer));
    PT_END(pt);
PT THREAD(receiver(struct pt *pt))
   PT BEGIN(pt);
    /* Wait until a packet has been received, and send an acknowledgment. */
    PT_WAIT_UNTIL(pt, packet_received());
    send acknowledgement();
    PT_END(pt);
```

```
//一个实现 delay---用于 LCD 显示时延时,当然需要增加时间信息
struct\ state\ \{
   char *text;
    char *scrollptr;
    struct pt pt;
   struct timer timer;
PT_THREAD(display_text(struct state *s))
    PT_BEGIN(&s->pt);
    /* If the text is shorter than the display size, show it right away. */
   if(strlen(s->text) <= LCD_SIZE)</pre>
        lcd_display_text(s->text);
   }
   else
        /* If the text is longer than the display, we should scroll in the text from the right with a delay of
one second per scroll step. We do this in a for() loop, where the loop variable is the pointer to the first character
to be displayed. */
        for (s-) scrollptr = s-) text; strlen(s-) scrollptr) > LCD_SIZE;
                                                                       ++s->scrollptr)
           lcd_display_text(s->scrollptr);
            /* Wait for one second. */
           timer_set(&s->timer, ONE_SECOND);
           PT_WAIT_UNTIL(&s->pt, timer_expired(&s->timer));
    PT END(&s->pt);
```

官网第一页示例:

官方生产者消费者例子 (example-buffer.c):

(1) 全局变量

```
#define NUM_ITEMS 32
                             // 定义了生产或消费的货物有 32 个
#define BUFSIZE 8
                              // 定义了缓冲区的大小为 8
static int buffer[BUFSIZE];
                             // 缓冲区
static int bufptr;
                             // 缓冲区数组下标
                             // 定义了货物的标号
static int item = 0;
                             // 定义了生产的次数
static int produced;
static int consumed;
                             // 定义了消费的次数
static struct pt_sem full, empty; // 定义了两个信号量
(2) 数据操作
    1)往缓冲区里添加货物 add_to_buffer()
    2)往缓冲区里取出货物 get_from_buffer()
   3)生产一个货物 produce_item()
    4)消费一个货物 consume_item()
(3) 三个线程的定义
    1) 生产者线程
static PT THREAD(producer(struct pt *pt))
 static int produced;
 PT_BEGIN(pt);
 for(produced = 0; produced < NUM_ITEMS; ++produced) {</pre>
    PT_SEM_WAIT(pt, &full);
    add to buffer(produce item());
    PT_SEM_SIGNAL(pt, &empty);
 PT END(pt);
可以发现,通过 PT BIGIN() 和 PT END() 保证线程操作的原子性,而通过 PT SEM WAIT() 和 PT SEM SIGNAL() 保证生产者
和消费者根据缓冲区内容的多少来行为。
    2) 生产者线程
static PT_THREAD(consumer(struct pt *pt))
 static int consumed;
 PT BEGIN(pt);
 for(consumed = 0; consumed < NUM_ITEMS; ++consumed) {</pre>
   PT SEM WAIT(pt, &empty);
   consume_item(get_from_buffer());
   PT SEM SIGNAL(pt, &full);
 PT_END(pt);
    3)驱动线程
static PT_THREAD(driver_thread(struct pt *pt))
 static struct pt pt_producer, pt_consumer;
 PT_BEGIN(pt);
 PT_SEM_INIT(&empty, 0);
 PT_SEM_INIT(&full, BUFSIZE);
 PT INIT(&pt producer);
 PT_INIT(&pt_consumer);
 PT_WAIT_THREAD(pt, producer(&pt_producer) & consumer(&pt_consumer));
 PT END(pt);
```

```
(4) 主函数
int main(void)
{
    struct pt driver_pt;

    PT_INIT(&driver_pt);

    while(PT_SCHEDULE(driver_thread(&driver_pt))) {
        /*
        * When running this example on a multitasking system, we must
        * give other processes a chance to run too and therefore we call
        * usleep() resp. Sleep() here. On a dedicated embedded system,
        * we usually do not need to do this.
        */
#ifdef _WIN32
        Sleep(0);
#else
        usleep(10);
#endif
    }
    return 0;
}
```

```
int a_protothread(struct pt *pt) {
    PT_BEGIN(pt);

PT_WAIT_UNTIL(pt, condition1);
    if(something) {
        PT_WAIT_UNTIL(pt, condition2);
    }

PT_END(pt);
}
```

Hierarchical protothreads

事件驱动程序中的顺序流控制情况(《使用 Protothread 简化嵌入式系统中的顺序流控制》,其有个密码锁例子):

