EV3

Getting Started

EV3

What Can You Program?

Supplies?









EV3 Controller

Mini-USB Cable











Color Touch Sensor Sensor

Gyro Sensor

Sensor

Ultrasonic Motors (2 Large & 1 Medium)

Handling?











Electronics Connections?

The EV3 Controller has five different types of ports:

- PC port for USB cable to download
- Wire Output ports A,B,C and D for motors
- Wire Input ports 1,2,3 and 4 for sensors
- USB Host Port for Wi-Fi or connecting Bricks
- SD Card Port

Available at:

https://github.com/chaosbuster/StarterCards



Downloading Programs?



1. Go to a PC with the LEGO Mindstorm EV3 software installed. Run the software.



2. Connect PC and EV3 Controller in one of three ways: Mini-USB cable, Wireless Bluetooth or Wi-Fi via Wi-Fi Dongle



- 3. Create your program (see below for ideas & How-Tos)
- 4. Download program to EV3 by clicking one of the Hardware Page options

Inspiration?







Ideas & Challenges



Instructables



Simple Robot



More on the EV3



How They Work!

EVERYONE HAS A PART IN KEEPING OUR MAKERSPACE CLEAN!

