
1: Types of Printers, Scanners and Webcams

Device	Type	Real-Life Use Case
Printer	Inkjet Printer	Printing college assignments and color photos
	Laser Printer	Printing many documents in an office
	Thermal Printer	Printing bills and receipts at shops
Scanner	Flatbed Scanner	Scanning certificates and important documents
	Sheet-fed Scanner	Scanning multiple pages quickly
Webcam	Built-in Webcam	Attending online classes or meetings
	USB Webcam	Video calls and online interviews

2: Diagram – Connecting a Home Printer to a Computer



3: Connection Interfaces

Connection Interface	Advantage	Disadvantage
USB	Fast and reliable connection	Requires a cable
Wi-Fi	Wireless and can connect multiple devices	Requires Wi-Fi/network setup
Bluetooth	Easy wireless connection for nearby devices	Short range and usually slower than USB

4: Steps to Connect a Printer to a Computer Using Wi-Fi

Device: Printer
Connection Method: Wi-Fi (Wireless)

Steps:

1. Turn on the printer and connect it to the power supply.
2. Make sure the printer supports Wi-Fi.
3. On the printer, open Wi-Fi or Network Settings.
4. Select your home Wi-Fi network from the available networks.
5. Enter the Wi-Fi password and connect the printer to the network.
6. Connect your laptop or PC to the same Wi-Fi network.
7. On the computer, open Settings → Bluetooth & devices → Printers & scanners.
8. Click Add device and wait for the computer to find the printer.
9. Select your printer from the list and click Add device.
10. If required, install the printer driver or printer software.
11. Open any document and select Print.
12. Select the connected printer and click Print to check the connection.