1. Common USB Keyboard/Mouse Issues

No.	Common Issue	Possible Solution
1	Keyboard/mouse is not detected	Unplug it and connect it to another USB port.
2	Keyboard or mouse is not working	Restart the laptop and reconnect the device.
3	USB port is not working	Try a different USB port or check the port for damage.
4	Device works slowly or stops responding	Update or reinstall the USB/device driver from Device Manager.
5	Wireless USB keyboard/mouse does not work	Check the batteries and reconnect the USB receiver.

2. Bluetooth Headphones Not Connecting to Phone

1. Open the phone's Check Bluetooth Settings → Bluetooth and make sure Bluetooth is ON**.**
2. Check headphones: Make sure the headphones are powered ON and have enough battery.
3. Enable pairing mode**:** Press and hold the Bluetooth/power button until the indicator light starts blinking.
4. Check the device list**:** Look for the headphone name under Available Devices.
5. Connect: Tap the headphone name and select Pair/Connect**.**
6. Check another device**:** Make sure the headphones are not already connected to another phone or laptop.
7. Forget and reconnect: If they were previously paired, select the headphones → Forget/Unpair**,** then pair them again.
8. Restart: Turn Bluetooth OFF and ON, then restart both the phone and headphones.
9. Check distance: Keep the headphones close to the phone and remove possible interference.
10. Final check**:** If they still do not connect, reset the headphones and try pairing again.

Indicators to check: Bluetooth ON/OFF status, headphone battery level, pairing light, and whether the headphone name appears in the available-device list.

3. External Webcam Not Detected in Zoom on Windows 10

1. Check USB connection: Unplug the webcam and connect it to another USB port.
2. Check Device Manager: Open Device Manager → Cameras/Imaging Devices and check whether the webcam is listed. Update the driver if required.
3. Check Privacy Settings: Go to Settings → Privacy → Camera and turn ON Allow apps to access your camera.
4. Check Zoom permissions**:** Make sure Zoom has permission to access the camera.
5. Select the correct camera in Zoom: Open Zoom → Settings → Video and select the external webcam from the camera list.
6. Close other applications: Close apps such as Teams, Skype, or Camera that may already be using the webcam, then restart Zoom.

4. Printer Showing "Offline" – Windows Troubleshooter

Steps to Use Windows Troubleshooter

1. Click Start → Settings → Update & Security → Troubleshoot.
2. Select Additional troubleshooters**.**
3. Select Printer and click Run the troubleshooter**.**
4. Windows will check the printer for common problems.
5. Select the affected printer if Windows asks you to choose one.
6. Follow the instructions shown by the troubleshooter.
7. Apply the recommended fix and try printing a test page.