1. Connect and Test a USB Webcam

Steps:

1. Connect the USB webcam to an available USB port on the computer.
2. Wait for Windows to detect the webcam automatically.
3. If required, install the webcam driver from the manufacturer's website.
4. Open Device Manager → Cameras and check that the webcam is listed without an error icon.
5. Open the Camera app from the Windows Start menu.
6. Select the connected webcam if more than one camera is available.
7. Check that the live video is displayed correctly.
8. Click the Capture/Photo button to take a photo.
9. Check the saved photo to confirm that the webcam is working properly.

2. Set Up a Local Printer and Print a Test Page

Steps:

1. Connect the printer to the computer using a USB cable or connect it to the same network as the computer.
2. Turn ON the printer and check that it is ready.
3. Open Settings → Devices → Printers & scanners.
4. Click Add a printer or scanner.
5. Select the detected printer and click Add device.
6. If Windows asks for a driver, install the correct printer driver.
7. Open the printer settings and select Manage → Print a test page.
8. Check the printed page for clear text and proper printing.

3. Printer Not Detected After Unplugging USB Cable

Steps:

1. Unplug the printer's USB cable from the computer.
2. Open Device Manager by searching for it in the Start menu.

3. Check Printers, Print queues, or Universal Serial Bus controllers.
4. Look for the printer or any device with a yellow warning/error icon.
5. Reconnect the printer's USB cable properly.
6. In Device Manager, click Action → Scan for hardware changes.
7. Wait for Windows to detect the printer again.
8. If the printer still has an error, right-click it and select Update driver.
9. Check Settings → Devices → Printers & scanners to confirm that the printer appears.
10. Print a test page to verify that the problem is fixed.

4. Webcam Works in Camera App but Not in Zoom

Steps:

1. First, close the Camera app and any other application that may be using the webcam.
2. Restart Zoom and check the webcam again.
3. Open Windows Settings → Privacy → Camera.
4. Make sure Allow apps to access your camera is turned ON.
5. Make sure Allow desktop apps to access your camera is also turned ON.
6. Open Zoom → Settings → Video.
7. Select the correct webcam from the Camera drop-down list.
8. Check the video preview to confirm that the webcam is working.
9. If the video still does not appear, restart Zoom and the computer.
10. Test the webcam again in Zoom.