Exercise 2: Keyboard Interrupt

EG-252 Group Design Exercise – Microcontroller Laboratory

Dr K. S. (Joseph) Kim Dr Chris P. Jobling

September 2014

Exercise 2: Keyboard Interrupt

For this exercise you are provided sample keyboard interrupt programs in both C and Assembly in the appendices; make sure that you have downloaded electronic versions of the program from the GitHub repository before the exercise. The program uses the interrupt generated by push buttons to switch on/off the LEDs on the MC9S08AW60 evaluation board.

You are to carry out the following three tasks with this exercise:

- Use the sample program to practice using interrupt mechanism to interface peripheral devices with the evaluation board.
- Answer the questions related to the CPU interrupt procedure (3 marks given on the final report).
- Adjust the sample program to use the onboard switches to control the display of your student number (7 marks, with 4 marks given on demonstration and 3 marks given on the final report).

The demonstration of your program on the board needs to be done no later than *Monday*, 10 November 2014.

You can view this document as a web page HTML , PDF or as a Word Document .docx

I. Experiment with the Sample Program

The sample program, "kbi_interrupt.c" and "kbi_interrupt.asm", flashes on-board LEDs upon the interrupt requests generated by the keyboard inputs, which are SW3 and SW4 used as keyboard inputs 6 and 5, respectively. The flowchart

of the program is shown in Figure 1. Enter it or copy the electronic file onto your CodeWarrior project, which is created targeting on HCS08 CPU family and MC9S08AW60 MCU.




Figure 1: Flowchart of keyboard interrupt program

After you create your own keyboard interrupt project, you can use the evaluation board to debug the sample keyboard interrupt program. Next we will introduce how to use evaluation board to configure peripheral device inputs and generate interrupts.

A. Interrupt Generation with the Evaluation Board

The evaluation board includes four pushbutton switches (SW1-SW4) which can provide momentary active low input for user applications. SW3 and SW4 are connected to MCU Port PTD3 and PTD2 respectively. If the pins of PTD3 and PTD2 are configured as KBI inputs, they will be read with "1" if the corresponding pushbutton is not pressed and "0" if pressed. Edge events and edge/level events

can be easily generated by pressing SW3 and SW4. The KBI inputs can detect the selected events as configured by the programmer and generate interrupt requests if keyboard interrupt for the inputs is enabled.

B. Experiment with the Interrupt Mechanism

Once we know how to generate keyboard interrupt events, we can use the sample program and evaluation board kits to experiment with interrupt mechanism.

According to the interrupt procedure, CPU will leave the main program and run the interrupt service routine (ISR) if interrupt for the keyboard module is enabled. You can use "Single step" or set breakpoint(s) to observe how the CPU responds to interrupt requests. After the CPU finishes the ISR, it returns to the main program. You can generate as many keyboard interrupts as you like by pushing down the switches.

You can also experiment with detection of rising edge and rising edge/high level events and correspondingly generating keyboard interrupt events by configuring the keyboard interrupt status and control register.

II. Questions

By doing experiments with either slightly modified sample C or assembly program, you are required to answer the following questions.

- 1) Upon the generation of keyboard interrupt requests, the ISR will be run by the CPU. Experiment with evaluation board, record and compare the content in the stack just before and after the CPU enter the ISR, just before and after the CPU leaves the ISR corresponding to a keyboard interrupt. You can get stack pointer value from register panel in real-time debugger window.
- 2) Explain why the stack content may change as you have observed.

III. Adjust the Sample Program to Display your Student Numbers

All the eight KBI inputs share the KBI source. In this task you are required to adjust the ISR shown in the Appendix, in order to determine which of the two pushbuttons SW3 and SW4 triggered a KBI interrupt and correspondingly display a student number of a member in your team.

Suppose the student numbers for your team are 43210 and 12345, respectively. On reset, if pushbutton SW3 is pressed down, in your ISR you should light up the leftmost nonzero digit 4 in the first student number over LEDs (i.e., in a binary

format using four LEDs). Then the CPU should leave the ISR and return to the main program. If SW3 is released and then pressed down again, the next digit 3 in the first student should be displayed over LED in your ISR. With more pressing of SW3, the following digits in the first student number are displayed sequentially. Note that after the rightmost digit 0 was displayed over LEDs upon the last pressing of SW3, the leftmost digit 4 will be displayed over LEDs upon new SW3 pressing. Similar operations are performed for the second student number 12345 if pushbutton SW4 is pressed.

You are required to design and debug the ISR program (using either Assembly or C language), and demonstrate the application to Dr Chris Jobling or Dr Tim Davies.

Appendix A

Sample Program in C

```
/* kbi interrupt.c */
2
                                       /* for EnableInterrupts macro */
   #include <hidef.h>
3
                                   /* include peripheral declarations */
   #include "derivative.h"
   typedef unsigned char muint8;
   typedef unsigned short muint16;
   typedef unsigned long muint32;
   typedef char mint8;
   typedef short mint16;
11
   typedef long mint32;
12
13
   /* to clear or set single bits in a byte variable */
14
   #define b_SetBit(bit_ID, varID)
                                          (varID |= (muint8)(1<<bit_ID))
15
   #define b_ClearBit(bit_ID, varID)
                                            (varID &= ~(muint8)(1<<bit_ID))</pre>
16
   #define b_XorBit(bit_ID, varID)
                                                    (varID ^= (muint8)(1<<bit ID))</pre>
17
18
   muint8 LED_onseq;
19
20
   void main(void) {
21
                                    /* enable interrupts */
22
           EnableInterrupts;
           SOPT = 0x00;
                                         /* disable COP */
23
24
           /* begin LED/switch test */
26
           PTDPE = 0xFF;
                                          /* enable port D pullups for push button switch interre
27
28
```

```
/* Init_GPIO init code */
29
            PTFDD = OxFF;
                                          /* set port F as outputs for LED operation */
30
           LED_onseq = OxOF;
                                     /* initialize LED_onseq */
31
            /* enable interrupt for keyboard input */
33
                                        /* KBI1SC: KBIE=0, disable KBI interrupt request */
           b_ClearBit(1, KBI1SC);
            KBI1PE = 0x60;
                                                   /* KBI1PE: KBIPE7=1, enable KBI function for
35
            b_ClearBit(0, KBI1SC);
                                           /* KBI1SC: KBIMOD=0, select edge-only detection */
36
37
            /* in defaut only falling edge events to be detected */
                                        /* KBI1SC: KBACK=1, to clear KBI flag */
           b_SetBit(2, KBI1SC);
39
            b_SetBit(1, KBI1SC);
                                        /* KBI1SC: KBIE=1, enable KBI */
40
41
            for(;;) {
42
                    __RESET_WATCHDOG(); /* feeds the dog */
                     /* loop forever */
44
                    /* please make sure that you never leave main */
45
46
47
   interrupt 22 void intKBI_SW(){
48
           KBI1SC_KBACK = 1;
                                      /*acknowledge interrupt*/
49
            PTFD = LED_onseq;
50
            LED_onseq ^= 0xFF;
                                      /* toggle LED_onseq bits */
51
   }
52
```

View on GitHub

Appendix B

Sample Program in Assembly

; Include derivative-specific definitions

```
INCLUDE 'derivative.inc'
15
16
    FLASH
                  EQU
                                       $2000
17
    RAM
                        EQU
                                             $0070
18
    WATCH
                  EQU
                                       $1802
19
20
                     ORG
                                          RAM
^{21}
                   DS.B
                                                  ; Define a variable VAR_D with a size of 1 byte
22
    LED_on
                                1
23
    ;Start program after reset
                                          FLASH
                     ORG
25
    START_UP
26
                     LDA
                                          #$00
27
                     STA
                                          WATCH
                                                                          ; Turn off the watchdog time
28
29
    ;Init_GPIO init code
30
                     LDA
                              #$FF
31
                     STA
                              PTFDD
32
                     MOV
                                                ; Initialize VAR_D, used to control the LEDs
                              #$OF, LED_on
                     LDA
                              #$FF
34
                     STA
                              PTDPE
                                                ; Port D is enabled with pull-up
                     RSP
                                                                             ; Reset stack pointer
36
37
    ;Enable interrupt for Keyboard input
38
                     LDA
                              #$60
39
                     STA
                              KBI1PE
                                                 ; KBI1PE: KBIPE7=1, enable KBI function for pins 5
40
                                                 ; KBI1SC: KBACK=1, to clear KBI flag
                     BSET
                              $02, KBI1SC
41
                              $01, KBI1SC
                                                 ; KBI1SC: KBIE=1, enable KBI
                     BSET
42
43
                     CLI
                                                 ; Enable interrupt
44
45
    MAINLOOP
46
                     LDA
                              LED on
                                                 ; Simple routine
47
                     BRA
                                          MAINLOOP
48
49
    ; Interrupt service routine for a keyboard interrupt generated upon the press of a pushbutton
50
    ; with a falling edge (transition from high logic level "1" to low logic level "0")
51
    LED_SWITCH
                     BSET
                              $02, KBI1SC
                                                ; clear KBI flag
53
                     LDA
                              LED_on
54
                     EOR
                              #$FF
                                                ; Toggle bits in VAR_D
55
                     STA
                              PTFD
                                                ; Output to light LEDs (port F)
                     STA
                                                ; Store the new value to VAR_D
                              LED on
57
                     RTI
58
59
    ; INT_VECTOR
```

61	ORG	\$FFD2
62	DC.W	LED_SWITCH
63		
64	ORG	\$FFFE
65	DC.W	START_UP

View on GitHub