Tabletop Measure

Print A4 at Actual Size / 100%. Disable Fit to Page.

Verify the OUTSIDE edges with a ruler before calibration.

Outside width = 15.00 cm; outside height = 10.00 cm

Select outside corners: top-left, top-right, bottom-right, bottom-left.
Keep the rectangle flat and align it with the camera image axes.
Calibrate with the empty desk. Remove this paper for the background
photo and product photos. Keep the phone position and lens unchanged.
If printed dimensions differ, reprint or enter the measured dimensions.