

Parameter	Description	Type	Size	Default
init-string	Init string in hexadecimal format (even length).	string	Maximum length: 127	
model	MODEM model name.	string	Maximum length: 35	
modeswitch-string	USB modeswitch arguments. For example: '-v 1410 -p 9030 -V 1410 -P 9032 -u 3'.	string	Maximum length: 127	
product-id	USB product ID in hexadecimal format (0000-ffff).	user	Not Specified	
vendor	MODEM vendor name.	string	Maximum length: 35	
vendor-id	USB vendor ID in hexadecimal format (0000-ffff).	user	Not Specified	

config system accprofile

Configure access profiles for system administrators.

```

config system accprofile
  Description: Configure access profiles for system administrators.
  edit <name>
    set admintimeout {integer}
    set admintimeout-override [enable|disable]
    set authgrp [none|read|...]
    set cli-config [enable|disable]
    set cli-diagnose [enable|disable]
    set cli-exec [enable|disable]
    set cli-get [enable|disable]
    set cli-show [enable|disable]
    set comments {var-string}
    set ftviewgrp [none|read|...]
    set fwgrp [none|read|...]
    config fwgrp-permission
      Description: Custom firewall permission.
      set address [none|read|...]
      set others [none|read|...]
      set policy [none|read|...]
      set schedule [none|read|...]
      set service [none|read|...]
    end
    set loggrp [none|read|...]
    config loggrp-permission
      Description: Custom Log & Report permission.
      set config [none|read|...]
      set data-access [none|read|...]
      set report-access [none|read|...]
      set threat-weight [none|read|...]
    end
    set netgrp [none|read|...]
    config netgrp-permission
      Description: Custom network permission.

```

```

        set cfg [none|read|...]
        set packet-capture [none|read|...]
        set route-cfg [none|read|...]
    end
    set scope [vdom|global]
    set secfabgrp [none|read|...]
    set sysgrp [none|read|...]
    config sysgrp-permission
        Description: Custom system permission.
        set admin [none|read|...]
        set cfg [none|read|...]
        set mnt [none|read|...]
        set upd [none|read|...]
    end
    set system-execute-ssh [enable|disable]
    set system-execute-telnet [enable|disable]
    set utmgrp [none|read|...]
    config utmgrp-permission
        Description: Custom Security Profile permissions.
        set antivirus [none|read|...]
        set application-control [none|read|...]
        set casb [none|read|...]
        set dlp [none|read|...]
        set dnsfilter [none|read|...]
        set emailfilter [none|read|...]
        set endpoint-control [none|read|...]
        set file-filter [none|read|...]
        set icap [none|read|...]
        set ips [none|read|...]
        set videofilter [none|read|...]
        set virtual-patch [none|read|...]
        set voip [none|read|...]
        set waf [none|read|...]
        set webfilter [none|read|...]
    end
    set vpngrp [none|read|...]
    set wanoptgrp [none|read|...]
    set wifi [none|read|...]
next
end

```

config system accprofile

Parameter	Description	Type	Size	Default
admintimeout	Administrator timeout for this access profile.	integer	Minimum value: 1 Maximum value: 480	10
admintimeout-override	Enable/disable overriding the global administrator idle timeout.	option	-	disable

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>enable</i>	Enable overriding the global administrator idle timeout.		
	<i>disable</i>	Disable overriding the global administrator idle timeout.		
authgrp	Administrator access to Users and Devices.	option	-	none
	Option	Description		
	<i>none</i>	No access.		
	<i>read</i>	Read access.		
	<i>read-write</i>	Read/write access.		
cli-config	Enable/disable permission to run config commands.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable permission to run config commands.		
	<i>disable</i>	Disable permission to run config commands.		
cli-diagnose	Enable/disable permission to run diagnostic commands.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable permission to run diagnostic commands.		
	<i>disable</i>	Disable permission to run diagnostic commands.		
cli-exec	Enable/disable permission to run execute commands.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable permission to run execute commands.		
	<i>disable</i>	Disable permission to run execute commands.		
cli-get	Enable/disable permission to run get commands.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable permission to run get commands.		
	<i>disable</i>	Disable permission to run get commands.		
cli-show	Enable/disable permission to run show commands.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable permission to run show commands.		