

Parameter	Description	Type	Size	Default
npu-offload *	Enable/disable NPU offloading.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable NPU offloading.		
	<i>disable</i>	Disable NPU offloading.		
remote-gw	Peer gateway.	ipv4-address	Not Specified	0.0.0.0
remotespi	Remote SPI, a hexadecimal 8-digit (4-byte) tag. Discerns between two traffic streams with different encryption rules.	user	Not Specified	

* This parameter may not exist in some models.

config vpn ipsec phase1-interface

Configure VPN remote gateway.

```
config vpn ipsec phase1-interface
  Description: Configure VPN remote gateway.
  edit <name>
    set acct-verify [enable|disable]
    set add-gw-route [enable|disable]
    set add-route [disable|enable]
    set aggregate-member [enable|disable]
    set aggregate-weight {integer}
    set assign-ip [disable|enable]
    set assign-ip-from [range|usrgrp|...]
    set authmethod [psk|signature]
    set authmethod-remote [psk|signature]
    set authpasswd {password}
    set authusr {string}
    set authusrgrp {string}
    set auto-discovery-crossover [allow|block]
    set auto-discovery-forwarder [enable|disable]
    set auto-discovery-offer-interval {integer}
    set auto-discovery-psk [enable|disable]
    set auto-discovery-receiver [enable|disable]
    set auto-discovery-sender [enable|disable]
    set auto-discovery-shortcuts [independent|dependent]
    set auto-negotiate [enable|disable]
    set azure-ad-autoconnect [enable|disable]
    set backup-gateway <address1>, <address2>, ...
    set banner {var-string}
    set cert-id-validation [enable|disable]
    set cert-peer-username-strip [disable|enable]
    set cert-peer-username-validation [none|othername|...]
    set cert-trust-store [local|ems]
    set certificate <name1>, <name2>, ...
    set childless-ike [enable|disable]
```

```
set client-auto-negotiate [disable|enable]
set client-keep-alive [disable|enable]
set client-resume [enable|disable]
set client-resume-interval {integer}
set comments {var-string}
set default-gw {ipv4-address}
set default-gw-priority {integer}
set dev-id {string}
set dev-id-notification [disable|enable]
set dhcp-ra-giaddr {ipv4-address}
set dhcp6-ra-linkaddr {ipv6-address}
set dhgrp {option1}, {option2}, ...
set digital-signature-auth [enable|disable]
set distance {integer}
set dns-mode [manual|auto]
set domain {string}
set dpd [disable|on-idle|...]
set dpd-retrycount {integer}
set dpd-retryinterval {user}
set eap [enable|disable]
set eap-cert-auth [enable|disable]
set eap-exclude-peergrp {string}
set eap-identity [use-id-payload|send-request]
set ems-sn-check [enable|disable]
set encap-local-gw4 {ipv4-address}
set encap-local-gw6 {ipv6-address}
set encap-remote-gw4 {ipv4-address}
set encap-remote-gw6 {ipv6-address}
set encapsulation [none|gre|...]
set encapsulation-address [ike|ipv4|...]
set enforce-unique-id [disable|keep-new|...]
set esn [require|allow|...]
set exchange-fgt-device-id [enable|disable]
set exchange-interface-ip [enable|disable]
set exchange-ip-addr4 {ipv4-address}
set exchange-ip-addr6 {ipv6-address}
set fallback-tcp-threshold {integer}
set fec-base {integer}
set fec-codec [rs|xor]
set fec-egress [enable|disable]
set fec-health-check {string}
set fec-ingress [enable|disable]
set fec-mapping-profile {string}
set fec-receive-timeout {integer}
set fec-redundant {integer}
set fec-send-timeout {integer}
set fgsp-sync [enable|disable]
set fortinet-esp [enable|disable]
set fragmentation [enable|disable]
set fragmentation-mtu {integer}
set group-authentication [enable|disable]
set group-authentication-secret {password-3}
set ha-sync-esp-seqno [enable|disable]
set idle-timeout [enable|disable]
set idle-timeoutinterval {integer}
set ike-version [1|2]
```

```

set inbound-dscp-copy [enable|disable]
set include-local-lan [disable|enable]
set interface {string}
set internal-domain-list <domain-name1>, <domain-name2>, ...
set ip-delay-interval {integer}
set ip-fragmentation [pre-encapsulation|post-encapsulation]
set ip-version [4|6]
set ipv4-dns-server1 {ipv4-address}
set ipv4-dns-server2 {ipv4-address}
set ipv4-dns-server3 {ipv4-address}
set ipv4-end-ip {ipv4-address}
config ipv4-exclude-range
    Description: Configuration Method IPv4 exclude ranges.
    edit <id>
        set end-ip {ipv4-address}
        set start-ip {ipv4-address}
    next
end
set ipv4-name {string}
set ipv4-netmask {ipv4-netmask}
set ipv4-split-exclude {string}
set ipv4-split-include {string}
set ipv4-start-ip {ipv4-address}
set ipv4-wins-server1 {ipv4-address}
set ipv4-wins-server2 {ipv4-address}
set ipv6-dns-server1 {ipv6-address}
set ipv6-dns-server2 {ipv6-address}
set ipv6-dns-server3 {ipv6-address}
set ipv6-end-ip {ipv6-address}
config ipv6-exclude-range
    Description: Configuration method IPv6 exclude ranges.
    edit <id>
        set end-ip {ipv6-address}
        set start-ip {ipv6-address}
    next
end
set ipv6-name {string}
set ipv6-prefix {integer}
set ipv6-split-exclude {string}
set ipv6-split-include {string}
set ipv6-start-ip {ipv6-address}
set keepalive {integer}
set keylife {integer}
set kms {string}
set link-cost {integer}
set local-gw {ipv4-address}
set local-gw6 {ipv6-address}
set localid {string}
set localid-type [auto|fqdn|...]
set loopback-asymroute [enable|disable]
set mesh-selector-type [disable|subnet|...]
set mode [aggressive|main]
set mode-cfg [disable|enable]
set mode-cfg-allow-client-selector [disable|enable]
set monitor <name1>, <name2>, ...
set monitor-hold-down-delay {integer}

```

```

set monitor-hold-down-time {user}
set monitor-hold-down-type [immediate|delay|...]
set monitor-hold-down-weekday [everyday|sunday|...]
set monitor-min {integer}
set natTraversal [enable|disable|...]
set negotiate-timeout {integer}
set net-device [enable|disable]
set network-id {integer}
set network-overlay [disable|enable]
set npu-offload [enable|disable]
set packet-redistribution [enable|disable]
set passive-mode [enable|disable]
set peer {string}
set peergrp {string}
set peerid {string}
set peertype [any|one|...]
set ppk [disable|allow|...]
set ppk-identity {string}
set ppk-secret {password-3}
set priority {integer}
set proposal {option1}, {option2}, ...
set psksecret {password-3}
set psksecret-remote {password-3}
set qkd [disable|allow|...]
set qkd-profile {string}
set reauth [disable|enable]
set rekey [enable|disable]
set remote-gw {ipv4-address}
set remote-gw-country {string}
set remote-gw-end-ip {ipv4-address-any}
set remote-gw-match [any|ipmask|...]
set remote-gw-start-ip {ipv4-address-any}
set remote-gw-subnet {ipv4-classnet-any}
set remote-gw6 {ipv6-address}
set remote-gw6-country {string}
set remote-gw6-end-ip {ipv6-address}
set remote-gw6-match [any|ipprefix|...]
set remote-gw6-start-ip {ipv6-address}
set remote-gw6-subnet {ipv6-network}
set remotegw-ddns {string}
set rsa-signature-format [pkcs1|pss]
set rsa-signature-hash-override [enable|disable]
set save-password [disable|enable]
set send-cert-chain [enable|disable]
set signature-hash-alg {option1}, {option2}, ...
set split-include-service {string}
set suite-b [disable|suite-b-gcm-128|...]
set transport [udp|udp-fallback-tcp|...]
set type [static|dynamic|...]
set unity-support [disable|enable]
set usrgrp {string}
set vni {integer}
set wizard-type [custom|dialup-forticlient|...]
set xauthtype [disable|client|...]
next
end

```

config vpn ipsec phase1-interface

Parameter	Description	Type	Size	Default
acct-verify	Enable/disable verification of RADIUS accounting record.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable verification of RADIUS accounting record.		
	<i>disable</i>	Disable verification of RADIUS accounting record.		
add-gw-route	Enable/disable automatically add a route to the remote gateway.	option	-	disable
	Option	Description		
	<i>enable</i>	Automatically add a route to the remote gateway.		
	<i>disable</i>	Do not automatically add a route to the remote gateway.		
add-route	Enable/disable control addition of a route to peer destination selector.	option	-	enable
	Option	Description		
	<i>disable</i>	Do not add a route to destination of peer selector.		
	<i>enable</i>	Add route to destination of peer selector.		
aggregate-member	Enable/disable use as an aggregate member.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable use as an aggregate member.		
	<i>disable</i>	Disable use as an aggregate member.		
aggregate-weight	Link weight for aggregate.	integer	Minimum value: 1 Maximum value: 100	1
assign-ip	Enable/disable assignment of IP to IPsec interface via configuration method.	option	-	enable
	Option	Description		
	<i>disable</i>	Do not assign an IP address to the IPsec interface.		
	<i>enable</i>	Assign an IP address to the IPsec interface.		
assign-ip-from	Method by which the IP address will be assigned.	option	-	range

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>range</i>	Assign IP address from locally defined range.		
	<i>usrgrp</i>	Assign IP address via user group.		
	<i>dhcp</i>	Assign IP address via DHCP.		
	<i>name</i>	Assign IP address from firewall address or group.		
authmethod	Authentication method.	option	-	psk
	Option	Description		
	<i>psk</i>	PSK authentication method.		
	<i>signature</i>	Signature authentication method.		
authmethod-remote	Authentication method (remote side).	option	-	
	Option	Description		
	<i>psk</i>	PSK authentication method.		
	<i>signature</i>	Signature authentication method.		
authpasswd	XAuth password (max 35 characters).	password	Not Specified	
authusr	XAuth user name.	string	Maximum length: 64	
authusrgrp	Authentication user group.	string	Maximum length: 35	
auto-discovery-crossover	Allow/block set-up of short-cut tunnels between different network IDs.	option	-	allow
	Option	Description		
	<i>allow</i>	Allow set-up of short-cut tunnels between different network IDs.		
	<i>block</i>	Block set-up of short-cut tunnels between different network IDs.		
auto-discovery-forwarder	Enable/disable forwarding auto-discovery short-cut messages.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable forwarding auto-discovery short-cut messages.		
	<i>disable</i>	Disable forwarding auto-discovery short-cut messages.		

Parameter	Description	Type	Size	Default
auto-discovery-offer-interval	Interval between shortcut offer messages in seconds.	integer	Minimum value: 1 Maximum value: 300	5
auto-discovery-psk	Enable/disable use of pre-shared secrets for authentication of auto-discovery tunnels.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable use of pre-shared-secret authentication for auto-discovery tunnels.		
	<i>disable</i>	Disable use of authentication defined by 'authmethod' for auto-discovery tunnels.		
auto-discovery-receiver	Enable/disable accepting auto-discovery short-cut messages.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable receiving auto-discovery short-cut messages.		
	<i>disable</i>	Disable receiving auto-discovery short-cut messages.		
auto-discovery-sender	Enable/disable sending auto-discovery short-cut messages.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable sending auto-discovery short-cut messages.		
	<i>disable</i>	Disable sending auto-discovery short-cut messages.		
auto-discovery-shortcuts	Control deletion of child short-cut tunnels when the parent tunnel goes down.	option	-	independent
	Option	Description		
	<i>independent</i>	Short-cut tunnels remain up if the parent tunnel goes down.		
	<i>dependent</i>	Short-cut tunnels are brought down if the parent tunnel goes down.		
auto-negotiate	Enable/disable automatic initiation of IKE SA negotiation.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable automatic initiation of IKE SA negotiation.		
	<i>disable</i>	Disable automatic initiation of IKE SA negotiation.		

Parameter	Description	Type	Size	Default
azure-ad-autoconnect	Enable/disable Azure AD Auto-Connect for FortiClient.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable Azure AD Auto-Connect for FortiClient.		
	<i>disable</i>	Disable Azure AD Auto-Connect for FortiClient.		
backup-gateway<address>	Instruct unity clients about the backup gateway address(es). Address of backup gateway.	string	Maximum length: 79	
banner	Message that unity client should display after connecting.	var-string	Maximum length: 1024	
cert-id-validation	Enable/disable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.		
	<i>disable</i>	Disable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.		
cert-peer-username-strip	Enable/disable domain stripping on certificate identity.	option	-	disable
	Option	Description		
	<i>disable</i>	Disable domain stripping on certificate identity.		
	<i>enable</i>	Enable domain stripping on certificate identity.		
cert-peer-username-validation	Enable/disable cross validation of peer username and the identity in the peer's certificate.	option	-	none
	Option	Description		
	<i>none</i>	Disable cross validation of peer username and the identity in the peer's certificate.		
	<i>othername</i>	Validate principal name in SAN othername.		
	<i>rfc822name</i>	Validate RFC822 email address in SAN.		
	<i>cn</i>	Validate CN in subject.		
cert-trust-store	CA certificate trust store.	option	-	local

Parameter	Description	Type	Size	Default						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>local</i></td><td>Use local CA certificate.</td></tr><tr><td><i>ems</i></td><td>Use EMS CA certificate.</td></tr></table>	Option	Description	<i>local</i>	Use local CA certificate.	<i>ems</i>	Use EMS CA certificate.			
	Option	Description								
	<i>local</i>	Use local CA certificate.								
<i>ems</i>	Use EMS CA certificate.									
certificate <name>	The names of up to 4 signed personal certificates. Certificate name.	string	Maximum length: 79							
childless-ike	Enable/disable childless IKEv2 initiation (RFC 6023).	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable childless IKEv2 initiation (RFC 6023).</td></tr><tr><td><i>disable</i></td><td>Disable childless IKEv2 initiation (RFC 6023).</td></tr></table>	Option	Description	<i>enable</i>	Enable childless IKEv2 initiation (RFC 6023).	<i>disable</i>	Disable childless IKEv2 initiation (RFC 6023).			
	Option	Description								
	<i>enable</i>	Enable childless IKEv2 initiation (RFC 6023).								
<i>disable</i>	Disable childless IKEv2 initiation (RFC 6023).									
client-auto-negotiate	Enable/disable allowing the VPN client to bring up the tunnel when there is no traffic.	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable allowing the VPN client to bring up the tunnel when there is no traffic.</td></tr><tr><td><i>enable</i></td><td>Enable allowing the VPN client to bring up the tunnel when there is no traffic.</td></tr></table>	Option	Description	<i>disable</i>	Disable allowing the VPN client to bring up the tunnel when there is no traffic.	<i>enable</i>	Enable allowing the VPN client to bring up the tunnel when there is no traffic.			
	Option	Description								
	<i>disable</i>	Disable allowing the VPN client to bring up the tunnel when there is no traffic.								
<i>enable</i>	Enable allowing the VPN client to bring up the tunnel when there is no traffic.									
client-keep-alive	Enable/disable allowing the VPN client to keep the tunnel up when there is no traffic.	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable allowing the VPN client to keep the tunnel up when there is no traffic.</td></tr><tr><td><i>enable</i></td><td>Enable allowing the VPN client to keep the tunnel up when there is no traffic.</td></tr></table>	Option	Description	<i>disable</i>	Disable allowing the VPN client to keep the tunnel up when there is no traffic.	<i>enable</i>	Enable allowing the VPN client to keep the tunnel up when there is no traffic.			
	Option	Description								
	<i>disable</i>	Disable allowing the VPN client to keep the tunnel up when there is no traffic.								
<i>enable</i>	Enable allowing the VPN client to keep the tunnel up when there is no traffic.									
client-resume	Enable/disable resumption of offline FortiClient sessions. When a FortiClient enabled laptop is closed or enters sleep/hibernate mode, enabling this feature allows FortiClient to keep the tunnel during this period, and allows users to immediately resume using the IPsec tunnel when the device wakes up.	option	-	disable						

Parameter	Description	Type	Size	Default												
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable client session resumption.</td></tr><tr><td><i>disable</i></td><td>Disable client session resumption.</td></tr></table>	Option	Description	<i>enable</i>	Enable client session resumption.	<i>disable</i>	Disable client session resumption.									
	Option	Description														
	<i>enable</i>	Enable client session resumption.														
<i>disable</i>	Disable client session resumption.															
client-resume-interval	Maximum time in seconds during which a VPN client may resume using a tunnel after a client PC has entered sleep mode or temporarily lost its network connection.	integer	Minimum value: 120 Maximum value: 172800	7200												
comments	Comment.	var-string	Maximum length: 255													
default-gw	IPv4 address of default route gateway to use for traffic exiting the interface.	ipv4-address	Not Specified	0.0.0.0												
default-gw-priority	Priority for default gateway route. A higher priority number signifies a less preferred route.	integer	Minimum value: 0 Maximum value: 4294967295	0												
dev-id	Device ID carried by the device ID notification.	string	Maximum length: 63													
dev-id-notification	Enable/disable device ID notification.	option	-	disable												
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable device ID notification.</td></tr><tr><td><i>enable</i></td><td>Enable device ID notification.</td></tr></table>	Option	Description	<i>disable</i>	Disable device ID notification.	<i>enable</i>	Enable device ID notification.									
	Option	Description														
	<i>disable</i>	Disable device ID notification.														
<i>enable</i>	Enable device ID notification.															
dhcp-ra-giaddr	Relay agent gateway IP address to use in the giaddr field of DHCP requests.	ipv4-address	Not Specified	0.0.0.0												
dhcp6-ra-linkaddr	Relay agent IPv6 link address to use in DHCP6 requests.	ipv6-address	Not Specified	::												
dhgrp	DH group.	option	-	14												
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>1</td><td>DH Group 1.</td></tr><tr><td>2</td><td>DH Group 2.</td></tr><tr><td>5</td><td>DH Group 5.</td></tr><tr><td>14</td><td>DH Group 14.</td></tr><tr><td>15</td><td>DH Group 15.</td></tr></table>	Option	Description	1	DH Group 1.	2	DH Group 2.	5	DH Group 5.	14	DH Group 14.	15	DH Group 15.			
	Option	Description														
	1	DH Group 1.														
	2	DH Group 2.														
	5	DH Group 5.														
	14	DH Group 14.														
15	DH Group 15.															

Parameter	Description	Type	Size	Default																										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>16</td><td>DH Group 16.</td></tr><tr><td>17</td><td>DH Group 17.</td></tr><tr><td>18</td><td>DH Group 18.</td></tr><tr><td>19</td><td>DH Group 19.</td></tr><tr><td>20</td><td>DH Group 20.</td></tr><tr><td>21</td><td>DH Group 21.</td></tr><tr><td>27</td><td>DH Group 27.</td></tr><tr><td>28</td><td>DH Group 28.</td></tr><tr><td>29</td><td>DH Group 29.</td></tr><tr><td>30</td><td>DH Group 30.</td></tr><tr><td>31</td><td>DH Group 31.</td></tr><tr><td>32</td><td>DH Group 32.</td></tr></table>	Option	Description	16	DH Group 16.	17	DH Group 17.	18	DH Group 18.	19	DH Group 19.	20	DH Group 20.	21	DH Group 21.	27	DH Group 27.	28	DH Group 28.	29	DH Group 29.	30	DH Group 30.	31	DH Group 31.	32	DH Group 32.			
	Option	Description																												
	16	DH Group 16.																												
	17	DH Group 17.																												
	18	DH Group 18.																												
	19	DH Group 19.																												
	20	DH Group 20.																												
	21	DH Group 21.																												
	27	DH Group 27.																												
	28	DH Group 28.																												
	29	DH Group 29.																												
	30	DH Group 30.																												
	31	DH Group 31.																												
	32	DH Group 32.																												
digital-signature-auth	Enable/disable IKEv2 Digital Signature Authentication (RFC 7427).	option	-	disable																										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Enable IKEv2 Digital Signature Authentication (RFC 7427).</td></tr><tr><td>disable</td><td>Disable IKEv2 Digital Signature Authentication (RFC 7427).</td></tr></table>	Option	Description	enable	Enable IKEv2 Digital Signature Authentication (RFC 7427).	disable	Disable IKEv2 Digital Signature Authentication (RFC 7427).																							
	Option	Description																												
	enable	Enable IKEv2 Digital Signature Authentication (RFC 7427).																												
disable	Disable IKEv2 Digital Signature Authentication (RFC 7427).																													
distance	Distance for routes added by IKE.	integer	Minimum value: 1 Maximum value: 255	15																										
dns-mode	DNS server mode.	option	-	manual																										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>manual</td><td>Manually configure DNS servers.</td></tr><tr><td>auto</td><td>Use default DNS servers.</td></tr></table>	Option	Description	manual	Manually configure DNS servers.	auto	Use default DNS servers.																							
	Option	Description																												
	manual	Manually configure DNS servers.																												
auto	Use default DNS servers.																													
domain	Instruct unity clients about the single default DNS domain.	string	Maximum length: 63																											
dpd	Dead Peer Detection mode.	option	-	on-demand																										

Parameter	Description	Type	Size	Default								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable Dead Peer Detection.</td></tr><tr><td><i>on-idle</i></td><td>Trigger Dead Peer Detection when IPsec is idle.</td></tr><tr><td><i>on-demand</i></td><td>Trigger Dead Peer Detection when IPsec traffic is sent but no reply is received from the peer.</td></tr></table>	Option	Description	<i>disable</i>	Disable Dead Peer Detection.	<i>on-idle</i>	Trigger Dead Peer Detection when IPsec is idle.	<i>on-demand</i>	Trigger Dead Peer Detection when IPsec traffic is sent but no reply is received from the peer.			
	Option	Description										
	<i>disable</i>	Disable Dead Peer Detection.										
	<i>on-idle</i>	Trigger Dead Peer Detection when IPsec is idle.										
<i>on-demand</i>	Trigger Dead Peer Detection when IPsec traffic is sent but no reply is received from the peer.											
dpd-retrycount	Number of DPD retry attempts.	integer	Minimum value: 0 Maximum value: 10	3								
dpd-retryinterval	DPD retry interval.	user	Not Specified									
eap	Enable/disable IKEv2 EAP authentication.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable IKEv2 EAP authentication.</td></tr><tr><td><i>disable</i></td><td>Disable IKEv2 EAP authentication.</td></tr></table>	Option	Description	<i>enable</i>	Enable IKEv2 EAP authentication.	<i>disable</i>	Disable IKEv2 EAP authentication.					
	Option	Description										
	<i>enable</i>	Enable IKEv2 EAP authentication.										
<i>disable</i>	Disable IKEv2 EAP authentication.											
eap-cert-auth	Enable/disable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.</td></tr><tr><td><i>disable</i></td><td>Disable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.</td></tr></table>	Option	Description	<i>enable</i>	Enable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.	<i>disable</i>	Disable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.					
	Option	Description										
	<i>enable</i>	Enable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.										
<i>disable</i>	Disable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.											
eap-exclude-peergp	Peer group excluded from EAP authentication.	string	Maximum length: 35									
eap-identity	IKEv2 EAP peer identity type.	option	-	use-id-payload								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>use-id-payload</i></td><td>Use IKEv2 IDi payload to resolve peer identity.</td></tr><tr><td><i>send-request</i></td><td>Use EAP identity request to resolve peer identity.</td></tr></table>	Option	Description	<i>use-id-payload</i>	Use IKEv2 IDi payload to resolve peer identity.	<i>send-request</i>	Use EAP identity request to resolve peer identity.					
	Option	Description										
	<i>use-id-payload</i>	Use IKEv2 IDi payload to resolve peer identity.										
<i>send-request</i>	Use EAP identity request to resolve peer identity.											
ems-sn-check	Enable/disable verification of EMS serial number.	option	-	disable								

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>enable</i>	Enable EMS serial number verification.		
	<i>disable</i>	Disable EMS serial number verification.		
encap-local-gw4	Local IPv4 address of GRE/VXLAN tunnel.	ipv4-address	Not Specified	0.0.0.0
encap-local-gw6	Local IPv6 address of GRE/VXLAN tunnel.	ipv6-address	Not Specified	::
encap-remote-gw4	Remote IPv4 address of GRE/VXLAN tunnel.	ipv4-address	Not Specified	0.0.0.0
encap-remote-gw6	Remote IPv6 address of GRE/VXLAN tunnel.	ipv6-address	Not Specified	::
encapsulation	Enable/disable GRE/VXLAN/VPNID encapsulation.	option	-	none
	Option	Description		
	<i>none</i>	No additional encapsulation.		
	<i>gre</i>	GRE encapsulation.		
	<i>vxlan</i>	VXLAN encapsulation.		
	<i>vpn-id-ipip</i>	VPN ID with IPIP encapsulation.		
encapsulation-address	Source for GRE/VXLAN tunnel address.	option	-	ike
	Option	Description		
	<i>ike</i>	Use IKE/IPsec gateway addresses.		
	<i>ipv4</i>	Specify separate GRE/VXLAN tunnel address.		
	<i>ipv6</i>	Specify separate GRE/VXLAN tunnel address.		
enforce-unique-id	Enable/disable peer ID uniqueness check.	option	-	disable
	Option	Description		
	<i>disable</i>	Disable peer ID uniqueness enforcement.		
	<i>keep-new</i>	Enforce peer ID uniqueness, keep new connection if collision found.		
	<i>keep-old</i>	Enforce peer ID uniqueness, keep old connection if collision found.		

Parameter	Description	Type	Size	Default								
esn *	Extended sequence number (ESN) negotiation.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>require</i></td><td>Require extended sequence number.</td></tr><tr><td><i>allow</i></td><td>Allow extended sequence number.</td></tr><tr><td><i>disable</i></td><td>Disable extended sequence number.</td></tr></table>	Option	Description	<i>require</i>	Require extended sequence number.	<i>allow</i>	Allow extended sequence number.	<i>disable</i>	Disable extended sequence number.			
Option	Description											
<i>require</i>	Require extended sequence number.											
<i>allow</i>	Allow extended sequence number.											
<i>disable</i>	Disable extended sequence number.											
exchange-fgt-device-id	Enable/disable device identifier exchange with peer FortiGate units for use of VPN monitor data by FortiManager.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable exchange of FortiGate device identifier.</td></tr><tr><td><i>disable</i></td><td>Disable exchange of FortiGate device identifier.</td></tr></table>	Option	Description	<i>enable</i>	Enable exchange of FortiGate device identifier.	<i>disable</i>	Disable exchange of FortiGate device identifier.					
Option	Description											
<i>enable</i>	Enable exchange of FortiGate device identifier.											
<i>disable</i>	Disable exchange of FortiGate device identifier.											
exchange-interface-ip	Enable/disable exchange of IPsec interface IP address.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable exchange of IPsec interface IP address.</td></tr><tr><td><i>disable</i></td><td>Disable exchange of IPsec interface IP address.</td></tr></table>	Option	Description	<i>enable</i>	Enable exchange of IPsec interface IP address.	<i>disable</i>	Disable exchange of IPsec interface IP address.					
Option	Description											
<i>enable</i>	Enable exchange of IPsec interface IP address.											
<i>disable</i>	Disable exchange of IPsec interface IP address.											
exchange-ip-addr4	IPv4 address to exchange with peers.	ipv4-address	Not Specified	0.0.0.0								
exchange-ip-addr6	IPv6 address to exchange with peers.	ipv6-address	Not Specified	::								
fallback-tcp-threshold	Timeout in seconds before falling back IKE/IPsec traffic to tcp.	integer	Minimum value: 1 Maximum value: 300	15								
fec-base	Number of base Forward Error Correction packets.	integer	Minimum value: 1 Maximum value: 20	10								
fec-codec	Forward Error Correction encoding/decoding algorithm.	option	-	rs								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>rs</i></td><td>Reed-Solomon FEC algorithm.</td></tr></table>	Option	Description	<i>rs</i>	Reed-Solomon FEC algorithm.							
Option	Description											
<i>rs</i>	Reed-Solomon FEC algorithm.											

Parameter	Description	Type	Size	Default							
fec-egress	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>xor</i></td><td>XOR FEC algorithm.</td></tr></table>		Option	Description	<i>xor</i>	XOR FEC algorithm.	option	-	disable		
	Option	Description									
	<i>xor</i>	XOR FEC algorithm.									
	Enable/disable Forward Error Correction for egress IPsec traffic.										
<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable Forward Error Correction for egress IPsec traffic.</td></tr><tr><td><i>disable</i></td><td>Disable Forward Error Correction for egress IPsec traffic.</td></tr></table>		Option	Description	<i>enable</i>	Enable Forward Error Correction for egress IPsec traffic.	<i>disable</i>	Disable Forward Error Correction for egress IPsec traffic.				
Option	Description										
<i>enable</i>	Enable Forward Error Correction for egress IPsec traffic.										
<i>disable</i>	Disable Forward Error Correction for egress IPsec traffic.										
fec-health-check	SD-WAN health check.	string	Maximum length: 35								
fec-ingress	Enable/disable Forward Error Correction for ingress IPsec traffic.		option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable Forward Error Correction for ingress IPsec traffic.</td></tr><tr><td><i>disable</i></td><td>Disable Forward Error Correction for ingress IPsec traffic.</td></tr></table>		Option	Description	<i>enable</i>	Enable Forward Error Correction for ingress IPsec traffic.	<i>disable</i>	Disable Forward Error Correction for ingress IPsec traffic.			
	Option	Description									
	<i>enable</i>	Enable Forward Error Correction for ingress IPsec traffic.									
<i>disable</i>	Disable Forward Error Correction for ingress IPsec traffic.										
Forward Error Correction (FEC) mapping profile.		string	Maximum length: 35								
fec-receive-timeout	Timeout in milliseconds before dropping Forward Error Correction packets.	integer	Minimum value: 1 Maximum value: 1000	50							
fec-redundant	Number of redundant Forward Error Correction packets.	integer	Minimum value: 1 Maximum value: 5	1							
fec-send-timeout	Timeout in milliseconds before sending Forward Error Correction packets.	integer	Minimum value: 1 Maximum value: 1000	5							
fgsp-sync	Enable/disable IPsec syncing of tunnels for FGSP IPsec.	option	-	disable							
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable IPsec syncing of tunnels to other cluster members.</td></tr><tr><td><i>disable</i></td><td>Disable IPsec syncing of tunnels to other cluster members.</td></tr></table>		Option	Description	<i>enable</i>	Enable IPsec syncing of tunnels to other cluster members.	<i>disable</i>	Disable IPsec syncing of tunnels to other cluster members.			
	Option	Description									
	<i>enable</i>	Enable IPsec syncing of tunnels to other cluster members.									
<i>disable</i>	Disable IPsec syncing of tunnels to other cluster members.										

Parameter	Description	Type	Size	Default
fortinet-esp	Enable/disable Fortinet ESP encapsulation.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable Fortinet ESP encapsulation.		
	<i>disable</i>	Disable Fortinet ESP encapsulation.		
fragmentation	Enable/disable fragment IKE message on re-transmission.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable intra-IKE fragmentation support on re-transmission.		
	<i>disable</i>	Disable intra-IKE fragmentation support.		
fragmentation-mtu	IKE fragmentation MTU.	integer	Minimum value: 500 Maximum value: 16000	1200
group-authentication	Enable/disable IKEv2 IDi group authentication.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable IKEv2 IDi group authentication.		
	<i>disable</i>	Disable IKEv2 IDi group authentication.		
group-authentication-secret	Password for IKEv2 ID group authentication. ASCII string or hexadecimal indicated by a leading 0x.	password-3	Not Specified	
ha-sync-esp-seqno	Enable/disable sequence number jump ahead for IPsec HA.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable HA syncing of ESP sequence numbers.		
	<i>disable</i>	Disable HA syncing of ESP sequence numbers.		
idle-timeout	Enable/disable IPsec tunnel idle timeout.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable IPsec tunnel idle timeout.		
	<i>disable</i>	Disable IPsec tunnel idle timeout.		

Parameter	Description	Type	Size	Default						
idle-timeoutinterval	IPsec tunnel idle timeout in minutes.	integer	Minimum value: 5 Maximum value: 43200	15						
ike-version	IKE protocol version.	option	-	1						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>1</td><td>Use IKEv1 protocol.</td></tr><tr><td>2</td><td>Use IKEv2 protocol.</td></tr></table>	Option	Description	1	Use IKEv1 protocol.	2	Use IKEv2 protocol.			
Option	Description									
1	Use IKEv1 protocol.									
2	Use IKEv2 protocol.									
inbound-dscp-copy	Enable/disable copy the dscp in the ESP header to the inner IP Header.	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Enable copy the dscp in the ESP header to the inner IP Header.</td></tr><tr><td>disable</td><td>Disable copy the dscp in the ESP header to the inner IP Header.</td></tr></table>	Option	Description	enable	Enable copy the dscp in the ESP header to the inner IP Header.	disable	Disable copy the dscp in the ESP header to the inner IP Header.			
Option	Description									
enable	Enable copy the dscp in the ESP header to the inner IP Header.									
disable	Disable copy the dscp in the ESP header to the inner IP Header.									
include-local-lan	Enable/disable allow local LAN access on unity clients.	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Disable local LAN access on Unity clients.</td></tr><tr><td>enable</td><td>Enable local LAN access on Unity clients.</td></tr></table>	Option	Description	disable	Disable local LAN access on Unity clients.	enable	Enable local LAN access on Unity clients.			
Option	Description									
disable	Disable local LAN access on Unity clients.									
enable	Enable local LAN access on Unity clients.									
interface	Local physical, aggregate, or VLAN outgoing interface.	string	Maximum length: 35							
internal-domain-list <domain-name>	One or more internal domain names in quotes separated by spaces. Domain name.	string	Maximum length: 79							
ip-delay-interval	IP address reuse delay interval in seconds.	integer	Minimum value: 0 Maximum value: 28800	0						
ip-fragmentation	Determine whether IP packets are fragmented before or after IPsec encapsulation.	option	-	post-encapsulation						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>pre-encapsulation</td><td>Fragment before IPsec encapsulation.</td></tr></table>	Option	Description	pre-encapsulation	Fragment before IPsec encapsulation.					
Option	Description									
pre-encapsulation	Fragment before IPsec encapsulation.									

Parameter	Description	Type	Size	Default						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>post-encapsulation</i></td><td>Fragment after IPsec encapsulation (RFC compliant).</td></tr></table>	Option	Description	<i>post-encapsulation</i>	Fragment after IPsec encapsulation (RFC compliant).					
	Option	Description								
	<i>post-encapsulation</i>	Fragment after IPsec encapsulation (RFC compliant).								
ip-version	IP version to use for VPN interface.	option	-	4						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>4</td><td>Use IPv4 addressing for gateways.</td></tr><tr><td>6</td><td>Use IPv6 addressing for gateways.</td></tr></table>	Option	Description	4	Use IPv4 addressing for gateways.	6	Use IPv6 addressing for gateways.			
	Option	Description								
	4	Use IPv4 addressing for gateways.								
6	Use IPv6 addressing for gateways.									
ipv4-dns-server1	IPv4 DNS server 1.	ipv4-address	Not Specified	0.0.0.0						
ipv4-dns-server2	IPv4 DNS server 2.	ipv4-address	Not Specified	0.0.0.0						
ipv4-dns-server3	IPv4 DNS server 3.	ipv4-address	Not Specified	0.0.0.0						
ipv4-end-ip	End of IPv4 range.	ipv4-address	Not Specified	0.0.0.0						
ipv4-name	IPv4 address name.	string	Maximum length: 79							
ipv4-netmask	IPv4 Netmask.	ipv4-netmask	Not Specified	255.255.255.255						
ipv4-split-exclude	IPv4 subnets that should not be sent over the IPsec tunnel.	string	Maximum length: 79							
ipv4-split-include	IPv4 split-include subnets.	string	Maximum length: 79							
ipv4-start-ip	Start of IPv4 range.	ipv4-address	Not Specified	0.0.0.0						
ipv4-wins-server1	WINS server 1.	ipv4-address	Not Specified	0.0.0.0						
ipv4-wins-server2	WINS server 2.	ipv4-address	Not Specified	0.0.0.0						
ipv6-dns-server1	IPv6 DNS server 1.	ipv6-address	Not Specified	::						
ipv6-dns-server2	IPv6 DNS server 2.	ipv6-address	Not Specified	::						
ipv6-dns-server3	IPv6 DNS server 3.	ipv6-address	Not Specified	::						
ipv6-end-ip	End of IPv6 range.	ipv6-address	Not Specified	::						
ipv6-name	IPv6 address name.	string	Maximum length: 79							

Parameter	Description	Type	Size	Default														
ipv6-prefix	IPv6 prefix.	integer	Minimum value: 1 Maximum value: 128	128														
ipv6-split-exclude	IPv6 subnets that should not be sent over the IPsec tunnel.	string	Maximum length: 79															
ipv6-split-include	IPv6 split-include subnets.	string	Maximum length: 79															
ipv6-start-ip	Start of IPv6 range.	ipv6-address	Not Specified	::														
keepalive	NAT-T keep alive interval.	integer	Minimum value: 5 Maximum value: 900	10														
keylife	Time to wait in seconds before phase 1 encryption key expires.	integer	Minimum value: 120 Maximum value: 172800	86400														
kms	Key Management Services server.	string	Maximum length: 35															
link-cost	VPN tunnel underlay link cost.	integer	Minimum value: 0 Maximum value: 255	0														
local-gw	IPv4 address of the local gateway's external interface.	ipv4-address	Not Specified	0.0.0.0														
local-gw6	IPv6 address of the local gateway's external interface.	ipv6-address	Not Specified	::														
localid	Local ID.	string	Maximum length: 63															
localid-type	Local ID type.	option	-	auto														
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>auto</td><td>Select ID type automatically.</td></tr><tr><td>fqdn</td><td>Use fully qualified domain name.</td></tr><tr><td>user-fqdn</td><td>Use user fully qualified domain name.</td></tr><tr><td>keyid</td><td>Use key-id string.</td></tr><tr><td>address</td><td>Use local IP address.</td></tr><tr><td>asn1dn</td><td>Use ASN.1 distinguished name.</td></tr></table>				Option	Description	auto	Select ID type automatically.	fqdn	Use fully qualified domain name.	user-fqdn	Use user fully qualified domain name.	keyid	Use key-id string.	address	Use local IP address.	asn1dn	Use ASN.1 distinguished name.
Option	Description																	
auto	Select ID type automatically.																	
fqdn	Use fully qualified domain name.																	
user-fqdn	Use user fully qualified domain name.																	
keyid	Use key-id string.																	
address	Use local IP address.																	
asn1dn	Use ASN.1 distinguished name.																	

Parameter	Description	Type	Size	Default								
loopback-asymroute	Enable/disable asymmetric routing for IKE traffic on loopback interface.	option	-	enable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Allow ingress/egress IKE traffic to be routed over different interfaces.</td></tr><tr><td>disable</td><td>Ingress/egress IKE traffic must be routed over the same interface.</td></tr></table>	Option	Description	enable	Allow ingress/egress IKE traffic to be routed over different interfaces.	disable	Ingress/egress IKE traffic must be routed over the same interface.					
Option	Description											
enable	Allow ingress/egress IKE traffic to be routed over different interfaces.											
disable	Ingress/egress IKE traffic must be routed over the same interface.											
mesh-selector-type	Add selectors containing subsets of the configuration depending on traffic.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Disable.</td></tr><tr><td>subnet</td><td>Enable addition of matching subnet selector.</td></tr><tr><td>host</td><td>Enable addition of host to host selector.</td></tr></table>	Option	Description	disable	Disable.	subnet	Enable addition of matching subnet selector.	host	Enable addition of host to host selector.			
Option	Description											
disable	Disable.											
subnet	Enable addition of matching subnet selector.											
host	Enable addition of host to host selector.											
mode	The ID protection mode used to establish a secure channel.	option	-	main								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>aggressive</td><td>Aggressive mode.</td></tr><tr><td>main</td><td>Main mode.</td></tr></table>	Option	Description	aggressive	Aggressive mode.	main	Main mode.					
Option	Description											
aggressive	Aggressive mode.											
main	Main mode.											
mode-cfg	Enable/disable configuration method.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Disable Configuration Method.</td></tr><tr><td>enable</td><td>Enable Configuration Method.</td></tr></table>	Option	Description	disable	Disable Configuration Method.	enable	Enable Configuration Method.					
Option	Description											
disable	Disable Configuration Method.											
enable	Enable Configuration Method.											
mode-cfg-allow-client-selector	Enable/disable mode-cfg client to use custom phase2 selectors.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Mode-cfg client to use wildcard selectors.</td></tr><tr><td>enable</td><td>Mode-cfg client to use custom selectors.</td></tr></table>	Option	Description	disable	Mode-cfg client to use wildcard selectors.	enable	Mode-cfg client to use custom selectors.					
Option	Description											
disable	Mode-cfg client to use wildcard selectors.											
enable	Mode-cfg client to use custom selectors.											
monitor <name>	IPsec interface as backup for primary interface. IPsec interface as backup for primary interface.	string	Maximum length: 79									

Parameter	Description	Type	Size	Default
monitor-hold-down-delay	Time to wait in seconds before recovery once primary re-establishes.	integer	Minimum value: 0 Maximum value: 31536000	0
monitor-hold-down-time	Time of day at which to fail back to primary after it re-establishes.	user	Not Specified	
monitor-hold-down-type	Recovery time method when primary interface re-establishes.	option	-	immediate
	Option		Description	
	immediate	Fail back immediately after primary recovers.		
	delay	Number of seconds to delay fail back after primary recovers.		
	time	Specify a time at which to fail back after primary recovers.		
monitor-hold-down-weekday	Day of the week to recover once primary re-establishes.	option	-	sunday
	Option		Description	
	everyday	Every Day.		
	sunday	Sunday.		
	monday	Monday.		
	tuesday	Tuesday.		
	wednesday	Wednesday.		
	thursday	Thursday.		
	friday	Friday.		
saturday	Saturday.			
monitor-min	Minimum number of links to become degraded before activating this interface. Zero (0) means all links must be down before activating this interface.	integer	Minimum value: 0 Maximum value: 4294967295	0
name	IPsec remote gateway name.	string	Maximum length: 15	
nattraversal	Enable/disable NAT traversal.	option	-	enable

Parameter	Description	Type	Size	Default
	Option Description			
	<i>enable</i>	Enable IPsec NAT traversal.		
	<i>disable</i>	Disable IPsec NAT traversal.		
	<i>forced</i>	Force IPsec NAT traversal on.		
negotiate-timeout	IKE SA negotiation timeout in seconds.	integer	Minimum value: 1 Maximum value: 300	30
net-device	Enable/disable kernel device creation.	option	-	disable
	Option Description			
	<i>enable</i>	Create a kernel device for every tunnel.		
	<i>disable</i>	Do not create a kernel device for tunnels.		
network-id	VPN gateway network ID.	integer	Minimum value: 0 Maximum value: 255	0
network-overlay	Enable/disable network overlays.	option	-	disable
	Option Description			
	<i>disable</i>	Disable network overlays.		
	<i>enable</i>	Enable network overlays.		
npu-offload *	Enable/disable offloading NPU.	option	-	enable
	Option Description			
	<i>enable</i>	Enable NPU offloading.		
	<i>disable</i>	Disable NPU offloading.		
packet-redistribution *	Enable/disable packet distribution (RPS) on the IPsec interface.	option	-	disable
	Option Description			
	<i>enable</i>	Enable packet redistribution.		
	<i>disable</i>	Disable packet redistribution.		
passive-mode	Enable/disable IPsec passive mode for static tunnels.	option	-	disable

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>enable</i>	Enable IPsec passive mode.		
	<i>disable</i>	Disable IPsec passive mode.		
peer	Accept this peer certificate.	string	Maximum length: 35	
peergrp	Accept this peer certificate group.	string	Maximum length: 35	
peerid	Accept this peer identity.	string	Maximum length: 255	
peertype	Accept this peer type.	option	-	peer
	Option	Description		
	<i>any</i>	Accept any peer ID.		
	<i>one</i>	Accept this peer ID.		
	<i>dialup</i>	Accept peer ID in dialup group.		
	<i>peer</i>	Accept this peer certificate.		
	<i>peergrp</i>	Accept this peer certificate group.		
ppk	Enable/disable IKEv2 Postquantum Preshared Key (PPK).	option	-	disable
	Option	Description		
	<i>disable</i>	Disable use of IKEv2 Postquantum Preshared Key (PPK).		
	<i>allow</i>	Allow, but do not require, use of IKEv2 Postquantum Preshared Key (PPK).		
	<i>require</i>	Require use of IKEv2 Postquantum Preshared Key (PPK).		
ppk-identity	IKEv2 Postquantum Preshared Key Identity.	string	Maximum length: 35	
ppk-secret	IKEv2 Postquantum Preshared Key (ASCII string or hexadecimal encoded with a leading 0x).	password-3	Not Specified	
priority	Priority for routes added by IKE.	integer	Minimum value: 1 Maximum value: 65535	1
proposal	Phase1 proposal.	option	-	

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>des-md5</i>	des-md5		
	<i>des-sha1</i>	des-sha1		
	<i>des-sha256</i>	des-sha256		
	<i>des-sha384</i>	des-sha384		
	<i>des-sha512</i>	des-sha512		
	<i>3des-md5</i>	3des-md5		
	<i>3des-sha1</i>	3des-sha1		
	<i>3des-sha256</i>	3des-sha256		
	<i>3des-sha384</i>	3des-sha384		
	<i>3des-sha512</i>	3des-sha512		
	<i>aes128-md5</i>	aes128-md5		
	<i>aes128-sha1</i>	aes128-sha1		
	<i>aes128-sha256</i>	aes128-sha256		
	<i>aes128-sha384</i>	aes128-sha384		
	<i>aes128-sha512</i>	aes128-sha512		
	<i>aes128gcm-prfsha1</i>	aes128gcm-prfsha1		
	<i>aes128gcm-prfsha256</i>	aes128gcm-prfsha256		
	<i>aes128gcm-prfsha384</i>	aes128gcm-prfsha384		
	<i>aes128gcm-prfsha512</i>	aes128gcm-prfsha512		
	<i>aes192-md5</i>	aes192-md5		
	<i>aes192-sha1</i>	aes192-sha1		
	<i>aes192-sha256</i>	aes192-sha256		
	<i>aes192-sha384</i>	aes192-sha384		
	<i>aes192-sha512</i>	aes192-sha512		
	<i>aes256-md5</i>	aes256-md5		
	<i>aes256-sha1</i>	aes256-sha1		
	<i>aes256-sha256</i>	aes256-sha256		
	<i>aes256-sha384</i>	aes256-sha384		
	<i>aes256-sha512</i>	aes256-sha512		

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>aes256gcm-prfsha1</i>	aes256gcm-prfsha1		
	<i>aes256gcm-prfsha256</i>	aes256gcm-prfsha256		
	<i>aes256gcm-prfsha384</i>	aes256gcm-prfsha384		
	<i>aes256gcm-prfsha512</i>	aes256gcm-prfsha512		
	<i>chacha20poly1305-prfsha1</i>	chacha20poly1305-prfsha1		
	<i>chacha20poly1305-prfsha256</i>	chacha20poly1305-prfsha256		
	<i>chacha20poly1305-prfsha384</i>	chacha20poly1305-prfsha384		
	<i>chacha20poly1305-prfsha512</i>	chacha20poly1305-prfsha512		
	<i>aria128-md5</i>	aria128-md5		
	<i>aria128-sha1</i>	aria128-sha1		
	<i>aria128-sha256</i>	aria128-sha256		
	<i>aria128-sha384</i>	aria128-sha384		
	<i>aria128-sha512</i>	aria128-sha512		
	<i>aria192-md5</i>	aria192-md5		
	<i>aria192-sha1</i>	aria192-sha1		
	<i>aria192-sha256</i>	aria192-sha256		
	<i>aria192-sha384</i>	aria192-sha384		
	<i>aria192-sha512</i>	aria192-sha512		
	<i>aria256-md5</i>	aria256-md5		
	<i>aria256-sha1</i>	aria256-sha1		
	<i>aria256-sha256</i>	aria256-sha256		
	<i>aria256-sha384</i>	aria256-sha384		
	<i>aria256-sha512</i>	aria256-sha512		
	<i>seed-md5</i>	seed-md5		
	<i>seed-sha1</i>	seed-sha1		
	<i>seed-sha256</i>	seed-sha256		
	<i>seed-sha384</i>	seed-sha384		
	<i>seed-sha512</i>	seed-sha512		

Parameter	Description	Type	Size	Default
psksecret	Pre-shared secret for PSK authentication (ASCII string or hexadecimal encoded with a leading 0x).	password-3	Not Specified	
psksecret-remote	Pre-shared secret for remote side PSK authentication (ASCII string or hexadecimal encoded with a leading 0x).	password-3	Not Specified	
qkd	Enable/disable use of Quantum Key Distribution (QKD) server.	option	-	disable
	Option		Description	
	<i>disable</i>		Disable use of a Quantum Key Distribution (QKD) server.	
	<i>allow</i>		Allow, but do not require, use of a Quantum Key Distribution (QKD) server.	
	<i>require</i>		Require use of a Quantum Key Distribution (QKD) server.	
qkd-profile	Quantum Key Distribution (QKD) server profile.	string	Maximum length: 35	
reauth	Enable/disable re-authentication upon IKE SA lifetime expiration.	option	-	disable
	Option		Description	
	<i>disable</i>		Disable IKE SA re-authentication.	
	<i>enable</i>		Enable IKE SA re-authentication.	
rekey	Enable/disable phase1 rekey.	option	-	enable
	Option		Description	
	<i>enable</i>		Enable phase1 rekey.	
	<i>disable</i>		Disable phase1 rekey.	
remote-gw	IPv4 address of the remote gateway's external interface.	ipv4-address	Not Specified	0.0.0.0
remote-gw-country	IPv4 addresses associated to a specific country.	string	Maximum length: 2	
remote-gw-end-ip	Last IPv4 address in the range.	ipv4-address-any	Not Specified	0.0.0.0
remote-gw-match	Set type of IPv4 remote gateway address matching.	option	-	any

Parameter	Description	Type	Size	Default										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>any</i></td><td>Match any IPv4 gateway address.</td></tr><tr><td><i>ipmask</i></td><td>Match IPv4 gateway address and mask.</td></tr><tr><td><i>iprange</i></td><td>Match IPv4 gateway address range.</td></tr><tr><td><i>geography</i></td><td>Match IPv4 gateway address from a specified country.</td></tr></table>	Option	Description	<i>any</i>	Match any IPv4 gateway address.	<i>ipmask</i>	Match IPv4 gateway address and mask.	<i>iprange</i>	Match IPv4 gateway address range.	<i>geography</i>	Match IPv4 gateway address from a specified country.			
	Option	Description												
	<i>any</i>	Match any IPv4 gateway address.												
	<i>ipmask</i>	Match IPv4 gateway address and mask.												
	<i>iprange</i>	Match IPv4 gateway address range.												
<i>geography</i>	Match IPv4 gateway address from a specified country.													
remote-gw-start-ip	First IPv4 address in the range.	ipv4-address-any	Not Specified	0.0.0.0										
remote-gw-subnet	IPv4 address and subnet mask.	ipv4-classnet-any	Not Specified	0.0.0.0 0.0.0.0										
remote-gw6	IPv6 address of the remote gateway's external interface.	ipv6-address	Not Specified	::										
remote-gw6-country	IPv6 addresses associated to a specific country.	string	Maximum length: 2											
remote-gw6-end-ip	Last IPv6 address in the range.	ipv6-address	Not Specified	::										
remote-gw6-match	Set type of IPv6 remote gateway address matching.	option	-	any										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>any</i></td><td>Match any IPv6 gateway address.</td></tr><tr><td><i>ipprefix</i></td><td>Match IPv6 gateway address and prefix.</td></tr><tr><td><i>iprange</i></td><td>Match IPv6 gateway address range.</td></tr><tr><td><i>geography</i></td><td>Match IPv6 gateway address from a specified country.</td></tr></table>	Option	Description	<i>any</i>	Match any IPv6 gateway address.	<i>ipprefix</i>	Match IPv6 gateway address and prefix.	<i>iprange</i>	Match IPv6 gateway address range.	<i>geography</i>	Match IPv6 gateway address from a specified country.			
	Option	Description												
	<i>any</i>	Match any IPv6 gateway address.												
	<i>ipprefix</i>	Match IPv6 gateway address and prefix.												
	<i>iprange</i>	Match IPv6 gateway address range.												
<i>geography</i>	Match IPv6 gateway address from a specified country.													
remote-gw6-start-ip	First IPv6 address in the range.	ipv6-address	Not Specified	::										
remote-gw6-subnet	IPv6 address and prefix.	ipv6-network	Not Specified	::/0										
remotegw-ddns	Domain name of remote gateway. For example, name.ddns.com.	string	Maximum length: 63											
rsa-signature-format	Digital Signature Authentication RSA signature format.	option	-	pkcs1										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>pkcs1</i></td><td>RSASSA PKCS#1 v1.5.</td></tr><tr><td><i>pss</i></td><td>RSASSA Probabilistic Signature Scheme (PSS).</td></tr></table>	Option	Description	<i>pkcs1</i>	RSASSA PKCS#1 v1.5.	<i>pss</i>	RSASSA Probabilistic Signature Scheme (PSS).							
	Option	Description												
	<i>pkcs1</i>	RSASSA PKCS#1 v1.5.												
<i>pss</i>	RSASSA Probabilistic Signature Scheme (PSS).													

Parameter	Description	Type	Size	Default										
rsa-signature-hash-override	Enable/disable IKEv2 RSA signature hash algorithm override.	option	-	disable										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Enable IKEv2 RSA signature hash algorithm override.</td></tr><tr><td>disable</td><td>Disable IKEv2 RSA signature hash algorithm override.</td></tr></table>	Option	Description	enable	Enable IKEv2 RSA signature hash algorithm override.	disable	Disable IKEv2 RSA signature hash algorithm override.							
	Option	Description												
	enable	Enable IKEv2 RSA signature hash algorithm override.												
disable	Disable IKEv2 RSA signature hash algorithm override.													
save-password	Enable/disable saving XAuth username and password on VPN clients.	option	-	disable										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Disable saving XAuth username and password on VPN clients.</td></tr><tr><td>enable</td><td>Enable saving XAuth username and password on VPN clients.</td></tr></table>	Option	Description	disable	Disable saving XAuth username and password on VPN clients.	enable	Enable saving XAuth username and password on VPN clients.							
	Option	Description												
	disable	Disable saving XAuth username and password on VPN clients.												
enable	Enable saving XAuth username and password on VPN clients.													
send-cert-chain	Enable/disable sending certificate chain.	option	-	enable										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Enable sending certificate chain.</td></tr><tr><td>disable</td><td>Disable sending certificate chain.</td></tr></table>	Option	Description	enable	Enable sending certificate chain.	disable	Disable sending certificate chain.							
	Option	Description												
	enable	Enable sending certificate chain.												
disable	Disable sending certificate chain.													
signature-hash-alg	Digital Signature Authentication hash algorithms.	option	-	sha2-512										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>sha1</td><td>SHA1.</td></tr><tr><td>sha2-256</td><td>SHA2-256.</td></tr><tr><td>sha2-384</td><td>SHA2-384.</td></tr><tr><td>sha2-512</td><td>SHA2-512.</td></tr></table>	Option	Description	sha1	SHA1.	sha2-256	SHA2-256.	sha2-384	SHA2-384.	sha2-512	SHA2-512.			
	Option	Description												
	sha1	SHA1.												
	sha2-256	SHA2-256.												
	sha2-384	SHA2-384.												
sha2-512	SHA2-512.													
split-include-service	Split-include services.	string	Maximum length: 79											
suite-b	Use Suite-B.	option	-	disable										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Do not use UI suite.</td></tr><tr><td>suite-b-gcm-128</td><td>Use Suite-B-GCM-128.</td></tr><tr><td>suite-b-gcm-256</td><td>Use Suite-B-GCM-256.</td></tr></table>	Option	Description	disable	Do not use UI suite.	suite-b-gcm-128	Use Suite-B-GCM-128.	suite-b-gcm-256	Use Suite-B-GCM-256.					
	Option	Description												
	disable	Do not use UI suite.												
	suite-b-gcm-128	Use Suite-B-GCM-128.												
suite-b-gcm-256	Use Suite-B-GCM-256.													
transport	Set IKE transport protocol.	option	-	udp										

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>udp</i>	Use UDP transport for IKE.		
	<i>udp-fallback-tcp</i>	Use UDP transport for IKE, with fallback to TCP transport.		
	<i>tcp</i>	Use TCP transport for IKE.		
type	Remote gateway type.	option	-	static
	Option	Description		
	<i>static</i>	Remote VPN gateway has fixed IP address.		
	<i>dynamic</i>	Remote VPN gateway has dynamic IP address.		
	<i>ddns</i>	Remote VPN gateway has dynamic IP address and is a dynamic DNS client.		
unity-support	Enable/disable support for Cisco UNITY Configuration Method extensions.	option	-	enable
	Option	Description		
	<i>disable</i>	Disable Cisco Unity Configuration Method Extensions.		
	<i>enable</i>	Enable Cisco Unity Configuration Method Extensions.		
usrgrp	User group name for dialup peers.	string	Maximum length: 35	
vni	VNI of VXLAN tunnel.	integer	Minimum value: 1 Maximum value: 16777215	0
wizard-type	GUI VPN Wizard Type.	option	-	custom
	Option	Description		
	<i>custom</i>	Custom VPN configuration.		
	<i>dialup-forticlient</i>	Dial Up - FortiClient Windows, Mac and Android.		
	<i>dialup-ios</i>	Dial Up - iPhone / iPad Native IPsec Client.		
	<i>dialup-android</i>	Dial Up - Android Native IPsec Client.		
	<i>dialup-windows</i>	Dial Up - Windows Native IPsec Client.		
	<i>dialup-cisco</i>	Dial Up - Cisco IPsec Client.		
	<i>static-fortigate</i>	Site to Site - FortiGate.		

Parameter	Description	Type	Size	Default														
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>dialup-fortigate</td><td>Dial Up - FortiGate.</td></tr><tr><td>static-cisco</td><td>Site to Site - Cisco.</td></tr><tr><td>dialup-cisco-fw</td><td>Dialup Up - Cisco Firewall.</td></tr><tr><td>simplified-static-fortigate</td><td>Site to Site - FortiGate (SD-WAN).</td></tr><tr><td>hub-fortigate-auto-discovery</td><td>Hub role in a Hub-and-Spoke auto-discovery VPN.</td></tr><tr><td>spoke-fortigate-auto-discovery</td><td>Spoke role in a Hub-and-Spoke auto-discovery VPN.</td></tr></table>	Option	Description	dialup-fortigate	Dial Up - FortiGate.	static-cisco	Site to Site - Cisco.	dialup-cisco-fw	Dialup Up - Cisco Firewall.	simplified-static-fortigate	Site to Site - FortiGate (SD-WAN).	hub-fortigate-auto-discovery	Hub role in a Hub-and-Spoke auto-discovery VPN.	spoke-fortigate-auto-discovery	Spoke role in a Hub-and-Spoke auto-discovery VPN.			
	Option	Description																
	dialup-fortigate	Dial Up - FortiGate.																
	static-cisco	Site to Site - Cisco.																
	dialup-cisco-fw	Dialup Up - Cisco Firewall.																
	simplified-static-fortigate	Site to Site - FortiGate (SD-WAN).																
	hub-fortigate-auto-discovery	Hub role in a Hub-and-Spoke auto-discovery VPN.																
spoke-fortigate-auto-discovery	Spoke role in a Hub-and-Spoke auto-discovery VPN.																	
xauthtype	XAuth type.	option	-	disable														
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Disable.</td></tr><tr><td>client</td><td>Enable as client.</td></tr><tr><td>pap</td><td>Enable as server PAP.</td></tr><tr><td>chap</td><td>Enable as server CHAP.</td></tr><tr><td>auto</td><td>Enable as server auto.</td></tr></table>	Option	Description	disable	Disable.	client	Enable as client.	pap	Enable as server PAP.	chap	Enable as server CHAP.	auto	Enable as server auto.					
	Option	Description																
	disable	Disable.																
	client	Enable as client.																
	pap	Enable as server PAP.																
	chap	Enable as server CHAP.																
auto	Enable as server auto.																	

* This parameter may not exist in some models.

config ipv4-exclude-range

Parameter	Description	Type	Size	Default
end-ip	End of IPv4 exclusive range.	ipv4-address	Not Specified	0.0.0.0
id	ID.	integer	Minimum value: 0 Maximum value: 4294967295	0
start-ip	Start of IPv4 exclusive range.	ipv4-address	Not Specified	0.0.0.0

config ipv6-exclude-range

Parameter	Description	Type	Size	Default
end-ip	End of IPv6 exclusive range.	ipv6-address	Not Specified	::
id	ID.	integer	Minimum value: 0 Maximum value: 4294967295	0
start-ip	Start of IPv6 exclusive range.	ipv6-address	Not Specified	::

config vpn ipsec phase1

Configure VPN remote gateway.

```
config vpn ipsec phase1
  Description: Configure VPN remote gateway.
  edit <name>
    set acct-verify [enable|disable]
    set add-gw-route [enable|disable]
    set add-route [disable|enable]
    set assign-ip [disable|enable]
    set assign-ip-from [range|usrgrp|...]
    set authmethod [psk|signature]
    set authmethod-remote [psk|signature]
    set authpasswd {password}
    set authusr {string}
    set authusrgrp {string}
    set auto-negotiate [enable|disable]
    set azure-ad-autoconnect [enable|disable]
    set backup-gateway <address1>, <address2>, ...
    set banner {var-string}
    set cert-id-validation [enable|disable]
    set cert-peer-username-strip [disable|enable]
    set cert-peer-username-validation [none|othername|...]
    set cert-trust-store [local|ems]
    set certificate <name1>, <name2>, ...
    set childless-ike [enable|disable]
    set client-auto-negotiate [disable|enable]
    set client-keep-alive [disable|enable]
    set client-resume [enable|disable]
    set client-resume-interval {integer}
    set comments {var-string}
    set dev-id {string}
    set dev-id-notification [disable|enable]
    set dhcp-ra-giaddr {ipv4-address}
    set dhcp6-ra-linkaddr {ipv6-address}
    set dhgrp {option1}, {option2}, ...
    set digital-signature-auth [enable|disable]
```

```

set distance {integer}
set dns-mode [manual|auto]
set domain {string}
set dpd [disable|on-idle|...]
set dpd-retrycount {integer}
set dpd-retryinterval {user}
set eap [enable|disable]
set eap-cert-auth [enable|disable]
set eap-exclude-peergrp {string}
set eap-identity [use-id-payload|send-request]
set ems-sn-check [enable|disable]
set enforce-unique-id [disable|keep-new|...]
set esn [require|allow|...]
set exchange-figt-device-id [enable|disable]
set fallback-tcp-threshold {integer}
set fec-base {integer}
set fec-codec [rs|xor]
set fec-egress [enable|disable]
set fec-health-check {string}
set fec-ingress [enable|disable]
set fec-mapping-profile {string}
set fec-receive-timeout {integer}
set fec-redundant {integer}
set fec-send-timeout {integer}
set fgsp-sync [enable|disable]
set fortinet-esp [enable|disable]
set fragmentation [enable|disable]
set fragmentation-mtu {integer}
set group-authentication [enable|disable]
set group-authentication-secret {password-3}
set ha-sync-esp-seqno [enable|disable]
set idle-timeout [enable|disable]
set idle-timeoutinterval {integer}
set ike-version [1|2]
set inbound-dscp-copy [enable|disable]
set include-local-lan [disable|enable]
set interface {string}
set internal-domain-list <domain-name1>, <domain-name2>, ...
set ip-delay-interval {integer}
set ipv4-dns-server1 {ipv4-address}
set ipv4-dns-server2 {ipv4-address}
set ipv4-dns-server3 {ipv4-address}
set ipv4-end-ip {ipv4-address}
config ipv4-exclude-range
    Description: Configuration Method IPv4 exclude ranges.
    edit <id>
        set end-ip {ipv4-address}
        set start-ip {ipv4-address}
    next
end
set ipv4-name {string}
set ipv4-netmask {ipv4-netmask}
set ipv4-split-exclude {string}
set ipv4-split-include {string}
set ipv4-start-ip {ipv4-address}
set ipv4-wins-server1 {ipv4-address}

```

```

set ipv4-wins-server2 {ipv4-address}
set ipv6-dns-server1 {ipv6-address}
set ipv6-dns-server2 {ipv6-address}
set ipv6-dns-server3 {ipv6-address}
set ipv6-end-ip {ipv6-address}
config ipv6-exclude-range
    Description: Configuration method IPv6 exclude ranges.
    edit <id>
        set end-ip {ipv6-address}
        set start-ip {ipv6-address}
    next
end
set ipv6-name {string}
set ipv6-prefix {integer}
set ipv6-split-exclude {string}
set ipv6-split-include {string}
set ipv6-start-ip {ipv6-address}
set keepalive {integer}
set keylife {integer}
set kms {string}
set link-cost {integer}
set local-gw {ipv4-address}
set localid {string}
set localid-type [auto|fqdn|...]
set loopback-asmroute [enable|disable]
set mesh-selector-type [disable|subnet|...]
set mode [aggressive|main]
set mode-cfg [disable|enable]
set mode-cfg-allow-client-selector [disable|enable]
set nattraversal [enable|disable|...]
set negotiate-timeout {integer}
set network-id {integer}
set network-overlay [disable|enable]
set npu-offload [enable|disable]
set peer {string}
set peergrp {string}
set peerid {string}
set peertype [any|one|...]
set ppk [disable|allow|...]
set ppk-identity {string}
set ppk-secret {password-3}
set priority {integer}
set proposal {option1}, {option2}, ...
set psksecret {password-3}
set psksecret-remote {password-3}
set qkd [disable|allow|...]
set qkd-profile {string}
set reauth [disable|enable]
set rekey [enable|disable]
set remote-gw {ipv4-address}
set remote-gw-country {string}
set remote-gw-end-ip {ipv4-address-any}
set remote-gw-match [any|ipmask|...]
set remote-gw-start-ip {ipv4-address-any}
set remote-gw-subnet {ipv4-classnet-any}
set remote-gw6-country {string}

```

```

set remote-gw6-end-ip {ipv6-address}
set remote-gw6-match [any|ipprefix|...]
set remote-gw6-start-ip {ipv6-address}
set remote-gw6-subnet {ipv6-network}
set remotegw-ddns {string}
set rsa-signature-format [pkcs1|pss]
set rsa-signature-hash-override [enable|disable]
set save-password [disable|enable]
set send-cert-chain [enable|disable]
set signature-hash-alg {option1}, {option2}, ...
set split-include-service {string}
set suite-b [disable|suite-b-gcm-128|...]
set transport [udp|udp-fallback-tcp|...]
set type [static|dynamic|...]
set unity-support [disable|enable]
set usrgp {string}
set wizard-type [custom|dialup-forticlient|...]
set xauthtype [disable|client|...]

```

next

end

config vpn ipsec phase1

Parameter	Description	Type	Size	Default
acct-verify	Enable/disable verification of RADIUS accounting record.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable verification of RADIUS accounting record.		
	<i>disable</i>	Disable verification of RADIUS accounting record.		
add-gw-route	Enable/disable automatically add a route to the remote gateway.	option	-	disable
	Option	Description		
	<i>enable</i>	Automatically add a route to the remote gateway.		
	<i>disable</i>	Do not automatically add a route to the remote gateway.		
add-route	Enable/disable control addition of a route to peer destination selector.	option	-	disable
	Option	Description		
	<i>disable</i>	Do not add a route to destination of peer selector.		
	<i>enable</i>	Add route to destination of peer selector.		
assign-ip	Enable/disable assignment of IP to IPsec interface via configuration method.	option	-	enable

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>disable</i>	Do not assign an IP address to the IPsec interface.		
	<i>enable</i>	Assign an IP address to the IPsec interface.		
assign-ip-from	Method by which the IP address will be assigned.	option	-	range
	Option	Description		
	<i>range</i>	Assign IP address from locally defined range.		
	<i>usrgrp</i>	Assign IP address via user group.		
	<i>dhcp</i>	Assign IP address via DHCP.		
	<i>name</i>	Assign IP address from firewall address or group.		
authmethod	Authentication method.	option	-	psk
	Option	Description		
	<i>psk</i>	PSK authentication method.		
	<i>signature</i>	Signature authentication method.		
authmethod-remote	Authentication method (remote side).	option	-	
	Option	Description		
	<i>psk</i>	PSK authentication method.		
	<i>signature</i>	Signature authentication method.		
authpasswd	XAuth password (max 35 characters).	password	Not Specified	
authusr	XAuth user name.	string	Maximum length: 64	
authusrgrp	Authentication user group.	string	Maximum length: 35	
auto-negotiate	Enable/disable automatic initiation of IKE SA negotiation.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable automatic initiation of IKE SA negotiation.		
	<i>disable</i>	Disable automatic initiation of IKE SA negotiation.		

Parameter	Description	Type	Size	Default										
azure-ad-autoconnect	Enable/disable Azure AD Auto-Connect for FortiClient.	option	-	disable										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable Azure AD Auto-Connect for FortiClient.</td></tr><tr><td><i>disable</i></td><td>Disable Azure AD Auto-Connect for FortiClient.</td></tr></table>	Option	Description	<i>enable</i>	Enable Azure AD Auto-Connect for FortiClient.	<i>disable</i>	Disable Azure AD Auto-Connect for FortiClient.							
Option	Description													
<i>enable</i>	Enable Azure AD Auto-Connect for FortiClient.													
<i>disable</i>	Disable Azure AD Auto-Connect for FortiClient.													
backup-gateway <address>	Instruct unity clients about the backup gateway address(es). Address of backup gateway.	string	Maximum length: 79											
banner	Message that unity client should display after connecting.	var-string	Maximum length: 1024											
cert-id-validation	Enable/disable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.	option	-	enable										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.</td></tr><tr><td><i>disable</i></td><td>Disable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.</td></tr></table>	Option	Description	<i>enable</i>	Enable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.	<i>disable</i>	Disable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.							
Option	Description													
<i>enable</i>	Enable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.													
<i>disable</i>	Disable cross validation of peer ID and the identity in the peer's certificate as specified in RFC 4945.													
cert-peer-username-strip	Enable/disable domain stripping on certificate identity.	option	-	disable										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable domain stripping on certificate identity.</td></tr><tr><td><i>enable</i></td><td>Enable domain stripping on certificate identity.</td></tr></table>	Option	Description	<i>disable</i>	Disable domain stripping on certificate identity.	<i>enable</i>	Enable domain stripping on certificate identity.							
Option	Description													
<i>disable</i>	Disable domain stripping on certificate identity.													
<i>enable</i>	Enable domain stripping on certificate identity.													
cert-peer-username-validation	Enable/disable cross validation of peer username and the identity in the peer's certificate.	option	-	none										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>none</i></td><td>Disable cross validation of peer username and the identity in the peer's certificate.</td></tr><tr><td><i>othername</i></td><td>Validate principal name in SAN othername.</td></tr><tr><td><i>rfc822name</i></td><td>Validate RFC822 email address in SAN.</td></tr><tr><td><i>cn</i></td><td>Validate CN in subject.</td></tr></table>	Option	Description	<i>none</i>	Disable cross validation of peer username and the identity in the peer's certificate.	<i>othername</i>	Validate principal name in SAN othername.	<i>rfc822name</i>	Validate RFC822 email address in SAN.	<i>cn</i>	Validate CN in subject.			
Option	Description													
<i>none</i>	Disable cross validation of peer username and the identity in the peer's certificate.													
<i>othername</i>	Validate principal name in SAN othername.													
<i>rfc822name</i>	Validate RFC822 email address in SAN.													
<i>cn</i>	Validate CN in subject.													
cert-trust-store	CA certificate trust store.	option	-	local										

Parameter	Description	Type	Size	Default						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>local</i></td><td>Use local CA certificate.</td></tr><tr><td><i>ems</i></td><td>Use EMS CA certificate.</td></tr></table>	Option	Description	<i>local</i>	Use local CA certificate.	<i>ems</i>	Use EMS CA certificate.			
	Option	Description								
	<i>local</i>	Use local CA certificate.								
<i>ems</i>	Use EMS CA certificate.									
certificate <name>	Names of up to 4 signed personal certificates. Certificate name.	string	Maximum length: 79							
childless-ike	Enable/disable childless IKEv2 initiation (RFC 6023).	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable childless IKEv2 initiation (RFC 6023).</td></tr><tr><td><i>disable</i></td><td>Disable childless IKEv2 initiation (RFC 6023).</td></tr></table>	Option	Description	<i>enable</i>	Enable childless IKEv2 initiation (RFC 6023).	<i>disable</i>	Disable childless IKEv2 initiation (RFC 6023).			
	Option	Description								
	<i>enable</i>	Enable childless IKEv2 initiation (RFC 6023).								
<i>disable</i>	Disable childless IKEv2 initiation (RFC 6023).									
client-auto-negotiate	Enable/disable allowing the VPN client to bring up the tunnel when there is no traffic.	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable allowing the VPN client to bring up the tunnel when there is no traffic.</td></tr><tr><td><i>enable</i></td><td>Enable allowing the VPN client to bring up the tunnel when there is no traffic.</td></tr></table>	Option	Description	<i>disable</i>	Disable allowing the VPN client to bring up the tunnel when there is no traffic.	<i>enable</i>	Enable allowing the VPN client to bring up the tunnel when there is no traffic.			
	Option	Description								
	<i>disable</i>	Disable allowing the VPN client to bring up the tunnel when there is no traffic.								
<i>enable</i>	Enable allowing the VPN client to bring up the tunnel when there is no traffic.									
client-keep-alive	Enable/disable allowing the VPN client to keep the tunnel up when there is no traffic.	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable allowing the VPN client to keep the tunnel up when there is no traffic.</td></tr><tr><td><i>enable</i></td><td>Enable allowing the VPN client to keep the tunnel up when there is no traffic.</td></tr></table>	Option	Description	<i>disable</i>	Disable allowing the VPN client to keep the tunnel up when there is no traffic.	<i>enable</i>	Enable allowing the VPN client to keep the tunnel up when there is no traffic.			
	Option	Description								
	<i>disable</i>	Disable allowing the VPN client to keep the tunnel up when there is no traffic.								
<i>enable</i>	Enable allowing the VPN client to keep the tunnel up when there is no traffic.									
client-resume	Enable/disable resumption of offline FortiClient sessions. When a FortiClient enabled laptop is closed or enters sleep/hibernate mode, enabling this feature allows FortiClient to keep the tunnel during this period, and allows users to immediately resume using the IPsec tunnel when the device wakes up.	option	-	disable						

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>enable</i>	Enable client session resumption.		
	<i>disable</i>	Disable client session resumption.		
client-resume-interval	Maximum time in seconds during which a VPN client may resume using a tunnel after a client PC has entered sleep mode or temporarily lost its network connection.	integer	Minimum value: 120 Maximum value: 172800	7200
comments	Comment.	var-string	Maximum length: 255	
dev-id	Device ID carried by the device ID notification.	string	Maximum length: 63	
dev-id-notification	Enable/disable device ID notification.	option	-	disable
	Option	Description		
	<i>disable</i>	Disable device ID notification.		
	<i>enable</i>	Enable device ID notification.		
dhcp-ra-giaddr	Relay agent gateway IP address to use in the giaddr field of DHCP requests.	ipv4-address	Not Specified	0.0.0.0
dhcp6-ra-linkaddr	Relay agent IPv6 link address to use in DHCP6 requests.	ipv6-address	Not Specified	::
dhgrp	DH group.	option	-	14
	Option	Description		
	1	DH Group 1.		
	2	DH Group 2.		
	5	DH Group 5.		
	14	DH Group 14.		
	15	DH Group 15.		
	16	DH Group 16.		
	17	DH Group 17.		
	18	DH Group 18.		
	19	DH Group 19.		

Parameter	Description	Type	Size	Default																		
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>20</td><td>DH Group 20.</td></tr><tr><td>21</td><td>DH Group 21.</td></tr><tr><td>27</td><td>DH Group 27.</td></tr><tr><td>28</td><td>DH Group 28.</td></tr><tr><td>29</td><td>DH Group 29.</td></tr><tr><td>30</td><td>DH Group 30.</td></tr><tr><td>31</td><td>DH Group 31.</td></tr><tr><td>32</td><td>DH Group 32.</td></tr></table>	Option	Description	20	DH Group 20.	21	DH Group 21.	27	DH Group 27.	28	DH Group 28.	29	DH Group 29.	30	DH Group 30.	31	DH Group 31.	32	DH Group 32.			
	Option	Description																				
	20	DH Group 20.																				
	21	DH Group 21.																				
	27	DH Group 27.																				
	28	DH Group 28.																				
	29	DH Group 29.																				
	30	DH Group 30.																				
	31	DH Group 31.																				
32	DH Group 32.																					
digital-signature-auth	Enable/disable IKEv2 Digital Signature Authentication (RFC 7427).	option	-	disable																		
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Enable IKEv2 Digital Signature Authentication (RFC 7427).</td></tr><tr><td>disable</td><td>Disable IKEv2 Digital Signature Authentication (RFC 7427).</td></tr></table>	Option	Description	enable	Enable IKEv2 Digital Signature Authentication (RFC 7427).	disable	Disable IKEv2 Digital Signature Authentication (RFC 7427).															
	Option	Description																				
	enable	Enable IKEv2 Digital Signature Authentication (RFC 7427).																				
disable	Disable IKEv2 Digital Signature Authentication (RFC 7427).																					
distance	Distance for routes added by IKE.	integer	Minimum value: 1 Maximum value: 255	15																		
dns-mode	DNS server mode.	option	-	manual																		
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>manual</td><td>Manually configure DNS servers.</td></tr><tr><td>auto</td><td>Use default DNS servers.</td></tr></table>	Option	Description	manual	Manually configure DNS servers.	auto	Use default DNS servers.															
	Option	Description																				
	manual	Manually configure DNS servers.																				
auto	Use default DNS servers.																					
domain	Instruct unity clients about the single default DNS domain.	string	Maximum length: 63																			
dpd	Dead Peer Detection mode.	option	-	on-demand																		
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Disable Dead Peer Detection.</td></tr><tr><td>on-idle</td><td>Trigger Dead Peer Detection when IPsec is idle.</td></tr><tr><td>on-demand</td><td>Trigger Dead Peer Detection when IPsec traffic is sent but no reply is received from the peer.</td></tr></table>	Option	Description	disable	Disable Dead Peer Detection.	on-idle	Trigger Dead Peer Detection when IPsec is idle.	on-demand	Trigger Dead Peer Detection when IPsec traffic is sent but no reply is received from the peer.													
	Option	Description																				
	disable	Disable Dead Peer Detection.																				
	on-idle	Trigger Dead Peer Detection when IPsec is idle.																				
on-demand	Trigger Dead Peer Detection when IPsec traffic is sent but no reply is received from the peer.																					

Parameter	Description	Type	Size	Default
dpd-retrycount	Number of DPD retry attempts.	integer	Minimum value: 0 Maximum value: 10	3
dpd-retryinterval	DPD retry interval.	user	Not Specified	
eap	Enable/disable IKEv2 EAP authentication.	option	-	disable
	Option		Description	
	<i>enable</i>		Enable IKEv2 EAP authentication.	
	<i>disable</i>		Disable IKEv2 EAP authentication.	
eap-cert-auth	Enable/disable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.	option	-	disable
	Option		Description	
	<i>enable</i>		Enable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.	
	<i>disable</i>		Disable peer certificate authentication in addition to EAP if peer is a FortiClient endpoint.	
eap-exclude-peergrp	Peer group excluded from EAP authentication.	string	Maximum length: 35	
eap-identity	IKEv2 EAP peer identity type.	option	-	use-id-payload
	Option		Description	
	<i>use-id-payload</i>		Use IKEv2 IDi payload to resolve peer identity.	
	<i>send-request</i>		Use EAP identity request to resolve peer identity.	
ems-sn-check	Enable/disable verification of EMS serial number.	option	-	disable
	Option		Description	
	<i>enable</i>		Enable EMS serial number verification.	
	<i>disable</i>		Disable EMS serial number verification.	
enforce-unique-id	Enable/disable peer ID uniqueness check.	option	-	disable

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>disable</i>	Disable peer ID uniqueness enforcement.		
	<i>keep-new</i>	Enforce peer ID uniqueness, keep new connection if collision found.		
	<i>keep-old</i>	Enforce peer ID uniqueness, keep old connection if collision found.		
esn *	Extended sequence number (ESN) negotiation.	option	-	disable
	Option	Description		
	<i>require</i>	Require extended sequence number.		
	<i>allow</i>	Allow extended sequence number.		
	<i>disable</i>	Disable extended sequence number.		
exchange-fgt-device-id	Enable/disable device identifier exchange with peer FortiGate units for use of VPN monitor data by FortiManager.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable exchange of FortiGate device identifier.		
	<i>disable</i>	Disable exchange of FortiGate device identifier.		
fallback-tcp-threshold	Timeout in seconds before falling back IKE/IPsec traffic to tcp.	integer	Minimum value: 1 Maximum value: 300	15
fec-base	Number of base Forward Error Correction packets.	integer	Minimum value: 1 Maximum value: 20	10
fec-codec	Forward Error Correction encoding/decoding algorithm.	option	-	rs
	Option	Description		
	<i>rs</i>	Reed-Solomon FEC algorithm.		
	<i>xor</i>	XOR FEC algorithm.		
fec-egress	Enable/disable Forward Error Correction for egress IPsec traffic.	option	-	disable

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>enable</i>	Enable Forward Error Correction for egress IPsec traffic.		
	<i>disable</i>	Disable Forward Error Correction for egress IPsec traffic.		
fec-health-check	SD-WAN health check.	string	Maximum length: 35	
fec-ingress	Enable/disable Forward Error Correction for ingress IPsec traffic.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable Forward Error Correction for ingress IPsec traffic.		
	<i>disable</i>	Disable Forward Error Correction for ingress IPsec traffic.		
fec-mapping-profile	Forward Error Correction (FEC) mapping profile.	string	Maximum length: 35	
fec-receive-timeout	Timeout in milliseconds before dropping Forward Error Correction packets.	integer	Minimum value: 1 Maximum value: 1000	50
fec-redundant	Number of redundant Forward Error Correction packets.	integer	Minimum value: 1 Maximum value: 5	1
fec-send-timeout	Timeout in milliseconds before sending Forward Error Correction packets.	integer	Minimum value: 1 Maximum value: 1000	5
fgsp-sync	Enable/disable IPsec syncing of tunnels for FGSP IPsec.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable IPsec syncing of tunnels to other cluster members.		
	<i>disable</i>	Disable IPsec syncing of tunnels to other cluster members.		
fortinet-esp	Enable/disable Fortinet ESP encapsulaton.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable Fortinet ESP encapsulation.		
	<i>disable</i>	Disable Fortinet ESP encapsulaton.		

Parameter	Description	Type	Size	Default
fragmentation	Enable/disable fragment IKE message on re-transmission.	option	-	enable
	Option Description			
	<i>enable</i>	Enable intra-IKE fragmentation support on re-transmission.		
	<i>disable</i>	Disable intra-IKE fragmentation support.		
fragmentation-mtu	IKE fragmentation MTU.	integer	Minimum value: 500 Maximum value: 16000	1200
group-authentication	Enable/disable IKEv2 IDi group authentication.	option	-	disable
	Option Description			
	<i>enable</i>	Enable IKEv2 IDi group authentication.		
	<i>disable</i>	Disable IKEv2 IDi group authentication.		
group-authentication-secret	Password for IKEv2 ID group authentication. ASCII string or hexadecimal indicated by a leading 0x.	password-3	Not Specified	
ha-sync-esp-seqno	Enable/disable sequence number jump ahead for IPsec HA.	option	-	enable
	Option Description			
	<i>enable</i>	Enable HA syncing of ESP sequence numbers.		
	<i>disable</i>	Disable HA syncing of ESP sequence numbers.		
idle-timeout	Enable/disable IPsec tunnel idle timeout.	option	-	disable
	Option Description			
	<i>enable</i>	Enable IPsec tunnel idle timeout.		
	<i>disable</i>	Disable IPsec tunnel idle timeout.		
idle-timeoutinterval	IPsec tunnel idle timeout in minutes.	integer	Minimum value: 5 Maximum value: 43200	15
ike-version	IKE protocol version.	option	-	1

Parameter	Description	Type	Size	Default						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>1</td><td>Use IKEv1 protocol.</td></tr><tr><td>2</td><td>Use IKEv2 protocol.</td></tr></table>	Option	Description	1	Use IKEv1 protocol.	2	Use IKEv2 protocol.			
	Option	Description								
	1	Use IKEv1 protocol.								
2	Use IKEv2 protocol.									
inbound-dscp-copy	Enable/disable copy the dscp in the ESP header to the inner IP Header.	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Enable copy the dscp in the ESP header to the inner IP Header.</td></tr><tr><td>disable</td><td>Disable copy the dscp in the ESP header to the inner IP Header.</td></tr></table>	Option	Description	enable	Enable copy the dscp in the ESP header to the inner IP Header.	disable	Disable copy the dscp in the ESP header to the inner IP Header.			
	Option	Description								
	enable	Enable copy the dscp in the ESP header to the inner IP Header.								
disable	Disable copy the dscp in the ESP header to the inner IP Header.									
include-local-lan	Enable/disable allow local LAN access on unity clients.	option	-	disable						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Disable local LAN access on Unity clients.</td></tr><tr><td>enable</td><td>Enable local LAN access on Unity clients.</td></tr></table>	Option	Description	disable	Disable local LAN access on Unity clients.	enable	Enable local LAN access on Unity clients.			
	Option	Description								
	disable	Disable local LAN access on Unity clients.								
enable	Enable local LAN access on Unity clients.									
interface	Local physical, aggregate, or VLAN outgoing interface.	string	Maximum length: 35							
internal-domain-list <domain-name>	One or more internal domain names in quotes separated by spaces. Domain name.	string	Maximum length: 79							
ip-delay-interval	IP address reuse delay interval in seconds.	integer	Minimum value: 0 Maximum value: 28800	0						
ipv4-dns-server1	IPv4 DNS server 1.	ipv4-address	Not Specified	0.0.0.0						
ipv4-dns-server2	IPv4 DNS server 2.	ipv4-address	Not Specified	0.0.0.0						
ipv4-dns-server3	IPv4 DNS server 3.	ipv4-address	Not Specified	0.0.0.0						
ipv4-end-ip	End of IPv4 range.	ipv4-address	Not Specified	0.0.0.0						
ipv4-name	IPv4 address name.	string	Maximum length: 79							
ipv4-netmask	IPv4 Netmask.	ipv4-netmask	Not Specified	255.255.255.255						

Parameter	Description	Type	Size	Default
ipv4-split-exclude	IPv4 subnets that should not be sent over the IPsec tunnel.	string	Maximum length: 79	
ipv4-split-include	IPv4 split-include subnets.	string	Maximum length: 79	
ipv4-start-ip	Start of IPv4 range.	ipv4-address	Not Specified	0.0.0.0
ipv4-wins-server1	WINS server 1.	ipv4-address	Not Specified	0.0.0.0
ipv4-wins-server2	WINS server 2.	ipv4-address	Not Specified	0.0.0.0
ipv6-dns-server1	IPv6 DNS server 1.	ipv6-address	Not Specified	::
ipv6-dns-server2	IPv6 DNS server 2.	ipv6-address	Not Specified	::
ipv6-dns-server3	IPv6 DNS server 3.	ipv6-address	Not Specified	::
ipv6-end-ip	End of IPv6 range.	ipv6-address	Not Specified	::
ipv6-name	IPv6 address name.	string	Maximum length: 79	
ipv6-prefix	IPv6 prefix.	integer	Minimum value: 1 Maximum value: 128	128
ipv6-split-exclude	IPv6 subnets that should not be sent over the IPsec tunnel.	string	Maximum length: 79	
ipv6-split-include	IPv6 split-include subnets.	string	Maximum length: 79	
ipv6-start-ip	Start of IPv6 range.	ipv6-address	Not Specified	::
keepalive	NAT-T keep alive interval.	integer	Minimum value: 5 Maximum value: 900	10

Parameter	Description	Type	Size	Default														
keylife	Time to wait in seconds before phase 1 encryption key expires.	integer	Minimum value: 120 Maximum value: 172800	86400														
kms	Key Management Services server.	string	Maximum length: 35															
link-cost	VPN tunnel underlay link cost.	integer	Minimum value: 0 Maximum value: 255	0														
local-gw	Local VPN gateway.	ipv4-address	Not Specified	0.0.0.0														
localid	Local ID.	string	Maximum length: 63															
localid-type	Local ID type.	option	-	auto														
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>auto</td><td>Select ID type automatically.</td></tr><tr><td>fqdn</td><td>Use fully qualified domain name.</td></tr><tr><td>user-fqdn</td><td>Use user fully qualified domain name.</td></tr><tr><td>keyid</td><td>Use key-id string.</td></tr><tr><td>address</td><td>Use local IP address.</td></tr><tr><td>asn1dn</td><td>Use ASN.1 distinguished name.</td></tr></table>				Option	Description	auto	Select ID type automatically.	fqdn	Use fully qualified domain name.	user-fqdn	Use user fully qualified domain name.	keyid	Use key-id string.	address	Use local IP address.	asn1dn	Use ASN.1 distinguished name.
Option	Description																	
auto	Select ID type automatically.																	
fqdn	Use fully qualified domain name.																	
user-fqdn	Use user fully qualified domain name.																	
keyid	Use key-id string.																	
address	Use local IP address.																	
asn1dn	Use ASN.1 distinguished name.																	
loopback-asmroute	Enable/disable asymmetric routing for IKE traffic on loopback interface.	option	-	enable														
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Allow ingress/egress IKE traffic to be routed over different interfaces.</td></tr><tr><td>disable</td><td>Ingress/egress IKE traffic must be routed over the same interface.</td></tr></table>				Option	Description	enable	Allow ingress/egress IKE traffic to be routed over different interfaces.	disable	Ingress/egress IKE traffic must be routed over the same interface.								
Option	Description																	
enable	Allow ingress/egress IKE traffic to be routed over different interfaces.																	
disable	Ingress/egress IKE traffic must be routed over the same interface.																	
mesh-selector-type	Add selectors containing subsets of the configuration depending on traffic.	option	-	disable														
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>disable</td><td>Disable.</td></tr><tr><td>subnet</td><td>Enable addition of matching subnet selector.</td></tr><tr><td>host</td><td>Enable addition of host to host selector.</td></tr></table>				Option	Description	disable	Disable.	subnet	Enable addition of matching subnet selector.	host	Enable addition of host to host selector.						
Option	Description																	
disable	Disable.																	
subnet	Enable addition of matching subnet selector.																	
host	Enable addition of host to host selector.																	

Parameter	Description	Type	Size	Default								
mode	ID protection mode used to establish a secure channel.	option	-	main								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>aggressive</i></td><td>Aggressive mode.</td></tr><tr><td><i>main</i></td><td>Main mode.</td></tr></table>	Option	Description	<i>aggressive</i>	Aggressive mode.	<i>main</i>	Main mode.					
Option	Description											
<i>aggressive</i>	Aggressive mode.											
<i>main</i>	Main mode.											
mode-cfg	Enable/disable configuration method.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable Configuration Method.</td></tr><tr><td><i>enable</i></td><td>Enable Configuration Method.</td></tr></table>	Option	Description	<i>disable</i>	Disable Configuration Method.	<i>enable</i>	Enable Configuration Method.					
Option	Description											
<i>disable</i>	Disable Configuration Method.											
<i>enable</i>	Enable Configuration Method.											
mode-cfg-allow-client-selector	Enable/disable mode-cfg client to use custom phase2 selectors.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Mode-cfg client to use wildcard selectors.</td></tr><tr><td><i>enable</i></td><td>Mode-cfg client to use custom selectors.</td></tr></table>	Option	Description	<i>disable</i>	Mode-cfg client to use wildcard selectors.	<i>enable</i>	Mode-cfg client to use custom selectors.					
Option	Description											
<i>disable</i>	Mode-cfg client to use wildcard selectors.											
<i>enable</i>	Mode-cfg client to use custom selectors.											
name	IPsec remote gateway name.	string	Maximum length: 35									
nattraversal	Enable/disable NAT traversal.	option	-	enable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable IPsec NAT traversal.</td></tr><tr><td><i>disable</i></td><td>Disable IPsec NAT traversal.</td></tr><tr><td><i>forced</i></td><td>Force IPsec NAT traversal on.</td></tr></table>	Option	Description	<i>enable</i>	Enable IPsec NAT traversal.	<i>disable</i>	Disable IPsec NAT traversal.	<i>forced</i>	Force IPsec NAT traversal on.			
Option	Description											
<i>enable</i>	Enable IPsec NAT traversal.											
<i>disable</i>	Disable IPsec NAT traversal.											
<i>forced</i>	Force IPsec NAT traversal on.											
negotiate-timeout	IKE SA negotiation timeout in seconds.	integer	Minimum value: 1 Maximum value: 300	30								
network-id	VPN gateway network ID.	integer	Minimum value: 0 Maximum value: 255	0								
network-overlay	Enable/disable network overlays.	option	-	disable								

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>disable</i>	Disable network overlays.		
	<i>enable</i>	Enable network overlays.		
npu-offload *	Enable/disable offloading NPU.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable NPU offloading.		
	<i>disable</i>	Disable NPU offloading.		
peer	Accept this peer certificate.	string	Maximum length: 35	
peergrp	Accept this peer certificate group.	string	Maximum length: 35	
peerid	Accept this peer identity.	string	Maximum length: 255	
peertype	Accept this peer type.	option	-	peer
	Option	Description		
	<i>any</i>	Accept any peer ID.		
	<i>one</i>	Accept this peer ID.		
	<i>dialup</i>	Accept peer ID in dialup group.		
	<i>peer</i>	Accept this peer certificate.		
	<i>peergrp</i>	Accept this peer certificate group.		
ppk	Enable/disable IKEv2 Postquantum Preshared Key (PPK).	option	-	disable
	Option	Description		
	<i>disable</i>	Disable use of IKEv2 Postquantum Preshared Key (PPK).		
	<i>allow</i>	Allow, but do not require, use of IKEv2 Postquantum Preshared Key (PPK).		
	<i>require</i>	Require use of IKEv2 Postquantum Preshared Key (PPK).		
ppk-identity	IKEv2 Postquantum Preshared Key Identity.	string	Maximum length: 35	
ppk-secret	IKEv2 Postquantum Preshared Key (ASCII string or hexadecimal encoded with a leading 0x).	password-3	Not Specified	

Parameter	Description	Type	Size	Default
priority	Priority for routes added by IKE.	integer	Minimum value: 1 Maximum value: 65535	1
proposal	Phase1 proposal.	option	-	

Option	Description
<i>des-md5</i>	des-md5
<i>des-sha1</i>	des-sha1
<i>des-sha256</i>	des-sha256
<i>des-sha384</i>	des-sha384
<i>des-sha512</i>	des-sha512
<i>3des-md5</i>	3des-md5
<i>3des-sha1</i>	3des-sha1
<i>3des-sha256</i>	3des-sha256
<i>3des-sha384</i>	3des-sha384
<i>3des-sha512</i>	3des-sha512
<i>aes128-md5</i>	aes128-md5
<i>aes128-sha1</i>	aes128-sha1
<i>aes128-sha256</i>	aes128-sha256
<i>aes128-sha384</i>	aes128-sha384
<i>aes128-sha512</i>	aes128-sha512
<i>aes128gcm-prfsha1</i>	aes128gcm-prfsha1
<i>aes128gcm-prfsha256</i>	aes128gcm-prfsha256
<i>aes128gcm-prfsha384</i>	aes128gcm-prfsha384
<i>aes128gcm-prfsha512</i>	aes128gcm-prfsha512
<i>aes192-md5</i>	aes192-md5
<i>aes192-sha1</i>	aes192-sha1
<i>aes192-sha256</i>	aes192-sha256
<i>aes192-sha384</i>	aes192-sha384
<i>aes192-sha512</i>	aes192-sha512
<i>aes256-md5</i>	aes256-md5

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>aes256-sha1</i>	aes256-sha1		
	<i>aes256-sha256</i>	aes256-sha256		
	<i>aes256-sha384</i>	aes256-sha384		
	<i>aes256-sha512</i>	aes256-sha512		
	<i>aes256gcm-prfsha1</i>	aes256gcm-prfsha1		
	<i>aes256gcm-prfsha256</i>	aes256gcm-prfsha256		
	<i>aes256gcm-prfsha384</i>	aes256gcm-prfsha384		
	<i>aes256gcm-prfsha512</i>	aes256gcm-prfsha512		
	<i>chacha20poly1305-prfsha1</i>	chacha20poly1305-prfsha1		
	<i>chacha20poly1305-prfsha256</i>	chacha20poly1305-prfsha256		
	<i>chacha20poly1305-prfsha384</i>	chacha20poly1305-prfsha384		
	<i>chacha20poly1305-prfsha512</i>	chacha20poly1305-prfsha512		
	<i>aria128-md5</i>	aria128-md5		
	<i>aria128-sha1</i>	aria128-sha1		
	<i>aria128-sha256</i>	aria128-sha256		
	<i>aria128-sha384</i>	aria128-sha384		
	<i>aria128-sha512</i>	aria128-sha512		
	<i>aria192-md5</i>	aria192-md5		
	<i>aria192-sha1</i>	aria192-sha1		
	<i>aria192-sha256</i>	aria192-sha256		
	<i>aria192-sha384</i>	aria192-sha384		
	<i>aria192-sha512</i>	aria192-sha512		
	<i>aria256-md5</i>	aria256-md5		
	<i>aria256-sha1</i>	aria256-sha1		
	<i>aria256-sha256</i>	aria256-sha256		
	<i>aria256-sha384</i>	aria256-sha384		
	<i>aria256-sha512</i>	aria256-sha512		
	<i>seed-md5</i>	seed-md5		
	<i>seed-sha1</i>	seed-sha1		

Parameter	Description	Type	Size	Default								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>seed-sha256</i></td><td>seed-sha256</td></tr><tr><td><i>seed-sha384</i></td><td>seed-sha384</td></tr><tr><td><i>seed-sha512</i></td><td>seed-sha512</td></tr></table>	Option	Description	<i>seed-sha256</i>	seed-sha256	<i>seed-sha384</i>	seed-sha384	<i>seed-sha512</i>	seed-sha512			
	Option	Description										
	<i>seed-sha256</i>	seed-sha256										
	<i>seed-sha384</i>	seed-sha384										
<i>seed-sha512</i>	seed-sha512											
psksecret	Pre-shared secret for PSK authentication (ASCII string or hexadecimal encoded with a leading 0x).	password-3	Not Specified									
psksecret-remote	Pre-shared secret for remote side PSK authentication (ASCII string or hexadecimal encoded with a leading 0x).	password-3	Not Specified									
qkd	Enable/disable use of Quantum Key Distribution (QKD) server.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable use of a Quantum Key Distribution (QKD) server.</td></tr><tr><td><i>allow</i></td><td>Allow, but do not require, use of a Quantum Key Distribution (QKD) server.</td></tr><tr><td><i>require</i></td><td>Require use of a Quantum Key Distribution (QKD) server.</td></tr></table>	Option	Description	<i>disable</i>	Disable use of a Quantum Key Distribution (QKD) server.	<i>allow</i>	Allow, but do not require, use of a Quantum Key Distribution (QKD) server.	<i>require</i>	Require use of a Quantum Key Distribution (QKD) server.			
	Option	Description										
	<i>disable</i>	Disable use of a Quantum Key Distribution (QKD) server.										
	<i>allow</i>	Allow, but do not require, use of a Quantum Key Distribution (QKD) server.										
<i>require</i>	Require use of a Quantum Key Distribution (QKD) server.											
qkd-profile	Quantum Key Distribution (QKD) server profile.	string	Maximum length: 35									
reauth	Enable/disable re-authentication upon IKE SA lifetime expiration.	option	-	disable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable IKE SA re-authentication.</td></tr><tr><td><i>enable</i></td><td>Enable IKE SA re-authentication.</td></tr></table>	Option	Description	<i>disable</i>	Disable IKE SA re-authentication.	<i>enable</i>	Enable IKE SA re-authentication.					
	Option	Description										
	<i>disable</i>	Disable IKE SA re-authentication.										
<i>enable</i>	Enable IKE SA re-authentication.											
rekey	Enable/disable phase1 rekey.	option	-	enable								
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable phase1 rekey.</td></tr><tr><td><i>disable</i></td><td>Disable phase1 rekey.</td></tr></table>	Option	Description	<i>enable</i>	Enable phase1 rekey.	<i>disable</i>	Disable phase1 rekey.					
	Option	Description										
	<i>enable</i>	Enable phase1 rekey.										
<i>disable</i>	Disable phase1 rekey.											
remote-gw	Remote VPN gateway.	ipv4-address	Not Specified	0.0.0.0								
remote-gw-country	IPv4 addresses associated to a specific country.	string	Maximum length: 2									

Parameter	Description	Type	Size	Default
remote-gw-end-ip	Last IPv4 address in the range.	ipv4-address-any	Not Specified	0.0.0.0
remote-gw-match	Set type of IPv4 remote gateway address matching.	option	-	any
	Option	Description		
	any	Match any IPv4 gateway address.		
	ipmask	Match IPv4 gateway address and mask.		
	iprange	Match IPv4 gateway address range.		
	geography	Match IPv4 gateway address from a specified country.		
remote-gw-start-ip	First IPv4 address in the range.	ipv4-address-any	Not Specified	0.0.0.0
remote-gw-subnet	IPv4 address and subnet mask.	ipv4-classnet-any	Not Specified	0.0.0.0 0.0.0.0
remote-gw6-country	IPv6 addresses associated to a specific country.	string	Maximum length: 2	
remote-gw6-end-ip	Last IPv6 address in the range.	ipv6-address	Not Specified	::
remote-gw6-match	Set type of IPv6 remote gateway address matching.	option	-	any
	Option	Description		
	any	Match any IPv6 gateway address.		
	ipprefix	Match IPv6 gateway address and prefix.		
	iprange	Match IPv6 gateway address range.		
	geography	Match IPv6 gateway address from a specified country.		
remote-gw6-start-ip	First IPv6 address in the range.	ipv6-address	Not Specified	::
remote-gw6-subnet	IPv6 address and prefix.	ipv6-network	Not Specified	::/0
remotegw-ddns	Domain name of remote gateway. For example, name.ddns.com.	string	Maximum length: 63	
rsa-signature-format	Digital Signature Authentication RSA signature format.	option	-	pkcs1

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>pkcs1</i>	RSASSA PKCS#1 v1.5.		
	<i>pss</i>	RSASSA Probabilistic Signature Scheme (PSS).		
rsa-signature-hash-override	Enable/disable IKEv2 RSA signature hash algorithm override.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable IKEv2 RSA signature hash algorithm override.		
	<i>disable</i>	Disable IKEv2 RSA signature hash algorithm override.		
save-password	Enable/disable saving XAuth username and password on VPN clients.	option	-	disable
	Option	Description		
	<i>disable</i>	Disable saving XAuth username and password on VPN clients.		
	<i>enable</i>	Enable saving XAuth username and password on VPN clients.		
send-cert-chain	Enable/disable sending certificate chain.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable sending certificate chain.		
	<i>disable</i>	Disable sending certificate chain.		
signature-hash-alg	Digital Signature Authentication hash algorithms.	option	-	sha2-512
	Option	Description		
	<i>sha1</i>	SHA1.		
	<i>sha2-256</i>	SHA2-256.		
	<i>sha2-384</i>	SHA2-384.		
	<i>sha2-512</i>	SHA2-512.		
split-include-service	Split-include services.	string	Maximum length: 79	
suite-b	Use Suite-B.	option	-	disable
	Option	Description		
	<i>disable</i>	Do not use UI suite.		

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>suite-b-gcm-128</i>	Use Suite-B-GCM-128.		
	<i>suite-b-gcm-256</i>	Use Suite-B-GCM-256.		
transport	Set IKE transport protocol.	option	-	udp
	Option	Description		
	<i>udp</i>	Use UDP transport for IKE.		
	<i>udp-fallback-tcp</i>	Use UDP transport for IKE, with fallback to TCP transport.		
	<i>tcp</i>	Use TCP transport for IKE.		
type	Remote gateway type.	option	-	static
	Option	Description		
	<i>static</i>	Remote VPN gateway has fixed IP address.		
	<i>dynamic</i>	Remote VPN gateway has dynamic IP address.		
	<i>ddns</i>	Remote VPN gateway has dynamic IP address and is a dynamic DNS client.		
unity-support	Enable/disable support for Cisco UNITY Configuration Method extensions.	option	-	enable
	Option	Description		
	<i>disable</i>	Disable Cisco Unity Configuration Method Extensions.		
	<i>enable</i>	Enable Cisco Unity Configuration Method Extensions.		
usrgrp	User group name for dialup peers.	string	Maximum length: 35	
wizard-type	GUI VPN Wizard Type.	option	-	custom
	Option	Description		
	<i>custom</i>	Custom VPN configuration.		
	<i>dialup-forticlient</i>	Dial Up - FortiClient Windows, Mac and Android.		
	<i>dialup-ios</i>	Dial Up - iPhone / iPad Native IPsec Client.		
	<i>dialup-android</i>	Dial Up - Android Native IPsec Client.		
	<i>dialup-windows</i>	Dial Up - Windows Native IPsec Client.		
	<i>dialup-cisco</i>	Dial Up - Cisco IPsec Client.		

Parameter	Description	Type	Size	Default																
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>static-fortigate</i></td><td>Site to Site - FortiGate.</td></tr><tr><td><i>dialup-fortigate</i></td><td>Dial Up - FortiGate.</td></tr><tr><td><i>static-cisco</i></td><td>Site to Site - Cisco.</td></tr><tr><td><i>dialup-cisco-fw</i></td><td>Dialup Up - Cisco Firewall.</td></tr><tr><td><i>simplified-static-fortigate</i></td><td>Site to Site - FortiGate (SD-WAN).</td></tr><tr><td><i>hub-fortigate-auto-discovery</i></td><td>Hub role in a Hub-and-Spoke auto-discovery VPN.</td></tr><tr><td><i>spoke-fortigate-auto-discovery</i></td><td>Spoke role in a Hub-and-Spoke auto-discovery VPN.</td></tr></table>	Option	Description	<i>static-fortigate</i>	Site to Site - FortiGate.	<i>dialup-fortigate</i>	Dial Up - FortiGate.	<i>static-cisco</i>	Site to Site - Cisco.	<i>dialup-cisco-fw</i>	Dialup Up - Cisco Firewall.	<i>simplified-static-fortigate</i>	Site to Site - FortiGate (SD-WAN).	<i>hub-fortigate-auto-discovery</i>	Hub role in a Hub-and-Spoke auto-discovery VPN.	<i>spoke-fortigate-auto-discovery</i>	Spoke role in a Hub-and-Spoke auto-discovery VPN.			
	Option	Description																		
	<i>static-fortigate</i>	Site to Site - FortiGate.																		
	<i>dialup-fortigate</i>	Dial Up - FortiGate.																		
	<i>static-cisco</i>	Site to Site - Cisco.																		
	<i>dialup-cisco-fw</i>	Dialup Up - Cisco Firewall.																		
	<i>simplified-static-fortigate</i>	Site to Site - FortiGate (SD-WAN).																		
	<i>hub-fortigate-auto-discovery</i>	Hub role in a Hub-and-Spoke auto-discovery VPN.																		
<i>spoke-fortigate-auto-discovery</i>	Spoke role in a Hub-and-Spoke auto-discovery VPN.																			
xauthtype	XAuth type.	option	-	disable																
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>disable</i></td><td>Disable.</td></tr><tr><td><i>client</i></td><td>Enable as client.</td></tr><tr><td><i>pap</i></td><td>Enable as server PAP.</td></tr><tr><td><i>chap</i></td><td>Enable as server CHAP.</td></tr><tr><td><i>auto</i></td><td>Enable as server auto.</td></tr></table>	Option	Description	<i>disable</i>	Disable.	<i>client</i>	Enable as client.	<i>pap</i>	Enable as server PAP.	<i>chap</i>	Enable as server CHAP.	<i>auto</i>	Enable as server auto.							
	Option	Description																		
	<i>disable</i>	Disable.																		
	<i>client</i>	Enable as client.																		
	<i>pap</i>	Enable as server PAP.																		
	<i>chap</i>	Enable as server CHAP.																		
<i>auto</i>	Enable as server auto.																			

* This parameter may not exist in some models.

config ipv4-exclude-range

Parameter	Description	Type	Size	Default
end-ip	End of IPv4 exclusive range.	ipv4-address	Not Specified	0.0.0.0
id	ID.	integer	Minimum value: 0 Maximum value: 4294967295	0
start-ip	Start of IPv4 exclusive range.	ipv4-address	Not Specified	0.0.0.0

config ipv6-exclude-range

Parameter	Description	Type	Size	Default
end-ip	End of IPv6 exclusive range.	ipv6-address	Not Specified	::
id	ID.	integer	Minimum value: 0 Maximum value: 4294967295	0
start-ip	Start of IPv6 exclusive range.	ipv6-address	Not Specified	::

config vpn ipsec phase2-interface

Configure VPN autokey tunnel.

```
config vpn ipsec phase2-interface
  Description: Configure VPN autokey tunnel.
  edit <name>
    set add-route [phase1|enable|...]
    set auto-discovery-forwarder [phase1|enable|...]
    set auto-discovery-sender [phase1|enable|...]
    set auto-negotiate [enable|disable]
    set comments {var-string}
    set dhcp-ipsec [enable|disable]
    set dhgrp {option1}, {option2}, ...
    set diffserv [enable|disable]
    set diffservcode {user}
    set dst-addr-type [subnet|range|...]
    set dst-end-ip {ipv4-address-any}
    set dst-end-ip6 {ipv6-address}
    set dst-name {string}
    set dst-name6 {string}
    set dst-port {integer}
    set dst-start-ip {ipv4-address-any}
    set dst-start-ip6 {ipv6-address}
    set dst-subnet {ipv4-classnet-any}
    set dst-subnet6 {ipv6-prefix}
    set encapsulation [tunnel-mode|transport-mode]
    set inbound-dscp-copy [phase1|enable|...]
    set initiator-ts-narrow [enable|disable]
    set ipv4-df [enable|disable]
    set keepalive [enable|disable]
    set keylife-type [seconds|kbs|...]
    set keylifekbs {integer}
    set keylifeseconds {integer}
    set l2tp [enable|disable]
    set pfs [enable|disable]
    set phase1name {string}
    set proposal {option1}, {option2}, ...
```

```

set protocol {integer}
set replay [enable|disable]
set route-overlap [use-old|use-new|...]
set single-source [enable|disable]
set src-addr-type [subnet|range|...]
set src-end-ip {ipv4-address-any}
set src-end-ip6 {ipv6-address}
set src-name {string}
set src-name6 {string}
set src-port {integer}
set src-start-ip {ipv4-address-any}
set src-start-ip6 {ipv6-address}
set src-subnet {ipv4-classnet-any}
set src-subnet6 {ipv6-prefix}
next
end

```

config vpn ipsec phase2-interface

Parameter	Description	Type	Size	Default
add-route	Enable/disable automatic route addition.	option	-	phase1
	Option	Description		
	<i>phase1</i>	Add route according to phase1 add-route setting.		
	<i>enable</i>	Add route for remote proxy ID.		
	<i>disable</i>	Do not add route for remote proxy ID.		
auto-discovery-forwarder	Enable/disable forwarding short-cut messages.	option	-	phase1
	Option	Description		
	<i>phase1</i>	Forward short-cut messages according to the phase1 auto-discovery-forwarder setting.		
	<i>enable</i>	Enable forwarding auto-discovery short-cut messages.		
	<i>disable</i>	Disable forwarding auto-discovery short-cut messages.		
auto-discovery-sender	Enable/disable sending short-cut messages.	option	-	phase1
	Option	Description		
	<i>phase1</i>	Send short-cut messages according to the phase1 auto-discovery-sender setting.		
	<i>enable</i>	Enable sending auto-discovery short-cut messages.		
	<i>disable</i>	Disable sending auto-discovery short-cut messages.		

Parameter	Description	Type	Size	Default																																				
auto-negotiate	Enable/disable IPsec SA auto-negotiation.	option	-	disable																																				
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable setting.</td></tr><tr><td><i>disable</i></td><td>Disable setting.</td></tr></table>				Option	Description	<i>enable</i>	Enable setting.	<i>disable</i>	Disable setting.																														
	Option	Description																																						
	<i>enable</i>	Enable setting.																																						
	<i>disable</i>	Disable setting.																																						
comments	Comment.	var-string	Maximum length: 255																																					
dhcp-ipsec	Enable/disable DHCP-IPsec.	option	-	disable																																				
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable setting.</td></tr><tr><td><i>disable</i></td><td>Disable setting.</td></tr></table>				Option	Description	<i>enable</i>	Enable setting.	<i>disable</i>	Disable setting.																														
	Option	Description																																						
	<i>enable</i>	Enable setting.																																						
	<i>disable</i>	Disable setting.																																						
dhgrp	Phase2 DH group.	option	-	14																																				
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>1</td><td>DH Group 1.</td></tr><tr><td>2</td><td>DH Group 2.</td></tr><tr><td>5</td><td>DH Group 5.</td></tr><tr><td>14</td><td>DH Group 14.</td></tr><tr><td>15</td><td>DH Group 15.</td></tr><tr><td>16</td><td>DH Group 16.</td></tr><tr><td>17</td><td>DH Group 17.</td></tr><tr><td>18</td><td>DH Group 18.</td></tr><tr><td>19</td><td>DH Group 19.</td></tr><tr><td>20</td><td>DH Group 20.</td></tr><tr><td>21</td><td>DH Group 21.</td></tr><tr><td>27</td><td>DH Group 27.</td></tr><tr><td>28</td><td>DH Group 28.</td></tr><tr><td>29</td><td>DH Group 29.</td></tr><tr><td>30</td><td>DH Group 30.</td></tr><tr><td>31</td><td>DH Group 31.</td></tr><tr><td>32</td><td>DH Group 32.</td></tr></table>				Option	Description	1	DH Group 1.	2	DH Group 2.	5	DH Group 5.	14	DH Group 14.	15	DH Group 15.	16	DH Group 16.	17	DH Group 17.	18	DH Group 18.	19	DH Group 19.	20	DH Group 20.	21	DH Group 21.	27	DH Group 27.	28	DH Group 28.	29	DH Group 29.	30	DH Group 30.	31	DH Group 31.	32	DH Group 32.
	Option	Description																																						
	1	DH Group 1.																																						
	2	DH Group 2.																																						
	5	DH Group 5.																																						
	14	DH Group 14.																																						
	15	DH Group 15.																																						
	16	DH Group 16.																																						
	17	DH Group 17.																																						
	18	DH Group 18.																																						
	19	DH Group 19.																																						
	20	DH Group 20.																																						
	21	DH Group 21.																																						
	27	DH Group 27.																																						
	28	DH Group 28.																																						
	29	DH Group 29.																																						
	30	DH Group 30.																																						
	31	DH Group 31.																																						
	32	DH Group 32.																																						

Parameter	Description	Type	Size	Default
diffserv	Enable/disable applying DSCP value to the IPsec tunnel outer IP header.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
diffservcode	DSCP value to be applied to the IPsec tunnel outer IP header.	user	Not Specified	
dst-addr-type	Remote proxy ID type.	option	-	subnet
	Option	Description		
	<i>subnet</i>	IPv4 subnet.		
	<i>range</i>	IPv4 range.		
	<i>ip</i>	IPv4 IP.		
	<i>name</i>	IPv4 firewall address or group name.		
	<i>subnet6</i>	IPv6 subnet.		
	<i>range6</i>	IPv6 range.		
	<i>ip6</i>	IPv6 IP.		
	<i>name6</i>	IPv6 firewall address or group name.		
dst-end-ip	Remote proxy ID IPv4 end.	ipv4-address-any	Not Specified	0.0.0.0
dst-end-ip6	Remote proxy ID IPv6 end.	ipv6-address	Not Specified	::
dst-name	Remote proxy ID name.	string	Maximum length: 79	
dst-name6	Remote proxy ID name.	string	Maximum length: 79	
dst-port	Quick mode destination port.	integer	Minimum value: 0 Maximum value: 65535	0
dst-start-ip	Remote proxy ID IPv4 start.	ipv4-address-any	Not Specified	0.0.0.0
dst-start-ip6	Remote proxy ID IPv6 start.	ipv6-address	Not Specified	::

Parameter	Description	Type	Size	Default
dst-subnet	Remote proxy ID IPv4 subnet.	ipv4-classnet-any	Not Specified	0.0.0.0 0.0.0.0
dst-subnet6	Remote proxy ID IPv6 subnet.	ipv6-prefix	Not Specified	::/0
encapsulation	ESP encapsulation mode.	option	-	tunnel-mode
	Option Description			
	<i>tunnel-mode</i>	Use tunnel mode encapsulation.		
	<i>transport-mode</i>	Use transport mode encapsulation.		
inbound-dscp-copy	Enable/disable copying of the DSCP in the ESP header to the inner IP header.	option	-	phase1
	Option Description			
	<i>phase1</i>	copy the DCSP in the ESP header to the inner IP Header according to the phase1 inbound_dscp_copy setting.		
	<i>enable</i>	Enable copying of the DSCP in the ESP header to the inner IP header.		
	<i>disable</i>	Disable copying of the DSCP in the ESP header to the inner IP header.		
initiator-ts-narrow	Enable/disable traffic selector narrowing for IKEv2 initiator.	option	-	disable
	Option Description			
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
ipv4-df	Enable/disable setting and resetting of IPv4 'Don't Fragment' bit.	option	-	disable
	Option Description			
	<i>enable</i>	Set IPv4 DF the same as original packet.		
	<i>disable</i>	Reset IPv4 DF.		
keepalive	Enable/disable keep alive.	option	-	disable
	Option Description			
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
keylife-type	Keylife type.	option	-	seconds

Parameter	Description	Type	Size	Default
	Option Description			
	<i>seconds</i>	Key life in seconds.		
	<i>kbs</i>	Key life in kilobytes.		
	<i>both</i>	Key life both.		
keylifekbs	Phase2 key life in number of kilobytes of traffic.	integer	Minimum value: 5120 Maximum value: 4294967295	5120
keylifeseconds	Phase2 key life in time in seconds.	integer	Minimum value: 120 Maximum value: 172800	43200
l2tp	Enable/disable L2TP over IPsec.	option	-	disable
	Option Description			
	<i>enable</i>	Enable L2TP over IPsec.		
	<i>disable</i>	Disable L2TP over IPsec.		
name	IPsec tunnel name.	string	Maximum length: 35	
pfs	Enable/disable PFS feature.	option	-	enable
	Option Description			
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
phase1name	Phase 1 determines the options required for phase 2.	string	Maximum length: 15	
proposal	Phase2 proposal.	option	-	
	Option Description			
	<i>null-md5</i>	null-md5		
	<i>null-sha1</i>	null-sha1		
	<i>null-sha256</i>	null-sha256		
	<i>null-sha384</i>	null-sha384		

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>null-sha512</i>	null-sha512		
	<i>des-null</i>	des-null		
	<i>des-md5</i>	des-md5		
	<i>des-sha1</i>	des-sha1		
	<i>des-sha256</i>	des-sha256		
	<i>des-sha384</i>	des-sha384		
	<i>des-sha512</i>	des-sha512		
	<i>3des-null</i>	3des-null		
	<i>3des-md5</i>	3des-md5		
	<i>3des-sha1</i>	3des-sha1		
	<i>3des-sha256</i>	3des-sha256		
	<i>3des-sha384</i>	3des-sha384		
	<i>3des-sha512</i>	3des-sha512		
	<i>aes128-null</i>	aes128-null		
	<i>aes128-md5</i>	aes128-md5		
	<i>aes128-sha1</i>	aes128-sha1		
	<i>aes128-sha256</i>	aes128-sha256		
	<i>aes128-sha384</i>	aes128-sha384		
	<i>aes128-sha512</i>	aes128-sha512		
	<i>aes128gcm</i>	aes128gcm		
	<i>aes192-null</i>	aes192-null		
	<i>aes192-md5</i>	aes192-md5		
	<i>aes192-sha1</i>	aes192-sha1		
	<i>aes192-sha256</i>	aes192-sha256		
	<i>aes192-sha384</i>	aes192-sha384		
	<i>aes192-sha512</i>	aes192-sha512		
	<i>aes256-null</i>	aes256-null		
	<i>aes256-md5</i>	aes256-md5		
	<i>aes256-sha1</i>	aes256-sha1		

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>aes256-sha256</i>	aes256-sha256		
	<i>aes256-sha384</i>	aes256-sha384		
	<i>aes256-sha512</i>	aes256-sha512		
	<i>aes256gcm</i>	aes256gcm		
	<i>chacha20poly1305</i>	chacha20poly1305		
	<i>aria128-null</i>	aria128-null		
	<i>aria128-md5</i>	aria128-md5		
	<i>aria128-sha1</i>	aria128-sha1		
	<i>aria128-sha256</i>	aria128-sha256		
	<i>aria128-sha384</i>	aria128-sha384		
	<i>aria128-sha512</i>	aria128-sha512		
	<i>aria192-null</i>	aria192-null		
	<i>aria192-md5</i>	aria192-md5		
	<i>aria192-sha1</i>	aria192-sha1		
	<i>aria192-sha256</i>	aria192-sha256		
	<i>aria192-sha384</i>	aria192-sha384		
	<i>aria192-sha512</i>	aria192-sha512		
	<i>aria256-null</i>	aria256-null		
	<i>aria256-md5</i>	aria256-md5		
	<i>aria256-sha1</i>	aria256-sha1		
	<i>aria256-sha256</i>	aria256-sha256		
	<i>aria256-sha384</i>	aria256-sha384		
	<i>aria256-sha512</i>	aria256-sha512		
	<i>seed-null</i>	seed-null		
	<i>seed-md5</i>	seed-md5		
	<i>seed-sha1</i>	seed-sha1		
	<i>seed-sha256</i>	seed-sha256		
	<i>seed-sha384</i>	seed-sha384		
	<i>seed-sha512</i>	seed-sha512		

Parameter	Description	Type	Size	Default																		
protocol	Quick mode protocol selector.	integer	Minimum value: 0 Maximum value: 255	0																		
replay	Enable/disable replay detection.	option	-	enable																		
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Enable setting.</td></tr><tr><td>disable</td><td>Disable setting.</td></tr></table>	Option	Description	enable	Enable setting.	disable	Disable setting.															
	Option	Description																				
	enable	Enable setting.																				
disable	Disable setting.																					
route-overlap	Action for overlapping routes.	option	-	use-new																		
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>use-old</td><td>Use the old route and do not add the new route.</td></tr><tr><td>use-new</td><td>Delete the old route and add the new route.</td></tr><tr><td>allow</td><td>Allow overlapping routes.</td></tr></table>	Option	Description	use-old	Use the old route and do not add the new route.	use-new	Delete the old route and add the new route.	allow	Allow overlapping routes.													
	Option	Description																				
	use-old	Use the old route and do not add the new route.																				
	use-new	Delete the old route and add the new route.																				
allow	Allow overlapping routes.																					
single-source	Enable/disable single source IP restriction.	option	-	disable																		
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>enable</td><td>Only single source IP will be accepted.</td></tr><tr><td>disable</td><td>Source IP range will be accepted.</td></tr></table>	Option	Description	enable	Only single source IP will be accepted.	disable	Source IP range will be accepted.															
	Option	Description																				
	enable	Only single source IP will be accepted.																				
disable	Source IP range will be accepted.																					
src-addr-type	Local proxy ID type.	option	-	subnet																		
	<table><tr><th>Option</th><th>Description</th></tr><tr><td>subnet</td><td>IPv4 subnet.</td></tr><tr><td>range</td><td>IPv4 range.</td></tr><tr><td>ip</td><td>IPv4 IP.</td></tr><tr><td>name</td><td>IPv4 firewall address or group name.</td></tr><tr><td>subnet6</td><td>IPv6 subnet.</td></tr><tr><td>range6</td><td>IPv6 range.</td></tr><tr><td>ip6</td><td>IPv6 IP.</td></tr><tr><td>name6</td><td>IPv6 firewall address or group name.</td></tr></table>	Option	Description	subnet	IPv4 subnet.	range	IPv4 range.	ip	IPv4 IP.	name	IPv4 firewall address or group name.	subnet6	IPv6 subnet.	range6	IPv6 range.	ip6	IPv6 IP.	name6	IPv6 firewall address or group name.			
	Option	Description																				
	subnet	IPv4 subnet.																				
	range	IPv4 range.																				
	ip	IPv4 IP.																				
	name	IPv4 firewall address or group name.																				
	subnet6	IPv6 subnet.																				
	range6	IPv6 range.																				
ip6	IPv6 IP.																					
name6	IPv6 firewall address or group name.																					
src-end-ip	Local proxy ID end.	ipv4-address-any	Not Specified	0.0.0.0																		

Parameter	Description	Type	Size	Default
src-end-ip6	Local proxy ID IPv6 end.	ipv6-address	Not Specified	::
src-name	Local proxy ID name.	string	Maximum length: 79	
src-name6	Local proxy ID name.	string	Maximum length: 79	
src-port	Quick mode source port.	integer	Minimum value: 0 Maximum value: 65535	0
src-start-ip	Local proxy ID start.	ipv4-address-any	Not Specified	0.0.0.0
src-start-ip6	Local proxy ID IPv6 start.	ipv6-address	Not Specified	::
src-subnet	Local proxy ID subnet.	ipv4-classnet-any	Not Specified	0.0.0.0 0.0.0.0
src-subnet6	Local proxy ID IPv6 subnet.	ipv6-prefix	Not Specified	::/0

config vpn ipsec phase2

Configure VPN autokey tunnel.

```

config vpn ipsec phase2
  Description: Configure VPN autokey tunnel.
  edit <name>
    set add-route [phase1|enable|...]
    set auto-negotiate [enable|disable]
    set comments {var-string}
    set dhcp-ipsec [enable|disable]
    set dhgrp {option1}, {option2}, ...
    set diffserv [enable|disable]
    set diffservcode {user}
    set dst-addr-type [subnet|range|...]
    set dst-end-ip {ipv4-address-any}
    set dst-end-ip6 {ipv6-address}
    set dst-name {string}
    set dst-name6 {string}
    set dst-port {integer}
    set dst-start-ip {ipv4-address-any}
    set dst-start-ip6 {ipv6-address}
    set dst-subnet {ipv4-classnet-any}
    set dst-subnet6 {ipv6-prefix}
    set encapsulation [tunnel-mode|transport-mode]
    set inbound-dscp-copy [phase1|enable|...]
    set initiator-ts-narrow [enable|disable]
    set ipv4-df [enable|disable]

```

```

set keepalive [enable|disable]
set keylife-type [seconds|kbs|...]
set keylifekbs {integer}
set keylifeseconds {integer}
set l2tp [enable|disable]
set pfs [enable|disable]
set phase1name {string}
set proposal {option1}, {option2}, ...
set protocol {integer}
set replay [enable|disable]
set route-overlap [use-old|use-new|...]
set selector-match [exact|subset|...]
set single-source [enable|disable]
set src-addr-type [subnet|range|...]
set src-end-ip {ipv4-address-any}
set src-end-ip6 {ipv6-address}
set src-name {string}
set src-name6 {string}
set src-port {integer}
set src-start-ip {ipv4-address-any}
set src-start-ip6 {ipv6-address}
set src-subnet {ipv4-classnet-any}
set src-subnet6 {ipv6-prefix}
set use-natip [enable|disable]
next
end

```

config vpn ipsec phase2

Parameter	Description	Type	Size	Default
add-route	Enable/disable automatic route addition.	option	-	phase1
	Option	Description		
	<i>phase1</i>	Add route according to phase1 add-route setting.		
	<i>enable</i>	Add route for remote proxy ID.		
	<i>disable</i>	Do not add route for remote proxy ID.		
auto-negotiate	Enable/disable IPsec SA auto-negotiation.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
comments	Comment.	var-string	Maximum length: 255	
dhcp-ipsec	Enable/disable DHCP-IPsec.	option	-	disable

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
dhgrp	Phase2 DH group.	option	-	14
	Option	Description		
	1	DH Group 1.		
	2	DH Group 2.		
	5	DH Group 5.		
	14	DH Group 14.		
	15	DH Group 15.		
	16	DH Group 16.		
	17	DH Group 17.		
	18	DH Group 18.		
	19	DH Group 19.		
	20	DH Group 20.		
	21	DH Group 21.		
	27	DH Group 27.		
	28	DH Group 28.		
	29	DH Group 29.		
	30	DH Group 30.		
	31	DH Group 31.		
	32	DH Group 32.		
diffserv	Enable/disable applying DSCP value to the IPsec tunnel outer IP header.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
diffservcode	DSCP value to be applied to the IPsec tunnel outer IP header.	user	Not Specified	
dst-addr-type	Remote proxy ID type.	option	-	subnet

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>subnet</i>	IPv4 subnet.		
	<i>range</i>	IPv4 range.		
	<i>ip</i>	IPv4 IP.		
	<i>name</i>	IPv4 firewall address or group name.		
dst-end-ip	Remote proxy ID IPv4 end.	ipv4-address-any	Not Specified	0.0.0.0
dst-end-ip6	Remote proxy ID IPv6 end.	ipv6-address	Not Specified	::
dst-name	Remote proxy ID name.	string	Maximum length: 79	
dst-name6	Remote proxy ID name.	string	Maximum length: 79	
dst-port	Quick mode destination port.	integer	Minimum value: 0 Maximum value: 65535	0
dst-start-ip	Remote proxy ID IPv4 start.	ipv4-address-any	Not Specified	0.0.0.0
dst-start-ip6	Remote proxy ID IPv6 start.	ipv6-address	Not Specified	::
dst-subnet	Remote proxy ID IPv4 subnet.	ipv4-classnet-any	Not Specified	0.0.0.0 0.0.0.0
dst-subnet6	Remote proxy ID IPv6 subnet.	ipv6-prefix	Not Specified	::/0
encapsulation	ESP encapsulation mode.	option	-	tunnel-mode
	Option	Description		
	<i>tunnel-mode</i>	Use tunnel mode encapsulation.		
	<i>transport-mode</i>	Use transport mode encapsulation.		
inbound-dscp-copy	Enable/disable copying of the DSCP in the ESP header to the inner IP header.	option	-	phase1
	Option	Description		
	<i>phase1</i>	copy the DCSP in the ESP header to the inner IP Header according to the phase1 inbound_dscp_copy setting.		

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>enable</i>	Enable copying of the DSCP in the ESP header to the inner IP header.		
	<i>disable</i>	Disable copying of the DSCP in the ESP header to the inner IP header.		
initiator-ts-narrow	Enable/disable traffic selector narrowing for IKEv2 initiator.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
ipv4-df	Enable/disable setting and resetting of IPv4 'Don't Fragment' bit.	option	-	disable
	Option	Description		
	<i>enable</i>	Set IPv4 DF the same as original packet.		
	<i>disable</i>	Reset IPv4 DF.		
keepalive	Enable/disable keep alive.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
keylife-type	Keylife type.	option	-	seconds
	Option	Description		
	<i>seconds</i>	Key life in seconds.		
	<i>kbs</i>	Key life in kilobytes.		
	<i>both</i>	Key life both.		
keylifekbs	Phase2 key life in number of kilobytes of traffic.	integer	Minimum value: 5120 Maximum value: 4294967295	5120
keylifeseconds	Phase2 key life in time in seconds.	integer	Minimum value: 120 Maximum value: 172800	43200

Parameter	Description	Type	Size	Default
l2tp	Enable/disable L2TP over IPsec.	option	-	disable
	Option	Description		
	<i>enable</i>	Enable L2TP over IPsec.		
	<i>disable</i>	Disable L2TP over IPsec.		
name	IPsec tunnel name.	string	Maximum length: 35	
pfs	Enable/disable PFS feature.	option	-	enable
	Option	Description		
	<i>enable</i>	Enable setting.		
	<i>disable</i>	Disable setting.		
phase1name	Phase 1 determines the options required for phase 2.	string	Maximum length: 35	
proposal	Phase2 proposal.	option	-	
	Option	Description		
	<i>null-md5</i>	null-md5		
	<i>null-sha1</i>	null-sha1		
	<i>null-sha256</i>	null-sha256		
	<i>null-sha384</i>	null-sha384		
	<i>null-sha512</i>	null-sha512		
	<i>des-null</i>	des-null		
	<i>des-md5</i>	des-md5		
	<i>des-sha1</i>	des-sha1		
	<i>des-sha256</i>	des-sha256		
	<i>des-sha384</i>	des-sha384		
	<i>des-sha512</i>	des-sha512		
	<i>3des-null</i>	3des-null		
	<i>3des-md5</i>	3des-md5		
	<i>3des-sha1</i>	3des-sha1		
	<i>3des-sha256</i>	3des-sha256		

Parameter	Description	Type	Size	Default
	Option	Description		
	<i>3des-sha384</i>	3des-sha384		
	<i>3des-sha512</i>	3des-sha512		
	<i>aes128-null</i>	aes128-null		
	<i>aes128-md5</i>	aes128-md5		
	<i>aes128-sha1</i>	aes128-sha1		
	<i>aes128-sha256</i>	aes128-sha256		
	<i>aes128-sha384</i>	aes128-sha384		
	<i>aes128-sha512</i>	aes128-sha512		
	<i>aes128gcm</i>	aes128gcm		
	<i>aes192-null</i>	aes192-null		
	<i>aes192-md5</i>	aes192-md5		
	<i>aes192-sha1</i>	aes192-sha1		
	<i>aes192-sha256</i>	aes192-sha256		
	<i>aes192-sha384</i>	aes192-sha384		
	<i>aes192-sha512</i>	aes192-sha512		
	<i>aes256-null</i>	aes256-null		
	<i>aes256-md5</i>	aes256-md5		
	<i>aes256-sha1</i>	aes256-sha1		
	<i>aes256-sha256</i>	aes256-sha256		
	<i>aes256-sha384</i>	aes256-sha384		
	<i>aes256-sha512</i>	aes256-sha512		
	<i>aes256gcm</i>	aes256gcm		
	<i>chacha20poly1305</i>	chacha20poly1305		
	<i>aria128-null</i>	aria128-null		
	<i>aria128-md5</i>	aria128-md5		
	<i>aria128-sha1</i>	aria128-sha1		
	<i>aria128-sha256</i>	aria128-sha256		
	<i>aria128-sha384</i>	aria128-sha384		
	<i>aria128-sha512</i>	aria128-sha512		

Parameter	Description	Type	Size	Default																																						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>aria192-null</i></td><td>aria192-null</td></tr><tr><td><i>aria192-md5</i></td><td>aria192-md5</td></tr><tr><td><i>aria192-sha1</i></td><td>aria192-sha1</td></tr><tr><td><i>aria192-sha256</i></td><td>aria192-sha256</td></tr><tr><td><i>aria192-sha384</i></td><td>aria192-sha384</td></tr><tr><td><i>aria192-sha512</i></td><td>aria192-sha512</td></tr><tr><td><i>aria256-null</i></td><td>aria256-null</td></tr><tr><td><i>aria256-md5</i></td><td>aria256-md5</td></tr><tr><td><i>aria256-sha1</i></td><td>aria256-sha1</td></tr><tr><td><i>aria256-sha256</i></td><td>aria256-sha256</td></tr><tr><td><i>aria256-sha384</i></td><td>aria256-sha384</td></tr><tr><td><i>aria256-sha512</i></td><td>aria256-sha512</td></tr><tr><td><i>seed-null</i></td><td>seed-null</td></tr><tr><td><i>seed-md5</i></td><td>seed-md5</td></tr><tr><td><i>seed-sha1</i></td><td>seed-sha1</td></tr><tr><td><i>seed-sha256</i></td><td>seed-sha256</td></tr><tr><td><i>seed-sha384</i></td><td>seed-sha384</td></tr><tr><td><i>seed-sha512</i></td><td>seed-sha512</td></tr></table>	Option	Description	<i>aria192-null</i>	aria192-null	<i>aria192-md5</i>	aria192-md5	<i>aria192-sha1</i>	aria192-sha1	<i>aria192-sha256</i>	aria192-sha256	<i>aria192-sha384</i>	aria192-sha384	<i>aria192-sha512</i>	aria192-sha512	<i>aria256-null</i>	aria256-null	<i>aria256-md5</i>	aria256-md5	<i>aria256-sha1</i>	aria256-sha1	<i>aria256-sha256</i>	aria256-sha256	<i>aria256-sha384</i>	aria256-sha384	<i>aria256-sha512</i>	aria256-sha512	<i>seed-null</i>	seed-null	<i>seed-md5</i>	seed-md5	<i>seed-sha1</i>	seed-sha1	<i>seed-sha256</i>	seed-sha256	<i>seed-sha384</i>	seed-sha384	<i>seed-sha512</i>	seed-sha512			
	Option	Description																																								
	<i>aria192-null</i>	aria192-null																																								
	<i>aria192-md5</i>	aria192-md5																																								
	<i>aria192-sha1</i>	aria192-sha1																																								
	<i>aria192-sha256</i>	aria192-sha256																																								
	<i>aria192-sha384</i>	aria192-sha384																																								
	<i>aria192-sha512</i>	aria192-sha512																																								
	<i>aria256-null</i>	aria256-null																																								
	<i>aria256-md5</i>	aria256-md5																																								
	<i>aria256-sha1</i>	aria256-sha1																																								
	<i>aria256-sha256</i>	aria256-sha256																																								
	<i>aria256-sha384</i>	aria256-sha384																																								
	<i>aria256-sha512</i>	aria256-sha512																																								
	<i>seed-null</i>	seed-null																																								
	<i>seed-md5</i>	seed-md5																																								
	<i>seed-sha1</i>	seed-sha1																																								
	<i>seed-sha256</i>	seed-sha256																																								
	<i>seed-sha384</i>	seed-sha384																																								
<i>seed-sha512</i>	seed-sha512																																									
protocol	Quick mode protocol selector.	integer	Minimum value: 0 Maximum value: 255	0																																						
replay	Enable/disable replay detection.	option	-	enable																																						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Enable setting.</td></tr><tr><td><i>disable</i></td><td>Disable setting.</td></tr></table>	Option	Description	<i>enable</i>	Enable setting.	<i>disable</i>	Disable setting.																																			
	Option	Description																																								
	<i>enable</i>	Enable setting.																																								
<i>disable</i>	Disable setting.																																									
route-overlap	Action for overlapping routes.	option	-	use-new																																						
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>use-old</i></td><td>Use the old route and do not add the new route.</td></tr></table>	Option	Description	<i>use-old</i>	Use the old route and do not add the new route.																																					
	Option	Description																																								
<i>use-old</i>	Use the old route and do not add the new route.																																									

Parameter	Description	Type	Size	Default										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>use-new</i></td><td>Delete the old route and add the new route.</td></tr><tr><td><i>allow</i></td><td>Allow overlapping routes.</td></tr></table>	Option	Description	<i>use-new</i>	Delete the old route and add the new route.	<i>allow</i>	Allow overlapping routes.							
	Option	Description												
	<i>use-new</i>	Delete the old route and add the new route.												
<i>allow</i>	Allow overlapping routes.													
selector-match	Match type to use when comparing selectors.	option	-	auto										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>exact</i></td><td>Match selectors exactly.</td></tr><tr><td><i>subset</i></td><td>Match selectors by subset.</td></tr><tr><td><i>auto</i></td><td>Use subset or exact match depending on selector address type.</td></tr></table>	Option	Description	<i>exact</i>	Match selectors exactly.	<i>subset</i>	Match selectors by subset.	<i>auto</i>	Use subset or exact match depending on selector address type.					
	Option	Description												
	<i>exact</i>	Match selectors exactly.												
	<i>subset</i>	Match selectors by subset.												
<i>auto</i>	Use subset or exact match depending on selector address type.													
single-source	Enable/disable single source IP restriction.	option	-	disable										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>enable</i></td><td>Only single source IP will be accepted.</td></tr><tr><td><i>disable</i></td><td>Source IP range will be accepted.</td></tr></table>	Option	Description	<i>enable</i>	Only single source IP will be accepted.	<i>disable</i>	Source IP range will be accepted.							
	Option	Description												
	<i>enable</i>	Only single source IP will be accepted.												
<i>disable</i>	Source IP range will be accepted.													
src-addr-type	Local proxy ID type.	option	-	subnet										
	<table><tr><th>Option</th><th>Description</th></tr><tr><td><i>subnet</i></td><td>IPv4 subnet.</td></tr><tr><td><i>range</i></td><td>IPv4 range.</td></tr><tr><td><i>ip</i></td><td>IPv4 IP.</td></tr><tr><td><i>name</i></td><td>IPv4 firewall address or group name.</td></tr></table>	Option	Description	<i>subnet</i>	IPv4 subnet.	<i>range</i>	IPv4 range.	<i>ip</i>	IPv4 IP.	<i>name</i>	IPv4 firewall address or group name.			
	Option	Description												
	<i>subnet</i>	IPv4 subnet.												
	<i>range</i>	IPv4 range.												
	<i>ip</i>	IPv4 IP.												
<i>name</i>	IPv4 firewall address or group name.													
src-end-ip	Local proxy ID end.	ipv4-address-any	Not Specified	0.0.0.0										
src-end-ip6	Local proxy ID IPv6 end.	ipv6-address	Not Specified	::										
src-name	Local proxy ID name.	string	Maximum length: 79											
src-name6	Local proxy ID name.	string	Maximum length: 79											
src-port	Quick mode source port.	integer	Minimum value: 0 Maximum value: 65535	0										

Parameter	Description	Type	Size	Default
src-start-ip	Local proxy ID start.	ipv4-address-any	Not Specified	0.0.0.0
src-start-ip6	Local proxy ID IPv6 start.	ipv6-address	Not Specified	::
src-subnet	Local proxy ID subnet.	ipv4-classnet-any	Not Specified	0.0.0.0 0.0.0.0
src-subnet6	Local proxy ID IPv6 subnet.	ipv6-prefix	Not Specified	::/0
use-natip	Enable to use the FortiGate public IP as the source selector when outbound NAT is used.	option	-	enable
	Option	Description		
	enable	Replace source selector with interface IP when using outbound NAT.		
	disable	Do not modify source selector when using outbound NAT.		

config vpn kmip-server

KMIP server entry configuration.

```

config vpn kmip-server
  Description: KMIP server entry configuration.
  edit <name>
    set interface {string}
    set interface-select-method [auto|sdwan|...]
    set password {password}
    set server-identity-check [enable|disable]
    config server-list
      Description: KMIP server list.
      edit <id>
        set cert {string}
        set port {integer}
        set server {string}
        set status [enable|disable]
      next
    end
    set source-ip {string}
    set ssl-min-proto-version [default|SSLv3|...]
    set username {string}
  next
end

```