History plots

Data plotting from Konsole summary

Plotting software is here: cd /neuro/cryo/bin

Syntax = `./plot <period> --<metric>`

Commonly used arguments:

- `--all` Plot the 3 basic plots: tank pressure, cabinet temperatures, and dewar temperatures.
- `--temps` Plot cabinet temperatures and dewar temperatures (instead of tank pressures).
- `--wins` Shade MEG window and liquefaction times in the tank pressure diagram.
- `--slopes` Plot the derivative of tank pressure.
- `--heliumvolume` Plot system total helium volume (for leakage detection).
- `--workgas` Plot cryocooler compressor working gas pressure.
- `--dewar` Plot dewar pressure on the secondary axis of tank pressure plot.
- `--gantry` Plot gantry positions on the secondary axis of tank pressure plot.
- `--from=<YYYYmmDD>` Plot the requested time period in history starting from the given time point.
- `--rates` Provides a text file with the average liquefaction and boiling rates