2 x 5 LxPad
FO cable
PROPixx PROJECTOR
USB
DVI
PROPixx Controller
DVI
MONITOR
ONBOARD
"PROPIXX"
BNC Frontend
NAtA Converter
STI 102
FO cable
Electronics Cabinet
LabJack U3-LV
ScrewTerminal connections
USB
DVI
USB
KVM
USB
USB
USB
(via 8-way UPS Extension)
USB
USB
MOUSE
KEYBOARD
(via 4-port Hub)
Participant
Speakers
SOUNDPixx
Electronics Cabinet
FO cable
STI 101
37pin DIN
DVI
PROPixx Adapter
USB (power)
USB SWITCH
Speakers
Participant
NATUS
4-WAY P PORT SWITCH
C
A
B
DVI
DP
USB #2
(connect as required)
P PORT #1
USB #1
USB #1
"AUDIO-NEW"
"AUDIO-OLD"
ONBOARD
SND CARD
P PORT #1
2 x HDD
2 x SSD (RAID 1)
1 x HDD
NIC Switch
(via 8-way UPS Extension)
NIC#2
NIC#1
NIC#2
UoB or MEGIN
NIC#1
MEG-STIM-01
CHBH-ST-MEG-W02
RACK
6-way Mains Extension
EyeLink PC, EyeLink Camera
FO cable
Mains Equipment shared between UPS #1 & #2
UPS #1
APC BACK-UPS BX1400UI
UPS #2
APC BACK-UPS BX1400UI
MAINS
EyeLink Camera Head
(EyeLink Camera Head/Illuminator in MSR, powered by battery, or AC Adapter in Stimulus Cabinet)