






K
K'
PARAMS
TRACKS
TRACK FX
STEP
PRESET
SONG
SETTINGS
AT ROUTE
1
5


F2
9
13
STEP
DRUMS
ARP
SCALE
WAVEFORM
FILTER



R
KNOB PAGE
JUMP
PATTERN
PASTE
COARSE
PAGE



T
K
R
M
F1
F2
LAYER
SCREEN
FINE
TAP TEMPO
TRACK
PARAMS
TRACKS
TRACK FX
STEP
PRESET
SONG
SETTINGS
AT ROUTE
KNOB PAGE
JUMP
PATTERN
PASTE
COARSE
PAGE
REWIND
SILENCE
CLEAR
FILL
COPY
NEPTUNE
KEY SPLIT
PAD PAGE
HOLD
TRACK
MUTE
STEP
DRUMS
ARP
SCALE
WAVEFORM
FILTER



100 mm
0 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170 180 190 200 mm
0 1 2 3 4 5 6 7 8 in



0 10 20 30 40 50 60 70 80 90 100
100 mm



F1
NEPTUNE
KEY SPLIT
PAD PAGE
HOLD
TRACK
MUTE



T
LATCH
SCREEN
FINE
TAP TEMPO
TRACK


M
REWIND
SILENCE
CLEAR
FILL
COPY


T
K
R
M
F1
F2
LATCH
SCREEN
FINE
TAP TEMPO
TRACK
PARAMS
TRACKS
TRACK FX
STEP
PRESET
SONG
SETTINGS
AT ROUTE
KNOB PAGE
JUMP
PATTERN
PASTE
COARSE
PAGE
REWIND
SILENCE
CLEAR
FILL
COPY
NEPTUNE
KEY SPLIT
PAD PAGE
HOLD
TRACK
MUTE
STEP
DRUMS
ARP
SCALE
WAVEFORM
FILTER


100 mm
0 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170 180 190 200 mm
0 1 2 3 4 5 6 7 8 in


0 10 20 30 40 50 60 70 80 90 100
100 mm



amber, diamond: with Shift held

blue, ring: with Func held

with Shift and Func held

Play

Record

undo, redo

back, on

the solid bar: that row of pads

the eight cells of a grid screen

Words on the six pieces: 42

PARAMS · TRACKS · TRACK · FX · STEP · PRESET · SONG · SETTINGS · AT · ROUTE · STEP · DRUMS · ARP · SCALE · WAVEFORM · FILTER · KNOB · PAGE · JUMP · PATTERN · PASTE
COARSE · PAGE · NEPTUNE · KEY · SPLIT · PAD · PAGE · HOLD · TRACK · MUTE · FINE · TAP · TEMPO · TRACK · LATCH · SCREEN · REWIND · SILENCE · CLEAR · FILL · COPY

