
C3
C1
U3
23LC512
U1
MCP23S17 ch6 ADDR
J2
SD
GND
5V
MISO
MOSI
SCK
CS
KEY
J1
CARD
1=F2
2=F1
LCD
GND
5V
SDA
SCL
J3
R1
C2
C4
U2
MCP23S17 ch7 DATA
Powered by
Cheeky-Smokey