NIGHT VISION MONOCULAR - CONTROLS
LAFVIN ESP32-S3 1.69" LCD board (OV3660 camera) by Chemistry of Questionable Quality

Sketch: lafvin_nightvision_nolib.ino

BOOT BUTTON (the GPIO0 button)
  Short press : change view mode
                 NIGHT (green tint) -> MONO (grayscale) -> DAY (colour) -> back to NIGHT
  Long press   : change screen brightness (hold about 1 second, then release)
                 100% -> 50% -> 15% -> 4% -> back to 100%

STATUS STRIP (top of the screen)
  Coloured square : current mode
                    green = NIGHT, grey = MONO, yellow = DAY
  Number   : frames per second
  Four bars   : screen brightness (4 lit = 100%, 1 lit = 4%)

RESET BUTTON
  Restarts the program.

TIPS
  - DAY mode is handy for focusing the lens in daylight. Re-check focus
    under IR light, since IR focuses slightly differently.
  - Lower screen brightness keeps your eye dark-adapted and saves battery.
  - Do not hold BOOT while powering on. That puts the board into
    firmware download mode and nothing will run.

STARTUP ERROR SCREENS
  Solid RED screen   : PSRAM not found (set PSRAM to OPI PSRAM)
  Solid MAGENTA screen : camera failed to start (check the camera ribbon cable)

FLASHING NEW CODE
  1. Hold BOOT, plug in the USB cable, release BOOT.
  2. Upload.
  3. Press RESET when it finishes.