MCC125 Wireless link project Link Budget

Microwave Surfers Group

Bingcheng Chen Filip Aldebrink Geo Philip Muppathiyil Jiquan Mao Malik Fahd

December 22, 2023

Chalmers University of Technology Wireless link project MCC125

1 Introduction

This document describes the link budget for the project in which we implement a one-way wireless communication system that can communicate over 100 meter.

The parameters we selected for the system are illustrated in Table 1

Seq	Item	Value
1	RF Frequency	2.4 GHz
2	IF frequency	20 MHz
3	Target Bitrate R_b	10 Mbits/s
4	Modulation Format	64-QAM
5	Modulation Order m	6
6	Symbol Rate R_s	$1.67~\mathrm{MBaud/s}$
7	Bandwidth	1.67 MHz
8	Distance	100 m

Table 1: Parameters selected for the system

2 System Overview

By choosing a desired BER of 10^{-6} , we get a $\frac{E_b}{N_0}$, for our chosen modulation, from the graph shown in Figure 1.




Figure 1: Estimated BER vs $E_{\rm b}/N_0$ [1].

We can read that we have a $E_b/N_0 = 18.8 \,\mathrm{dB}$ when we use 64-QAM with a BER of 10^{-6} . With this, the required minimum SNR at the receiver is given by, with a $R_b/B = 10 \,\mathrm{Mbps}/1.67 \,\mathrm{MHz} = 6$, the following equation [2]:

$$SNR_{In} = 10log_{10}(\frac{E_b}{N_0} \cdot \frac{R_b}{B}) = 10log_{10}(\frac{E_b}{N_0} \cdot 6) = 26.78 \, dB$$

2.1 Receiver Details

The block diagram of the receiver are illustrated in Figure 2.




Figure 2: Receiver Block Diagram

From the block diagram shown in Figure 2, we can calculate the noise figure as:

$$NF_{tot} = 10log_{10}(NF_1 + \frac{NF_2 - 1}{G_1} + \frac{NF_3 - 1}{G_1G_2} + \cdots) = 4.74 \,\mathrm{dB}$$

2.2 Link Budget Calculation

We can calculate the noise power from the following equation:

$$P_n = -174 + 10log_{10}(BW) + NF_{tot} = -107.04 \, dBm$$

Where -174 is the Boltzmann constant in dBm/Hz. The SNR_{in} is the ratio between the received signal power and the noise power, hence the receiver sensitivity is given by:

$$P_r = P_p + SNR = -80.26 \, dBm$$

With a frequency of 2.4 GHz and a distance of 100 m the free space loss can be calculated by the following equation:

$$FSPL = 20 \cdot log_{10}(\frac{c}{4\pi \cdot d \cdot f}) = 20 \times log_{10}(\frac{3 \times 10^8}{4\pi \times 100 \times 2.4 \times 10^9}) = -80 \ dB$$

The minimum required transmitted power in ideal circumstances can be calculated by Friis formula:

$$P_t = P_r - FSPL - G_t - G_r = -6.21 \, dBm$$

2.3 Transmitter Details

The block diagram of the transmitter can be seen in Figure 3.




Figure 3: Transmitter Block Diagram

Seq	Component	Device	Input power (dBm)	$rac{{ m Gain/Loss}}{{ m (dB)}}$	Output power (dBm)	1-dB compression (dBm)
1	DAC	USRP N210	-	-	-15	-
2	Amplifier	HMC480	-15	20	5	20
3	Mixer	HMC213	5	-10	-5	8
4	Amplifier	MAX2615	-5	18.6	13.6	19.5
5	Antenna	VERT2450	13.6	3 dBi	16.6	

Table 2: Detailed input and output power of the transmitter

The 1-dB compression point of the transmitter is given by,

$$P_{1dB,tot} = 10log_{10} \left[\left(\dots + \frac{1}{P_{1dB,n-2}G_{n-1}G_n} + \frac{1}{P_{1dB,n-1}G_n} + \frac{1}{P_{1dB,n}} \right)^{-1} \right] = 18.3 \ dBm$$

Our designed transmitter power is $13.6 \ dBm$, which is within the safe range of the minimum required transmitted power of $-6.21 \ dBm$.

References

[1] Unknown (2023) - "Eb/N0". Retrieved from: https://www.linuxtv.org/wiki/index.php/Eb/N0 [Online resorce]

[2] Vessen Vassilev (2023) - "Introduction". Retrieved from: https://chalmers.instructure.com/courses/26387/files/3001161?module_item_id=420200 [Lecture]

A MATLAB code

```
1 clc, clf, clear all;
  c = 3e8;
  f = 2.4 e9;
  R=100;
  Ebn0=19; %dB for 64QAM at e-6 BER
  Rb=10e6; %bit/s
  M = 64;
  m=log2(M); %modulation order for 64QAM
  B=Rb/m;
11
  SNRin=Ebn0+10*log10 (m)
13
  G1 = -2;
15
  F1=2;
  G2 = 18.6;
  F2=2;
  G3 = -10;
  F3 = 10;
  F4 = 0.6;
  G4 = 0.6;
  F5 = 3.5;
  G5=20;
  F6 = 3.5;
25
  G6=20;
26
27
  Frx=10*log10(10^{(F1/10)}+((10^{(F2/10)}-1)/10^{(G1/10)})+((10^{(F3/10)}-1)/10^{(F3/10)})
      -1)/(10^{(G1+G2)/10}))+((10^{(F4/10)-1})/(10^{(G1+G2+G3)/10}))
      +((10^{(5/10)}-1)/(10^{((G1+G2+G3+G4)/10)})+((10^{(5/10)}-1)/(10^{((G1+G2+G3+G4)/10)}))
      G1+G2+G3+G4+G5)/10)))
29
  Pn = -174 + 10 * log 10 (B) + Frx
  Pr=SNRin+Pn
31
32
  Lfs = 10 * log 10 ((c/(4*pi*R*f))^2)
33
34
  Gr=3; %dBi
  Gt=3; %dBi
  Pt=Pr-Lfs-Gt-Gr
```