ACT8846 问题分析


--手机组 张晴

RESET:

按 reset 按键必须按下>4s(硬复位),PMU 内部才能清楚寄存器恢复到默认,然后 PMIC 掉电,按开机键重新开机。如果<4s(软复位),是无法清除 PMU 内部寄存器的,所以会出现在电压较低时按 reset 键无法重启。具体解决方法如下:

PMU 的电路有如下两种, 区别在 VSELR 脚:

1、旧的方案, PMU 电路



Reset:

这种是不支持短按 reset 复位的,必须要按下>4s,启动硬复位。


此时不需要开启宏: Device Drivers ---> Voltage and Current Regulator Support -> ACT8846 PMIC SUPPORT RESET

休眠唤醒电压设置:

```
只需要在板级文件中 act8846_dcdc_info 结构体中初始化各路休眠电压:
```

```
= "vdd cpu",
                                     //arm
        . name
                        = 1000000,
        .min_uv
                       = 1000000,
        .max_uv
        #ifdef CONFIG ACT8846 SUPPORT RESET
        .suspend_vol = 1200000,
        #else
        .suspend_vol = 900000,
        #endif
   },
    000000000000
};
在待机时只需要拉高 PMU_SLEEP 脚即可实现休眠电压的切换。
PMU_SLEEP 脚处理在 board-pmu-act8846. c 中的:
void __sramfunc board_pmu_act8846_suspend(void)
    #ifdef CONFIG_CLK_SWITCH_TO_32K
     sram_gpio_set_value(pmic_sleep, GPIO_HIGH);
    #endif
void sramfunc board pmu act8846 resume(void)
    #ifdef CONFIG CLK SWITCH TO 32K
    sram_gpio_set_value(pmic_sleep, GPIO_LOW);
    sram_udelay(2000);
    #endif
由于 PMU_SLEEP 是跟24M 切换32K 同一个 IO, 所以需要开启宏 CONFIG_CLK_SWITCH_TO_32K。
```

2、新的方案, PMU 电路



按照上述修改后,只需要更新代码(commit 4f3e4efb38fd205c44c505242c6038f073e6ea16),打开宏: Device Drivers ---> Voltage and Current Regulator Support -> ACT8846 PMIC SUPPORT

RESET

RESET:

上述是我们后期已经修改电路,只要按照我们最新的电路修改,然后更新代码,即可实现短按复

原理:复位按下后 DVSO_CTL 恢复成默认状态(低电平), ACT8846内部寄存器切换到 REGO, REGO 中 DCDC 设置默认值较高,足够系统重启。系统正常运行时 DVSO_CTL 为高,ACT8846切换到 REG1, REG1设置平时需要的各路 DCDC 电压(包括 DVFS 的电压调整)

注意: 在复位是切换的默认电压设置不可过低,设置位置在板级文件 act8846_dcdc_info[] 中. suspend vol。如:

```
#ifdef CONFIG ACT8846 SUPPORT RESET
        .suspend_vol = 1200000,
#else
```

```
休眠唤醒电压设置:
休眠唤醒的电压设置在 board-pmu-act8846.c 中的:
void act8846_device_suspend(void)
    struct regulator *dcdc;
    #ifdef CONFIG_ACT8846_SUPPORT_RESET
    sram_gpio_set_value(pmic_vsel, GPIO_LOW);
    dcdc =dvfs_get_regulator( "vdd_cpu");
    vdd cpu vol = regulator get voltage(dcdc);
    regulator_set_voltage(dcdc, 900000, 900000); //设置休眠电压
    udelay(100);
    dcdc =dvfs_get_regulator( "vdd_core");
    vdd_core_vol = regulator_get_voltage(dcdc);
    regulator_set_voltage(dcdc, 900000, 900000);
    udelay(100);
    dcdc =regulator_get(NULL, "act_dcdc4");
    regulator_set_voltage(dcdc, 2800000, 2800000);
    regulator_put(dcdc);
    udelay(100);
    #endif
}
void act8846_device_resume(void)
    struct regulator *dcdc;
    #ifdef CONFIG_ACT8846_SUPPORT_RESET
```

```
dcdc =dvfs_get_regulator( "vdd_cpu");
    regulator_set_voltage(dcdc, vdd_cpu_vol, vdd_cpu_vol);
    udelay(100);
    dcdc =dvfs_get_regulator( "vdd_core");
    regulator_set_voltage(dcdc, vdd_core_vol, vdd_core_vol);
    udelay(100);
    dcdc =regulator_get(NULL, "act_dcdc4");
    regulator_set_voltage(dcdc, 3000000, 3000000);
    regulator_put(dcdc);
    udelay(100);
    sram_gpio_set_value(pmic_vsel, GPIO_HIGH);
    #endif
}
按照上述设置后,在 board-pmu-act8846.c 中下面函数中拉高拉低 IO 即可实现休眠唤醒电压
的切换。
void __sramfunc board_act8846_set_suspend_vol(void)
{
#ifdef CONFIG ACT8846 SUPPORT RESET
    sram_gpio_set_value(pmic_vsel, GPIO_HIGH);
#endif
void __sramfunc board_act8846_set_resume_vol(void)
#ifdef CONFIG_ACT8846_SUPPORT_RESET
    sram_gpio_set_value(pmic_vsel, GPIO_LOW);
#endif
}
```