

B2501D

Porta sapone destro

Right soap dish holder







B2501S

Porta sapone sinistro

Left soap dish holder






B2502D

Porta bicchiere destro


Right glass holder



B2502S

Porta bicchiere sinistro


Left glass holder



B9330D

Dispenser destro (L 0,50)


Right dispenser (L 0,50)



B9330S


Dispenser sinistro (L 0,50)

Left dispenser (L 0,50)




Porta sapone d'appoggio

Standing soap dish holder




Bicchiere d'appoggio

Standing glass holder



Spandisapone d'appoggio (L 0,50)


Standing soap dispenser (L 0,50)




AR37


Appenditutto

Hook




Porta rotolo Roll holder






Porta salvietta ad anello

Ring towel holder




Porta salvietta

Towel holder




Porta salvietta

Towel holder




Porta salvietta

Towel holder




Porta salvietta doppio a snodo

Double bar towel holder




Scopino d'appoggioStanding brush holder



B2507D

Porta scopino destro

Right brush holder



B2507S

Porta scopino sinistro

Left brush holder

