
## Getimagefilefromfloppydisk

- 1. Downloadsoftware Winhex
- 2. Install
- 3. Regist: run the software keygen. exe under the directroy, copy the register code, open menu: Help->Register, pasteregistercodeintowindow, complete
- 4. Plugfloppydiskintofloppydriver , openmenu: Tools ->Opendisk , select: Physical



- 5. Openmenu: Edit -> SelectAll , select: Edit -> CopyBlock -> IntoNewFile , named 000.IMG or with other number , if used for YAMAHAE L series for decode , named EL000.IMG, ornamedEL+numbers
- 6. The capacityofimagefileis 1 .44MB (highdensity ) or 720KB (lowdensity )