Over the last 56 years, Intel Corporation has played a central role in the computing sector. Founded in California, Intel is now the world's largest semiconductor chip manufacturer. However, the big numbers surrounding this global tech giant (over 131,000 employees, $146.7 billion net worth) are underpinned by tiny products — semiconductor chips that serve as computer processors.

Without processors, computers wouldn't work. Intel has been the dominant force in developing the global computing industry, the growth of the internet and modern-day reliance on cloud services. But while Intel's story is well known, the history of its processors is less extensively documented.



History of Intel Processors

To celebrate the development of products that have literally changed the world, here's a walkthrough of the history of Intel processors, starting with the first commercially available processor.

Comparison Table

Year	Processor	Bus Width	Process Size	Frequency (Clock Speeds)
1971	Intel 4004	4-bit	10 µm (10,000 nm)	108 kHz → 740 kHz
1972	Intel 8008	8-bit	*(not stated)*	0.5–0.8 MHz
1974	Intel 8080	8-bit	6,000 nm	Up to 2 MHz
1978–82	Intel 8086	16-bit	3,000 nm	5–10 MHz
1979–82	Intel 8088	8-bit external bus (16-bit internal)	3,000 nm	5–8 MHz
1982	Intel 80186	16-bit	2,000 nm	~6 MHz (1+ MIPS)
1981	iAPX 432	32-bit	*(not stated)*	4–8 MHz
1982	80286	16-bit	1,500 nm	Up to 25 MHz
1985	386DX	32-bit	1,500 nm	16–33 MHz
1988	386SX	16-bit external bus	1,000 nm	Similar 16–33 MHz
1990	386SL	32-bit	*(not stated)*	20–25 MHz
1989	486DX	32-bit	1,000 / 800 nm	25–50 MHz
1991	486SX	32-bit	*(not stated)*	16–33 MHz
1992	486DX2	32-bit	*(not stated)*	Up to 66 MHz
1994	486DX4	32-bit	600 nm	Up to 100 MHz
1989	i860	32-bit (RISC)	*(not stated)*	*(varied)*
1993	Pentium (P5)	32-bit	800 nm → 350 nm	60 MHz → 200 MHz
1997	Pentium MMX	32-bit	350 nm	Up to 233 MHz (mobile 300 MHz)
1995	Pentium Pro	32-bit	350 nm	150–200 MHz
1997	Pentium II	32-bit	350→250 nm	233–450 MHz
1997	Pentium II Xeon	32-bit	250 nm	Similar ranges

Year	Processor	Bus Width	Process Size	Frequency (Clock Speeds)
1998	Celeron	32-bit	250 nm	266–300 MHz (up to 500 MHz mobile)
1999	Pentium III	32-bit	250→180→130 nm	450 MHz → 1.4 GHz
2000	Pentium 4	32-bit	180→130→90→65 nm	1.3 GHz → 3.8 GHz
2001	Xeon (Netburst)	32-bit	180 nm	1.4–2.0 GHz
2001	Itanium	64-bit	180 nm	733–800 MHz
2002	Hyper-Threaded P4	32-bit	130 nm	~3 GHz
2003	Pentium M (Banias)	32-bit	130 nm → 90 nm (Dothan)	900 MHz → 2.13 GHz
2005	Pentium D (dual-core Netburst)	32-bit	90 nm / 65 nm	Up to 3.73 GHz
2005–09	Terascale chips	Varies	Research nodes	~1 TFLOP+
2006	Core 2 Duo	64-bit	65 nm → 45 nm	1.2–3.0 GHz
2007	vPro systems	*(various CPUs)*	—	—
2008	Nehalem (Core i3/i5/i7)	64-bit	45 nm	Up to 3.33 GHz
2008	Atom	32/64-bit	45 nm	Very low power; <2 GHz
2010	HD Graphics CPUs	64-bit	32 nm	Varies
2010	Xeon Phi (Knights Ferry)	64-bit	*(not stated)*	1.2 GHz • 32 cores
2012	Intel SoCs (Bay Trail)	64-bit	22 nm	Low power (<2 GHz)
2013	Haswell	64-bit	22 nm	Up to 4.4 GHz
2014	Broadwell	64-bit	14 nm	Similar to Haswell; more efficient
2015	Skylake	64-bit	14 nm	Up to ~4 GHz

Year	Processor	Bus Width	Process Size	Frequency (Clock Speeds)
2016	Kaby Lake	64-bit	14 nm+	Slightly higher frequencies
2019	Ice Lake	64-bit	10 nm	~3.7 GHz (Xeon SP)
2020	Tiger Lake	64-bit	10 nm SuperFin	Up to 5 GHz (i9-11980HK)
2022	Alder Lake	Hybrid (P+E cores)	Intel 7 (≈10 nm ESF)	Up to 5.5 GHz
2023	Raptor Lake	Hybrid	Intel 7	Up to 5.6 GHz
2023	Raptor Lake Refresh	Hybrid	Intel 7	Up to 6.2 GHz
2023	Meteor Lake	Hybrid chipset	Intel 4	*(not specified; mobile ranges)*

1. Early Microprocessors (1971–1978)

- **4004 (1971)**: *World's first commercial microprocessor*; 4-bit CPU built on a 10 µm process, marking the start of single-chip computing.
- **8008 (1972) & 8080 (1974)**: 8-bit processors that enabled early personal computers such as the Altair 8800 and set the foundation for modern CPU design.

2. Beginning of the x86 Era (1978–1985)

- **8086/8088 (1978–81)**: *First 16-bit x86 processors*; the 8088 powered the original IBM PC, creating *industry-wide adoption* of the x86 architecture.
- **80186 & 80286 (1982)**: Introduced improved performance, *memory protection and the basis of business PCs (IBM AT)*.

3. 32-bit Revolution (1985–1995)

- **80386 (1985)**: *First 32-bit x86 CPU*, enabling advanced multitasking and modern OS capabilities.
- **80486 (1989)**: *Added on-chip FPU and cache*, delivering major speed improvements.
- **Pentium (1993)**: First superscalar x86 processor capable of executing multiple instructions per cycle; introduced MMX later.

FPU = Floating Point Unit

4. High-Performance & Server Evolution (1995–2005)

- **Pentium Pro (1995)**: *Optimized for servers*; introduced out-of-order execution.
- **Pentium II & III (1997-99)**: Improved multimedia performance and introduced mobile features like Speed Step.
- **Pentium 4 (2000)**: NetBurst architecture focused on very high clock speeds; eventually limited by power consumption.
- **Itanium (2001)**: 64-bit EPIC architecture for high-end servers, but struggled with compatibility and adoption.

Speed Step = **power-saving feature** designed to optimize CPU performance while reducing energy consumption. It dynamically adjusts the processor's voltage and frequency based on the workload, ensuring that the CPU only uses the power it needs at any given moment

5. Multi-Core & Efficiency Shift (2003–2010)

- **Pentium M (2003)**: Power-efficient mobile CPU that inspired Intel's future Core architecture.
- **Pentium D (2005)**: First dual-core desktop processor.
- **Core 2 Duo (2006)**: Major shift from clock-speed race to efficiency; regained Intel's performance leadership.
- **Nehalem (2008)**: First Core i3/i5/i7 series; integrated memory controller and Hyper-Threading revival.
- **Atom (2008)**: Intel's entry into low-power and mobile markets.

6. Integrated Graphics & New Architectures (2010–2016)

- **HD Graphics (2010)**: Integrated GPU on the CPU die—huge leap for laptops and desktops.
- **Sandy Bridge / Ivy Bridge / Haswell / Broadwell**: Strong generation-based improvements in power, graphics and IPC.
- **Skylake (2015)**: Major architectural refinement used across many product lines.

7. Modern Hybrid and AI-Ready Processors (2016–Present)

- **Kaby Lake (2016)**: Improved clock speeds and better 4K media support.

- **Ice Lake (2019)**: First 10 nm Core CPUs, better AI, graphics and efficiency.
- **Tiger Lake (2020)**: 10 nm SuperFin, excellent integrated Xe graphics.
- **Alder Lake (2022)**: First hybrid architecture (Performance + Efficiency cores), huge design shift.
- **Raptor Lake (2023)**: Enhanced hybrid core design, faster clocks up to 6.2 GHz.
- **Meteor Lake (2023)**: First chiplet-based Intel CPU, built-in NPU (AI accelerator), ultra-efficient mobile design.

Intel's 10nm SuperFin transistor achieves ~17.5% performance uplift and significantly higher clock speeds compared to vanilla 10nm.

Summary

Intel's microprocessor evolution moved through clear phases:

1. **Single-chip and 8-bit origins**
2. **Rise of x86 and PC standardization**
3. **32-bit computing revolution**
4. **Superscalar and high-performance expansion**
5. **Shift to mobility and multi-core efficiency**
6. **Modern integrated graphics and energy-efficient designs**
7. **Hybrid, AI-accelerated, chiplet-based processors**

Questions:

1. **Explain the Evolution of INTEL series microprocessor highlighting the recent trends.**