

# Container Refrigeration Unit

Models 69NT20-284 69NT40-461 69NT40-464



# SERVICE PARTS LIST CONTAINER REFRIGERATION UNIT MODELS 69NT20-284 69NT40-461 & 69NT40-464

### **CONTENTS**

Intr	oducti	on	İ
Orc	lering	Instructions	i
Lett	ter Des	signations	i
Мо	del Ch	art	i
1.	Quick	List - Clamps, Filter-drier, Fuse, Ty-raps, And Wire Terminals	1
2.	Tools		1
3.	Refrig	eration Unit Assembly	2
	3.1	Refrigeration Unit – Front	2
	3.2	Control Box Door	4
	3.3	Control Box	6
	3.4	Control Box – High Voltage Shield Removed	8
	3.5	Condenser Fan Motor And Coil Section	10
	3.6	Water-Cooled Condenser/Receiver And Tubing Section	12
	3.7	Evaporator Fan Motor And Access Panel Section	14
	3.8	Evaporator Coil Section – Rear Panels Removed	16
	3.9	Evaporator Coil Section – Rear Panels Attached	17
	3.10	Recording Thermometer (Partlow)	20
	3.11	Recording Thermometer (Saginomiya)	21
	3.12	Recording Thermometer (Fuji Kiki)	22
	3.13	Thermostatic Expansion Valve – Alco	23
	3.14	Suction Solenoid Valve	24
	3.15	Modulating Solenoid Valve	25
	3.16	Compressor Mounting And Gauges	26
	3.17	Voltage Option And Power Transformer	28
	3.18	Labels and Decals	30
4.	Comp	pressor – Motor Assembly	32
	4.1	Service Replacement Compressor	33
	4.2	Terminal Mounting And Junction Box Group	33
	4.3	Service Valve Group	33
	4.4	Compressor – Motor Body Group	33
	4.5	Pump End Group	34
	4.6	Crankshaft, Rod And Piston Group	34
	4.7	Valve Plate Group	35
	4.8	Gasket Set	36



### SERVICE PARTS LIST

### INTRODUCTION

This parts list identifies service replacement parts for the Carrier Transicold Container Models listed in the Model Chart below.

### ORDERING INSTRUCTIONS

All orders and inquiries for parts must include: Model, Unit Serial Number, Part Number, description of part as shown on list and quantity required. Address all correspondence for parts to the following address:

> CARRIER TRANSICOLD DIVISION Replacement Component Group TR-20, P.O. Box 4805 Syracuse, New York 13221

### LETTER DESIGNATIONS

The following letter designations are used to classify parts throughout this list:

A/R	As Required.		Suffix P added to part number means part is available in packaged quantity only. Example:	
NLO	No Longer Offered.		P/N34-00373-01P10 is a package of 10 P/I 34-00373-01. Use part number and P suffi	
NS	Not Shown in the illustration.		when ordering.	
NSA	Non-Stock Assembly – order components listed		Purchase Locally.	
	under the assembly.	SST	Stainless Steel –	
NSI	Non-Stock Item – may be available on special order.		300 Series unless otherwise specified.	
NSS	Not Sold Separately – order next higher	SV	<i>Suffix SV</i> – added to part number designates service replacement part.	

### MODEL CHART

assembly or kit.

MODELS	Hinged Rear Panels	Two Speed Evaporator Fan Motors	Water-Cooled Condenser	Receiver	Power Transformer	Suction & Discharge Gauges	Dual Voltage Compressor	Heat Exchanger
69NT20-284	Χ	Χ	_	-	Χ	Χ	_	_
69NT20-284-1	_	_	_	_	_	_	_	_
69NT20-284-2	_	_	_	_	_	_	_	_
69NT20-284-3	Χ	_	Χ	_	_	_	Χ	_
69NT40-461-7	_	_	_	Χ	_	_	Χ	_
69NT40-461-8	_	_	_	Χ	_	_	Χ	_
69NT40-464	_	_	Α	_	_	_	Χ	_
69NT40-464-1	_	_	Α	_	_	Χ	Χ	_
69NT40-464-2	_	_	Α	_	_	_	Χ	_
69NT40-464-3	Χ	Χ	Χ	_	Χ	Χ	_	_
69NT40-464-4	Χ	Χ	_	_	Χ	Χ	_	_
69NT40-464-5	_	_	Α	_	_	_	Χ	_
69NT40-464-7	_	_	_	Χ	_	_	Χ	С
69NT40-464-8	_	_	Α	_	_	_	Χ	_
69NT40-464-9	_	_	Α	_	_	_	Χ	С
69NT40-464-10	_	_	_	Χ	_	_	_	_
69NT40-464-12	_	-	Α	-	-	-	_	_
69NT40-464-15	-	-	Α	-	_	-	Χ	_

A - Provision for water-cooled condenser. If water-cooled condenser is added, refrigerant charge will change.

B – Provision for step-up power transformer.
C – Provision for heat exchanger.
X – Designates item provided.

# **DESCRIPTION**

# 1. QUICK LIST -- CLAMPS, FILTER-DRIER, FUSE, TY-RAPS, AND WIRE TERMINALS

34-00373-51P10	Clamp, Tube, 1/4 - SST
34-00373-53P10	Clamp, Tube, 3/8 – SST
34-00373-05P10	Clamp, Tube, 1/2 – SST
34-00373-07P10	Clamp, Tube, 5/8 – SST
34-00373-59P10	Clamp, Tube, 3/4 – SST
34-00373-11P10	Clamp, Tube, 7/8 – SST
34-00373-65P10	Clamp, Tube, 1-1/8 – SST
34-00373-67P10	Clamp, Tube, 1-1/4 – SST
34-00373-69P10	Clamp, Tube, 1-3/8 – SST
34-00373-71P10	Clamp, Tube, 1-1/2 – SST
22-00066-01P25	Connector, Butt End, Wire Range – 22 to 16 Gauge
22-00066-02P25	Connector, Butt End, Wire Range – 16 to 14 Gauge
22-00066-03P25	Connector, Butt End, Wire Range – 12 to 10 Gauge
22-00041-00P25	Connector, Closed End, Wire Range – 22 to 14 Gauge
22-00041-02P25	Connector, Closed End, Wire Range – 18 to 10 Gauge
66U1-7472-1	Filter-Drier
HY10FJ006-P05	Fuse, Glass – 6 amp
22-00060-20P05	Fuse, Glass – 3 amp
22-01140-01P25	Ring Terminal, #6, Wire Range – 12 to 10 Gauge
22-01140-02P25	Ring Terminal, #10, Wire Range – 12 to 10 Gauge
22-01140-04P25	Ring Terminal, 3/8, Wire Range – 12 to 10 Gauge
22-00119-04P25	Ring Terminal, 1/4, Wire Range – 12 to 10 Gauge
22-00120-04P25	Ring Terminal, #10, Wire Range – 16 to 14 Gauge
22-00120-07P25	Ring Terminal, 5/16, Wire Range – 16 to 14 Gauge
22-00121-07P25	Ring Terminal, #10, Wire Range – 22 to 16 Gauge
22-01139-04P25	Ring Terminal, 3/8, Wire Range – 16 to 14 Gauge
22-01141-01P25	Spade Terminal, .032 x .250, Wire Range – 16 to 14 Gauge
22-00595-01P25	Spade Terminal, 3/8, Wire Range – 12 to 10 Gauge
22-01106-00F25	Spiral Wrap, 1/4 inch Diameter x 25 ft Long
22-01107-00F25	Spiral Wrap, 1/2 inch Diameter x 25 ft Long
66U1-3803-P10	Tube, Heat Shrink, 1/4 ID x 2.12 inches Ig
44-01043-05P25	Ty-Raps, 5-1/2 inches Long
44-01043-07P25	Ty-Raps, 11 inches Long
22-50007 Series	Wire Markers


### 2. TOOLS

07-00013	Temperature Tester (Simpson Meter)
07-00013-01	Temperature Test Lead (15 ft)
07-00013-02	Temperature Test Lead (50 ft)
07-00013-03	Adapter, Males (Both Ends) (Use with Temperature Tester)
07-00015	Case, Carrying (For P/N 07-00013)
07-00219	Wrench, Compressor Sight Glass
07-00221	Inspection Light with Mirror
07-00226	Board, Temperature Controller Simulator Module (TCSM)
07-00228	Volt-Ohmmeter, Digital
07-00229	Amprobe Clamp (Used with 07-00228)
07-00237	Gauge Manifold Set

1


### 3. REFRIGERATION UNIT ASSEMBLY

### 3.1 REFRIGERATION UNIT -- FRONT



ITE	M PART NO.	DESCRIPTION	QTY
3.1	REFRIGERATION UNI	T FRONT	
1	_	Panel, Access & Evaporator Fan Motor – Refer to Section 3.7	
2	_	Labels and Decals – Refer to Section 3.18	_
3	66U1-8662	Cap and Chain 69NT20-284	1
4	_	Valve, Thermostatic Expansion (Location) – Refer to Section 3.13	_
5	_	Box, Control – Refer to Sections 3.2 thru 3.4	
6	_	Coil, Condenser – Refer to Section 3.5	_
7	_	Tubing Section – Refer to Section 3.6	
8	_	Receiver, Water-Cooled Condenser – Refer to Section 3.6	_
9	_	Compressor – Refer to Sections 3.16 & 4	_
10	_	Cables, Power – Refer to Section 3.17	_
11	_	Guard, Compressor – Refer to Section 3.16	_
12	69NT40-976	Cover, Makeup Air	1
13	66U1-5362-1	Nut, Wing 1/4-20 – SST	2
14	66U1-5321-7	Washer, Flat, 1/4 – SST	A/R
15	_	Thermometer, Recording – Refer to Section 3.10, 3.11 & 3.12	_
16	_	Condenser Fan Motor & Fan – Refer to Section 3.5	


# 3.2 CONTROL BOX DOOR



ITEM	PART NO.	DESCRIPTION	QTY


### 3.2 CONTROL BOX DOOR 2 1 66U1-6811-10 Screw, Retaining 2 2 34-01226-00 Washer, Retaining Door Assembly 69NT20-284-1,-2 & 69NT40-464-10 - Includes: 1 3 69NT40-818-12 NS 42-01083-00 Gasket 1 4 58-01180-01F50 Seal Rubber (50 ft, Cut to length) A/R 5 69NT35-4574-1 Panel, Switch 1 3 69NT40-818-21 Door Assembly - Includes: 1 NS 42-01083-00 Gasket 1 Seal Rubber (50 ft, Cut to length) 58-01180-01F50 A/R 5 69NT35-4574 Panel, Switch 1 6 69NT35-3413 Label, CB1, CB2 69NT20-284 & 69NT40-464-1,-3,-15 & 69NT40-461-7, -8 1 69NT35-1162 Label, CB1 **69NT40-464-12** (NSI) 1 6 Label, Warning 69NT20-284-1,-2 & 69NT40-464,-2,-5,-8,-15 & 7 69NT35-3164 69NT40-461-7, -8 1 7 69NT35-5644 Label, Warning 69NT20-284 & 69NT40-464-1,-4 1 7 Label, Warning 69NT40-464-3 1 69NT35-5304 7 69NT35-1288 Label, Warning 69NT40-464-12 1 8 Label, Status Indicator 69NT20-284-1,-2 & 69NT40-464,-2,-8 1 69NT35-4733 8 69NT35-6243 Label, Status Indicator 69NT20-284 & 69NT40-464-1,-4 1 8 69NT35-5873 Label, Status Indicator 69NT40-464-3 1 Label, Status Indicator (NSI) 69NT40-464-5,-8,-15 & 69NT40-461-7, -8 8 69NT35-1477 1 Label, Status Indicator (NSI) 69NT40-464-12 8 69NT35-2397 1 9 69NT35-4013 Label, Switch, (RM, MD, ST) 69NT20-284-3 & 69NT40-464,-2,-5,-7,-8,-9,-12,-15 & 69NT40-461-7, -8 1 9 Label, Switch, (RM, MD, ST) 69NT20-284 & 69NT40-464-1,-4 1 69NT35-8583 9 Label, Switch, (MD, ST) (NSI) 69NT40-464-3 69NT35-5893 1 9 Label, Switch, (MD, ST) 69NT20-284-1,-2 & 69NT40-464-10 1 69NT35-4443 10 Receptacle, Remote Monitoring (Plastic) - Optional 22-02341-00 1 66U1-6835 Gasket, Receptacle 1 11 12 22-02341-01 Cap and Chain (RM) 1 Screw, Round Head, #4-40 x 3/4 lg - SST 13 PL4 14 PL Locknut, #4-40 - SST 4 15 10-00221 Switch, Toggle (MDS) 1 2 16 66U1-9752 Seal, Bushing NS 69NT35-4192 Adapter Strip 1 17 10-00237 Switch, Toggle (On-Off) 1 Indicator, Status (4 Light Bar) 18 12-01078-03 1 Indicator, Status (4 Light Bar) 69NT40-464-3 1 18 12-01078-05 2 19 44-01116-00 PL20 Screw, Machine, #10-24 x 1/2 lg - SST 4 21 PLWasher, Lock, #10 - SST 4 22 Ы Washer, Flat, #10 - SST 4 23 34-01167-01 Nut, Double 2 24 Label, Operating Instruction – Refer to Section 3.18 25 69NT35-6022 Label, Controlled Air Temperature 69NT20-284 & 69NT40-464-1,-4 1 25 Label, Controlled Air Temperature (NSI) 69NT35-4002 69NT20-284-1,-2,-3 & 69NT40-464,-2,-5,-7,-8,-9,-15 & 1 69NT40-461-7, -8 25 69NT35-5392 Label, Controlled Air Temperature (NSI) 69NT40-464-3 1 25 Label, Controlled Air Temperature (NSI) 69NT40-464-12 1 69NT35-7312


### 3.3 CONTROL BOX



ITE	M PART NO.	RT NO. DESCRIPTION	
3.3	CONTROL BOX		
1	69NT40-427	Switch Assembly (TDS & TSS) - Includes:	1
NS	NSS	Connector	1
2	10-01142-03	Switch, Push Button (TDS)	1
3	10-01133	Switch, Toggle (TSS)	1
4	69NT35-8453	Label, Switch (TSS,SDS,TDS,DIS) (NSI)	1
4	69NT35-6503	Label, Switch (TSS,SDS,TDS,DIS) (NSI) 69NT40-464-3	1
5	69NT40-983-1	Switch Assembly, Rotary (DIS) 69NT40-464-3 – Includes:	1
5	69NT40-437-1	Switch Assembly, Rotary (DIS) – Includes:	1
6	10-01132-01	Switch, Rotary	1
7	66U1-9522	Knob	1
8	12-01112-00	Switch, Supply Probe - Optional	1
9	69NT35-297-2	Shield, High Voltage 69NT20 – Includes:	1
9	69NT35-297-3	Shield, High Voltage 69NT40 – Includes:	1
10	66U1-3442-2	Stud, 1/4 Turn	2
11	66U1-9212-1	Retainer	2
12	_	Plate Assembly, Schematic & Diagram – Refer to Section 3.18	_
13	34-01142-01	Receptacle	2
14	PL	Rivet, Blind, .125 dia x 0.125 - 0.32 Grip Range – SST	4
15	22-01324-02	Fuse Block	1
16	HY10FJ006	Fuse, 6 amp	2
17	PL	Washer, Lock , #6 - SST	2
18	PL	Screw, Pan Head, #6-32 x 7/16 lg - SST	2
19	10-01161-01	Transformer, Current Limiting (CLT) – Optional	1
20	58-00950-00	Cover, Plastic - Transformer Mounting (For use with CLT)	1
21	PL	Washer, Flat, #8 - SST	4
22	PL	Washer, Lock, #8 - SST	8
23	PL	Screw, Pan Head, #8-32 x 1/2 lg - SST	8
24	PL	Capscrew, Hex Head, 1/4-20 x 3/4 lg - SST	2
25	PL	Nut, Hex, 1/4-20 – SST	1
26	22-02249	Temperature Selector (_F/_C)	1
26	22-02249-01	Temperature Selector (_C)	1
27	PL	Nut, Hex, #8-32 - SST	4
NS	69NT40-417-3	Switch Assembly (For use with digital display) – Optional – Includes:	1
28	10-01133-02	Switch, Scale Selector (SSS)	1
29	10-01146-03	Switch, Set Temperature Display (SDS)	1
NS	22-02306-01	Plug	1
NS	22-02305-00	Contact, Socket	1
30	22-02352-00	Block, Terminal	1
31	10-00237	Switch, Toggle (HCS) – Optional	1
32	69NT20-1912	Label (HCS) – Optional (NSI)	1

### 3.4 CONTROL BOX -- HIGH VOLTAGE SHIELD REMOVED






UNITS WITH ONE-SPEED EVAPORATOR MOTORS

ITEM	PART NO.	DESCRIPTION	QTY
3.4	CONTROL BOX HI	GH VOLTAGE SHIELD REMOVED	
1	12-01059-10	Board, Power Supply and IRS	1
1	12-01059-30	Board, Power Supply and IRS – Remanufactured	1
2	12-01058-10	Board, Timing and Current Control	1
2	12-01058-30	Board, Timing and Current Control – Remanufactured	1
3	12-01085-00	Board, Temperature Control	1
3	12-01085-20	Board, Temperature Control – Remanufactured	1
NS	69NT35-936	Cover Assembly, Printed Circuit Board 69NT40-464-4	1
4	22-00060-20	Fuse, 3 amp	2
5	_	Indicator, Status – Refer to Section 3.2	_
6	10-00304-32	Relay, Condenser Fan Motor and Heater (CF& HR)	1
7	PL	Screw, Hex Head, #10-24 x 1/2 lg - SST	16
8	PL	Washer, Lock, #10 - SST	16
9	66U1-3823	Meter, Hour (Optional)	1
NS	69NT35-5823	Bracket, Hour Meter (NSI)	1
10	66U1-9222	Receptacle	2
11	10-00304-00	Contactor, Compressor (C) 69NT40-464-4	1
11	10-00304-33	Contactor, Compressor (C)	1
12	66U1-6311	Relay, Evaporator Fan Motor (EF & ES)	2
13	10-01149-01	Voltage Switch (3 Station)	1
13	10-01148-01	Voltage Switch (14 Station)	1
14	10-01149-04	Knob (for 3 Station) – Includes:	1
NS	10-01149-04SV	Element, Tightening	1
14	10-01148-04	Knob (for 14 Station) – Includes:	1
NS	10-01148-04SV	Element, Tightening	1
15	66U1-4522-2	Circuit Breaker – 230 vac	1
15	10-00227-00	Circuit Breaker – 230 vac 69NT40-464-15 & 69NT461-7,-8	1
16	PL	Screw, Pan Head, #6-32 x 5/16 lg - SST	4
17	PL	Washer, Lock, #6 – SST	4
18	66U1-1723-3	Circuit Breaker – 460 vac (69NT40)	1
18	66U1-1723-2	Circuit Breaker – 460 vac (69NT20)	1
19	PL	Screw, Pan Head, #6-32 x 7/16 lg - SST	4
20	PL	Screw, Binding Head, 1/4-20 x 5/16 lg - Brass (For Terminals)	6
21	66U1-2353	Transformer, Control (Located behind CB panel)	1
22	10-00237	Switch, Control Limiting – Optional	1
23	12-01087-00	Time Delay (3 Second) – Optional (Located behind digital display)	1
24	12-01073-00SV	Display, Digital Temperature – Optional	1
24	12-01073-20	Display, Digital Temperature – Remanufactured	1
25	69NT40-447	Plug, Harness (For Digital Display) – Includes:	1
26	22-02306-00	Plug (6 position)	1
27	58-01181-02	Standoff (For use with digital display)	4
28	58-01181-03	Standoff (For use with digital display)	4
29	10-00220	Relay	A/R
30	22-02269-11	Board, Main Printed Circuit	1
30	22-02269-31	Board, Main Printed Circuit – Remanufactured	1
31	PL	Screw, Hex Head - Slotted, #8-32 x 3/4 lg - SST	14
32	PL	Washer, Lock #8 - SST	7
33	66U1-9592-3	Standoff	10
34	69NT20-1602	Angle, Status Indicator (NSI)	1
35	69NT20-1612	Shield, Status Indicator (NSI)	1
36	66U1-5162-1	Relay (CR & KR) 69NT40-464-3	2
37	73-00130-00	Clip, Relay (CR & KR) <b>69NT40-464-3</b>	2
38	66U1-5162-1	Socket, Relay (CR & KR) 69NT40-464-3	2
NS	12-01100-00	Time Delay (60 minute) – Defrost Terminator 69NT40-464-3	1
NS	07-50001	Humiseal, 12 oz.	A/R
NS	07-50003-01	Lubricant, Contact	A/R


### 3.5 CONDENSER FAN MOTOR AND COIL SECTION




### 3.5 CONDENSER FAN MOTOR AND COIL SECTION

69NT42-244	Cover, Condenser Coil	1
PL	Screw, Hex Head, #10-24 x 1/2 lg - SST	A/R
	Washer, Flat, #10 – SST	A/R
	Washer, Fender, .063 Thick – SST (NSI)	A/R
PL	Washer, Lock, #10 – SST	A/R
	Coil, Condenser – Copper (Includes Mylar washers and protectors)	1
		11
		11
		A/R
		A/R
		A/R
		1
		1
		es) 2
	Protector, Mylar (Apply to center between frame & coil & coil cover)	2
		2
		1
58-04026-10		2
58-04026-11	Protector, Mylar (Apply between coil mounting & frame LH side)	1
69NT40-847-2		1
		1
		1
69NT40-837-1		1
		4 2
		2
		4
		1
		1
		1
		2
		1
		1
		1
		1
		1
		4
		8
		4
		2
		2 2
		2
34-01150-31	Receptacle	2
	PL PL 69NT35-2692 PL 69NT42-108-SV 66U1-5361-25 66U1-5321-7 58-50013-02 58-50013-04 34-06053-05 58-04026-00 58-04026-03 58-04026-04 58-04026-08 58-04026-09 58-04026-10 58-04026-11 69NT40-847-2 69NT35-7944	PL PL Washer, Flat, #10 – SST  69NT35-2692 PL Washer, Fender, .063 Thick – SST (NSI) Washer, Lock, #10 – SST  69NT42-108-SV Coil, Condenser – Copper (Includes Mylar washers and protectors) Capscrew, Hex Head, 1/4-20 x 3/4 lg – SST (NSI) Washer, Lock, #10 – SST  66U1-5321-7 S8-50013-02 Washer, Mylar, 1/4 lD x 3/4 OD S8-50013-04 Washer, Mylar, 1/4 lD x 1.00 OD 34-06053-05 Washer, Mylar, 13/64 lD x 39/64 OD S8-04026-00 Protector, Mylar (Apply between coil mounting & frame RH side) Protector, Mylar (Apply between coil mounting & frame, RH side) Protector, Mylar (Apply to top side center coil mounting) S8-04026-04 Protector, Mylar (Apply to top side center coil mounting) Protector, Mylar (Apply to top side of coil bracket, RH & LH side) Protector, Mylar (Apply between coil mounting & frame, RH & LH side) Protector, Mylar (Apply between coil bracket, RH & LH sides) Protector, Mylar (Apply between coil bracket, RH & LH sides) Protector, Mylar (Apply between coil wounting & frame LH side) Grille, Condenser 69NT40-464-3,-7,-9,-10 & 69NT40-461-7,-8 Grille, Condenser Fan (For 16-00 diameter Fan) Venturi, Condenser Fan (For 17-1/2 diameter Fan) Venturi, Condenser Fan Grille Rivet, Blind, 5/32 Diameter, Grip Range – 1/8-1/4 – SST Hinge, Condenser (16-00 diameter) – SST – Includes: Set Screw, Square Head, 5/16-24 x 5/8 lg – SST Motor, Condenser Fan (NLO) – Includes: Set Screw, Square Head, 5/16-18 x 1.25 – SST Washer, Hill, Screw, Square Read, 5/16-18 x 1.25 – SST Washer, Hill, Screw, Square Read, 5/16-18 x 1.25 – SST Washer, Hill, Screw, Square Read, 5/16-18 x 1.25 – SST Washer, Hill, Screw, Square Read, 5/16-18 x 1.25 – SST Washer, Hill, Screw, Square Read, 5/16-18 x 1.25 – SST Washer, Retaining Washer, Retaining Washer, Retaining

### 3.6 WATER-COOLED CONDENSER/RECEIVER AND TUBING SECTION






**UNITS WITH RECEIVER** 

### 3.6 WATER-COOLED CONDENSER/RECEIVER AND TUBING SECTION


NS	69NT42-914	Kit, Condenser/Receiver (Optional Field Installed) – Includes:	A/R
1	69NT42-914-1	Condenser/Receiver – Includes:	1
2	14-00111	Sight Glass – Includes:	1
3	NSS	Ball, Float	1
4	58-00956-00	Protector, Condenser/Receiver Bracket Protector, Coupling Bracket Coupling (Water-In)	2
5	58-00957-00		1
6	66U1-2763-5		1
7	66U2-1142	Cap, Dust	A/R
8	40-01129	Coupling, Self Draining – Includes:	1
9	42-50000	O-Ring Seal	1
10	66U2-1152	Cap, Dust	1
11	12-01071-01SV	Switch, Water Pressure – Optional	1
12	66U1-5361-7	Bolt, Hex Head, 3/8-16 x 1.00 lg – SST (NSI)	1
13	66U1-5321-5	Washer, Flat, 3/8 – SST (NSI)	1
14	AU11JR241	Washer, Lock, 3/8 – SST	1
15	58-50013-00	Washer, Mylar, 3/8 ID x 1.00 OD	1
16	66U1-5361-25	Capscrew, Hex Head, 1/4-20 x 3/4 lg – SST (NSI)	A/R
17	66U1-5321-7	Washer, Lock, 1/4 – SST	A/R
18	58-04026-05	Protector	1
19	69NT40-937	Receiver (Optional) – Painted Steel	1
19	69NT40-977-1	Receiver (Optional) – SST	1
20	12-01072-01SV	Sensor, Supply Temperature (STS)	1
21	14-00195-00	Valve, High Side Pressure Relief	1
NS	14-00195-03	Valve, High Side Pressure Relief <b>69NT40-461-7</b>	1
NS	-	Valve, Low Side Pressure Relief – Refer to Section 3.16	-
22	-	Valve, Modulating Solenoid – Refer to Section 3.15 Valve, Suction Solenoid – Refer to Section 3.14 Valve, Quench (Solenoid)	-
23	-		-
24	14-01090-01		1
25	14-00189-00	Valve, Quench (Thermostatic Expansion) Coil, Solenoid Screw, (Special), Coil Hold Down	1
26	14-01091-01		1
NS	34-50012-00		1
27	66U1-8552	Valve, Liquid Line – Includes:	1
28	40-00086-04	Cap, Flare – 1/4	1
29	17-21002-01	Cap, Valve	1
30	14-00202-00	Indicator, Moisture – Liquid (Brass) Filter-Drier 69NT40-464-3 – Includes: Gasket, Filter-Drier 69NT40-464-3	1
31	14-01103-00SV		1
NS	42-01097-00		2
31	66U1-7472-1	Filter-Drier	1
NS	66U1-2552-133	Gasket (Use between Filter-Drier and container wall)	A/R
32	69NP20-1031	Clamp, Filter-Drier – Includes:	1
NS	58-50014-00F16	Gasket, Clamp (16 FT, cut to length)	A/R
33	66U1-5361-25	Screw, Hex Head, 1/4-20 x 3/4 lg – SST (NSI)	2
34	34-06053-03	Washer, Mylar, 1/4 lD x 1.00 OD	2

### 3.7 EVAPORATOR FAN MOTOR AND ACCESS PANEL SECTION




ITEM	PART NO.	DESCRIPTION	QTY
3.7 I	EVAPORATOR FAN M	OTOR AND ACCESS PANEL SECTION	
1	69NT40-908-1	Panel, Access – Includes:	2
2	42-01082	Gasket	1
3	66U1-8115-F20	Gasket, Access Panel Seal - Adhesive Back, Pressure Sensitive,	
		4 x 1/2 thick (20 ft, Cut to size)	A/R
4	AA06JA170	Capscrew, Hex Head, 1/4-20 x 1.00 lg - SST	24
5	AN96OC416	Washer, Flat, 1/4 – SST	24
6	58-50013-03	Washer, Mylar, 1/4 ID X 1/2 OD	24
7	69NT41-308	Panel, Access 69NT40-464-3 – Includes:	1
7	69NT40-898-1	Panel, Access – Includes:	1
8	42-01081	Gasket	1
9	69NT35-1173	Bracket, Motor Mount (69NT40)	2
9	69NT20-1033	Bracket, Motor Mount (69NT20)	2
10	34-00933-12	Capscrew, Hex Head, 5/16-18 x 1-1/2 lg - SST (NSI)	4
11	34-01181-01	Washer, Flat, 5/16 - SST (NSI)	8
12	34-00667-12	Locknut, 5/16-18 - SST (NSI)	4
13	54-00513-00	Motor, Evaporator Fan (Two-Speed) – Includes:	2
14	34-00672	Key, 3/16 x 3/16 x 1-1/4 lg – SST	2
NS	22-50071-00	Capacitor	1
13	54-00507-00	Motor, Evaporator Fan (One-Speed) – Includes:	2
14	34-00672	Key, 3/16 x 3/16 x 1-1/4 lg – SST	2
NS	22-50072-00	Capacitor	1
15	38-00121	Fan, Evaporator (EFM-1) <b>(69NT20)</b> – Includes:	1
15	38-00126	Fan, Evaporator (EFM-1) <b>(69NT40)</b> – Includes:	1
15	38-00122	Fan, Evaporator (EFM-2) <b>(69NT20)</b> – Includes:	1
15	38-00125	Fan, Evaporator (EFM-2) <b>(69NT40)</b> – Includes:	1
NS	PL	Setscrews, 5/16-24 x 5/8 lg - SST	2
16	66U1-5361-7	Bolt, Hex Head, 3/8-16 x 1.00 lg - SST (NSI)	8
17	66U1-5321-5	Washer, Flat, 3/8 - SST (NSI)	8
18	AU11JR241	Washer, Lock, 3/8 – SST	8

### 3.8 EVAPORATOR COIL SECTION -- REAR PANELS REMOVED



1	12-01134-00	Switch, Defrost Air Pressure 69NT20-284 & 69NT40-464-1,-4	1
2	12-01062-01	Thermostat, Suction Solenoid (69NT40)	1
3	12-01072-01SV	Sensor, Thermistor (RTS)	1
NS	_	Sensor, Thermistor – Temp. Recorder (Refer to Section 3.10, 3.11 or 3.12	) –
4	66U1-6912-8	Thermostat, Defrost, 75_F (24_C)	1
5	PL	Capscrew, Hex Head, #8-32 x 1/2 lg - SST	4
6	PL	Washer, Lock, #8 – SST	4
7	66U1-6912-7	Thermostat, High Temperature, 130_F (54_C)	1
8	66U1-2683-4	Heater	4
NS	69NT35-6532	Clip, Heater	4
8	24-00006-00	Heater 69NT40-464-3	6
NS	69NT35-6852	Clip, Heater 69NT40-464-3	6
9	24-00003	Heater, Drain Pan (69NT40-464-3 quantity is 2)	1
10	12-01063-02	Thermostat, Safety Overide (Location) 69NT40-464-3	1
11	69NT42-968-1*	Coil, Evaporator (69NT40)	1
NS	69NT35-6522	Retainer (69NT40) 4 heater	1
NS	69NT35-6842	Retainer (69NT40) 6 heater	1
11	69NT21-234-1*	Coil, Evaporator (69NT20)	1
NS	69NT20-2032	Retainer (69NT20)	1
12	PL	Capscrew, Hex Head, 1/4-20 x 3/4 lg - SST	9
13	PL	Washer, Lock, 1/4 – SST	9
14	PL	Screw, Lag, 1/4-10 x 2.00 lg	6
15	PL	Washer, Flat, 1/4	6
16	PL	Capscrew, Hex Head, 1/4-20 x 1/2 lg - SST	1
17	34-06053-00	Washer, Mylar, 1/4 ID x 0.80 OD	A/R
18	PL	Capscrew, Hex Head, 1/4-20 x 1-1/4 lg - SST	4
19	PL	Washer, Fender, 1/4 x 5/8 thick – SST	4
NS	12-01066	Sensor, Humidity – Optional	1
NS	58-00616-00	Plug, Hole, Nylon – Black (For 2.00 Dia. hole located on fan deck)	A/R
* Note:	Does not include ther	mostats or heaters.	


### 3.9 EVAPORATOR COIL SECTION -- REAR PANELS ATTACHED



### **UNITS WITH HINGED PANELS**

1	69NT20-218	Grille, Top (69NT20)	1
1	69NT40-614	Grille, Top (69NT40)	1
2	66U1-6832-1	Rivet, Blind, 5/16 Diameter, Grip Range – 1/8-1/4 (NSI)	A/R
3	34-01150-31	Receptacle, Retaining (For 1/4 Turn Stud)	15
4	69NT40-578-1	Panel Assembly, Upper, (SST) 69NT20-284-3 – Includes:	1
NS	NSS	Drain Pan, Center	1
NS	NSS	Drain Pan, Side	2
4	69NT41-488	Panel Assembly, Upper 69NT40-464-3 – Includes:	1
NS	NSS	Drain Pan, Center	1
NS	NSS	Drain Pan, Side	2 4
5	69NT35-3282	Hinge	4
9	34-01150-04	Stud, 1/4 Turn, 31/32 lg, Grip Range – 9/64-13/64	15
10	34-01150-30	Washer, Retaining	15
4	69NT40-634	Panel Assembly, Upper 69NT40-464-4 – Includes:	1
NS	NSS	Drain Pan, Center	1
NS	NSS	Drain Pan, Side	2
5	69NT35-3282	Hinge	4
6	66U1-6832-6	Rivet, Blind, 1/4 Diameter, Grip Range – 1/8-3/16 (NSI)	A/R
7	66U1-6832-3	Rivet, Blind, 1/4 Diameter, Grip Range – 3/16-1/4 (NSI)	A/R
8	69NT35-3494	Panel, Bottom - SST	1
8	69NT35-3014	Panel, Bottom 69NT40-464-4	1
9	34-01150-04	Stud, 1/4 Turn, 31/32 lg, Grip Range – 9/64-13/64	14
10	34-01150-30	Washer, Retaining	15
11	34-01150-06	Stud, 1/4 Turn, 1.03 lg, Grip Range – 13/64-17/64	1
NS	66U1-8075-F25	Gasket (25 ft, Cut to length)	A/R


### 3.9 EVAPORATOR COIL SECTION -- REAR PANELS ATTACHED (CONTINUED)



### **UNITS WITH BOLTED PANELS**

20 20 20	69NT20-218 69NT40-614 69NT21-144	Grille, Top <b>(69NT20)</b> Grille, Top <b>(69NT40)</b> Grille, Top <b>69NT20-284-1</b>	1 1 1
21	66U1-6832-1	Rivet, Blind, 5/16 Diameter, Grip Range – 1/8-1/4 (NSI)	A/R
22	66U1-6832-6	Rivet, Blind, 1/4 Diameter, Grip Range – 1/8-3/16 (NSI)	A/R
23	66U1-6832-3	Rivet, Blind, 1/4 Diameter, Grip Range – 3/16-1/4 (NSI)	A/R
24	66U1-2403	Screw, Machine, Truss Head, #10-24 x 1/2 lg - SST (NSI)	19
25	69NT35-2692	Washer, Fender, #10 x 1.00 OD - SST (NSI)	19
26	69NT40-624-1	Panel Assembly, Upper – Includes:	1
NS	NSS	Drain Pan	1
26	69NT40-624-4	Panel Assembly, Upper 69NT20-284-1 – Includes:	1
NS	NSS	Drain Pan, Side	2
NS	NSS	Drain Pan, Center	1
27	69NT35-3014	Panel, Bottom	1
27	69NT35-3014-1	Panel, Bottom (NSI) <b>69NT40-464-5</b>	1
27	69NT20-3544	Panel, Bottom 69NT20-284-1	1
28	69NT21-174	Panel Assembly, Evaporator Coil 69NT20-284-1	1
29	69NT20-922	Spacer Assy (Evaporator coil panel to upper panel) (NSI) 69NT2	<b>0-284-1</b> 1
30	66U1-5371-7	Screw, Hex Head, #10-24 x 1/2 lg - SST 69NT20-284-1 (NSI)	7
31	66U1-5321-8	Washer, Flat, #10 - SST <b>69NT20-284-1</b> (NSI)	7
32	69NT35-5843	Cover, Sensor Port 69NT40-464-5	1
NS	66U1-8075-F25	Gasket (25 ft, Cut to length)	A/R


### 3.9 EVAPORATOR COIL SECTION -- REAR PANELS ATTACHED (CONTINUED)



### **UNITS WITH BOLTED PANELS**


40	69NT40-614	Grille, Top	1
41	66U1-6832-1	Rivet, Blind, 5/16 Diameter, Grip Range – 1/8-1/4 (NSI)	A/R
42	69NT40-624-4	Panel Assembly, Upper – Includes:	1
NS	NSS	Drain Pan, Side	2
NS	NSS	Drain Pan, Center	1
43	69NT35-9744-3	Panel, Bottom (Provision for heat exchanger) 69NT40-464-7,-8	,-10,-12 &
		69NT40-461-7,-8	1
43	69NT35-9744-5	Panel, Bottom (USDA sensor port) 69NT40-464-5,-9,-15	1
44	69NT35-9744-2	Panel, Bottom (Provision for heat exchanger) 69NT40-464-7,-8	,-10,-12 &
		69NT40-461-7,-8	1
44	69NT35-9744-4	Panel, Bottom (USDA sensor port) 69NT40-464-5,-9,-15	1
45	69NT35-5843	Cover, Sensor Port <b>69NT40-464-5,-9,-15</b>	1
46	66U1-2403	Screw, Machine, Truss Head, #10-24 x 1/2 lg - SST (NSI)	19
47	69NT35-2692	Washer, Fender, #10 x 1.00 OD - SST (NSI)	19
48	66U1-6832-6	Rivet, Blind, 1/4 Diameter, Grip Range – 1/8-3/16 (NSI)	A/R
49	66U1-6832-3	Rivet, Blind, 1/4 Diameter, Grip Range – 3/16-1/4 (NSI)	A/R
NS	66U1-8075-F25	Gasket (25 ft, Cut to length)	A/R

# 3.10 RECORDING THERMOMETER (PARTLOW)




_	12-01076-00	Recording Thermometer (NSI) – Includes:	_
1	09-00265-00	Cover Assembly (Bottom Latch) – Includes:	1
NS	09-00100-01	Seal, Cover – Rubber	1
NS	09-00100-02	Gasket, Cover Glass	1
2	09-00101	Glass, Cover	1
NS	09-00102	Catch Assembly, Cover	2
3	09-00104-05	Stylus Kit – Includes:	1
4	NSS	Screw, Round Head, #2-56 x 3/16 lg	2
4 5	09-00147	Mechanism Assembly	1
6	09-00112	Push Rod (Includes Setscrews)	1
7	09-00115	Clip, Key Mounting	1
8 9	09-00114	Key, Clock Winding	1
9	09-00119	Nut and Chain, Chart (Sonceboz Clock)	1
9	09-00180-00	Nut and Chain, Chart (Gluck Clock)	1
10	PL	Screw, Round Head #6-32 x 5/16	7
11	09-00116	Platen, Chart	1
12	09-00118	Flange, Chart Drive <b>(Sonceboz)</b>	1
12	09-00180-01	Flange, Chart Drive <b>(Gluck)</b>	1
13	09-00123	Clock, 31 Day, CCW (Counterclockwise)	1
14	09-00132	Stand, Mounting, Chart Drive (NSI)	1
15	09-00267-00	Case (Top Hinge)	1
16	09-00137	O-Ring, Element Flange	4
17	09-00209	Element, 9 ft lg – Includes:	1
NS	09-00222	Sensor, Thermistor (Accessory 344 and Jack) – 15 ft lg	1
NS	22-02243	Pin (Use with Partlow Thermister Assembly)	3
18	09-00136	Screw, Flange (NSI)	2
NS	09-00128	Charts _F - 31 Day (Box of 50) (-20_F to +80_F)	A/R
NS	09-00128-01	Charts _C - 31 Day (Box of 50) (-25_C to +25_C)	A/R

### 3.11 RECORDING THERMOMETER (SAGINOMIYA)




		2 1 21	
_	12-01094-00	Recording Thermometer – Includes:	_
1	09-00324-00	Stylus, Lift Arm	1
2	09-00320-00	Element Assembly (9 ft.) (2.74 M)	1
3	09-00321-00	Voltage Indicator	1
4	PL	Battery (Mallory R14P/S 1.5 vdc)	1
5	09-00326-00	Shaft, Chart	1
6	09-00329-00	Block, Terminal (NSI)	1
7	09-00322-00	Timer (31 Day)	1
NS	09-00323-00	Plate, Recorder	1
NS	09-00325-00	Nut, Chart (Male)	1
8	69NT40-402-1	Sensor Assembly, Return Temperature – Includes:	1
NS	12-01095-00	Sensor, Thermistor	1
9	22-02370-00	Jack, Phono	1
10	69NT41-754-1	Box Assembly (NSI)	1
11	42-01098-00	Gasket, Door	1
12	69NT41-844	Door Assembly	1
13	66U1-6811-10	Retaining Screw	2
NS	34-01226-00	Washer, Retaining	2 2
14	34-01142-01	Receptacle	2
15	PL	Window, Lexan (8.37 x 10 x .12 inches thick)(212 x 254 x 3 mm)	1
16	PL	Gasket, Window	1
17	69NT35-9343	Bracket, Window Mounting (NSI)	1
18	69NT35-5492	Plate, Window Mounting	2
19	PL	Nut, Hex Head, #10-32 - SST	4
20	PL	Washer, Lock, #10 - SST	4
21	69NT40-392	Hinge Assembly	2
NS	09-00128-01	Charts _C - 31 Day (Box of 50) (-25_C to +25_C)	A/R
NS	09-00128	Charts $_{F}$ - 31 Day (Box of 50) (-20 $_{F}$ to +80 $_{F}$ )	A/R

### 3.12 RECORDING THERMOMETER (FUJI KIKI)




- 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	12-01099-00 09-00350-00 09-00351-00 09-00355-00 PL 09-00352-00 09-00353-00 09-00356-00 09-00358-00 09-00357-00 69NT41-398-1 42-01098-00 69NT41-378 69NT35-5492 66U1-6811-10 34-01226-00 PL PL 69NT35-5412	Recording Thermometer (NSI) – Includes: Printed Circuit Board Servo Assembly Stylus Assembly Battery (Mallory R14P/S 1.5 vdc) Clock, Quartz Fuse (2 amp) Transformer Nut, Chart Sensor, Thermistor (RRS) Sensor, Thermistor (SRS) Box Assembly (NSI) Gasket, Door Door Assembly Plate Assembly Retaining Screw Washer, Retaining Window, Lexan (8.37 x 11.88 x .12 inches thick) (212 x 301.75 x 3 mm) Gasket, Window Angle, Window Mounting (NSI)	- 1 1 1 1 1 1 1 1 1 1 1 2 2
20	69NT40-392	Angle, Window Mounting (NSI) Hinge Assembly	2 2 2
21	34-01142-01	Receptacle	
NS	09-00128-01	Charts _C - 31 Day (Box of 50) (-25_C to +25_C)	A/R
NS NC	09-00128	Charts _F = 31 Day (Box of 50) (=20_F to +80_F)	A/R
NS	69NT40-562	Cable Assembly (Recorder to Main Printed Circuit Board) (NSI)	ı


# 3.13 THERMOSTATIC EXPANSION VALVE -- Alco



1	14-01104-02	Kit, Repair <b>(69NT20)</b> – Includes:	1
1	14-01104-03	Kit, Repair <b>(69NT40)</b> – Includes:	1
2	NSS	Power Head Assembly and Gasket, Item 5	1
3	NSS	Cage Assembly and Gasket, Item 6	1
4	66U1-6225	Gasket Set, Universal – Includes:	1
5	NSS	Gasket, Body Flange A625-4A	2
6	NSS	Gasket, Seat – A625-2A	1
7	66U1-1214-13	Flange, Body (NSI)	1

# 3.14 SUCTION SOLENOID VALVE (69NT40 ONLY)






<u>SPORLAN</u> <u>ALCO</u>

1	14-01083	Solenoid Valve, Suction – Includes:	1
2	14-50010	Coil	1
3	NSS	Tube, Enclosing	1
4	14-50011	Kit, Repair – Includes:	1
5	NSS	Gasket	1
6	NSS	Stem and Plunger Assembly	1
7	NSS	Disc, Seat	1
8	34-50012-00	Screw (Special), Coil Hold Down	1
9	14-00192-00	Solenoid Valve, Suction – Includes:	1
10	17-40408-02	Cap, Snap	1
11	14-50027-00	Coil	1
12	14-50025-00	Kit, Repair	1
13	14-50026-00	Kit, Repair Diaphragm	1


# 3.15 MODULATING SOLENOID VALVE



1	14-50021-01	Kit, Enclosing Tube & Coil Housing – Includes:	1
2	14-50021-03	Nut, Coil – Includes:	1
3	NSS	Nut, Coil	1
4	NSS	O-Ring, Coil Nut	1
5	14-50021-04	Housing, Coil – Includes:	1
6	NSS	Housing, Coil	1
*7	NSS	Plate, Coil Bottom	1
8	NSS	O-Ring, Coil Bottom Plate	1
9	NSS	Sleeve, Solenoid Coil	1
10	NSS	Tube Assembly, Coil Plate & Enclosing	1
11	14-01100-01	Valve, Modulating Solenoid – Includes:	1
12	14-50021-02	Coil, Solenoid – Includes:	1
9	NSS	Sleeve, Solenoid Coil	1


<sup>\* –</sup> Item 7, Coil Bottom Plate is only supplied in Kit 14-50021-04 as a separate item for use on early style Enclosing Tube Assemblies.

### 3.16 COMPRESSOR MOUNTING AND GAUGES



### **COMPRESSOR FOOT CUTAWAY VIEW**

### **CENTER CYLINDER HEAD VIEW**




**UNIT SECTIONAL VIEW** 

### 3.16 COMPRESSOR MOUNTING AND GAUGES

1 2	- 14-01093-00	Compressor – Refer to Section 4 Snubber Assembly	- 1
3	66U1-6942-4	Switch, High Pressure	1
3	66U1-6942-6	Switch, High Pressure (Use with 41 CFM Compressor)	1
4 5	69NT41-543	Tube Assembly, High Pressure Tube Assembly, Low Pressure  Used with pressure	1 1
5 5	69NT41-303-2 69NT41-553		1
6	69NT40-942	Stiffener Assembly	1
NS	0910140-942 PL	Screw, Hex Head, #10-24 x 3/4 lg - SST \ Used to mount	2
NS	PL	Washer, Flat, #10 – SST stiffener assembly	2
7	69NT40-912	Bracket Assembly, Gauge – Optional	1
8	12-01124-00	Gauge, Suction Pressure – Optional	1
9	12-01125-01	Gauge, Discharge Pressure – Optional	1
10	CA21JA051	Tee 1/4 NPT (NSI)	1
11	06DA403-844	Valve Assembly, Core, Check – Brass Used with pressure gauges	2
12	14-00195-02	Valve, Low Side Pressure Relief	1
NS	-	Valve, High Side Pressure Relief – Refer to Section 3.6	
13	40-00249-01	Tee, Male, 1/4 fpt x 1/4 fpt x 1/4 mpt – Brass (NSI)	1
14	69NT35-6132	Protector (Compressor to Compressor Base)	1
15	PL	Washer, Lock, 3/8 – SST	
16	PL	Capscrew, Hex Head, 3/8-16 x 1-1/4 lg - SST	2 2
17	69NT43-108	Base, Compressor	1
NS	66U1-5361-7	Bolt, Hex Head, 3/8-16 x 1.00 lg - SST (NSI) Used to mount	7
NS	66U1-5321-5	Washer, Flat, 3/8 – SST (NSI) compressor base	7
NS	AU11JR241	Washer, Lock, 3/8 – SST to unit frame	7
NS	58-50013-00	Washer, Mylar, 1/2 ID x 1.00 OD	7
18	PL	Capscrew, 7/16-14 x 2-3/4 lg - SST	2
19	PL	Locknut, 7/16-14 - SST	2
20	PL	Washer, Flat, 7/16 - SST	4
21	58-50013-01	Washer, Mylar, 1/2 ID x 1-1/8 OD	2
22	69NT35-3573	Panel, Guard 69NT20-284-1, -2 & 69NT40-464-1, -2, -5, -8,-12,-15 &	
		69NT40-461-7,-8 (NSI)	1
23	PL	Screw, Hex Head, #10-24 x 3/4 lg - SST	1
24	PL	Washer, Flat, #10 – SST	1
25	PL	Bolt, Hex Head, 5/16-18 x 1.00 lg - SST	1
26	PL	Washer, Flat, 5/16-18 – SST	1
27	PL	Capscrew, Hex Head, 1/4-20 x 1-1/2 lg — SST	A/R
28	PL	Locknut, 1/4-20 – SST	A/R
29	66U1-5321-7	Washer, Flat, 1/4 – SST	A/R
30	69NT35-3104-1	Guard, Compressor	1

### 3.17 VOLTAGE OPTION AND POWER TRANSFORMER



ITEN	M PART NO.	DESCRIPTION	QTY
3.17	VOLTAGE OPTION AN	D POWER TRANSFORMER	
1 2	58-01214-00 58-01213-00	Plug, Hole, Dupont Zytel – Black (For 3/8 to 13/32 diameter hole) Plug, Hole, Nylon – Black (For 1/4 diameter hole in doghouse wall)	A/R A/R
3	69NT35-3253-SV	Cover, Voltage Selector Switch – Includes:	1
4	66U1-2803	Hinge (Cut to length)	1
5	66U1-9102-2	Rivet	3
6	PL	Screw, #10 Phillips	4
7	69NT35-6153	Partition Assembly, Right Hand (NSI) 69NT20-284 & 69NT40-464-4	1
8	66U1-9782	Cable, Power (460 vac Extra Heavy Duty Yellow) (NSI)	1
8	66U1-9782-1	Cable, Power (460 vac Extra Heavy Duty Black) (NSI)	
		69NT40-464-12,-15 & 69NT40-461-7	1
8	66U1-5951	Cable, Power (460 vac Heavy Duty Black) (NSI)	1
9	76-00390	Plug, Power <b>(460 vac) 69NT40-464-3</b>	1
9	22-02378-00	Plug, Power (460 vac) - MENNEKES	1
NS	22-02324-01	Bushing (for P/N 22-02378-00) (NSI)	4
10	69NT20-533	Partition Assembly, Left Hand (NSI) 69NT20-284 & 69NT40-464-4	1
11	66U1-6772	Cable, Power (230 vac) (NSI)	1
12	22-02375-00	Plug, Power <b>(230 vac) 69NT40-464-3</b>	1
12	22-02322	Plug, Power <b>(230 vac)</b> (NSI) <b>69NT20-284 &amp; 69NT40-464-1,-4</b>	1
13	76-00365-01	Transformer, Power - Optional	1
4.4	/ONITOE 777	December Assessed to Transferment (NICI) (ONITIO OOA O (ONITIO ACA O A	4

Washer, Flat, 5/16 - SST (NSI)

Bracket Assembly, Transformer (NSI) 69NT20-284 & 69NT40-464-3,-4

Locknut, Hex Head, 5/16-18 – SST (NSI) Used to mount trans-

1

4

4

former bracket assembly

14

15


16

69NT35-777


34-00667-12

34-01181-01

### 3.18 LABELS AND DECALS



ITE	M PART NO.	DESCRIPTION	QTY
3.18	LABELS AND DECALS		
1	62-02531-00	Decal, Carrier Transicold	1
1	62-03642-00	Decal, Carrier Transicold <b>69NT40-464-3</b>	1
2	66U1-8912	Label, Direction Arrow	1
3	69NT35-3164	Label, Fan Warning 69NT20-284-1,-2 & 69NT40-464,-2,-8,-15 &	•
ū	0,11100 0101	69NT40-461-7,-8	1
3	69NT35-5644	Label, Fan Warning 69NT20-284 & 69NT40-464-1	1
3	69NT35-1288	Label, Fan Warning (NSI) <b>69NT40-464-12</b>	1
4	69NT35-5524	Label, Operating Instruction (NSI)	
		69NT20-284-3 & 69NT40-464,-2,-5,-7,-8,-9,-15 & 69NT40-461-7,-8	1
4	69NT35-8404	Label, Operating Instruction (NSI) 69NT20-284 & 69NT40-464-1,-4	1
4	69NT35-5834	Label, Operating Instruction 69NT40-464-3	1
4	69NT35-9024	Label, Operating Instruction (NSI) 69NT20-284-1,-2 & 69NT40-464-10	1
4	69NT35-1278	Label, Operating Instruction (NSI) 69NT40-464-12	1
5	69NT35-8143	Label, Voltage Selector (VS) (NSI) 69NT20-284-3 &	
		69NT40-464,-2,-5,-7,-8,-9,-15 & 69NT40-461-7,-8	1
5	69NT35-6253	Label, Voltage Selector (VS) (NSI) 69NT20-284 & 69NT40-464-1,-4	1
5	69NT35-5853	Label, Voltage Selector (VS) 69NT40-464-3	1
6	66U1-7471	Label, Charge with R-12	1
7	69NT35-3842	Label, Compressor-Frost	1
7	69NT35-5402	Label, Compressor – Frost 69NT40-464-3	1
7	69NT35-3842-4	Label, Compressor – Frost 69NT40-464-4	1
8	66CH1-1002-33	Label, Arrow (NSI)	1
9	69NT35-5323	Label, Air Exchange (NSI) 69NT20-284-1,-2, -3 &	
•	(01)705 (0/0	69NT40-464,-2,-5,-7,-8,-9,-10,-15 & 69NT40-461-7,-8	1
9	69NT35-6263	Label, Air Exchange (NSI) 69NT20-284 & 69NT40-464-1,-4	1
9	69NT35-5883	Label, Air Exchange (NSI) 69NT40-464-3	1
9	69NT35-2387	Label, Air Exchange (NSI) 69NT40-464-12	1
10	69NT35-5314	Label, Warning 69NT40-464-3 (NSI)	1
10	69NT35-4773	Label, Warning (NSI)	1
NS	69NT20-373-103	Plate Assembly, Schematic & Diagram (NSI) 69NT20-284	1
NS	69NT20-373-100	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464	1 1
NS	69NT20-373-102	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-1	1
NS NS	69NT20-373-107 69NT20-373-108	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-2 Plate Assembly, Schematic & Diagram (NSI)	ļ
NS	0911120-373-100	(Units with S/N 90105284 thru 90105383) 69NT40-464-8	1
NS	69NT20-373-111	Plate Assembly, Schematic & Diagram (NSI)	ı
NO	0411120-373-111	(Units starting with S/N 90105384) 69NT40-464-8	1
NS	69NT20-373-112	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-3	1
NS	69NT20-373-112	Plate Assembly, Schematic & Diagram (NSI) 69NT20-284-1,-2	1
NS	69NT20-373-116	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-4	1
NS	69NT20-373-117	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-5	1
NS	69NT20-373-126	Plate Assembly, Schematic & Diagram (NSI) 69NT20-284-3	1
NS	69NT20-373-130	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-9,-15	1
NS	69NT20-373-131	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-10	1
NS	69NT20-373-132	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-7 &	-
		69NT40-461-7,-8	1
NS	69NT20-373-139	Plate Assembly, Schematic & Diagram (NSI) 69NT40-464-12	1




ITEM	PART NO.	DESCRIPTION	QTY
4.1 S	SERVICE REPLACEME	ENT COMPRESSOR	
1 1 1 1 1 1 1	18-00043-08 18-00043-09 18-00043-16 18-00043-06 18-00043-07 18-00043-19 18-00048-21	Compressor, 28 CFM, 460 vac/3 ph/60 hz 69NT20-284,-1,-2 Compressor, 28 CFM, 230/460 vac/3 ph/60 hz 69NT40-284-3 Compressor, 37 CFM, 460 vac/3 ph/60 hz 69NT40-464-3 Compressor, 37 CFM, 460 vac/3 ph/60 hz 69NT40-464-4,-12 Compressor, 37 CFM, 230/460 vac/3 ph/60 hz 69NT40-464,-1,-2,-5,-8, Compressor, 41 CFM, 460 vac/3 ph/60 hz 69NT40-464-10 Compressor, 41 CFM, 230/460 vac/3 ph/60 hz 69NT40-464-7,-9 Compressor, 41 CFM, 230/460 vac/3 ph/60 hz 69NT40-461-7,-8	1 1 1 1 -151 1 1
4.2 T	ERMINAL MOUNTING	S AND JUNCTION BOX GROUP	
2 3 4 5 2 5 2 6 7 7 8 NS NS	69NT20-2083 PL PL 69NT20-513-SV 69NT20-2083 69NT20-2083 PL 17-40093-02 17-40093-01 76-00355 76-00384 17-40075-05 34-06053-05	Cover, Junction Box Screw, Hex Head, #10-24 x 1/2 lg (Cover to box) Washer, Lock, #10 (Cover to box) Junction Box (Located at front of compressor) – Includes: Cover, Junction Box Junction Box (Located at rear of 230/460 vac compressor) – Includes: Cover, Junction Box Screw, Pan Head, #10-32 x 3/8 lg (Box to compressor) Terminal, Compressor (5 Terminals) Terminal, Compressor (6 Terminals) Kit, Compressor Terminal Wiring Kit, Compressor Terminal Wiring (Dual voltage to dual/single voltage) Gasket, Terminal Plate Washer, Mylar, 13/64 ID x 39/64 OD	1 2 1 1 1 2 1 1 1 1 1 1 A/R
4.3 S	SERVICE VALVE GROU	JP	
14 15 NS 16 17 18 NS 19 20 21	14-01042-03 17-10812-00 17-10806-02 17-10811-05 14-01042-04 17-10812-00 17-10806-02 17-10811-05 17-40012 17-40013	Valve, Suction Shut-Off, 1-1/8" ODS – Includes: Cap, Seal – Includes: Gasket, Seal Cap Gasket, Suction Service Valve Valve, Discharge Shut-Off, 7/8 ODS – Includes: Cap, Seal – Includes: Gasket, Seal Cap Gasket, Discharge Service Valve Bolt, Hex Head, 5/16-18 x 1-7/8 lg - SST Gasket, Bolt, 5/16	1 1 1 1 1 1 1 2 2
	COMPRESSOR MOT		
NS 29 30 31 32 33 34 34A 35 36 40	- 17-21040 17-40016-01 17-40018 17-55001 17-55006 17-40034 17-40037 17-40020 17-21062-00 17-44011	Gasket Set – Refer to Section 4.8 Cylinder Head – Side Bank (Shaved Head) Cylinder Head – Center Bank Screw, Hex Head – Center Head, 3/8-16 x 3 lg-SAE Grade 5 Gasket, Cylinder Head – Side Bank (Standard) Gasket, Center Cylinder Head Screw, Hex Head, 3/8-16 x 2 lg – SAE Grade 5 Screw, Hex Head, 3/8-16 x 1 lg – SAE Grade 5 Screen Assembly, Oil Filter Tube, Oil Suction Valve, Oil Relief	- 2 1 8 2 1 12 4 1 1

ITEN	M PART NO.	DESCRIPTION	QTY
4.4	COMPRESSOR MOT	FOR BODY GROUP (CONTINUED)	
41 42 43 44 45 46 47 48 49 50 51 52 NS	17-10218 17-10218-02 17-20004 17-40029-05 PL 17-40032 17-40033-05 17-40034 17-20005 PL 17-40042 17-21063-00 PL	Sight Glass Package, Oil Level – Includes: Gasket, Sight Glass Cover, Motor End (NSI) Gasket, Motor End Cover Screw, Hex Head, 7/16-14 x 1-1/4 lg – SAE Grade 5 Plate, Bottom Gasket, Bottom Plate Screw, Hex Head, 3/8-16 x 2 lg – SAE Grade 5 Strainer Assembly, Suction (NSI) Plug, Pipe, Oil Fill, 1/4 Check Valve Assembly, Oil Return Plate, Screen Hold Down Pipe Plug – (High & Low Pressure Connection & Oil Drain),1/4-18 NPT	1 1 1 18 1 2 22 1 1 1 1
4.5	PUMP END GROUP		
60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82	17-40060  NSS NSS NSS 17-40064 17-40065 17-40068 17-40066 17-40071 NSS 17-40069 17-40076 17-40077 17-40013 17-40078-05 17-40078-05 17-40074-01 17-40072 17-10715 17-40073 17-40073 17-40079 17-21070-00	Bearing Head & Oil Pump Package (VANE) Consists of:  (Used in 18-00043-06, -07, -08, -19, -20 Compressor)  Bearing Head and Oil Pump Assembly – Includes:  Pump Rotor  Pump Vane  Plunger Vane Spring  Plunger Vane Spring Guide  Rotor Retaining Ring  Retaining Ring, Plunger  Oil Pump Drive Segment  Guide Vane, Oil Feed  Vane Spring, Oil Feed  Plate, Cover  Screw, Hex Head, 5/16-18 x 3/4 lg – SAE Grade 5  Gasket, Screw, 5/16  Gasket, Cover Plate  Gasket, Bearing Head  Screw, Socket Head, 1/4-28 x 5/8 lg (Special)  Screw, Socket Head, #10-32 x 1/2 lg (Special)  Washer, Lock – Drive Segment, #10  Screw, Hex Head, Bearing Head, 3/8-16 x 1 lg – SAE Grade 5  Gasket, Capscrew, 3/8  Bearing Head & Oil Pump Package (GEAR)  (Used in 18-00048-21 Compressor)	1 1 1 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1
4.6	CRANKSHAFT, ROD AI		'
90 90 90 90 91 92 93 94 95 96	17-21036 17-40049 17-21066-00 N/A 17-40059 17-40048 34-01110 17-10831 17-40046 17-40044	Crankshaft (Used in 18-00043-08, -09 Compressor) Crankshaft (Used in 18-00043-06, -07, -16 Compressor) Crankshaft (Used in 18-00043-19, -20 Compressor) Crankshaft (Used in 18-00048-21 Compressor) Washer, Thrust Pin, Spiral, 5/32 Diameter x 5/8 lg Key, Rotor Drive Washer, Rotor (NSI) Washer, Rotor Star, 5/8 (NSI) Tube Assembly, Equalizer (NSI)	1 1 1 1 1 1 1 1 1

ITEN	M PART NO.	DESCRIPTION	QTY
4.6		ND PISTON GROUP (CONTINUED)	
97	17-21065-01	Piston & Pin Pkg (Standard)	,
97	17-21065-03	(For 18-00043-08,09 Compressors) — Includes: Piston & Pin Pkg (+0.020 inches)	6
		(For 18-00043-08,09 Compressors) – Includes:	A/R
97	17-21064-01	Piston & Pin Pkg (Standard)	,
97	17-21064-03	<b>(For 18-00043-06,07 Compressors)</b> – Includes: Piston & Pin Pkg (+0.020 inches)	6
,,	17 21004 03	(For 18-00043-06,07 Compressors) – Includes:	A/R
97	17-21061-00	Piston & Pin Pkg (Contoured Head – Standard)	
07	17 44115 01	(For 18-00043-16 Compressor) – Includes:	6
97	17-44115-01	Piston & Pin Pkg (Standard) (For 18-00043-19,20 Compressors) – Includes:	6
97	17-44115-20	Piston & Pin Pkg (+0.020 inches)	J
		(For 18-00043-19, -20 & 18-00048-21 Compressors) – Includes:	A/R
98	NSS	Piston  Pin Diston	1
99 100	17-40052-00 17-40053	Pin, Piston Retainer, Piston Pin	1 2
101	17-40055	Ring, Compression (For Standard & +0.020 inch Piston)	12
102	17-40056	Connecting Rod and Cap Assembly (Standard) – Includes:	6
102	17-55023	Connecting Rod and Cap Assembly (+0.010) - Includes:	A/R
NS	17-40057	Pin, Dowel	2
103	17-55008	Capscrew – Special	2
4.7	VALVE PLATE GROUP		
110	17-55007	Package, Valve Plate Assembly (Center Bank) – Includes:	1
NS 111	NSS NSS	Plate Assembly, Valve – Includes:	1
112	17-40086	Plate, Valve Valve, Discharge	1 2
113	17-40087	Valve, Bischarge Valve, Stop Discharge	2
114	17-44113-00	Screw, Hex Head, 1/4-28 x 3/8 lg	4
115	17-10715	Washer, Lock, 1/4	4
116	17-40082	Valve, Suction	2 2
117	17-40083	Spring, Suction Valve Positioning	
33 118	17-55006 17-55002	Gasket, Cylinder Head Gasket, Valve Plate	1 1
120	17-55002	Package, Valve Plate Assembly (Side Bank) – Includes:	2
NS	NSS	Plate Assembly, Valve – Includes:	1
121	NSS	Plate, Valve	1
112	17-40086	Valve, Discharge	2
113	17-40087	Valve, Stop Discharge	2
114 115	17-44113-00 17-10715	Screw, Hex Head, 1/4-28 x 3/8 lg Washer, Lock, 1/4	4 4
116	17-40082	Valve, Suction	2
117	17-40083	Spring, Suction Valve Positioning	2
32	17-55001	Gasket, Cylinder Head	1
118	17-55002	Gasket, Valve Plate	1
122	17-44112-01	Package, Valve Plate Assembly (Center and Side Banks Canted)	2
NS	NSS	(For Compressors 18-00043-16,19,20 & 18-00048-21) — Includes Plate Assembly, Valve — Includes:	s: 3 1
123	NSS	Plate, Valve	1
112	17-40086	Valve, Discharge	2
113	17-40087	Valve, Stop Discharge	2
114	17-44113-00	Screw, Hex Head, 1/4-28 x 3/8 lg	4
115 116	17-10715 17 44111 00	Washer, Lock, 1/4	4
116 117	17-44111-00 17-40083	Valve, Suction Spring, Suction Valve Positioning	2 2
32	17-55001	Gasket, Cylinder Head	1
118	17-55002	Gasket, Valve Plate	1
119	17-40057	Pin, Dowel (Valve Plate)	12

# 4.8 GASKET SET



_	17-55020-20	Gasket Set – Includes:	_
1	17-40005-05	Gasket, Suction Service Valve (4 Bolt)	1
2	17-44004-05	Gasket, Shaft Seal (05G)	1
3	17-44007-05	Gasket, Valve Plate <b>(05G)</b>	3
4	17-44001-06	Gasket, End Flange <b>(05G)</b> – Includes:	1
5	17-44014	Gasket, Flange Spacer (05G)	2
6	17-55001	Gasket, Cylinder Head – Right and Left (Standard)	2
7	17-55002	Gasket, Valve Plate	3
8	17-55006	Gasket, Cylinder Head – Center	1
9	17-55005	Gasket, Cylinder Head – Right and Left (Hot Gas Bypass Unloader)	2
10	17-40316	Gasket, Oil Supply Tube (O-Ring, <b>05D</b> )	1
11	17-10218-02	Gasket, Sight Glass	2
12	17-40104-07	Gasket, Unloader Body	2
13	17-40075-05	Gasket, Oil Pump Cover	1
14	17-10811-05	Gasket, Service Valve (2 Bolt)	2
15	17-40033-05	Gasket, Bottom Plate	1
16	17-40078-05	Gasket, Pump End Bearing Head	1
17	17-40319-05	Shaft Seal (05D)	1
18	17-40029-05	Gasket, Motor End Cover	1
19	17-21042-00	Gasket, Cylinder Head (Suction Cutoff Unloader)	2