
CRR 40 & 20 mP-D

TK 50193-11.52



Printed (February 15, 2006)

Copyright @ 1998 - Thermo King Corp. - Minneapolis, MN U.S.A. Electronically printed in U.S.A.

General Information

Tables of Contents

This Parts Manual contains a numerical table of contents listing each assembly name, its associated Grid number and page number. The numerical table of contents is arranged numerically by Grid number. There are references in a parts list referring to other Grid numbers, the numerical table of contents is arranged to facilitate finding the referenced illustrations. At the rear of this parts manual are two indexes, a numerical and alphabetical. The indexes contain all of the part numbers and descriptions which appear in this manual.

Assemblies and Subassemblies

When parts are indented in the description list, they are preceded with a bullet (•). This indicates that the part(s) is available separately or included in an assembly.

GRID NO. 67D6 SWITCH PANEL ASSEMBLY

REF	PART#	DESCRIPTION	QTY
	45-1239	PANEL - assy, switch	1
1	99-1960	• PANEL	1
	99-6280	• • NAMEPLATE - panel	1
2	33-743	• GASKET	1

For example: the switch panel nameplate (99-6280) is available separately, available as part of the switch panel (99-1960) and with the panel assembly (45-1239).

ABBREVIATIONS The following abbreviations appear in parts manuals

В	AC	current as required accumulator adjusting aluminum alternator ampere assembly board bearing breaker	F	(continued) evap. evaporator exch exchanger exp expansion ext external F. Farenheit fill fillister fi fuel injection fl flare fpt female pipe thread tt ft feet ftg fitting	O P	os oversized od outside diameter pcb printed circuit
D	C	clockwise counter- clockwise camshaft compressor condenser connecting, connector cylinder defrost degree dehydrator	H I	hex	S	req required rpm revolutions per minute sec second sld solder soc hd solder solder soc hd solenoid spl special sq square ss stainless steel std standard stl steel suct suction sw switch
E	DC	direct current discharge differential Extended Maintenance Interval European Economic Community	N	lg long mm milimeter mpt male pipe thread mod modulating neg negative No number NS not supplied NSS not sold separately	U V	term terminal temp temperature thk thick us undersize vib vibrasorber W watt w/ with w/o without

CRR 40 & 20 mP-D

Contents

Name	Grid	Page
CRR 40 & 20 mP-D REFERENCE SHEET	.4U53	5
DEUTSCH IN-LINE CONNECTORS		
WEATHER PACK CONNECTORS		
CONDENSER FAN GROUP		
EVAPORATOR FAN GROUP		
AIR VENT (40 FT CONTAINERS)		
EVAPORATOR PANELS (UNITS w/3 EVAP FANS)		
DEFROST DRAIN	143D10	123
DEFROST DRAIN		
HEATER DOOR)	145D8	105
POWER MODULE CIRCUIT BOARD (CRR)	145F1	53
MAIN & SENSOR HARNESS		
REFRIGERATION COMPONENTS		
COMPRESSOR GROUP		
ELECTRICAL COMPONENTS		
HIGH VOLTAGE TRAY		
CONTROL BOX DOOR		
NAMEPLATES		
CONTROL BOX.		
COMPOUND GAUGE R134a (OPTION 098022)		
RECORDING THERMOMETER (OPTION 098025)		
SIMPSON LEAD (OPTION 098027)		
BATTERY CHARGER GROUP (OPTION 098029)		
TRANSFRESH GROUP (OPTION 098021)		
RECORDING THERMOMETER - 31 DAY FAHRENHEIT		
SENSOR RETAINERS		
RECORDING THERMOMETER (OPTION 098026 & 098030)		
RECORDING THERMOMETER (OPTION 098026)		
REMOTE MONITOR (OPTION 098039)		
TRANSFRESH GROUP (OPTION 098038)	.148A14	87
TRANSFORMER GROUP (098024, 098040, 098041, 098043,		
098071, 098123, 098128)	.148G2	91
RMM MODEM (OPTION 098052)	.148G3	93
HUMIDITY COMPONENTS (OPTION 098100)	.149A14	99
HIGH VOLTAGE TRAY - HUMIDITY (OPTION 098036)	.149B1	95
WATER COOLED CONDENSER - FRESH WATER (OPTION		
098056)		
NAMEPLATES - LANGUAGE (OPTION 098075)	.151A4	127
KVQ VALVE		
AIR VENT (20 FT CONTAINERS)	.151A6	103
REDUNDANT SENSORS (OPTION 098080)	.152A1	115
EVAPORATOR GROUP (TWO FANS)		
EVAPORATOR PANELS (UNITS w/2 EVAP FANS)	152C5	121
TRANSFRESH GROUP (OPTION 098103)	152F7	89
CONDENSER FAN GROUP	157G2	11
EVAPORATOR GROUP (TWO FANS & SEPARATE HARNESSES)		
COMPRESSOR GROUP (UNITS w/o SUCTION VALVE)		
GAUGE GROUP (089028)		
REFRIGERATION COMPONENTS (UNITS w/o SUCTION VALVE).	15706	ან იი
HUMIDITY CONTROL (OPTIONS 098104, 098137 & 098188)	.15/6/	41


CRR 40 & 20 mP-D

Contents

Name	Grid	Page
ELECTRICAL COMPONENTS (2 FAN SYSTEM)		
WATER COOLED CONDENSER (098128)		
CONDENSER COMPONENTS (UNITS w/2 EVAP FANS)		
AMP CONNECTORS	169E1	
MULTI-PACK CONNECTORS	169E2	

CRR 40 & 20 mP-D Contents

Name Grid Page





В/М	DESCRIPTION	Date
CRR-40- 100	CRR40-100	6/98
CRR-40- 101	CRR40-101	6/98
916107	CRR40-103	6/98
CRR-40- 103	CRR40-103	6/98
CRR-40- 104	CRR40-104	6/98
CRR-40- 106	CRR40-106	1/99
CRR-40- 107	CRR40-107	6/98
CRR-40- 110	CRR40-110	9/98
CRR-40- 111	CRR40-111	6/98
CRR-40- 112	CRR40-112	7/98
CRR-40- 114	CRR40-114	6/98
CRR-40- 116	CRR40-116	8/98
CRR-40- 123	CRR40-123	1/99
CRR-20- 125	CRR20-125	11/98
CRR-40- 126	CRR40SL-126	11/98
CRR-40- 128	CRR40-128	11/98
CRR-40- 130	CRR40SL-130	1/99
CRR-40- 138	CRR40-138	5/99
CRR-40- 141	CRR40-141	2/00
916141	CRR40-141	2/00
CRR-40- 147	CRR40-147	2/00
916147	CRR40-147	2/00





CRR-40-148 2/0 148 2/0 916148 CRR40-148 2/0 CRR-40-149 CRR40-149 2/0 916149 CRR40-149 2/0 CRR-40-149 CRR40-793 5/9 793 793 2/0 098015 CRR40 mP-D 2/0	/00 /00 /00 /00 /00 /98 /98 /98 /98
916148 CRR40-148 2/0 CRR-40- CRR40-149 2/0 916149 CRR40-149 2/0 CRR-40- CRR40-793 5/9 793 5/9 098015 CRR40 mP-D 2/0	/00 /00 /98 /00 /98 /98 /98
149 916149 CRR40-149 2/0 CRR-40- CRR40-793 5/9 793 098015 CRR40 mP-D 2/0	/00 /98 /00 /98 /98 /98
CRR-40- CRR40-793 5/93 98015 CRR40 mP-D 2/9	/98 /00 /98 /98 /98 /98
793 098015 CRR40 mP-D 2/0	/00 /98 /98 /98 /98
	/98 /98 /98 /98
098020 CRR40 3/9	/98 /98 /98
	/98 /98
098021 Transfresh 3/9	/98
098022 R134a Compound Gauge 3/9	
098024 APL Transformer 3/9	/98
098025 31 Day Partlow Recording Thermometer 3/9	
098026 Recording Thermometer 2/0	/00
098027 Simpson Lead 3/9	/98
098028 Gauge 2/0	/00
098029 Battery/Charger 3/9	/98
098031 Cannon Bayonet 3/9	/98
098032 Cannon Threaded 3/9	/98
098037 Sensor - Dehumidifier 5/9	/98
098038 Transfresh 4/9	/98
098039 Remote Monitor 4/9	/98
098041 Transformer 11	1/98
098042 Fan 3/9	/98
098052 RMM Modem 6/9	/98
098056 Water Cooled Condenser - Fresh Water 9/9	/98
098061 Power Cable - MIPCO 1/9	/99
098062 Humidity Option 8/9	/98
098067 Power Cable 5/9	/98
098070 Cable 5/9	/98
098071 Transformer - Triton 6/9	/98
098072 Purge Port for Transfresh 6/9	/98
098073 Gauges 11	1/98
098074 C/Atmosphere 1/9	/99
098075 Nameplate - Korean 9/9	/98


Revised 9/10/01

CRR 40 & 20 mP-D REFERENCE SHEET



B/M	DESCRIPTION	Date
098076	Door w/ Latch	11/98
098078	USDA Sensor	8/98
098080	Redundant Sensors	1/99
098081	Suction Valve	11/98
098089	Nameplate - Spanish	11/98
098090	Nameplate - Simpson	11/98
098104	Humidity	2/00
098111	Humidity	2/00
098123	Transformer	2/00
098128	Water Cooled Condenser	2/00
098134	Controlled Atmosphere	2/00
098137	Dehumidity	2/00
098138	Transfresh	2/00






CONDENSER FAN GROUP



REF	PART#	DESCRIPTION	QTY
1	98-5925	ORIFICE - condenser fan	1
	503-120	GASKET	1
	55-7035	SCREW - guard	4
	55-8904	FLATWASHER (8.4 mm id)	10
	55-8893	FLATWASHER (6.4 mm id)	8
	55-9054	WASHER (nylon)	7
	55-9380	NUT (M8)	4
2	78-1167	FAN - condenser	1
3	104-677	MOTOR - condenser fan	1
	55-6993	SCREW - motor	4
	55-6988	FLATWASHER	8
	55-7342	LOCKWASHER	4
	55-9380	NUT	4
4	55-8907	GRIP - cable	1
	55-8908	LOCKNUT	1
5	33-367	GROMMET	1
6	41-2953	HARNESS - condenser fan	1
7	33-3043	EXTRUSION (6.26 ft)	1






CONDENSER FAN GROUP




REF	PART#	DESCRIPTION	QTY
1	91-9912	ORIFICE - condenser fan	1
	55-7035	SCREW - orifice	4
	55-3045	WASHER - dome	4
	55-6997	NUT - captive	4
2	78-1173	FAN - condenser	1
3	104-689	MOTOR - condenser fan	1
	55-6993	SCREW - motor	4
	55-6988	FLATWASHER	8
	55-7342	LOCKWASHER	4
	55-9380	NUT	4
4	55-5900	GRIP - cable	1
	55-8908	LOCKNUT	1
5	33-367	GROMMET	1
6	41-3116	HARNESS - condenser fan	1
7	60-285	COIL - condenser	1
	99-5966	STRIP - gasket (15 x 15 mm)	A/R
	33-2950	GASKET (10 x 15 mm)	A/R
	55-8910	SCREW - coil	7
	55-6995	FLATWASHER	7
	55-9054	WASHER (nylon)	7



EVAPORATOR FAN GROUP




REF	PART#	DESCRIPTION	QTY
1	104-691	MOTOR - evaporator fan	3
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	44-8340	TERMINAL	20
	55-8903	SCREW - motor (22 mm)	12
	55-6993	SCREW - motor (25 mm)	12
	55-8904	FLATWASHER	12
	55-7066	LOCKWASHER	15
	55-9380	NUT	12
	55-7341	INSERT - threaded	12
	99-4931	NAMEPLATE - arrow	1
2	78-1078	FAN - evaporator (19 deg pitch, 355 mm dia)	3
	508-165	FAN - evaporator (22 deg pitch, option, 355 mm dia)	3
	78-1101	FAN - evaporator (CRR 40SL, 25 deg pitch, 312 mm dia)	3
	78-1196	FAN - evaporator (CRR 20SL, 270 mm dia)	3
3	91-8466	BRACKET - motor	3
	55-8903	SCREW - bracket	12
	55-6988	FLATWASHER	21
4	98-5403	BRACKET - motor mount	1
	55-8891	SCREW - bracket	17
5	92-2209	BRACKET - motor	3
6	92-2208	BRACKET - motor	3
7	33-3215	GROMMET (47 mm)	1
8	33-2946	GROMMET (37 mm)	5
9	33-3838	GROMMET (22 mm)	1
10	55-2324	KEY - fan	3
11	55-8907	CONNECTOR - harness	4
	55-8908	LOCKNUT	4
12	41-3112	HARNESS - fan motor	1
	44-8340	TERMINAL - motor	20



EVAPORATOR GROUP (TWO FANS)



REF	PART#	DESCRIPTION	QTY
1	98-5475	HOUSING - evaporator (CRR 119)	1
	98-5918	HOUSING - evaporator (800 & 800A)	1
	98-5919	HOUSING - evaporator (800B)	1
	98-5768	HOUSING - evaporator (CRR 40-300)	1
	98-6213	HOUSING - evaporator (CRR 40-303 & 800D)	1
	98-6657	HOUSING - evaporator (800E & CRR40)	1
2	92-2331	BRACKET - left	2
	92-2779	• BRACKET - left (800E & CRR40)	2
3	92-2332	BRACKET - right	2
	55-9162	RIVET - shroud	10
4	33-3215	GROMMET (47 mm)	1
5	33-3044	TRIM - edge guard	A/R
6	55-5900	CONNECTOR - harness & sensor	3
7	78-1117	FAN - evaporator (14 in, 355 mm dia)	2
8	67-1558	COIL - evaporator	1
	67-1923	COIL - evaporator (800E & CRR40)	1
	55-8891	SCREW - coil	9
	55-9217	CAP - tube	3
9	91-9328	BLOCK - coil	2
10	41-3277	HARNESS - fan & heater (800 & 800A)	1
	41-3685	HARNESS - fan (CRR 40-300, units w/o heater door)	1
	41-4018	HARNESS - evap fan (800B & CRR40)	1
11	104-691	MOTOR - fan	2
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	55-6993	SCREW - motor	8
	55-7066	LOCKWASHER (external tooth)	2
	55-7342	LOCKWASHER	6
	55-7085	FLATWASHER	8
12	99-4931	NAMEPLATE - arrow	1
13	91-8466	BRACKET - motor	2
	55-8903	SCREW - bracket	8
	55-8904	FLATWASHER	16
	55-7342	LOCKWASHER	8
	55-7339	NUT	8
14	33-2946	GROMMET (37 mm)	5
15	33-3838	GROMMET (22 mm)	2
16	92-2775	COVER - tube	1
	55-7172	SCREW - cover	3
	55-7075	FLATWASHER	3
17	33-367	GROMMET (0.625 id)	3
_			




Revised 8/21/02

EVAPORATOR GROUP (TWO FANS & SEPARATE HARNESSES)



REF	PART#	DESCRIPTION	QTY
1	98-5475	SHROUD - evaporator	1
2	92-2331	BRACKET - left	2
3	92-2332	BRACKET - right	2
	55-9162	RIVET - shroud	10
4	33-3215	GROMMET (47 mm)	1
5	33-3044	TRIM - edge guard	A/R
6	55-8907	CONNECTOR - harness & sensor	3
	55-8908	NUT	3
7	78-1117	FAN - evaporator (25 deg)	2
8	67-1558	COIL - evaporator	1
	55-8891	SCREW - coil	9
	55-9217	CAP - screw	3
9	91-9328	BLOCK - coil	2
10	41-3113	HARNESS - evap fan (#1)	1
11	41-3114	HARNESS - evap fan (#2)	1
12	104-691	MOTOR - fan	2
	55-6993	SCREW - motor	8
	55-7066	LOCKWASHER (external tooth)	2
	55-7342	LOCKWASHER	6
	55-7085	FLATWASHER	8
13	99-4931	NAMEPLATE - arrow	1
14	91-8466	BRACKET - motor	2
	55-8903	SCREW - bracket	8
	55-8904	FLATWASHER	16
	55-7342	LOCKWASHER	8
	55-7339	NUT	8
15	33-2946	GROMMET (37 mm)	4
16	33-3838	GROMMET (22 mm)	1






REFRIGERATION COMPONENTS



REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (see 145D10)	1
2	60-285	COIL - condenser	1
3	67-1517	TANK - receiver	1
4	66-9081	TUBE - condenser to receiver	1
5	66-9082	TUBE - receiver to condenser	1
6	506-364	PLUG - fusible	1
7	66-8811	SIGHT GLASS	1
	505-606	WASHER (nylon)	4
	509-1635	BRACKET - sight glass	1
	55-8891	SCREW - bracket	2
8	33-3007	GASKET	5
9	506-375	TUBE - condenser to indicator	1
10	66-9125	VALVE - shutoff	1
	55-7843	SCREW - valve	2
	505-603	WASHER	2
11	506-374	TUBE - indicator to drier	1
12	66-8767	DEHYDRATOR	1
	91-8620	LABEL - dehydrator	1
13	55-8938	CLAMP - dehydrator	1
	55-8891	SCREW - bracket	2
14	506-369	TUBE - discharge	1
15	66-8467	VALVE - check	1
16	506-370	TUBE - discharge	1
17	504-1418	PIPE - temperature	1
18	66-8473	FILTER	1
19	66-9163	KVQ - actuator (see 146E6)	1
20	66-9073	TUBE - heat exchanger to dehydrator	1
	55-8951	SHOULDER (o-ring seal)	1
	55-8950	NUT - shoulder	1
21	66-9071	TUBE - KVQ to compressor	1
22	61-726	TUBE - exchanger to KVQ	1
23	66-8849	HEAT EXCHANGER (CRR 40)	1
	506-272	HEAT EXCHANGER (CRR 20)	1
24	66-9069	TUBE - evaporator to exchanger	1
25	61-727	TUBE - solenoid to KVQ	1
26	66-9168	VALVE - solenoid (pulse)	1
27	66-9214	TUBE - valve to tee	1
28	55-6218	TEE	1
29	66-9167	VALVE - solenoid (normally closed)	1
	41-3301	• COIL	1
	504-977	KIT - repair (Danfoss, normally closed, no stem)	1
30	66-9085	TUBE - valve to exchanger	1






REFRIGERATION COMPONENTS



REF	PART#	DESCRIPTION	QTY
31	66-9900	VALVE - expansion	1
32	66-9165	TUBE - valve to tee	1
33	55-2296	TEE	1
34	66-9166	TUBE - tee to valve	1
35	66-9032	VALVE - solenoid (dehumidifier option)	1
	41-2399	COIL - liquid line valve	1
36	66-9084	TUBE - valve to coil	1
37	66-9087	TUBE - tee to coil	1
38	67-1532	COIL - evaporator (CRR 40)	1
	67-1614	COIL - evaporator (CRR 20)	1
39	55-2299	REDUCER	2
40	66-9285	REDUCER	2
41	66-9075	TUBE - equalizer	1
42	66-9072	ELBOW	1
43	66-9164	TUBE - tee to valve	1
44	66-9210	TUBE	1
45	66-6610	ADAPTER - service	1
46	66-9148	TUBE - filter to dehydrator	1
	55-8951	SHOULDER (o-ring seal)	1
	55-8950	• NUT - o-ring	1
47	66-9062	TUBE - valve replacement	1






REFRIGERATION COMPONENTS (UNITS w/o SUCTION VALVE)



REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (CRR 40, see 154E10)	1
2	60-285	COIL - condenser	1
	33-2949	GASKET - coil	A/R
	55-8910	SCREW - coil	7
	55-6995	FLATWASHER	7
	55-9054	WASHER (nylon)	7
3	67-1651	TANK - receiver	1
4	66-9893	TUBE - condenser to receiver	1
5	66-9894	TUBE - receiver to condenser	1
6	506-364	PLUG - fusible	1
7	66-8811	SIGHT GLASS	1
8	33-3007	GASKET	5
9	61-152	TUBE - condenser to indicator	1
10	61-151	VALVE - shutoff	1
	509-1635	BRACKET - valve	1
	55-7843	SCREW - valve	2
	505-603	WASHER	2
11	61-152	TUBE - valve to dehydrator	1
12	66-9307	DEHYDRATOR	1
	55-4390	HANGER - dehydrator	1
	91-8620	LABEL - dehydrator	1
13	55-8938	CLAMP - dehydrator	1
	55-8891	SCREW - bracket	2
14	506-369	TUBE - discharge	1
15	66-8467	VALVE - check	1
16	506-370	TUBE - discharge	1
17	Not Used		
18	Not Used		
19	66-9163	KVQ - actuator (see 151A5)	1
20	61-145	TUBE - heat exchanger to dehydrator	1
	55-8951	SHOULDER - seal	1
	55-8950	• NUT - shoulder	1
21	66-9071	TUBE - KVQ to compressor	1
22	61-726	TUBE - exchanger to KVQ	1
23	67-1650	HEAT EXCHANGER	1
24	61-143	TUBE - evaporator to exchanger	1
25	61-144	TUBE - solenoid to KVQ	1
26	66-9866	VALVE - solenoid (pulse, Alco)	1
	41-3301	COIL - only	1
27	61-150	TUBE - valve to tee	1
28	55-6218	TEE	1
29	61-149	VALVE - solenoid	1






Revised 4/16/03

REFRIGERATION COMPONENTS (UNITS w/o SUCTION VALVE)



REF	PART#	DESCRIPTION	QTY
	41-3301	COIL	1
30	61-148	TUBE - valve to exchanger	1
31	66-9900	VALVE - expansion	1
32	66-9035	TUBE - valve to tee	1
33	55-2296	TEE	1
34	66-9868	TUBE - tee to valve	1
35	41-3303	VALVE - solenoid (dehumidifier, option 098104)	1
	41-3301	COIL - valve	1
36	61-146	TUBE - valve to coil	1
37	61-147	TUBE - tee to coil	1
38	67-1558	COIL - evaporator (units w/ 2 evap fans, see 152C1)	1
39	66-9062	TUBE - valve replacement	1
40	Not Used		
41	66-9075	TUBE - equalizer	1
42	Not Used		
43	66-9164	TUBE - tee to valve	1
44	66-9210	TUBE	1






REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (CRR 40 & DF Delta Reed compressor)	1
	102-673	COMPRESSOR (CRR 20)	1
2	22-1051	KIT - valve plate (see note)	1
	22-1132	KIT - valve plate (Delta Reed compressor only)	1
3	33-2510	•• GASKET - valve plate (see note)	1
	33-3513	•• GASKET - valve plate (Delta reed compressor only)	1
4	503-278	•• GASKET - cylinder head	1
5	502-240	•• KIT - reed suction	1
	203-516	OIL - compressor	A/R
6	504-246	PROBE - high temperature	1
7	22-1186	ADAPTER - discharge	1
	55-2747	SCREW - adapter	2
	55-2159	LOCKWASHER	2
	55-2173	FLATWASHER	2
8	33-2548	GASKET - adapter/suction	2
9	33-981	GASKET - valve	1
10	66-9150	VALVE - discharge	1
11	66-6610	ADAPTER - service (highside)	1
	66-7182	CAP - adapter (red)	1
12	506-161	CAP - discharge valve	1
13	66-9149	VALVE - suction	1
14	506-165	CAP - suction valve	1
15	503-230	GASKET - suction	1
16	66-1845	COUPLING	1
17	66-2457	COLLAR	1
18	55-3490	SCREW - collar	1
19	66-6607	FITTING - service (lowside)	1
20	509-1153	LABEL - compressor oil	1
21	22-398	SIGHT GLASS - oil	1
	33-2222	GASKET - sight glass	1
22	41-1626	SWITCH - hpco	1
23	41-2447	SENSOR - head temperature	1
24	41-2716	CABLE - compressor power	1
25	55-5257	FITTING - harness	1
26	55-9037	SCREW - compressor (50 mm)	4
	55-7360	FLATWASHER	4
	55-5025	NUT	4

NOTE: Compressors with model number starting with 3DSTA-- are Delta Reed compressors, use the noted replacement parts.


NOTE: Sensor #23 41-2447 screws into the compressor cylinder head. Sensor #27 504-246 slides into a temperature tube attached to the discharge tube.



COMPRESSOR GROUP (UNITS w/o SUCTION VALVE)




REF	PART#	DESCRIPTION	QTY
1	8102-743	COMPRESSOR (CRR 40)	1
2	22-1051	KIT - valve plate	1
3	33-2510	•• GASKET - valve plate	1
4	502-240	•• KIT - reed suction	1
5	503-278	•• GASKET - cylinder head	1
6	22-1051	KIT - valve plate	1
	203-516	OIL - compressor	A/R
7	22-1186	ADAPTER - discharge	1
	55-2747	SCREW - adapter	2
	55-2159	LOCKWASHER	2
	55-2173	FLATWASHER	2
8	33-2548	GASKET - adapter/suction	1
9	33-981	GASKET - valve	1
10	66-9377	VALVE - discharge	1
11	66-6610	ADAPTER - service (highside)	1
	66-7182	CAP - adapter (red)	1
12	506-161	CAP - discharge valve	1
13	22-1099	FLANGE - suction	1
14	55-2976	SCREW - flange	2
15	55-2173	FLATWASHER	2
16	66-8054	ADAPTER (lowside)	1
17	66-6607	FITTING - service (lowside)	1
18	66-7183	CAP - fitting	1
19	41-2447	SENSOR - head temperature	1
20	509-1153	LABEL - compressor oil	1
21	22-398	SIGHT GLASS - oil	1
	33-2222	GASKET - sight glass	1
22	44-6360	SWITCH - hpco	1
22	41-3302	SWITCH - hpco	1
23	55-459	COUPLING - switch	1
24	41-3701	CABLE - compressor	1
25	55-5257	FITTING - harness	1
26	55-8911	SCREW - compressor (50 mm)	4
	55-8912	FLATWASHER	4
	55-8992	NUT	4
27	91-6435	ANGLE - lifting	1
	55-2505	ELBOW	1
28	33-3175	GASKET - discharge (rubberized)	1
29	92-1682	BOX - junction (plastic)	1
30	02-7043	KIT - spacer	1




REF	PART#	DESCRIPTION	QTY
1	66-9163	VALVE - KVQ	1
2	504-980	• ACTUATOR	1
3	41-2603	HARNESS (before 10/02)	1
	41-5420	HARNESS (after 9/02)	1
4	503-291	GASKET	1






Revised 10/14/98

COMPOUND GAUGE R134a (OPTION 098022)



REF	PART#	DESCRIPTION	QTY
1	91-8701	PLATE - guard	1
2	66-7031	GAUGE - compound	1
3	55-8457	NUT - shoulder	1
4	55-8456	SHOULDER	1
5	33-2545	O-RING	1
6	66-9170	ADAPTER	1
7	91-8664	PLATE - gauge (w/o holes)	1






GAUGE GROUP (089028)



REF	PART#	DESCRIPTION	QTY
1	66-9194	GAUGE - suction pressure	1
	55-8382	SCREW - gauge	3
	55-7830	FLATWASHER	3
	55-9165	WASHER (nylon)	3
2	33-3212	GASKET - gauge	1
3	61-154	TUBE - gauge	1
4	91-8762	BRACKET - gauge	1
	55-6993	SCREW - bracket	1
	55-7085	FLATWASHER	1
	55-9043	WASHER (nylon)	1






Revised 4/4/00

WATER COOLED CONDENSER - FRESH WATER (OPTION 098056)



REF	PART#	DESCRIPTION	QTY
1	67-1531	TANK - condenser (fresh water)	1
	55-6993	SCREW - tank	4
	55-7342	LOCKWASHER	4
	55-7085	FLATWASHER	4
2	506-388	INDICATOR - liquid	2
3	33-3007	GASKET - indicator	2
4	66-4788	COUPLING - outlet	1
5	91-6627	CAP - dust cover	1
6	55-1827	PLUG - inlet	1
7	91-6628	CAP - dust cover	1
8	55-9161	COUPLING - pressure switch	1
9	33-768	GASKET - switch	1
10	66-4687	SWITCH - water valve (for connectors see 115D14)	1
11	66-6603	VALVE - angle	1
12	66-2170	CAP - valve	1
13	66-6610	FITTING - charge port (highside)	1
14	66-7182	CAP - charge port (red)	1
15	66-7392	VALVE - relief	1
16	33-1015	O-RING - valve	1
17	66-9283	TUBE - bottom	1
18	66-9282	TUBE - top	1
	55-3295	• FITTING - valve	1
19	91-9038	BRACKET - tube	2
	55-5639	SCREW - bracket	2
20	55-6730	CLAMP - tube	4
	55-8464	SCREW - clamp	2
	55-7075	FLATWASHER	4
	55-7042	NUT	2
21	91-9505	PLATE - cable	1
	55-6994	SCREW - plate	2
	55-6695	FLATWASHER	2
	55-8933	WASHER (nylon)	2
	55-9168	NUT - plate	2
	55-9054	WASHER (nylon)	2




WATER COOLED CONDENSER (098128)



REF	PART#	DESCRIPTION	QTY
1	67-1652	TANK - condenser	1
2	66-8811	• INDICATOR	1
3	33-3007	• GASKET	1
4	66-9873	ADAPTER - service	1
5	66-9842	• VALVE	1
6	506-364	PLUG - fusible	1
	55-7691	SCREW - tank	4
	55-7342	LOCKWASHER	4
	55-8904	FLATWASHER	4
7	66-4788	COUPLING - outlet	1
8	91-6627	CAP - dust cover	1
9	55-1827	PLUG - outlet	1
10	91-6628	CAP - dust cover	1
11	66-9875	TUBE - top	1
12	61-155	TUBE - bottom	1
13	91-9038	BRACKET - tube	2
	55-5639	SCREW - bracket	2
14	91-759	CLAMP - tube (1 tube)	4
	55-8993	SCREW - clamp	4
	55-8893	FLATWASHER	4
15	91-445	CLAMP - tube (2 tube)	6






Revised 12/12/05

HUMIDITY CONTROL (OPTIONS 098104, 098137 & 098188)




REF	PART#	DESCRIPTION	QTY
1	41-3303	VALVE - solenoid (humidity control)	1
	41-3301	• COIL	1
2	66-9159	TUBE (replaces valve)	1
3	41-5635	SENSOR - humidity	1
	41-2838	HARNESS - sensor	1
4	55-1203	CLAMP - sensor	2
	55-8991	SPACER - clamp	2
	55-9173	SCREW - clamp	2




ELECTRICAL COMPONENTS




REF	PART#	DESCRIPTION	QTY
1	55-6409	CONNECTOR - probe holder	1
2	41-3112	HARNESS - evaporator	1
3	504-980	COIL - KVQ	1
	503-291	GASKET - KVQ	1
4	41-2503	CABLE - power (11 ga, 63 ft)	1
	45-237	CABLE - power (10 ga, MIPCO)	1
	41-1976	PLUG - power (Minnekes)	1
	44-6952	PLUG - power (MIPCO)	1
	41-2820	PLUG - power (ESL)	1
	44-6310	TERMINAL - pin (17 mm lg, plug end)	4
	44-9891	TERMINAL - pin (12 mm lg, cable end)	3
5	91-6988	BRACKET - cable restraint	1
	55-9164	SCREW - cable	1
	55-7357	FLATWASHER	1
	55-7344	NUT	1
	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
	55-7170	LOCKWASHER	4
6	91-8140	SPRING - heater	6
7	41-3301	COIL (24V 50/60 Hz)	2
8	104-639	MOTOR - condenser fan (see 145D9)	1
9	41-3116	HARNESS - condenser fan	1
10	104-691	MOTOR - evaporator fan (see 145D13)	3
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
11	41-2517	HARNESS - main (see 146F9)	1
12	45-1791	HEATER	6
13	40-871	KIT - sensor (graded)	3
14	41-4021	SENSOR - temperature (ungraded)	2
15	91-8142	BRACKET - heater (CRR 40)	1
	509-1763	BRACKET - heater (CRR 20)	2
16	91-8467	BRACKET - heater (CRR 40)	2
	509-1767	BRACKET - heater (CRR 20)	2
	55-8891	SCREW - bracket	11
17	8102-743	COMPRESSOR (see 146F2)	1
18	NSS	BOX - control (see 146F4)	1
19	41-2716	CABLE - compressor power	1
20	41-2603	HARNESS - KVQ valve	1
21	41-2399	COIL - liquid line valve	1
22	506-329	SENSOR - humidity (optional)	1
23	41-2447	SENSOR - head temperature	1




ELECTRICAL COMPONENTS (2 FAN SYSTEM)




REF	PART#	DESCRIPTION	QTY
1	41-3113	HARNESS - evaporator fan (#1, see 157G3)	1
2	41-3114	HARNESS - evaporator fan (#2, see 157G3)	1
3	504-980	COIL - KVQ (see 151A5)	1
4	41-2503	CABLE - power (63 ft, 11 ga)	1
	45-237	CABLE - power (63 ft, 10 ga)	1
	41-1976	PLUG - power (Minnekes)	1
	44-6952	PLUG - power (MIPCO)	1
5	91-6988	BRACKET - cable restraint	1
	55-9164	SCREW - cable	1
	55-7357	FLATWASHER	1
	55-7344	NUT	1
	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
	55-7170	LOCKWASHER	4
6	91-8140	SPRING - heater	6
7	41-3301	COIL	2
8	104-689	MOTOR - condenser fan (see 152B14)	1
9	41-3116	HARNESS - condenser fan (see 140D2)	1
10	104-691	MOTOR - evaporator fan (see 140D2)	2
11	41-3342	HARNESS - control box	1
12	45-1791	HEATER	6
13	40-871	KIT - sensor (evap coil, return air & supply air, graded)	3
14	41-4021	SENSOR - temperature (cond coil & ambient, ungraded)	2
15	91-8142	BRACKET - heater	1
16	91-8467	BRACKET - heater	2
	55-8891	SCREW - bracket	11
17	8102-743	COMPRESSOR (see 157G4)	1
18	NSS	BOX - control (see 146F8)	1
	55-8075	SCREW - control box	4
	55-8893	WASHER	4
	55-9054	WASHER (nylon)	4
19	41-2716	CABLE - compressor power	1
20	41-2603	HARNESS - KVQ	1
21	41-3303	VALVE - solenoid (dehumidifier, see 157G7)	1
	41-3301	COIL - dehumidifier	1
22	41-5635	SENSOR - humidity (option 098104 & 098137)	1
23	41-2447	SENSOR - head temperature	1
24	41-3115	HARNESS - heater	1



REF	PART#	DESCRIPTION	QTY
1	98-5443	BOX - control	1
	55-6994	SCREW - box	4
	55-7075	FLATWASHER	4
	55-9054	WASHER (nylon)	4
2	99-6093	MOUNT - cable	5
	55-7862	SCREW - mount	5
	55-7368	FLATWASHER	5
	55-7665	NUT	5
3	55-5257	CONNECTOR - harness	3
4	55-5900	CONNECTOR - harness	4
	33-1435	GROMMET - connector	2
	33-2753	GROMMET - connector (0.25 id)	1
5	91-8659	LATCH - cover	1
	55-7035	SCREW - latch	1
	55-2641	FLATWASHER	1
	55-2363	LOCKWASHER	1
	55-7042	NUT	1
6	55-9029	SPACER - latch	1
	203-392	SEALER - antiseize	A/R
7	41-2406	CAP - dust	1
	99-3685	CHAIN - cap	1
8	55-6147	CLAMP - harness	1
9	NSS	COVER - control box (see 146F6)	1
10	91-8672	NAMEPLATE - schematic	1
11	91-9761	PLACARD - wiring	1
	91-9762	PLACARD - schematic	1
12	41-2517	HARNESS - main (see 146F9)	1
13	41-2518	HARNESS - sensor (see 146F9)	1
14	204-918	HARNESS - mP-D adapter	1
15	91-8693	NAMEPLATE - on/off	1
16	41-2170	HARNESS - switch	1
	44-6560	• SWITCH	1
17	44-739	BOOT - switch	1
18	NSS	TRAY - high voltage (see 146F5)	1
19	91-8553	NAMEPLATE - controller setup	1
20	91-8589	NAMEPLATE - control box layout	1




REF	PART#	DESCRIPTION	QTY
1	91-8662	PANEL - high voltage	1
2	91-8147	BRACKET - power module	1
	55-7862	SCREW - bracket	3
	55-7369	LOCKWASHER	4
3	45-1806	MODULE - power (CRR units, see 145F1)	1
4	41-2129	TRANSFORMER	1
	55-7369	LOCKWASHER	4
	55-7698	NUT	5
5	41-2208	TAP - thermo bus	1
6	41-2209	TERMINATOR	1
7	91-8661	BRACKET - emergency bypass	1
8	41-2210	PC BOARD - emergency bypass	1
	99-7849	STRIP - gasket (25 ft)	A/R
	55-8723	SCREW - bracket	4
9	91-8538	NAMEPLATE - emergency bypass	1
10	45-1853	MODULE - mP-D output	1
11	41-2446	CONTACTOR	7
12	44-8813	INTERLOCK	2
13	41-2520	SPACER - contactor	2
14	41-2701	MODULE - current sense (w/ filter)	1
	41-2401	MODULE - current sense	1
15	41-2521	BREAKER - circuit	1
16	91-8204	RAIL - din	1
	55-7862	SCREW - rail	6
	55-7369	LOCKWASHER	6
	55-7697	FLATWASHER	6
17	41-2690	HARNESS - contactor	1
18	41-2319	CONNECTOR - receptacle (12 pin)	1
19	99-6093	MOUNT - cable tie	2
	55-2864	RIVET - mount	2
	55-2332	BANDWRAP	18
20	91-8737	BLOCK - grounding	4
21	41-2689	HARNESS - output module	1
22	41-2407	• PLUG (35 pin)	1
23	41-2493	• PLUG (12 socket)	1
24	41-2492	CONNECTOR - receptacle (16 pin)	1
25	41-2249	• PLUG (3 socket)	1
26	41-2522	HARNESS - power module	1
27	41-2495	CONNECTOR - plug (6 socket)	1
	41-2494	CONNECTOR - receptacle (6 pin)	1






REF	PART#	DESCRIPTION	QTY
1	845-1949	CONTROLLER - mP-D	1
	92-179	BEZEL - controller	1
	55-7748	SCREW - controller	10
2	203-439	BATTERY - lithium	1
3	91-8716	DOOR - control box	1
4	33-2981	GASKET - door (340mm & 481mm)	A/R
5	55-6147	CLAMP - harness	1
	55-7034	NUT	1
	55-7370	LOCKWASHER	1
	55-7033	FLATWASHER	2
6	91-8738	NAMEPLATE - Operating Instructions	1
7	55-6994	SCREW - door latch	1
8	55-7075	FLATWASHER	2
9	99-8151	SPACER	1
10	99-8162	ROLLER - door latch	1
	203-392	SEALER - antiseize	A/R
11	55-7170	LOCKWASHER	1
12	55-7042	NUT	1
13	91-8658	HINGE - cover to box	2
	55-7748	SCREW - hinge	4
	55-7033	FLATWASHER	8
	55-7034	NUT	4
14	91-8256	PIN - hinge	2
15	91-8659	LATCH - door	1
	55-6994	SCREW - latch	1
	55-7075	FLATWASHER	2
	55-2363	LOCKWASHER	1
	55-7042	NUT	1
16	55-9029	SPACER - latch	1
	203-392	SEALER - antiseize	A/R



POWER MODULE CIRCUIT BOARD (CRR)



REF	PART#	DESCRIPTION	QTY
1	45-1806	MODULE - power	1
2	41-1932	• FUSE (1 amp)	3
3	41-2543	• FUSE (2 amp)	2
4	44-9524	• FUSE (3 amp)	6
5	41-1292	• FUSE (5 amp)	2
6	44-9359	• FUSE (7.5 amp)	1
	55-9195	SCREW - module	5
	55-8987	LOCKWASHER	5
	55-8410	FLATWASHER	5
7	91-8415	NAMEPLATE - fuses	1




MAIN & SENSOR HARNESS



REF	PART#	DESCRIPTION	QTY
1	41-2517	HARNESS - main	1
2	55-8661	CONNECTOR - harness	1
	55-8662	NUT - connector	1
3	41-2405	CONNECTOR - receptacle (data port, 5 pin)	1
4	41-2524	RECEPTACLE - sensor harness (24 pin)	1
5	41-2247	RECEPTACLE - current transformer (6 pin)	1
6	41-2249	PLUG - thermo bus (3 socket)	1
7	41-1946	• RECEPTACLE - power module CN4 (36 pin)	1
8	41-2319	CONNECTOR - receptacle (12 pin, power module CN1 & CN8)	1
9	41-2248	RECEPTACLE - power module CN6 (18 pin)	1
10	41-743	CONNECTOR (17 pin, A connector)	1
11	41-224	STRAIN RELIEF - connector (14 pin)	1
	55-7617	CLAMP (plastic)	1
12	41-747	• LOCKRING	2
13	41-744	CONNECTOR (23 pin, B connector)	1
14	41-225	STRAIN RELIEF - connector (19 pin)	2
	55-7618	CLAMP (plastic)	2
15	41-748	• LOCKRING	2
16	41-745	CONNECTOR (37 pin, D connector)	1
17	41-2518	HARNESS - sensor	1
18	41-2402	CONNECTOR - plug (28 pin, C connector)	1
19	44-8779	CLAMP - cable	1
20	41-2519	CONNECTOR - plug (24 socket, main harness)	1
21	91-8717	PLACARD - wiring	1
22	91-8718	PLACARD - schematic	1
23	91-8719	NAMEPLATE - schematic	1
24	91-8660	PLATE - harness	2
	55-9030	RIVET - plate	4








WEATHER PACK CONNECTORS





REF	PART#	DESCRIPTION	QTY
1	44-5836	TERMINAL - male (14-16 gauge)	A/R
	44-5883	TERMINAL - male (18-20 gauge)	A/R
	44-8851	TERMINAL - male (22 gauge)	A/R
2	44-8681	SEAL (red, 0.066 - 0.079 id)	A/R
	44-5885	SEAL (green, 0.087 - 0.110 id, 18-20 gauge)	A/R
	44-5837	SEAL (gray, 0.110 - 0.137 id, 14-16 gauge)	A/R
	44-6324	SEAL (blue, 0.137 - 0.165 id, 12-14 gauge)	A/R
	44-7812	PLUG - cavity (green, no hole)	A/R
3	44-7330	SHROUD (1 pin)	1
4	44-7327	CONNECTOR - tower (1 pin)	1
5	44-5839	TERMINAL (14-16 gauge, female)	A/R
	44-5884	TERMINAL (18-20 gauge, female)	A/R
	44-8853	TERMINAL (22 gauge, female)	A/R
6	44-5835	SHROUD (2 pin)	1
7	44-5838	CONNECTOR - tower (2 pin)	1
8	44-9569	SHROUD (3 pin)	1
9	44-6959	CONNECTOR - tower (3 pin)	1
10	44-7880	SHROUD (4 pin)	1
11	44-7881	CONNECTOR - tower (4 pin)	1
12	44-8294	SHROUD (6 pin)	1
13	44-7872	CONNECTOR - tower (6 pin)	1
14	44-7884	SHROUD (22 pin)	1
15	44-7829	CONNECTOR - tower (22 pin)	1
16	44-7811	LOCK - secondary	2
17	41-1527	CONNECTOR - tower (4 pin)	1
18	41-1310	SHROUD (4 pin)	1
19	204-623	TOOL - pin removal	1
20	204-624	TOOL - terminal crimper	1





















DEUTSCH IN-LINE CONNECTORS



REF	PART#	DESCRIPTION	QTY
1	44-9700	TERMINAL - socket (w/ 6 in wire lead)	2
	44-9587	TERMINAL - socket (without wire)	2
2	44-9585	PLUG (2 pin, w/ seal)	1
3	33-2392	SEAL	1
4	44-9586	WEDGE	1
5	44-9590	WEDGE	1
6	44-9589	RECEPTACLE (2 pin)	1
7	44-9701	TERMINAL - pin (w/ 6 in wire lead)	2
	44-9591	PIN - terminal (w/o wire)	2
8	44-9631	CONNECTOR (3 pin, w/ seal)	1
9	33-2393	SEAL	1
10	44-9536	WEDGE	1
11	44-9545	WEDGE	1
12	44-9544	RECEPTACLE (3 pin)	1
13	44-8935	PLUG (4 pin, w/ seal)	1
14	33-2394	SEAL	1
15	44-8936	WEDGE	1
16	44-8918	WEDGE	1
17	44-8915	RECEPTACLE (4 pin)	1
18	44-8920	CONNECTOR (6 pin, w/ seal)	1
19	33-2395	SEAL	1
20	44-8917	WEDGE	1
21	44-8921	WEDGE	1
22	44-8914	CONNECTOR (6 pin)	1
23	44-9903	PLUG (8 pin, w/ seal)	1
24	33-2396	SEAL	1
25	44-9902	WEDGE	1
26	44-9901	WEDGE	1
27	44-9900	RECEPTACLE (8 pin)	1
28	44-9600	PLUG (12 pin, w/ seal)	1
29	33-2397	SEAL	1
30	44-9601	WEDGE	1
31	44-9905	WEDGE	1
32	44-9904	RECEPTACLE (12 pin)	1
33	41-2323	PLUG - assembly (w/ 6 in wires)	1
34	41-2322	RECEPTACLE - assembly (w/ 6 in wires)	1
35	41-2325	PLUG - assembly (w/ 6 in wires)	1
36	41-2324	RECEPTACLE - assembly (w/ 6 in wires)	1
37	41-2327	PLUG - assembly (w/ 6 in wires)	1
38	41-2326	RECEPTACLE - assembly (w/ 6 in wires)	1
39	44-9602	PIN - sealing	A/R
40	44-9906	TAB - mounting (for all connectors except the 8 pin connector)	A/R




DEUTSCH IN-LINE CONNECTORS



REF	PART#	DESCRIPTION	QTY
41	44-9907	TAB - mounting (for 8 pin connector only)	A/R
42	204-703	KIT - crimper (w/ terminals)	1
	204-1038	• TOOL - crimper	1
	204-799	TOOL - wedge remover	1






Pin & Socket



REF	PART#	DESCRIPTION	QTY
1	44-8533	CLAMP - cable (#11 shell)	1
2	44-8535	PLUG (8 pin, 20-24 gauge)	1
3	44-8542	RECEPTACLE (8 pin, 20-24 gauge)	1
4	44-8532	PLUG (9 pin, 20-24 gauge)	1
5	44-9226	RECEPTACLE (9 pin, 20-24 gauge)	1
6	41-1126	CLAMP - cable (#14 shell)	1
7	41-4352	PLUG (5 pin)	1
8	41-1127	CONNECTOR - receptacle (5 pin)	1
9	41-1129	CAP - dust (#14 shell)	1
10	44-8779	CLAMP - cable (#17 shell)	1
11	44-8318	PLUG (3 pin)	1
12	44-8331	RECEPTACLE (3 pin)	1
13	41-1230	CAP - connector (w/ plastic strap)	1
14	41-747	LOCKRING (#17 shell)	1
15	44-8538	CLAMP - cable (#17 shell)	1
16	41-746	PLUG - reverse (9 pin)	1
17	41-743	PLUG - reverse (14 pin)	1
18	44-8783	RECEPTACLE (14 pin)	1
19	44-8537	PLUG (16 pin)	1
20	44-8543	RECEPTACLE (16 pin)	1
21	304-2786	PLUG - circular (16 pin)	1
22	304-2642	CONNECTOR - receptacle (16 pin)	1
23	41-1091	CONNECTOR - plug (28 pin, cab box)	1
24	41-2402	CONNECTOR - plug (reverse, 28 pin)	1
25	41-224	STRAIN RELIEF - connector (14 pin)	1
26	55-7617	CLAMP (#17, 1.25 dia)	1
27	41-225	STRAIN RELIEF - connector (19 pin)	1
28	55-7618	CLAMP (#23, 1.5 dia)	1
29	41-744	PLUG - reverse amp (19 pin)	1
30	41-4353	RECEPTACLE (19 pin)	1
31	41-4354	PLUG (24 pin)	1
32	41-2403	CONNECTOR - receptacle (24 pin)	1
33	41-4355	PLUG (37 pin)	1
34	41-1092	CONNECTOR - receptacle (37 pin)	1
35	41-182	TERMINAL - pin (18 gauge, tin)	A/R
	41-5652	TERMINAL - pin (18 gauge, gold)	A/R
	44-9343	PIN (20-24 gauge)	A/R
36	44-8539	TERMINAL - socket (18 gauge)	A/R
	44-8534	SOCKET (20-24 gauge)	A/R






MULTI-PACK CONNECTORS



REF	PART#	DESCRIPTION	QTY
1	41-2321	CONNECTOR - plug (9 socket)	1
2	41-2329	CONNECTOR - receptacle (9 socket)	1
3	41-2493	CONNECTOR - plug (12 socket)	1
4	41-2319	CONNECTOR - receptacle (12 pin)	1
5	41-2248	PLUG (18 pin)	1
6	41-2320	CONNECTOR - receptacle (18 pin)	1
7	41-2519	CONNECTOR - plug (24 socket)	1
8	41-2524	RECEPTACLE (24 pin)	1
9	41-4347	PLUG (36 pin)	1
10	41-1946	RECEPTACLE (36 pin)	1
11	41-182	TERMINAL - pin (18 gauge, tin, reel)	1
	41-5652	TERMINAL - pin (18 gauge, gold)	1
12	44-8539	TERMINAL - socket (18 gauge, reel)	1
13	41-1950	STRAIN RELIEF - connector (9 position)	1
14	41-1952	STRAIN RELIEF - connector (12 position)	1
15	41-1951	STRAIN RELIEF - connector (18 position)	1
16	41-4352	COVER - strain relief (24 pin)	1
17	41-1947	STRAIN RELIEF - connector (36 pin)	1




RECORDING THERMOMETER (OPTION 098025)



REF	PART#	DESCRIPTION	QTY
1	45-1830	THERMOMETER - recording (31 day, see 147B2)	1
	45-1834	THERMOMETER - 7 day (recording, see 147G13)	1
	55-7172	SCREW - recorder	4
	55-6996	LOCKWASHER	4
	55-6995	FLATWASHER	4
2	91-8705	BOX - recorder	1
	55-7341	SCREW - box	4
	55-6988	FLATWASHER	4
	55-8953	WASHER (nylon)	4
3	91-4218	PLATE - box (bottom)	1
	55-7340	SCREW - plate	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
4	33-451	GROMMET	1
5	99-7230	GUIDE - latch	1
6	55-7169	SCREW - guide (12 mm)	1
7	55-8720	SCREW - guide (25 mm)	1
8	55-7033	FLATWASHER	4
9	55-7404	LOCKWASHER	1
10	55-9444	WASHER - insulating (nylon)	4
11	55-7034	NUT	4
12	91-5005	LATCH - cover	1
	55-2988	RIVET - latch	2
13	91-5006	BRACKET - latch	1
	55-7340	SCREW - bracket	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
14	98-7209	COVER - recorder (incl items 15, 16 & 17)	1
15	91-5007	PLATE - keeper	1
	55-2988	RIVET - plate	2
16	91-8707	• WINDOW	1
17	33-3008	GASKET - cover	4
	91-4219	HINGE SET - left	1
18	91-8708	• HINGE - right (w/ pin)	1
19	91-8725	HINGE - right (w/o pin)	1
	55-7169	SCREW - hinge	8
	55-7033	FLATWASHER	8
	55-7404	LOCKWASHER	8
	91-4220	HINGE SET - right	1






Revised 8/30/05

RECORDING THERMOMETER (OPTION 098025)



REF	PART#	DESCRIPTION	QTY
20	91-8709	HINGE - left (w/ pin)	1
21	91-8726	HINGE - left (w/o pin)	1




Revised 2/2/06

RECORDING THERMOMETER - 31 DAY FAHRENHEIT



REF	PART#	DESCRIPTION	QTY
	45-1830	THERMOMETER (31 day, F)	1
1	44-5644	• ELEMENT - thermo (1/2 od, 7.5 in lg bulb, 10 ft capillary)	1
	44-2339	• ELEMENT - thermo (3/8 od, 14 in lg bulb, 10 ft capillary)	1
2	91-8217	• ROD - push	1
3	33-2962	• O-RING	1
4	41-2216	• MECHANISM	1
5	44-2966	DRIVE - chart (31 day)	1
6	55-5099	• NUT, CLIP & CORD	1
7	41-2218	• PLATEN	1
8	55-8955	• KEY - winding	1
9	91-2205	• KIT - stylus	1
10	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1






RECORDING THERMOMETER (OPTION 098026 & 098030)



REF	PART#	DESCRIPTION	QTY
1	45-1830	THERMOMETER - recording (31 day, Partlow, 098025, see 147B2)	1
	45-1831	THERMOMETER - recording (31 day, Saginomiya, battery, 098026, see 147B9)	1
	45-1832	THERMOMETER - recording (31 day, Saginomiya, AC power, 098030, see 147B9)	1
	55-7172	SCREW - recorder	4
	55-6996	LOCKWASHER	4
	55-6995	FLATWASHER	4
2	91-8705	BOX - recorder	1
	55-7341	SCREW - box	4
	55-6988	FLATWASHER	4
	55-8953	WASHER (nylon)	4
3	91-4218	PLATE - box (bottom)	1
	55-7340	SCREW - plate	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
4	33-451	GROMMET	1
5	99-7230	GUIDE - latch	1
6	55-7169	SCREW - guide (12 mm)	1
7	55-8720	SCREW - guide (25 mm)	1
8	55-7033	FLATWASHER	4
9	55-7464	LOCKWASHER	1
10	55-9444	WASHER - insulating (nylon)	4
11	55-7034	NUT	4
12	91-5005	LATCH - cover	1
	55-2988	RIVET - latch	2
13	91-5006	BRACKET - latch	1
	55-7340	SCREW - bracket	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
14	98-7209	COVER - recorder (incl items 15, 16 & 17)	1
15	91-5007	PLATE - keeper	1
	55-2988	RIVET - plate	2
16	91-8707	WINDOW	1
17	33-3008	GASKET - cover	4
	91-4219	HINGE SET - left	1
18	91-8708	HINGE - right (w/ pin)	1
19	91-8725	• HINGE - right (w/o pin)	1
20	91-8709	• HINGE - left (w/ pin)	1






Revised 12/12/05

RECORDING THERMOMETER (OPTION 098026 & 098030)



147B8

REF	PART#	DESCRIPTION	QTY
21	91-8726	HINGE - left (w/o pin)	1
	55-7169	SCREW - hinge	8
	55-7033	FLATWASHER	8
	55-7404	LOCKWASHER	8
	91-4220	HINGE SET - right	1




Revised 9/3/04


RECORDING THERMOMETER (OPTION 098026)



REF	PART#	DESCRIPTION	QTY
	45-1831	THERMOMETER - recording (Saginomiya, 31 day battery)	1
	45-1832	THERMOMETER - recording (Saginomiya, 31 day, AC power)	1
1	44-9780	• ELEMENT	1
2	44-9781	INDICATOR - volt	1
3	44-7782	• TIMER	1
4	509-911	PLATE - recorder	1
5	505-390	NUT - chart	1
6	509-912	• STYLUS - pen	1
7	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1




SIMPSON LEAD (OPTION 098027)



REF	PART#	DESCRIPTION	QTY
1	204-209	LEAD - thermistor	1
2	91-8702	CAP - probe	1
3	91-8703	BRACKET - lead	1
4	44-5114	POST - binding	1
5	33-2960	GASKET	1






REMOTE MONITOR (OPTION 098039)



REF	PART#	DESCRIPTION	QTY
1	41-2556	HARNESS - remote monitor	1
2	44-5537	SOCKET - relay	1
3	44-6822	SOCKET - monitor	1
	55-8382	SCREW - relay socket	6
	55-8410	FLATWASHER	12
	55-9057	LOCKWASHER	6
	55-7749	NUT	6
	55-9174	RIVET - monitor socket	4
	55-8410	WASHER	4
4	33-2630	GASKET - socket	1
5	41-896	RELAY - mini	3
6	92-206	CAP - dust	1




BATTERY CHARGER GROUP (OPTION 098029)



REF	PART#	DESCRIPTION	QTY
1	91-8710	BRACKET - battery charger	1
	55-7752	SCREW - bracket	4
	55-6995	FLATWASHER	4
	55-8877	WASHER (nylon)	4
2	91-8711	BOX - battery charger	1
	55-6994	SCREW - box	2
	55-6996	LOCKWASHER	2
	55-6995	FLATWASHER	2
3	55-8720	SCREW - ground	1
	55-3008	WASHER - sealing	1
	55-7370	LOCKWASHER	2
	55-7033	FLATWASHER	1
	55-7367	NUT	2
4	44-6591	CHARGER - battery	1
5	91-8712	BRACKET - battery charger	1
	55-7034	NUT - bracket	2
	55-7033	FLATWASHER	2
6	44-5534	BOARD - terminal	1
	55-7665	NUT - board	2
	55-7368	FLATWASHER	2
7	91-6202	NAMEPLATE	1
8	91-6205	NAMEPLATE	1
9	91-8713	COVER - box	1
	55-7035	SCREW - cover	1
	55-6995	FLATWASHER	1
	55-7479	WASHER - special	1
10	55-5111	CONNECTOR - harness grip	1
11	40-534	HARNESS - battery charger	1
12	203-525	BATTERY (12V)	1
13	44-5835	CONNECTOR - harness	1
14	91-8714	BRACKET - battery	1
	55-7752	SCREW - bracket	2
	55-6995	FLATWASHER	2
	55-8877	WASHER (nylon)	2
15	99-6968	STRIP - sealing (0.12 x 1 x 50 ft)	A/R
	99-8562	STRIP - gasket (battery, 3/8 thk x 25 ft)	A/R
16	99-8986	STRIP - gasket (cover, 25 ft)	A/R
17	55-6997	NUT - captive	1






TRANSFRESH GROUP (OPTION 098021)




REF	PART#	DESCRIPTION	QTY
1	98-5320	GRILLE - evaporator	1
2	91-8715	BOX - Transfresh	1
	55-2264	RIVET - box	4
3	33-3043	GASKET - rub strip	1
4	41-2537	TRANSFORMER	1
5	41-2538	HARNESS	1
6	NSS	DOOR - assembly (not available from Thermo King)	1




TRANSFRESH GROUP (OPTION 098038)




REF	PART#	DESCRIPTION	QTY
1	98-5320	GRILLE - evaporator	1
2	91-8715	BOX - Transfresh	1
	55-7713	RIVET - box	4
3	41-2554	CABLE - Transfresh (red bandwrap, 160 in lg)	1
4	41-2555	CABLE - Transfresh (green bandwrap, 120 in lg)	1



TRANSFRESH GROUP (OPTION 098103)



REF	PART#	DESCRIPTION	QTY
1	98-5523	GRILLE - evaporator	1
2	91-8715	BOX - Transfresh	1
	55-7713	RIVET - box	4
3	41-2554	CABLE - Transfresh (red bandwrap, 160 in lg)	1
4	41-2555	CABLE - Transfresh (green bandwrap, 120 in lg)	1




Revised 12/3/03

TRANSFORMER GROUP (098024, 098040, 098041, 098043, 098071, 098123, 098128)



148G2


REF	PART#	DESCRIPTION	QTY
1	45-1859	TRANSFORMER	1
2	41-1977	RECEPTACLE - power (32 amp, 440V)	1
	55-2995	SCREW - receptacle	4
	55-2964	• LOCKWASHER	2
	55-2001	• FLATWASHER	2
3	55-5919	CONNECTOR - grip	1
	55-2636	NUT - connector	1
4	41-3083	CABLE - power (69 ft)	1
5	91-9508	INSULATOR	2
6	55-7341	SCREW - transformer	2
	55-8891	SCREW - transformer	4
	55-7085	FLATWASHER	6
	55-7342	LOCKWASHER	6
7	91-6988	BRACKET - cable restraint (current units)	1
8	55-9164	SCREW - cable	1
	55-7357	FLATWASHER	1
	55-7344	NUT	1
9	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
	55-7170	LOCKWASHER	4
10	91-3238	BRACKET - cable (early units)	1
	55-7172	SCREW - bracket	3
	55-6995	FLATWASHER	6
	55-7042	NUT	3
11	44-3828	PLUG - power (50 amp)	1
	44-5133	PLUG - power (60 amp, orange)	1
	41-3429	PLUG - power (50 amp, blue)	1
	33-2482	BUSHING - plug	1



RMM MODEM (OPTION 098052)



REF	PART#	DESCRIPTION	QTY
1	41-2629	MODEM - RMM	1
	55-7862	SCREW - modem	4
	55-7369	LOCKWASHER	4
	55-7697	FLATWASHER	4
2	41-4208	HARNESS - RMM modem	1
3	41-1266	PLUG - circular (13-9)	1
	44-6381	CONNECTOR (1 pin, female)	2
4	91-8662	PANEL - high voltage	1




Revised 7/9/02

HIGH VOLTAGE TRAY - HUMIDITY (OPTION 098036)



REF	PART#	DESCRIPTION	QTY
1	91-8662	PANEL - high voltage	1
2	91-8147	BRACKET - power module	1
	55-7862	SCREW - bracket	3
	55-7369	LOCKWASHER	4
	55-7031	LOCKWASHER (internal tooth)	1
3	45-1806	MODULE - power (see 145F1)	1
	55-9195	SCREW - module	5
	55-8987	LOCKWASHER (internal tooth)	5
	55-8410	FLATWASHER	5
	91-8415	NAMEPLATE - fuses	1
4	41-2129	TRANSFORMER	1
	55-7698	LOCKWASHER	4
	55-7031	FLATWASHER	3
5	41-2208	TAP - thermo bus	1
	55-7367	NUT	5
	55-7370	LOCKWASHER	7
6	41-2209	TERMINATOR	1
7	91-8661	BRACKET - emergency bypass	1
8	41-2210	PC BOARD - emergency bypass	1
	99-7849	STRIP - gasket (25 ft)	A/R
	55-8723	SCREW - bracket	4
9	91-8538	NAMEPLATE - emergency bypass	1
10	45-1711	MODULE - mP-D output	1
11	41-2446	CONTACTOR	8
12	44-8813	INTERLOCK	2
13	41-2520	SPACER - contactor	2
14	41-2401	MODULE - current sense	1
15	41-2521	BREAKER - circuit	1
16	91-8204	RAIL - din	1
	55-7862	SCREW - rail	6
	55-7369	LOCKWASHER	2
	55-7697	FLATWASHER	2
17	41-2690	HARNESS - contactor	1
18	41-2319	CONNECTOR - receptacle (12 pin)	1
19	99-6093	MOUNT - cable tie	2
	55-2864	RIVET - mount	2
	55-2332	BANDWRAP	18
20	91-8737	BLOCK - grounding	4
21	41-2689	HARNESS - output module	1
22	41-2407	• PLUG (35 pin)	1
23	41-2493	• PLUG (12 socket)	1
24	41-2492	CONNECTOR - receptacle (16 pin)	1




Revised 7/9/02

HIGH VOLTAGE TRAY - HUMIDITY (OPTION 098036)




REF	PART#	DESCRIPTION	QTY
25	41-2249	• PLUG (3 socket)	1
26	41-2689	HARNESS - output module	1
27	41-2495	CONNECTOR - plug (6 socket)	1
	41-2494	CONNECTOR - receptacle (6 pin)	1
28	99-7834	NAMEPLATE - Caution	1




HUMIDITY COMPONENTS (OPTION 098100)



REF	PART#	DESCRIPTION	QTY
1	11-9085	COMPRESSOR - humidity	1
2	91-9002	PLATE - compressor	1
3	55-7339	NUT - compressor	4
	55-7085	FLATWASHER	4
4	55-2561	NIPPLE - compressor to nozzle	1
5	11-9084	NOZZLE - liquid spray	1
6	11-4860	ELBOW - hose (1/4)	2
7	10-243	KIT - sleeve & eyelet (1/4)	2
8	11-4841	NUT - hose (1/4)	2
9	11-4367	HOSE - supply & over flow (1/4 od x 35 ft lg)	A/R
10	41-3117	HARNESS - humidity compressor	2
11	41-5635	SENSOR - humidity	1
12	91-9003	FILTER	1
	91-6236	SCREEN	1
	91-6237	ADAPTER - outlet	1
13	55-6905	FITTING - barb (1/2 mpt, poly)	1
14	11-8983	HOSE - drain	2
15	55-9208	CONNECTOR - T-hose	1
16	11-9082	TANK - humidity	1
17	11-9083	CAP - tank	1
18	41-2691	HARNESS - tank heater	1
19	55-9149	SPACER - tank	4
20	55-4359	NIPPLE	1
21	55-7151	DRAIN COCK	1




AIR VENT (40 FT CONTAINERS)



REF	PART#	DESCRIPTION	QTY
	91-8252	VENT - air (complete)	1
1	91-9048	BRACKET - air vent handle	1
2	51-1426	SCREW - handle	1
	51-1474	• SCREW (M8 x 1.25 x 65, ss)	1
	55-9541	WASHER (nylon)	4
	51-1427	• NUT	1
3	91-8100	• SPRING	1
4	92-440	NAMEPLATE - Do Not Open Below 0 C	1
5	91-8102	HANDLE - air vent	1
6	77-2467	BEARING - slide	1
7	91-8104	BRACKET - handle	1
8	51-1428	• NUT	2
	51-1429	• LOCKWASHER	1
	51-1430	• FLATWASHER	1
9	51-1431	• NUT - wing	1
10	91-8103	DISK - air vent	1
11	33-4255	GASKET - air vent	1
12	91-8105	PLATE - air vent	1
	55-7172	SCREW - plate	4
	55-7075	• FLATWASHER	4
	55-9541	WASHER (nylon)	4
13	33-2944	GASKET - air vent	1
14	91-8663	PROTECTOR - edge	1
15	91-8106	• PIN - hinge	1
16	91-8107	NAMEPLATE - Do Not Open Below 0 C	1
17	55-9168	ADAPTER - hose	1
18	92-411	HINGE - air vent	1
	51-619	SCREW - mtg vent	8
	55-8933	WASHER - insulator (6.4 id)	4
	55-7075	FLATWASHER	4
	55-9054	WASHER - insulator (8.4 id)	6
	51-167	FLATWASHER	6
	55-7339	NUT	6






AIR VENT (20 FT CONTAINERS)



REF	PART#	DESCRIPTION	QTY
1	55-7349	SCREW - air vent	1
2	92-240	PLATE - air vent	1
3	33-3214	GASKET - air vent	1
	55-8875	SCREW	6
	55-8893	WASHER	6
	55-8877	WASHER (nylon)	6
4	509-1775	NAMEPLATE - air ventilation	1
5	91-8103	DISK - air vent	1
6	503-270	• GASKET	1
7	55-7342	LOCKWASHER	1
8	55-7825	NUT	2
9	92-242	BEARING - slide	1
10	55-7085	FLATWASHER	1
11	55-8888	NUT - wing	1
12	55-9168	BARB - hose adapter	1
13	55-8886	WASHER (nylon)	1






CONDENSER COMPONENTS (2 EVAPORATOR FANS W/HEATER DOOR)



REF	PART#	DESCRIPTION	QTY
1	91-8195	KEEPER - door latch	2
	55-9312	SCREW - keeper	4
	55-6995	WASHER	4
	55-8933	WASHER (nylon)	4
	55-8877	WASHER (nylon)	4
2	91-8108	BRACKET - frame	1
	55-6993	SCREW - bracket	3
	55-6988	WASHER	6
	55-8882	WASHER (nylon)	6
	55-9380	NUT	3
3	98-6236	PLATE - cable storage (front)	1
	55-9168	NUT	2
	55-9054	WASHER (nylon)	6
	55-6994	SCREW - plate	2
	51-167	FLATWASHER	6
	55-8933	WASHER (nylon)	6
4	Not Used		
5	98-5925	GRILLE - condenser (119, 800 & 800A)	1
	55-6994	SCREW - grille	4
	55-6995	FLATWASHER	4
	55-9054	WASHER (nylon)	6
6	98-6518	DOOR - evaporator (units w/ two evaporator fans)	1
	92-2995	HINGE - evap door	2
	51-620	• RIVET - hinge	8
7	91-8133	• KNOB	2
8	55-7035	• SCREW - door	2
9	91-8199	• SPRING	2
10	55-7354	• NUT	2
11	55-9054	WASHER (nylon)	2
12	91-9041	• LATCH - door	2
	55-2864	• RIVET - latch	4
13	91-8134	INSULATOR - latch	2
14	509-1654	• HINGE	2
	55-7341	• SCREW - hinge	4
	55-8882	WASHER (nylon)	4
15	91-8148	• PIN - hinge (w/ snap)	2
16	98-5199	DOOR - heater section	1
	55-8882	WASHER (nylon)	8
17	98-5291	FRAME - condenser	1
	98-5312	FRAME - condenser (units w/ mPD)	1






CONDENSER COMPONENTS (2 EVAPORATOR FANS W/HEATER DOOR)




REF PART#		DESCRIPTION	QTY	
	98-5920	FRAME - condenser (800 & 800A)	1	
	98-6237	FRAME - condenser (800B)	1	
	98-5359	FRAME - condenser (w/ purge port)	1	
	98-5332	FRAME - condenser (CRR 20)	1	
	98-6658	FRAME - condenser (800E)	1	
	98-5450	FRAME - condenser (C/atmosphere, option 098074)	1	
	98-6658	FRAME - condenser (800E)	1	
18	33-3001	GASKET - evaporator door	1	
19	33-3002	GASKET - door	1	
20	33-2983	GASKET - unit	1	
21	91-8728	COVER (instead of thermometer)	1	
	55-8891	SCREW - cover	3	
	55-6988	FLATWASHER	3	
22	91-8664	PLATE - guard	1	
	55-7341	SCREW - plate (20 mm)	2	
	55-6993	SCREW - plate (25 mm)	1	
	55-6988	FLATWASHER	3	
	55-8953	WASHER (nylon)	3	
23	91-9039	HOOK - strap	1	
	55-3065	CLAMP - hook	1	
	55-7341	SCREW - clamp	1	
24	509-937	STRAP - door	1	
	55-9173	SCREW - strap	1	
	55-7089	FLATWASHER	1	
25	98-5479	ORIFICE - condenser	1	
	55-7035	SCREW - orifice	4	
	55-7075	FLATWASHER	4	
	55-3045	WASHER - dome	4	
	55-8849	NUT - captive	4	
26	91-9949	PORT - injection	2	
	55-9211	RIVET - port		
27	91-9950	HOUSING - relief valve	1	
	55-9211	RIVET - housing		
28	91-9951	VALVE - pressure relief		
29	91-9952	PORT - purge		
	55-9211	RIVET - port	2	
30	91-8475	NAMEPLATE - TK	1	



$^{Revised}_{8/13/02}$ CONDENSER COMPONENTS (UNITS w/2 EVAP FANS)




REF	PART#	DESCRIPTION	QTY
1	91-8195	KEEPER - door latch	2
	55-9312	SCREW - keeper (TIR seal)	4
	55-6995	WASHER	4
	55-9054	WASHER (nylon)	4
	55-8877	WASHER (nylon)	4
2	91-8108	BRACKET - frame	1
	55-6993	SCREW - bracket	3
	55-6988	WASHER	6
	55-8882	WASHER (nylon)	6
	55-9380	NUT	3
3	91-9504	PLATE - cable storage (front)	1
	55-9168	NUT	2
	55-9054	WASHER (nylon)	6
	55-6994	SCREW - plate	2
	55-6695	FLATWASHER	6
	55-8933	WASHER (nylon)	6
4	Not Used		
5	98-5925	GRILLE - condenser	1
	55-6994	SCREW - grille	4
	55-6995	FLATWASHER	4
	55-9054	WASHER (nylon)	4
6	98-5477	DOOR - evaporator	1
7	91-9040	KNOB	2
8	55-7035	SCREW - door	2
9	91-8199	SPRING	2
10	55-7354	NUT	2
11	55-9054	WASHER (nylon)	2
12	91-9041	LATCH - door	2
	55-2864	RIVET - latch	4
13	91-8134	INSULATOR - latch	2
14	509-1654	HINGE	2
	55-9313	SCREW - hinge (TIR seal)	4
	55-8882	WASHER (nylon)	4
15	91-8256	PIN - hinge (w/ snap)	2
16	98-5199	DOOR - heater section	1
	55-6993	SCREW - door	4
	55-9313	SCREW - door (TIR seal)	1
	55-8882	WASHER (nylon)	8
	55-7085	WASHER	8
17	98-5478	FRAME - condenser	1
	98-5701	FRAME - condenser (atmosphere controlled, option 098134)	1
18	33-3001	GASKET - evaporator door	1



$^{Revised}_{8/13/02}$ CONDENSER COMPONENTS (UNITS w/2 EVAP FANS)




REF	PART#	DESCRIPTION	QTY
19	33-3002	GASKET - door	1
20	33-2983	GASKET - unit	1
21	91-8728	COVER (instead of thermometer)	1
	55-7391	SCREW - cover	3
	55-6988	FLATWASHER	3
22	91-8664	PLATE - guard	1
	55-7341	SCREW - plate (20 mm)	2
	55-6993	SCREW - plate (25 mm)	1
	55-8953	WASHER (nylon)	3
23	91-9039	HOOK - strap	1
	55-3065	CLAMP - hook	1
	55-9166	SCREW - clamp	1
24	509-937	STRAP - door	1
	55-9173	SCREW - strap	1
	55-7089	FLATWASHER	2
25	91-9912	ORIFICE - condenser	1
	55-7035	SCREW - orifice	4
	55-7075	FLATWASHER	4
	55-3045	WASHER - dome	4
	55-8849	NUT - captive	4
26	91-9949	PORT - injection (option 098134)	2
	55-9211	RIVET - port	4
27	91-9950	HOUSING - relief valve (option 098134)	1
	55-9211	RIVET - housing	4
28	91-9951	VALVE - pressure relief (option 098134)	1
29	91-9952	PORT - purge (option 098133)	1
	55-9211	RIVET - port	2
30	83-257	GROMMET	2
31	91-9511	NAMEPLATE - TK	1





REF	PART#	DESCRIPTION	QTY
1	91-8098	RETAINER - probe	1
2	509-964	CAP - retainer (w/o hole)	1
3	91-8702	CAP - retainer (w/ hole)	1
4	33-2960	GASKET - retainer	1
5	91-9754	POCKET - sensor	1
6	55-6409	CONNECTOR - sensor	1
7	91-9754	POCKET - sensor	2




Revised 9/24/01

REDUNDANT SENSORS (OPTION 098080)




REF	PART#	DESCRIPTION	QTY
1	91-8702	CAP - retainer (w/ hole)	1
	33-2960	GASKET	1
2	41-3063	SENSOR - redundant (see 112D9 for connectors)	2
3	33-3215	GROMMET (47 mm)	1
4	55-2239	CLAMP - sensor	1
	55-6994	SCREW - clamp	1
	55-7075	FLATWASHER	1
	55-7042	NUT	1
5	91-9268	BRACKET - sensor	1
	55-9206	SCREW - bracket	1
6	41-2831	HARNESS - redundant sensor	1



EVAPORATOR PANELS (UNITS w/3 EVAP FANS)



REF	PART#	DESCRIPTION	QTY
1	91-8258	PLATE - rear (bottom)	1
	98-5556	PLATE - rear (bottom, SL units)	1
	55-2264	RIVET - plate	36
2	98-5335	PLATE - rear (top)	1
	98-5555	PLATE - rear (top, SL units)	1
	55-8937	SCREW - plate	26
3	98-5200	GRILLE - evaporator (CRR 40 & CSR 40)	1
	91-8627	GRILLE - evaporator (CSR 40SL)	1
	509-1766	GRILLE - evaporator (CRR 20)	1
	55-2264	RIVET - grille	17
4	98-5925	CHANNEL - Z (CRR 40 & CSR 40)	3
	509-1772	CHANNEL - Z (CSR 40 SL)	3
	55-9055	RIVET - channel	21
5	33-2983	GASKET - unit	1
6	91-8760	PANEL - USDA receptacle (CSR 20 & 40 SL)	1
	91-8645	PANEL - USDA receptacle (CRR 40 & CSR 40)	1
	55-9055	RIVET - panel	4
7	41-2405	CONNECTOR - receptacle (5 pin)	1
	41-2575	HARNESS - adapter (cannon bayonet connector)	1
	41-2576	HARNESS - adapter (cannon threaded connector)	1
	55-8382	SCREW - receptacle	4
	55-8410	FLATWASHER	8
	55-7864	NUT	4
8	41-2406	CAP - dust	1
9	99-3685	CHAIN - cap	5
10	41-2541	RECEPTACLE (3 pin)	4
	55-2262	RIVET - receptacle	16
	55-8410	FLATWASHER	16
11	44-9602	PIN - sealing	5
12	41-890	CAP - dust	4
13	91-8135	CHANNEL - air (CRR-40 & CSR-40)	1
	509-1762	CHANNEL - fresh air (CSR 40 SL)	1
	203-389	SEALER - polyurethane	A/R
	55-8891	SCREW - channel	6
14	91-8141	INLET - fresh air	1
	55-2270	RIVET - inlet	10
	203-389	SEALER - polyurethane	A/R
15	91-8136	CHANNEL - fresh air (CRR 40 & CSR 40)	1
	509-1764	CHANNEL - fresh air (CRR 20)	1
	55-2270	RIVET - channel	8
16	91-8734	NAMEPLATE - USDA Connections	1




Revised 10/27/03

EVAPORATOR PANELS (UNITS w/3 EVAP FANS)



REF	PART#	DESCRIPTION	QTY
17	41-3107	SENSOR - USDA (options 098078, 098109 & 098126, 14 m lg)	2




EVAPORATOR PANELS (UNITS w/2 EVAP FANS)



REF	PART# DESCRIPTION		QTY
1	509-557	PLATE - rear (bottom)	1
	55-2264	RIVET - plate	36
2	509-473	PLATE - rear (top)	1
	55-8937	SCREW - plate	26
3	98-5480	GRILLE - evaporator	1
	98-5523	GRILLE - evaporator (Transfresh)	1
	55-2264	RIVET - grille	17
4	91-8097	CHANNEL - Z (CSR 40)	1
	509-1772	CHANNEL - Z (CSR 40 SL)	3
	55-9055	RIVET - channel	21
5	33-2983	GASKET - unit	1
	91-8645	PANEL - USDA receptacle (CRR 40)	1
6	91-8760	PANEL - USDA receptacle (CRR 20)	1
	55-9055	RIVET - panel	4
7	41-2405	CONNECTOR - receptacle (5 pin)	1
	41-2575	HARNESS - adapter (cannon bayonet connector)	1
	41-2576	HARNESS - adapter (cannon threaded connector)	1
	55-8382	SCREW - receptacle	4
	55-8410	FLATWASHER	8
	55-7864	NUT	4
8	41-2406	CAP - dust	1
9	99-3685	CHAIN - cap	5
10	41-890	RECEPTACLE (3 pin)	4
	55-2262	RIVET - receptacle	16
	55-8410	FLATWASHER	16
11	44-9602	PIN - sealing	5
12	41-2539	CAP - dust	4
13	91-9329	CHANNEL - air	1
	203-389	SEALER - polyurethane	A/R
	55-8891	SCREW - channel	6
14	91-9330	INLET - fresh air	1
	55-2270	RIVET - inlet	10
	203-389	SEALER - polyurethane	A/R
15	91-9331	CHANNEL - fresh air	1
	55-2270	RIVET - channel	8
16	91-8734	NAMEPLATE - USDA Connections	1
17	41-3107	SENSOR - USDA (option 098078)	2





REF	PART#	DESCRIPTION	QTY
1	91-8244	BRACKET - hose	1
2	99-3281	MOUNT - cable tie	5
	55-2260	RIVET - anchor	5
3	55-2686	CLAMP - hose	2
4	55-8891	SCREW - bracket	2
5	55-9208	CONNECTOR - T-hose	1
6	55-2330	BANDWRAP	6
7	11-8983	HOSE - flex	1







RMO KING **INGERSOLL**RAND

CAUTION

COMPRESSOR MAY SOFT START 3 ON/OFF CYCLES REFERENCE SERVICE MANUAL

PN: 1B16660H01





R 134a

4

CLOSED

CO2 ADAPTER

8 10 m³/h N 15 m³/h 9 CPM

BE 35 m²/h =

50 m³/h 30 CPM

12

DATALOGGER RECEPTACLE

RETRIEVER PLUG CARGO SENSOR USDA SENSOR USDA SENSOR NO. 2

USDA SENSOR NO. 3

14

OPEN

◆ USDA #1/ SPARE 1

USDA #2/ SPARE 2

WARNING

WARNING Hot Components Compressor discharge may be hot!

WARNING FANS START AUTÖMATICALLY

TRANSFRESH SCRUBBER CONNECTOR A 5

TRANSFRESH DATA CONNECTOR





DATALOGGER RECEPTACLE RETRIEVER PLUG CARGO SENSOR

DO NOT

18

OPEN BELOW 0°C 32°F 150 m³/h 90 CFM 225 m³/h 135CFM 280 m³/h 165CFM

PART NO: 3810016H01 3B10016H01 REV.C

11


PULP/ SPARE S

USDA #3/ SPARE 3

13

REF	PART#	DESCRIPTION	QTY
1	91-8665	NAMEPLATE - Smart Reefer	1
2	91-8756	NAMEPLATE - Thermo King	1
3	91-8475	NAMEPLATE - TK (crest)	1
4	91-6609	NAMEPLATE - Refrigerant R134a	1
5	91-8694	NAMEPLATE - Warning, Fan Start	1
6	91-8695	NAMEPLATE - Warning, Hot Components	1
7	91-7475	NAMEPLATE - Caution Compressor	1
8	91-8738	NAMEPLATE - Operating Instructions	1
9	91-8697	NAMEPLATE - Transfresh Data A3	1
10	91-8696	NAMEPLATE - Transfresh Scrubber A5	1
11	509-1150	NAMEPLATE - Air Vent	1
12	91-9441	NAMEPLATE - Air Vent Handle	1
13	91-8734	NAMEPLATE - USDA Connections	1
14	509-1157	NAMEPLATE - USDA Sensors	1
15	91-8746	NAMEPLATE - Ingersoll Rand (black letters)	1
	91-9043	NAMEPLATE - Ingersoll Rand (white letters)	1
16	91-8589	NAMEPLATE - Control Box Layout	1
17	91-8755	NAMEPLATE - Temperature Conversion	1
18	91-8964	NAMEPLATE - Datalogger	1
19	91-9498	NAMEPLATE - Consult	1








PRECAUCION Componentes Callentes La descarga del Compresor podra estar callentel



2



CONEXION DEL RECOLECTOR

SENSOR DE CARGA

SENSOR USDA
NO. 1

SENSOR USDA
NO. 2

SENSOR USDA
NO. 3

작동 지침서는 콘트롤 박스안에 있습니다.

5

"Instrucciones de Operación Localizadas en el interior de la CASA de CONTROL"

6

El cable guía Simpson Del Termistor se encuentra localizado en el suministro de aire

9

<u>시작됩니다.</u> 7

경고

팬은 자동으로



PRECAUCION
LOS VENTILADORES ENCIENDEN
AUTOMATICA MENTE



8

Revised 3/20/00

NAMEPLATES - LANGUAGE (OPTION 098075)



REF	PART#	DESCRIPTION	QTY
1	91-8843	NAMEPLATE - Compressor Hot (Korean)	1
2	91-9063	NAMEPLATE - Compressor Hot (Spanish)	1
3	91-8925	NAMEPLATE - Datalogger (Korean)	1
4	91-9062	NAMEPLATE - Datalogger (Spanish)	1
5	91-8840	NAMEPLATE - Operating Instructions (Korean)	1
6	91-9061	NAMEPLATE - Operating Instructions (Spanish)	1
7	91-8842	NAMEPLATE - Warning, Fan (Korean)	1
8	91-9060	NAMEPLATE - Warning, Fan (Spanish)	1
9	91-9066	NAMEPLATE - Simpson lead (Spanish)	1

02-7043	30	33-3002	108, 112	41-2329	66
10-243	100	33-3007	20, 24, 38, 40	41-2399	22, 44
102-673	28	33-3008	68, 74	41-2401	50, 96
104-639	44	33-3043	10, 86	41-2402	56, 64
104-677	10	33-3044	16, 18	41-2403	64
104-689	12, 46	33-3175	30	41-2405	56, 118, 122
104-691	14, 16, 18, 44, 46	33-3212	36	41-2406	48, 118, 122
11-4367	100	33-3214	104	41-2407	50, 96
11-4841	100	33-3215	14, 16, 18, 116	41-2446	50, 96
11-4860	100	33-3513	28	41-2447	28, 30, 44, 46
11-8983	100, 124	33-367	10, 12, 16	41-2492	50, 96
11-9082	100	33-3838	14, 16, 18	41-2493	50, 66, 96
11-9083	100	33-4255	102	41-2494	50, 98
11-9084	100	33-451	68, 74	41-2495	50, 98
11-9085	100	33-768	38	41-2503	44, 46
203-180	72, 78	33-981	28, 30	41-2517	44, 48, 56
203-389	118, 122	40-534	84	41-2518	48, 56
203-392	48, 52	40-871	44, 46	41-2519	56, 66
203-439	52	41-1091	64	41-2520	50, 96
203-516	28, 30	41-1092	64	41-2521	50, 96
203-525	84	41-1126	64	41-2522	50
204-1038	62	41-1127	64	41-2524	56, 66
204-209	80	41-1129	64	41-2537	86
204-623	58	41-1230	64	41-2538	86
204-624	58	41-1266	94	41-2539	122
204-703	62	41-1292	54	41-2541	118
204-799	62	41-1310	58	41-2543	54
204-918	48	41-1527	58	41-2554	88, 90
22-1051	28, 30	41-1626	28	41-2555	88, 90
22-1099	30	41-182	64, 66	41-2556	82
22-1033	28	41-1932	54	41-2575	118, 122
22-1186	28, 30	41-1946	56, 66	41-2576	118, 122
22-398	28, 30	41-1947	66	41-2603	32, 44, 46
304-2642	64	41-1950	66	41-2629	94
304-2786	64	41-1951	66	41-2689	50, 96, 98
33-1015	38	41-1952	66	41-2690	50, 96
33-1435	48	41-1976	44, 46	41-2691	100
33-2222	28, 30	41-1977	92	41-2701	50
33-2392	60	41-2129	50, 96	41-2716	28, 44, 46
33-2393	60	41-2170	48	41-2820	44
33-2394	60	41-2208	50, 96	41-2831	116
33-2395	60	41-2209	50, 96	41-2838	42
33-2396	60	41-2210	50, 96	41-2953	10
33-2397	60	41-2216	72	41-3063	116
33-2482	92	41-2218	72	41-3083	92
33-2510	28, 30	41-224	56, 64	41-3107	120, 122
33-2545	34	41-2247	56	41-3112	14, 44
33-2548	28, 30	41-2248	56, 66	41-3113	18, 46
33-2630	82	41-2249	50, 56, 98	41-3114	18, 46
33-2753	48	41-225	56, 64	41-3115	46
33-2944	102	41-2319	50, 56, 66, 96	41-3116	12, 44, 46
33-2946	14, 16, 18	41-2320	66	41-3117	100
33-2949	24	41-2321	66	41-3277	16
	12				
33-2950		41-2322	60	41-3301	20, 24, 26, 42, 44, 46
33-2960	80, 114, 116	41-2323	60	41-3302	30
33-2962	72	41-2324	60	41-3303	26, 42, 46
33-2981	52	41-2325	60	41-3342	46
33-2983	108, 112, 118, 122	41-2326	60	41-3429	92
33-3001	108, 110	41-2327	60	41-3685	16

44 0704	20	44.0040	4.4	45 4004	74 70
41-3701	30	44-8340	14	45-1831	74, 78
41-4018	16	44-8532	64	45-1832	74, 78
41-4021	44, 46	44-8533	64	45-1834	68
41-4208	94	44-8534	64	45-1853	50
41-4347	66	44-8535	64	45-1859	92
41-4352	64, 66	44-8537	64	45-237	44, 46
41-4353	64	44-8538	64	502-240	28, 30
41-4354	64	44-8539	64, 66	503-120	10
41-4355	64	44-8542	64	503-230	28
41-5420	32	44-8543	64	503-270	104
41-5635	42, 46, 100	44-8681	58	503-278	28, 30
41-5652	64, 66	44-8779	56, 64	503-291	32, 44
41-743	56, 64	44-8783	64	504-1418	20
41-744	56, 64	44-8813	50, 96	504-246	28
41-745	56	44-8851	58	504-977	20
41-746	64	44-8853	58	504-980	32, 44, 46
41-747	56, 64	44-8914	60	505-390	78
41-748	56	44-8915	60	505-603	20, 24
41-890	118, 122	44-8917	60	505-606	20, 24
41-896	82	44-8918	60	506-161	28, 30
44-2339	72	44-8920	60	506-165	28
	72		60	506-103	20
44-2966		44-8921			44
44-3828	92	44-8935	60	506-329	
44-5114	80	44-8936	60	506-364	20, 24, 40
44-5133	92	44-9226	64	506-369	20, 24
44-5534	84	44-9343	64	506-370	20, 24
44-5537	82	44-9359	54	506-374	20
44-5644	72	44-9524	54	506-375	20
44-5835	58, 84	44-9536	60	506-388	38
44-5836	58	44-9544	60	508-165	14
44-5837	58	44-9545	60	509-1150	126
44-5838	58	44-9569	58	509-1153	28, 30
44-5839	58	44-9585	60	509-1157	126
44-5883	58	44-9586	60	509-1635	20, 24
44-5884	58	44-9587	60	509-1654	106, 110
44-5885	58	44-9589	60	509-1762	118
44-6310	44	44-9590	60	509-1763	44
44-6324	58	44-9591	60	509-1764	118
44-6360	30	44-9600	60	509-1766	118
44-6381	94	44-9601	60	509-1767	44
44-6560	48	44-9602	60, 118, 122	509-1772	118, 122
44-6591	84	44-9631	60	509-1775	104
44-6822	82	44-9700	60	509-473	122
44-6952	44, 46	44-9701	60	509-557	122
44-6959	58	44-9780	78	509-911	78
44-7327	58	44-9781	78	509-912	78
44-7330	58	44-9891	44	509-937	108, 112
44-739	48	44-9900	60	509-964	114
44-7782	78	44-9901	60	51-1426	102
44-7811	58	44-9902	60	51-1427	102
44-7812	58	44-9903	60	51-1428	102
44-7829	58	44-9904	60	51-1420	102
44-7872	58	44-9905	60	51-1429	102
	58		60		102
44-7880		44-9906		51-1431 51 1474	
44-7881	58 59	44-9907 45-1711	62	51-1474 51-167	102
44-7884	58	45-1711 45-1701	96	51-167	102, 106
44-8294	58	45-1791	44, 46	51-619	102
44-8318	64	45-1806 45-1820	50, 54, 96	51-620	106
44-8331	64	45-1830	68, 72, 74	55-1203	42

55-1827	38, 40	55-7034	52, 68, 74, 84	55-8849	108, 112
55-2001	92	55-7035	10, 12, 48, 84, 106, 108,	55-8875	104
55-2159	28, 30		110, 112	55-8877	84, 104, 106, 110
55-2173	28, 30	55-7042	38, 48, 52, 92, 116	55-8882	106, 110
55-2239	116	55-7066	14, 16, 18	55-8886	104
55-2260	124	55-7075	16, 38, 44, 46, 48, 52,		104
55-2262	118, 122	00 1010	92, 102, 108, 112, 116	55-8891	14, 16, 18, 20, 24, 44,
		EE 700E		33-0091	
55-2264	86, 118, 122	55-7085	16, 18, 36, 38, 92, 100,		46, 92, 108, 118, 122,
55-2270	118, 122	FF 7000	104, 110	FF 0000	124
55-2296	22, 26	55-7089	108, 112	55-8893	10, 40, 46, 104
55-2299	22	55-7151	100	55-8903	14, 16, 18
55-2324	14	55-7169	68, 74, 76	55-8904	10, 14, 16, 18, 40
55-2330	124	55-7170	44, 46, 52, 92	55-8907	10, 14, 18
55-2332	50, 96	55-7172	16, 44, 46, 68, 74, 92,	55-8908	10, 12, 14, 18
55-2363	48, 52		102	55-8910	12, 24
55-2505	30	55-7339	16, 18, 100, 102	55-8911	30
55-2561	100	55-7340	68, 74	55-8912	30
55-2636	92	55-7341	14, 68, 74, 92, 106, 108,	55-8933	38, 102, 106, 110
55-2641	48		112	55-8937	118, 122
55-2686	124	55-7342	10, 12, 16, 18, 38, 40,		20, 24
55-2747	28, 30		92, 104	55-8950	20, 22, 24
55-2864	50, 96, 106, 110	55-7344	44, 46, 92	55-8951	20, 22, 24
55-2964	92	55-7349	104	55-8953	68, 74, 108, 112
55-2976	30	55-7354	68, 74, 106, 110	55-8955	72
	68, 74	55-7357			54, 96
55-2988			44, 46, 92	55-8987	42
55-2995	92	55-7360	28	55-8991	
55-3008	84	55-7367	84, 96	55-8992	30
55-3045	12, 108, 112	55-7368	48, 84	55-8993	40
55-3065	108, 112	55-7369	50, 94, 96	55-9029	48, 52
55-3295	38	55-7370	52, 84, 96	55-9030	56
55-3490	28	55-7391	112	55-9037	28
55-4359	100	55-7404	68, 74, 76	55-9043	36
55-4390	24	55-7464	74	55-9054	10, 12, 24, 38, 46, 48,
55-459	30	55-7479	84		102, 106, 110
55-5025	28	55-7617	56, 64	55-9055	118, 122
55-5099	72	55-7618	56, 64	55-9057	82
55-5111	84	55-7665	48, 84	55-9149	100
55-5257	28, 30, 48	55-7691	40	55-9161	38
55-5639	38, 40	55-7697	50, 94, 96	55-9162	16, 18
55-5900	12, 16, 48	55-7698	50, 96	55-9164	44, 46, 92
55-5919	92	55-7713	88, 90	55-9165	36
55-6147	48, 52	55-7748	52	55-9166	112
55-6218	20, 24	55-7749	82	55-9168	38, 102, 104, 106, 110
55-6409	44, 114	55-7752	84	55-9173	42, 108, 112
55-6695	38, 110	55-7825	104	55-9174	82
55-6730	38	55-7830	36	55-9195	54, 96
55-6905	100	55-7843	20, 24	55-9206	116
55-6988	10, 12, 14, 68, 74, 106,		48, 50, 94, 96	55-9208	100, 124
FF 0000	108, 110, 112	55-7864	118, 122	55-9211	108, 112
55-6993	10, 12, 14, 16, 18, 36,		46	55-9217	16, 18
FF 000.4	38, 106, 108, 110, 112	55-8382	36, 82, 118, 122	55-9312	106, 110
55-6994	38, 48, 52, 84, 106, 110,		54, 82, 96, 118, 122	55-9313	110
	116	55-8456	34	55-9380	10, 12, 14, 106, 110
55-6995	12, 24, 68, 74, 84, 92,		34	55-9444	68, 74
	106, 110	55-8464	38	55-9541	102
55-6996	68, 74, 84	55-8661	56	60-285	12, 20, 24
55-6997	12, 84	55-8662	56	61-143	24
55-7031	96	55-8720	68, 74, 84	61-144	24
55-7033	52, 68, 74, 76, 84	55-8723	50, 96	61-145	24

61-146	26	66-9285	22	01 9106	102
61-147	26		24	91-8106	102
61-148		66-9307	30	91-8107	
	26	66-9377		91-8108	106, 110
61-149	24 24	66-9842	40 24	91-8133	106
61-150		66-9866		91-8134	106, 110
61-151	24	66-9868	26	91-8135	118
61-152	24	66-9873	40	91-8136	118
61-154	36	66-9875	40	91-8140	44, 46
61-155	40	66-9893	24	91-8141	118
61-726	20, 24	66-9894	24	91-8142	44, 46
61-727	20	66-9900	22, 26	91-8147	50, 96
66-1845	28	67-1517	20	91-8148	106
66-2170	38	67-1531	38	91-8195	106, 110
66-2457	28	67-1532	22	91-8199	106, 110
66-4687	38	67-1558	16, 18, 26	91-8204	50, 96
66-4788	38, 40	67-1614	22	91-8217	72
66-6603	38	67-1650	24	91-8244	124
66-6607	28, 30	67-1651	24	91-8252	102
66-6610	22, 28, 30, 38	67-1652	40	91-8256	52, 110
66-7031	34	67-1923	16	91-8258	118
66-7182	28, 30, 38	77-1401	14, 16, 44	91-8415	54, 96
66-7183	30	77-1498	14, 16, 44	91-8466	14, 16, 18
66-7392	38	77-2467	102	91-8467	44, 46
66-8054	30	78-1078	14	91-8475	108, 126
66-8467	20, 24	78-1101	14	91-8538	50, 96
66-8473	20	78-1117	16, 18	91-8553	48
66-8767	20	78-1167	10	91-8589	48, 126
66-8811	20, 24, 40	78-1173	12	91-8620	20, 24
66-8849	20	78-1196	14	91-8627	118
66-9032	22	8102-743	20, 24, 28, 30, 44, 46	91-8645	118, 122
66-9035	26	83-257	112	91-8658	52
66-9062	22, 26	845-1949	52	91-8659	48, 52
66-9069	20	91-2205	72	91-8660	56
66-9071	20, 24	91-3238	92	91-8661	50, 96
66-9072	22	91-4218	68, 74	91-8662	50, 94, 96
66-9073	20	91-4219	68, 74	91-8663	102
66-9075	22, 26	91-4220	68, 76	91-8664	34, 108, 112
66-9081	20	91-445	40	91-8665	126
66-9082	20	91-5005	68, 74	91-8672	48
66-9084	22	91-5006	68, 74	91-8693	48
66-9085	20	91-5007	68, 74	91-8694	126
66-9087	22	91-6202	84	91-8695	126
66-9125	20	91-6205	84	91-8696	126
66-9148	22	91-6236	100	91-8697	126
66-9149	28	91-6237	100	91-8701	34
66-9150	28	91-6435	30	91-8702	80, 114, 116
66-9159	42	91-6609	126	91-8703	80
66-9163	20, 24, 32	91-6627	38, 40	91-8705	68, 74
66-9164	22, 26	91-6628	38, 40	91-8707	68, 74
66-9165	22	91-6988	44, 46, 92	91-8708	68, 74
66-9166	22	91-7475	126	91-8709	70, 74
66-9167	20	91-759	40	91-8710	84
66-9168	20	91-8097	122	91-8711	84
66-9170	34	91-8098	114	91-8712	84
66-9194	36	91-8100	102	91-8713	84
66-9210	22, 26	91-8102	102	91-8714	84
66-9214	20	91-8103	102, 104	91-8715	86, 88, 90
66-9282	38	91-8104	102	91-8716	52
66-9283	38	91-8105	102	91-8717	56

```
91-8718
            56
                                     92-2775
                                                  16
91-8719
            56
                                                  16
                                     92-2779
91-8725
            68, 74
                                     92-2995
                                                  106
            70, 76
                                                  102
91-8726
                                     92-411
            108, 112
91-8728
                                                  102
                                     92-440
91-8734
            118, 122, 126
                                     98-5199
                                                  106, 110
91-8737
            50, 96
                                     98-5200
                                                  118
91-8738
            52, 126
                                                  106
                                     98-5291
91-8746
            126
                                                  106
                                     98-5312
91-8755
            126
                                                  86, 88
                                     98-5320
91-8756
            126
                                                  108
                                     98-5332
91-8760
            118, 122
                                     98-5335
                                                  118
91-8762
            36
                                     98-5359
                                                  108
            128
                                                  14
91-8840
                                     98-5403
91-8842
            128
                                     98-5443
                                                  48
91-8843
            128
                                                  108
                                     98-5450
91-8925
            128
                                                  16, 18
                                     98-5475
91-8964
            126
                                     98-5477
                                                  110
91-9002
            100
                                     98-5478
                                                  110
91-9003
            100
                                                  108
                                     98-5479
91-9038
            38, 40
                                     98-5480
                                                  122
            108, 112
                                                  90, 122
91-9039
                                     98-5523
91-9040
                                     98-5555
                                                  118
            110
91-9041
            106, 110
                                     98-5556
                                                  118
91-9043
            126
                                     98-5701
                                                  110
91-9048
            102
                                     98-5768
                                                  16
91-9060
            128
                                     98-5918
                                                  16
91-9061
            128
                                     98-5919
                                                  16
91-9062
            128
                                     98-5920
                                                  108
91-9063
            128
                                     98-5925
                                                  10, 106, 110, 118
91-9066
            128
                                     98-6213
                                                  16
91-9268
                                                  106
            116
                                     98-6236
91-9328
            16, 18
                                                  108
                                     98-6237
91-9329
                                                  106
            122
                                     98-6518
91-9330
            122
                                                  16
                                     98-6657
91-9331
            122
                                     98-6658
                                                  108
91-9441
            126
                                     98-7209
                                                  68, 74
            126
                                                  124
91-9498
                                     99-3281
91-9504
            110
                                                  48, 118, 122
                                     99-3685
91-9505
            38
                                                  14, 16, 18
                                     99-4931
91-9508
            92
                                     99-5966
                                                  12
91-9511
            112
                                     99-6093
                                                  48, 50, 96
91-9754
            114
                                     99-6968
                                                  84
91-9761
            48
                                                  68, 74
                                     99-7230
91-9762
            48
                                                  98
                                     99-7834
91-9912
            12, 112
                                     99-7849
                                                  50, 96
91-9949
            108, 112
                                                  52
                                     99-8151
91-9950
            108, 112
                                     99-8162
                                                  52
91-9951
            108, 112
                                     99-8562
                                                  84
            108, 112
                                     99-8986
                                                  84
91-9952
92-1682
            30
92-179
            52
92-206
            82
92-2208
            14
92-2209
            14
92-2331
            16, 18
92-2332
            16, 18
92-240
            104
            104
92-242
```

INDEX NUMERICAL BY PART NUMBER

A	CAP - connector 64	COVER - recorder 68, 74
ACTUATOR 32	CAP - discharge valve 28, 30	COVER - strain relief 66
ADAPTER 30, 34	CAP - dust 48 , 64 , 82 , 118 , 122	COVER - tube 16
ADAPTER - discharge 28, 30	CAP - dust cover 38, 40	_
ADAPTER - hose 102	CAP - fitting 30	D
ADAPTER - outlet 100	CAP - probe 80	DEHYDRATOR 20, 24
ADAPTER - service 22 , 28 , 30 , 40	CAP - retainer 114, 116	DISK - air vent 102, 104
ANGLE - lifting 30	CAP - screw 18	DOOR - assembly 86
,g • •	CAP - suction valve 28	DOOR - control box 52
В	CAP - tank 100	DOOR - evaporator 106, 110
BANDWRAP 50 , 96 , 124	CAP - tube 16	DOOR - heater section 106, 110
BARB - hose adapter 104	CAP - valve 38	DRAIN COCK 100
BATTERY 84	CHAIN - cap 48, 118, 122	DRIVE - chart 72
BATTERY - lithium 52	CHANNEL - air 118, 122	
BEARING - opposite end 14, 16, 44	CHANNEL - fresh air 118, 122	E
BEARING - shaft end 14 , 16 , 44	CHANNEL - Z 118, 122	ELBOW 22, 30
BEARING - slide 102 , 104	CHARGER - battery 84	ELBOW - hose 100
BEZEL - controller 52	CHART 72, 78	ELEMENT 78
BLOCK - coil 16, 18	CLAMP 56 , 64	ELEMENT - thermo 72
•	CLAMP - cable 56, 64	EXTRUSION 10
BLOCK - grounding 50 , 96	CLAMP - dehydrator 20, 24	
BOARD - terminal 84	CLAMP - harness 48, 52	F
BOOT - switch 48	CLAMP - hook 108 , 112	FAN - condenser 10, 12
BOX - battery charger 84	CLAMP - hose 124	FAN - evaporator 14, 16, 18
BOX - control 44, 46, 48	CLAMP - sensor 42 , 116	FILTER 20, 100
BOX - junction 30	CLAMP - tube 38, 40	FITTING - barb 100
BOX - recorder 68, 74	COIL 20 , 26 , 42 , 44 , 46	FITTING - charge port 38
BOX - Transfresh 86 , 88 , 90	COIL - condenser 12, 20, 24	FITTING - charge port 36
BRACKET - air vent handle 102	COIL - dehumidifier 46	FITTING - namess 26, 30
BRACKET - battery 84	COIL - defiditioner 40 COIL - evaporator 16, 18, 22, 26	FITTING - service 26, 30
BRACKET - battery charger 84	- · · · · · · · · · · · · · · · · · · ·	
BRACKET - cable 92	COIL - KVQ 44, 46	FLANGE - suction 30
BRACKET - cable restraint 44, 46, 92	COIL - liquid line valve 22, 44	FLATWASHER 10, 12, 14, 16, 18, 24,
BRACKET - emergency bypass 50, 96	COIL - only 24	28, 30, 36, 38, 40, 44,
BRACKET - frame 106 , 110	COLLAR 26	46, 48, 50, 52, 54, 68,
BRACKET - gauge 36	COLLAR 28	74, 76, 82, 84, 92, 94,
BRACKET - handle 102	COMPRESSOR 20, 24, 28, 30, 44, 46	96, 100, 102, 104, 106,
BRACKET - heater 44, 46	COMPRESSOR - humidity 100	108, 110, 112, 116, 118,
BRACKET - hose 124	CONNECTOR 56 , 60 , 94	122
BRACKET - latch 68, 74	CONNECTOR - grip 92	FRAME - condenser 106 , 108 , 110
BRACKET - lead 80	CONNECTOR - harness 14, 48, 56, 84	FUSE 54
BRACKET - left 16, 18	CONNECTOR - harness grip 84	C
BRACKET - motor 14 , 16 , 18	CONNECTOR - harness & sensor 16,	G
BRACKET - motor mount 14	18	GASKET 10, 12, 20, 24, 32, 40, 80,
BRACKET - power module 50, 96	CONNECTOR - plug 50 , 56 , 64 , 66 , 98	104, 116
BRACKET - right 16, 18	CONNECTOR - probe holder 44	GASKET - adapter/suction 28, 30
BRACKET - sensor 116	CONNECTOR - receptacle 50 , 56 , 64 ,	GASKET - air vent 102 , 104
BRACKET - sight glass 20	66, 96, 98, 118, 122	GASKET - coil 24
BRACKET - tube 38, 40	CONNECTOR - sensor 114	GASKET - cover 68 , 74
BRACKET - valve 24	CONNECTOR - T-hose 100 , 124	GASKET - cylinder head 28, 30
BREAKER - circuit 50, 96	CONNECTOR - tower 58	GASKET - discharge 30
BUSHING - plug 92	CONTACTOR 50 , 96	GASKET - door 52 , 108 , 112
- 1 - 3 -	CONTROLLER - mP-D 52	GASKET - evaporator door 108, 110
C	COUPLING 28	GASKET - gauge 36
CABLE - compressor 30	COUPLING - outlet 38, 40	GASKET - indicator 38
CABLE - compressor power 28, 44, 46	COUPLING - pressure switch 38	GASKET - KVQ 44
CABLE - compressor power 23 , 44 , 46	COUPLING - switch 30	GASKET - retainer 114
CABLE - power 44 , 46 , 92 CABLE - Transfresh 88 , 90	COVER 108, 112	GASKET - rub strip 86
CAP - adapter 28, 30	COVER - box 84	GASKET - sight glass 28, 30
CAP - charge port 38	COVER - control box 48	GASKET - socket 82

GASKET - suction 28	HOSE - supply & over flow 100	NAMEPLATE - Air Vent Handle 126
GASKET - switch 38	HOUSING - evaporator 16	NAMEPLATE - air ventilation 104
GASKET - unit 108, 112, 118, 122	HOUSING - relief valve 108, 112	NAMEPLATE - arrow 14 , 16 , 18
GASKET - valve 28, 30	,	NAMEPLATE - Caution 98
GASKET - valve plate 28, 30	1	NAMEPLATE - Caution Compressor
GAUGE - compound 34	INDICATOR 40	126
GAUGE - suction pressure 36	INDICATOR - liquid 38	NAMEPLATE - Compressor Hot 128
GRILLE - condenser 106, 110	INDICATOR - volt 78	NAMEPLATE - Consult 126
GRILLE - evaporator 86, 88, 90, 118,	INLET - fresh air 118, 122	NAMEPLATE - Control Box Layout 126
122	INSERT - threaded 14	NAMEPLATE - control box layout 48
GRIP - cable 10, 12	INSULATOR 92	NAMEPLATE - controller setup 48
GROMMET 10, 12, 14, 16, 18, 68, 74,	INSULATOR - latch 106, 110	NAMEPLATE - Datalogger 126, 128
112, 116	INTERLOCK 50, 96	NAMEPLATE - Do Not Open Below 0 C
GROMMET - connector 48		102
GUIDE - latch 68, 74	K	NAMEPLATE - emergency bypass 50,
,	KEEPER - door latch 106, 110	96
Н	KEY - fan 14	NAMEPLATE - fuses 54, 96
HANDLE - air vent 102	KEY - winding 72	NAMEPLATE - Ingersoll Rand 126
HANGER - dehydrator 24	KIT - crimper 62	NAMEPLATE - on/off 48
HARNESS 32, 86	KIT - reed suction 28, 30	NAMEPLATE - Operating Instructions
HARNESS - adapter 118, 122	KIT - repair 20	52, 126, 128
HARNESS - battery charger 84	KIT - sensor 44, 46	NAMEPLATE - Refrigerant R134a 126
HARNESS - condenser fan 10, 12, 44,	KIT - sleeve & eyelet 100	NAMEPLATE - schematic 48, 56
46	KIT - spacer 30	NAMEPLATE - Simpson lead 128
HARNESS - contactor 50, 96	KIT - stylus 72	NAMEPLATE - Smart Reefer 126
HARNESS - control box 46	KIT - valve plate 28, 30	NAMEPLATE - Temperature
HARNESS - evap fan 16, 18	KNOB 106 , 110	Conversion 126
HARNESS - evaporator 44	KVQ - actuator 20, 24	NAMEPLATE - Thermo King 126
HARNESS - evaporator fan 46	·	NAMEPLATE - TK 108, 112, 126
HARNESS - fan 16	L	NAMEPLATE - Transfresh Data A3
HARNESS - fan motor 14	LABEL - compressor oil 28, 30	126
HARNESS - fan & heater 16	LABEL - dehydrator 20, 24	NAMEPLATE - Transfresh Scrubber
HARNESS - heater 46	LATCH - cover 48 , 68 , 74	A5 126
HARNESS - humidity compressor 100	LATCH - door 52 , 106 , 110	NAMEPLATE - USDA Connections
HARNESS - KVQ 46	LEAD - thermistor 80	118, 122, 126
HARNESS - KVQ valve 44	LOCK - secondary 58	NAMEPLATE - USDA Sensors 126
HARNESS - main 44, 48, 56	LOCKNUT 10, 12, 14	NAMEPLATE - Warning, Fan 128
HARNESS - mP-D adapter 48	LOCKRING 56, 64	NAMEPLATE - Warning, Fan Start 126
HARNESS - output module 50, 96, 98	LOCKWASHER 10, 12, 14, 16, 18, 28,	NAMEPLATE - Warning, Hot
HARNESS - power module 50	30, 38, 40, 44, 46, 48,	Components 126
HARNESS - redundant sensor 116	50, 52, 54, 68, 74, 76,	NIPPLE 100
HARNESS - remote monitor 82	82, 84, 92, 94, 96, 102,	NIPPLE - compressor to nozzle 100
HARNESS - RMM modem 94	104	NOZZLE - liquid spray 100
HARNESS - sensor 42, 48, 56		NUT 10, 12, 14, 16, 18, 28, 30, 38, 44,
HARNESS - switch 48	М	46, 48, 50, 52, 68, 74,
HARNESS - tank heater 100	MECHANISM 72	82, 84, 92, 96, 102, 104,
HEAT EXCHANGER 20, 24	MODEM - RMM 94	106, 110, 116, 118, 122
HEATER 44, 46	MODULE - current sense 50, 96	NUT - board 84
HINGE 106 , 110	MODULE - mP-D output 50, 96	NUT - bracket 84
HINGE - air vent 102	MODULE - power 50 , 54 , 96	NUT - captive 12, 84, 108, 112
HINGE - cover to box 52	MOTOR - condenser fan 10, 12, 44, 46	NUT - chart 78
HINGE - evap door 106	MOTOR - evaporator fan 14, 44, 46	NUT - compressor 100
HINGE - left 70 , 74 , 76	MOTOR - fan 16, 18	NUT - connector 56, 92
HINGE - right 68, 74	MOUNT - cable 48	NUT - hose 100
HINGE SET - left 68, 74	MOUNT - cable tie 50, 96, 124	NUT - o-ring 22
HINGE SET - right 68, 76		NUT - plate 38
HOOK - strap 108, 112	N	NUT - shoulder 20, 24, 34
HOSE - drain 100	NAMEPLATE 84	NUT - wing 102, 104
HOSE - flex 124	NAMERI ATE - Air Vent 126	NUT CUP & CORD 72

0	56	SCREW - mtg vent 102
OIL - compressor 28, 30	RECEPTACLE - sensor harness 56	SCREW - orifice 12, 108, 112
ORIFICE - condenser 108, 112	REDUCER 22	SCREW - plate 38, 68, 74, 102, 106,
ORIFICE - condenser fan 10, 12	RELAY - mini 82	108, 110, 112, 118, 122
O-RING 34, 72	RETAINER - probe 114	SCREW - rail 50, 96
O-RING - valve 38	RIVET - anchor 124	SCREW - receptacle 92, 118, 122
O-MINO - Valve 30	RIVET - box 86, 88, 90	SCREW - recorder 68, 74
P	RIVET - channel 118, 122	SCREW - relay socket 82
PANEL - high voltage 50, 94, 96	RIVET - grille 118, 122	SCREW - strap 108, 112
PANEL - USDA receptacle 118, 122	RIVET - hinge 106	SCREW - tank 38, 40
PC BOARD - emergency bypass 50 ,	RIVET - housing 108, 112	SCREW - transformer 92
	RIVET - inlet 118, 122	SCREW - valve 20, 24
96 DIN 64	RIVET - latch 68, 74, 106, 110	SEAL 58 , 60
PIN 64	RIVET - monitor socket 82	SEALER - antiseize 48, 52
PIN - hinge 52 , 102 , 106 , 110	RIVET - mount 50, 96	SEALER - polyurethane 118, 122
PIN - sealing 60 , 118 , 122	RIVET - panel 118, 122	SENSOR - head temperature 28, 30,
PIN - terminal 60	RIVET - plate 56 , 68 , 74 , 118 , 122	44, 46
PIPE - temperature 20	RIVET - port 108, 112	SENSOR - humidity 42 , 44 , 46 , 100
PLACARD - schematic 48 , 56	RIVET - receptacle 118 , 122	SENSOR - redundant 116
PLACARD - wiring 48, 56	RIVET - shroud 16, 18	SENSOR - temperature 44, 46
PLATE - air vent 102 , 104	ROD - push 72	SENSOR - USDA 120, 122
PLATE - box 68, 74	ROLLER - door latch 52	SHOULDER 20 , 22 , 34
PLATE - cable storage 106, 110		SHOULDER - seal 24
PLATE - cable storage 106 , 110	S	SHROUD 58
PLATE - compressor 100	SCREEN 100	SHROUD - evaporator 18
PLATE guard 34 109 113	SCREW 102 , 104	SIGHT GLASS 20, 24
PLATE - guard 34 , 108 , 112	SCREW - adapter 28, 30	SIGHT GLASS - oil 28, 30
PLATE kopper 69, 74	SCREW - air vent 104	SOCKET 64
PLATE - keeper 68 , 74	SCREW - box 48, 68, 74, 84	SOCKET - monitor 82
PLATE - rear 118, 122 PLATE - recorder 78	SCREW - bracket 14, 16, 18, 20, 24,	SOCKET - relay 82
PLATE - recorder 76 PLATEN 72	36, 38, 40, 44, 46, 50,	SPACER 52
	68, 74, 84, 92, 96, 106,	SPACER - clamp 42
PLUG 50, 60, 64, 66, 96, 98	110, 116, 124	SPACER - contactor 50, 96
PLUG - assembly 60 PLUG - cavity 58	SCREW - cable 44 , 46 , 92	SPACER - latch 48, 52
PLUG - circular 64, 94	SCREW - channel 118, 122	SPACER - tank 100
PLUG - fusible 20, 24, 40	SCREW - clamp 38, 40, 42, 108, 112,	SPRING 102 , 106 , 110
PLUG - inlet 38	116	SPRING - heater 44, 46
PLUG - outlet 40	SCREW - coil 12, 16, 18, 24	STRAIN RELIEF - connector 56, 64,
PLUG - power 44 , 46 , 92	SCREW - collar 28	66
PLUG - reverse 64	SCREW - compressor 28, 30	STRAP - door 108, 112
PLUG - reverse amp 64	SCREW - control box 46	STRIP - gasket 12, 50, 84, 96
PLUG - thermo bus 56	SCREW - controller 52	STRIP - sealing 84
POCKET - sensor 114	SCREW - cover 16, 84, 108, 112	STYLUS - pen 78
PORT - injection 108 , 112	SCREW - door 106, 110	SWITCH 48
PORT - purge 108 , 112	SCREW - door latch 52	SWITCH - hpco 28, 30
POST - binding 80	SCREW - flange 30	SWITCH - water valve 38
PROBE - high temperature 28	SCREW - gauge 36	
PROTECTOR - edge 102	SCREW - grille 106, 110	T
TROTEOTOR - eage 102	SCREW - ground 84	TAB - mounting 60, 62
R	SCREW - guard 10	TANK - condenser 38, 40
RAIL - din 50, 96	SCREW - guide 68, 74	TANK - humidity 100
RECEPTACLE 60 , 64 , 66 , 118 , 122	SCREW - handle 102	TANK - receiver 20, 24
RECEPTACLE - assembly 60	SCREW - hinge 52 , 68 , 76 , 106 , 110	TAP - thermo bus 50, 96
RECEPTACLE - assembly 66 RECEPTACLE - current transformer	SCREW - keeper 106, 110	TEE 20, 22, 24, 26
56	SCREW - latch 48, 52	TERMINAL 14, 58
RECEPTACLE - power 92	SCREW - modem 94	TERMINAL - male 58
RECEPTACLE - power module CN4	SCREW - module 54, 96	TERMINAL - motor 14
56	SCREW - motor 10, 12, 14, 16, 18	TERMINAL - pin 44, 60, 64, 66
RECEPTACLE - power module CN6	SCREW - mount 48	TERMINAL - socket 60, 64, 66

```
TERMINATOR 50, 96
                                     WASHER - insulator 102
THERMOMETER 72
                                     WASHER - sealing 84
                                     WASHER - special 84
THERMOMETER - 7 day 68
THERMOMETER - recording 68, 74,
                                     WEDGE 60
                                     WINDOW 68, 74
            78
TIMER 78
TOOL - crimper 62
TOOL - pin removal 58
TOOL - terminal crimper 58
TOOL - wedge remover 62
TRANSFORMER 50, 86, 92, 96
TRAY - high voltage 48
TRIM - edge guard 16, 18
TUBE 22, 26, 42
TUBE - bottom 38, 40
TUBE - condenser to indicator 20, 24
TUBE - condenser to receiver 20, 24
TUBE - discharge 20, 24
TUBE - equalizer 22, 26
TUBE - evaporator to exchanger 20, 24
TUBE - exchanger to KVQ 20, 24
TUBE - filter to dehydrator 22
TUBE - gauge 36
TUBE - heat exchanger to dehydrator
            20, 24
TUBE - indicator to drier 20
TUBE - KVQ to compressor 20, 24
TUBE - receiver to condenser 20, 24
TUBE - solenoid to KVQ 20, 24
TUBE - tee to coil 22, 26
TUBE - tee to valve 22, 26
TUBE - top 38, 40
TUBE - valve replacement 22, 26
TUBE - valve to coil 22, 26
TUBE - valve to dehydrator 24
TUBE - valve to exchanger 20, 26
TUBE - valve to tee 20, 22, 24, 26
V
VALVE 40
VALVE - angle 38
VALVE - check 20, 24
VALVE - discharge 28, 30
VALVE - expansion 22, 26
VALVE - KVQ 32
VALVE - pressure relief 108, 112
VALVE - relief 38
VALVE - shutoff 20, 24
VALVE - solenoid 20, 22, 24, 26, 42,
VALVE - suction 28
VENT - air 102
W
WASHER 10, 12, 20, 24, 36, 38, 46,
            48, 68, 74, 82, 84, 102,
            104, 106, 108, 110, 112
WASHER - dome 12, 108, 112
WASHER - insulating 68, 74
```