
CSR 40

TK 50192-7.48



Printed (August 1, 2006)

Copyright @ 1998 - Thermo King Corp. - Minneapolis, MN U.S.A. Electronically printed in U.S.A.

General Information

Tables of Contents

This Parts Manual contains a numerical table of contents listing each assembly name, its associated Grid number and page number. The numerical table of contents is arranged numerically by Grid number. There are references in a parts list referring to other Grid numbers, the numerical table of contents is arranged to facilitate finding the referenced illustrations. At the rear of this parts manual are two indexes, a numerical and alphabetical. The indexes contain all of the part numbers and descriptions which appear in this manual.

Assemblies and Subassemblies

When parts are indented in the description list, they are preceded with a bullet (•). This indicates that the part(s) is available separately or included in an assembly.

GRID NO. 67D6 SWITCH PANEL ASSEMBLY

REF	PART# DESCRIPTION		QTY
	45-1239	PANEL - assy, switch	1
1	99-1960	• PANEL	1
	99-6280	• • NAMEPLATE - panel	1
2	33-743	• GASKET	1

For example: the switch panel nameplate (99-6280) is available separately, available as part of the switch panel (99-1960) and with the panel assembly (45-1239).


ABBREVIATIONS The following abbreviations appear in parts manuals

В	AC	current as required accumulator adjusting aluminum alternator ampere assembly board bearing breaker	F	(continued) evap. evaporator exch exchanger exp expansion ext external F. Farenheit fill fillister fi fuel injection fl flare fpt female pipe thread tt ft feet ftg fitting	O P	os oversized od outside diameter pcb printed circuit
D	C	clockwise counter- clockwise camshaft compressor condenser connecting, connector cylinder defrost degree dehydrator	H I	hex	S	req required rpm revolutions per minute sec second sld solder soc hd solder solder soc hd solenoid spl special sq square ss stainless steel std standard stl steel suct suction sw switch
E	DC	direct current discharge differential Extended Maintenance Interval European Economic Community	N	lg long mm milimeter mpt male pipe thread mod modulating neg negative No number NS not supplied NSS not sold separately	U V	term terminal temp temperature thk thick us undersize vib vibrasorber W watt w/ with w/o without

CSR 40

Contents

Name	Grid	Page
CSR 40 REFERENCE SHEET	.4U54	3
DEUTSCH IN-LINE CONNECTORS	.112D9	49
WEATHER PACK CONNECTORS		
MODULATION VALVE ASSEMBLY		
AIR VENT (40 FT CONTAINERS)	.143D7	91
EVAPORATOR PANELS (UNITS w/ 3 EVAP FANS)	.143D9	93
DEFROST DRAIN	.143D10	101
REFRIGERATION COMPONENTS		
MAIN & SENSOR HARNESS		
COMPRESSOR GROUP		
HIGH VOLTAGE TRAY		
CONTROL BOX DOOR		
RECORDING THERMOMETER (OPTION 098025)		
SIMPSON LEAD (OPTION 098027)	.147A5	67
BATTERY CHARGER GROUP (OPTION 098029)		
TRANSFRESH GROUP (OPTION 098021)	.147A7	71
NAMEPLATES		
ELECTRICAL COMPONENTS (UNITS w/ 3 EVAP FANS)		
RECORDING THERMOMETER - 31 DAY FAHRENHEIT		
SENSOR RETAINERS	.147B3	89
CONDENSER FAN GROUP		
EVAPORATOR FAN GROUP		
CONTROL BOX		
CONDENSER COMPONENTS (UNITS w/ 3 EVAP FANS)		
RECORDING THERMOMETER (OPTION 098026 & 098030)		
RECORDING THERMOMETER (OPTION 098026)		
HUMIDITY CONTROL (OPTION 098033)	.147G12	25
THERMOMETER - 7 DAY FAHRENHEIT	.147G13	59
REMOTE MONITOR (OPTION 098039)		
TRANSFRESH GROUP (OPTION 098038)	.148A14	99
POWER MODULE CIRCUIT BOARD (CSR)	.148C1	41
TRANSFORMER GROUP (098024, 098040, 098041, 098043,		
098071, 098123, 098128)	.148G2	73
HUMIDITY COMPONENTS (OPTION 098100)	.149A14	79
HIGH VOLTAGE TRAY - HUMIDITY (OPTION 098036)	.149B1	37
REMOTE MONITOR BOX (IRMU TK COMM OPTION 098051)	.151A10	77
COMPRESSOR GROUP - HERMETIC	.152A4	23
REFRIGERATION COMPONENTS - HERMETIC	.152A5	17
CONDENSER COMPONENTS (UNITS w/ 2 EVAP FANS)	.152C4	85
EVAPORATOR PANELS (UNITS w/ 2 EVAP FANS)	.152C5	97
ELECTRICAL COMPONENTS (UNITS w/ 2 EVAP FANS)	.152F8	31
EVAPORATOR GROUP (TWO FAN)		






B/M	DESCRIPTION	Date
CSR-40- 100	CSR40-100	8/98
CSR-40- 103	CSR40-103	8/98
CSR-40- 101	CSR40-101	8/98
CSR-40- 104	CSR40-104	4/98
CSR-40- 105	CSR40-105	8/98
CSR-40- 107	CSR40-107	8/98
CSR-40- 109	CSR40-109	8/98
CSR-40- 110	CSR40-110	10/98
CSR-40- 111	CSR40-111	8/98
CSR-40- 112	CSR40-112	9/98
CSR-40- 114	CSR40-114	10/98
CSR-40- 115	CSR40-115	12/98
CSR-40- 116	CSR40-116	1/99
CSR-40- 117	CSR40-117	12/98
CSR-40- 121	CSR40-121	4/99
CSR-40- 123	CSR40-123	4/99
098002	CSR40 mP-D	4/99
098006	CSR40 SL	12/98
098010	CSR40	3/98
098017	CSR Hermetic	1/99
098021	Transfresh	3/98
098022	R134a Compound Gauge	3/98
098024	APL Transformer	3/98
098025	31 Day Partlow Recording Thermometer	3/98



CSR 40 REFERENCE SHEET

В/М	DESCRIPTION	Date
098026	31 Day Recording Thermometer	3/98
098027	Simpson Lead	3/98
098029	Battery/Charger	3/98
098031	Cannon Bayonet	4/98
098032	Cannon Threaded	4/98
098033	Humidity Control Option	4/98
098034	IRMU (Sea Land)	12/98
098035	Partlow 7 Day	4/98
098036	Humidity	8/98
098038	Transfresh	9/98
098039	Remote Monitor	4/98
098040	Transformer	8/98
098041	Transformer	4/99
098043	Transformer - PIL	8/98
098049	Power Cable - Minnekes	4/98
098051	TK COMM	12/98
098061	Power Cable - MIPCO	4/98
098071	Transformer - Triton	8/98
098076	Door w/ Latch	10/98
098079	Purge Port for Transfresh	10/98
098095	Cable 11/4 - ESL	12/98
098096	Nameplate - SLRE	12/98
098098	Nameplate - SLRE	12/98
098109	Sensor	4/99
098110	Frame	4/99




CONDENSER FAN GROUP



REF	PART#	DESCRIPTION	QTY
1	98-5925	GUARD - condenser fan	1
	55-7035	SCREW - guard	4
	55-8904	FLATWASHER (8.4 mm id)	10
	55-6995	FLATWASHER (6.4 mm id)	8
	55-9054	WASHER (nylon)	7
	55-7042	NUT	4
2	78-1173	FAN - condenser (w/ split hub)	1
3	104-689	MOTOR - condenser fan	1
	55-6993	SCREW - motor	4
	55-6988	FLATWASHER	8
	55-7342	LOCKWASHER	4
	55-7339	NUT	4
4	55-8907	GRIP - cable	1
	55-8908	LOCKNUT	1
5	33-367	GROMMET	1
6	41-3116	HARNESS - condenser fan motor	1
	44-8340	TERMINAL - splice	9
7	60-285	COIL - condenser (see 144F3)	1
	99-8562	STRIP - gasket (coil, 3/8 x 1.0)	1
	33-2950	GASKET - coil	1
	55-6994	SCREW - coil	7
	55-7075	FLATWASHER	7
	55-9054	WASHER (nylon)	7
8	70-191	KIT - fan hub	1
	77-2583	HUB - fan (split)	1
	55-8137	SCREW - hub to shaft	2
	55-7066	• LOCKWASHER	2
	55-6988	• FLATWASHER	2

NOTE: Kit 70-191 FAN HUB will update the set screw hub on fan 78-1079 to the split hub on fan 78-1173.




EVAPORATOR FAN GROUP



REF	PART#	DESCRIPTION	QTY
1	104-691	MOTOR - blower	1
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	55-8903	SCREW - motor (22 mm)	12
	55-6993	SCREW - motor (25 mm)	12
	55-8904	FLATWASHER	12
	55-7066	LOCKWASHER	15
	55-9380	NUT	12
	55-8986	INSERT - threaded	12
2	78-1078	FAN - evaporator (19 pitch)	3
	508-165	FAN - evaporator (22 deg pitch, option)	3
	78-1101	FAN - evaporator (CSR 40SL)	1
3	91-8466	BRACKET - motor	3
	55-8903	SCREW - bracket	12
	55-6988	FLATWASHER	21
4	98-5403	BRACKET - motor mount (CSR 40)	1
	91-8628	BRACKET - motor mount (CSR 40SL)	1
5	92-2209	BRACKET - motor	3
6	92-2208	BRACKET - motor	3
	55-8891	SCREW - bracket	17
7	33-3215	GROMMET (47 mm)	1
8	33-2946	GROMMET (37 mm)	5
9	33-3838	GROMMET (22 mm)	1
10	55-2324	KEY - fan	3
11	55-8907	CONNECTOR - harness	4
	55-8908	LOCKNUT	4
12	41-3112	HARNESS - fan motor	1
	44-8340	TERMINAL - motor	20






EVAPORATOR GROUP (TWO FAN)




REF	PART#	DESCRIPTION	QTY
1	98-5475	SHROUD - evaporator	1
	55-9162	RIVET - shroud	10
2	92-2331	BRACKET - left	2
3	92-2332	BRACKET - right	2
4	33-3215	GROMMET (47 mm)	1
5	33-3044	TRIM - edge guard	A/R
6	55-8907	CONNECTOR - harness & sensor	3
7	78-1117	FAN - evaporator	2
8	67-1558	COIL - evaporator	1
	55-8891	SCREW - coil	9
	55-9217	CAP - screw	3
9	91-9328	BLOCK - coil	2
10	91-8467	BRACKET - heater (end)	2
	55-8891	SCREW - bracket	4
11	91-8142	BRACKET - heater (center)	1
	55-3136	RIVET - bracket	1
12	45-1791	HEATER	6
13	91-8140	SPRING	6
14	41-3113	HARNESS - evap fan (#1)	1
15	41-3114	HARNESS - evap fan (#2)	1
	55-2332	BANDWRAP (small)	A/R
	55-2330	BANDWRAP (large)	A/R
16	104-691	MOTOR - fan	2
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	55-6993	SCREW - motor	8
	55-7066	LOCKWASHER (external tooth)	2
	55-7342	LOCKWASHER	6
	55-7085	FLATWASHER	8
17	99-4931	NAMEPLATE - arrow	1
18	91-8466	BRACKET - motor	2
	55-8903	SCREW - bracket	8
	55-8904	FLATWASHER	16
	55-7342	LOCKWASHER	8
	55-7339	NUT	8
19	33-2946	GROMMET (37 mm)	4
20	33-3838	GROMMET (22 mm)	1



REFRIGERATION COMPONENTS




REF	PART#	DESCRIPTION	QTY
1	102-796	COMPRESSOR - scroll (see 144F12)	1
	66-9004	VALVE	1
2	66-3942	VALVE - discharge	1
3	66-9181	TUBE - valve to coil	1
4	55-3680	COUPLING	1
5	60-285	COIL - condenser (see 147B4)	1
6	66-9016	TUBE - coil to receiver tank	1
7	67-1537	TANK - receiver	1
	55-6994	SCREW - receiver (20 mm)	2
	55-8316	SCREW - receiver (40 mm)	2
	55-9053	SPACER	1
	55-7075	FLATWASHER	8
	55-8877	WASHER (nylon)	4
	55-7042	NUT	4
8	66-8811	SIGHT GLASS	2
9	33-3007	GASKET	2
10	66-9033	TUBE - receiver to dehydrator	1
	55-8950	NUT	1
	55-8951	SHOULDER	1
11	66-6603	VALVE - angle	1
	66-2170	CAP - valve	1
12	66-7392	VALVE - relief	1
	66-6610	FITTING - highside	1
13	66-8473	FILTER (see item 45)	1
	33-1936	O-RING (3/8)	1
	55-8917	HANGER - filter	1
	91-8470	SPACER - hanger	1
14	66-8767	DEHYDRATOR (see item 45)	1
	55-4390	HANGER - dehydrator	1
15	66-9018	TUBE - exchanger to valve	1
16	67-1028	HEAT EXCHANGER	1
17	66-9020	TUBE - exchanger to evaporator	1
18	66-9024	TUBE - tee to expansion valve	1
19	66-7865	VALVE - modulation (w/ harness connectors)	1
	66-7981	• VALVE (see 123A8)	1
20	66-9021	TUBE - modulation valve to suction valve	1
21	66-1916	VALVE - suction (see 144F12)	1
22	66-9022	TUBE - exchanger to tee	1
23	55-6218	TEE	1
24	66-9023	TUBE - tee to valve	1
25	66-9195	VALVE - solenoid	1
	41-767	• COIL	1



REFRIGERATION COMPONENTS




REF	PART#	DESCRIPTION	QTY
26	66-9026	TUBE - valve to compressor	1
27	66-4341	COUPLING	1
28	66-8367	VALVE - solenoid (liquid injection)	1
	41-767	• COIL	1
29	66-9019	TUBE - dehydrator to exchanger	1
	55-8950	NUT	1
	55-8951	SHOULDER	1
30	61-443	VALVE - expansion	1
31	55-2296	TEE	1
32	66-9034	TUBE - expansion valve to tee	1
33	66-9035	TUBE - liquid	1
34	66-9029	TUBE - valve to evaporator	1
35	66-9030	TUBE - tee to evaporator	1
36	66-9036	TUBE - equalizer	1
37	66-9032	VALVE - solenoid (dehumidity, see 147G12, optional)	1
38	41-2399	COIL - liquid line valve	1
39	67-1532	COIL - evaporator (CSR 40, units w/ 3 evap fans)	1
	67-1558	COIL - evaporator (CSR 40, units w/ 2 evap fans)	1
	67-1504	COIL - evaporator (CSR 40SL)	1
	55-6993	SCREW (25 mm)	8
	55-8882	FLATWASHER (ins 8.4 mm id)	14
	55-6988	FLATWASHER (8.4 mm id)	14
40	66-9027	TUBE - coupling to valve	1
41	66-9037	TUBE - receiver to valve	1
42	91-8468	CLAMP - exchanger	1
43	91-8469	BRACKET - exchanger	1
	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
44	66-9159	TUBE (replaces valve)	1
45	60-272	KIT - dehydrator/oil filter conversion	1
46	33-566	• O-RING (1/2)	2
47	33-1015	• O-RING (3/8 id)	1
48	66-9307	DEHYDRATOR/OIL FILTER	1
49	61-1243	• ADAPTER	1



REFRIGERATION COMPONENTS - HERMETIC



REF	PART#	DESCRIPTION	QTY
1	102-671	COMPRESSOR - scroll (hermetic, see 152A4)	1
2	55-1659	ELBOW - discharge	1
3	66-9425	TUBE - elbow to valve	1
4	66-9424	TUBE - discharge process	1
5	41-2841	SWITCH - hpco	1
6	60-285	COIL - condenser (see 147B4)	1
7	66-9016	TUBE - coil to receiver tank	1
8	67-1549	TANK - receiver	1
	55-6994	SCREW - receiver (20 mm)	2
	55-8316	SCREW - receiver (40 mm)	2
	55-9053	SPACER	1
	55-7075	FLATWASHER	8
	55-8877	WASHER (nylon)	4
	55-7042	NUT	4
9	66-9426	TUBE - receiver to dehydrator	1
10	66-9428	VALVE - relief	1
11	66-9306	DEHYDRATOR	1
	55-4390	HANGER - dehydrator	1
12	66-9423	TUBE - dehydrator to exchanger	1
13	55-3251	TEE	1
14	66-9421	TUBE - exchanger to tee	1
15	67-1028	HEAT EXCHANGER	1
16	91-8468	CLAMP - exchanger	1
17	91-8469	BRACKET - exchanger	1
	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
18	66-9422	TUBE - tee to expansion valve	1
19	61-443	VALVE - expansion	1
20	66-9034	TUBE - expansion valve to tee	1
21	55-2296	TEE	1
22	66-9030	TUBE - tee to evaporator	1
23	66-9035	TUBE - liquid	1
24	66-9032	VALVE - solenoid (dehumidity, see 147G12, optional)	1
25	41-2399	COIL - liquid line valve	1
26	66-9029	TUBE - valve to evaporator	1
27	66-9159	TUBE (replaces valve)	1
28	67-1532	COIL - evaporator (units w/ 3 evap fans)	1
	67-1558	COIL - evaporator (units w/ 2 evap fans)	1
	55-6993	SCREW (25 mm)	8
	55-8882	FLATWASHER (ins 8.4 mm)	14
	55-6988	FLATWASHER (8.4 mm id)	14
29	66-9020	TUBE - exchanger to evaporator	1




REFRIGERATION COMPONENTS - HERMETIC




REF	PART#	DESCRIPTION	QTY
30	66-9036	TUBE - equalizer	1
31	66-9420	TUBE - exchanger to valve	1
32	66-7865	VALVE - modulation (w/ harness connectors)	1
	67-7981	• VALVE (see 123A8)	1
33	61-160	TUBE - modulation valve to suction valve	1
34	66-9419	TUBE - suction process	1
35	55-7386	ELBOW	1
36	66-7533	TUBE - elbow to compressor	1
37	66-8367	VALVE - solenoid (liquid injection)	1
	41-767	• COIL	1
38	61-159	TUBE - valve to compressor	1
39	55-3250	ELBOW	1
40	66-9027	TUBE - coupling to valve	1
41	66-9195	VALVE - solenoid	1
	41-767	• COIL	1
42	66-9427	TUBE - receiver to valve	1





REF	PART#	DESCRIPTION	QTY
	20-166	KIT - compressor (incl items 1 thru 5)	1
1	102-796	COMPRESSOR - scroll	1
	203-516	OIL - compressor	A/R
2	66-3942	VALVE - discharge	1
3	66-3015	CAP - valve	1
4	33-2805	GASKET - valve	1
5	66-9181	TUBE - compressor to coil	1
6	55-3680	COUPLING	1
	40-779	KIT - gasket & grease	1
7	33-2951	GASKET - power connector	1
	33-2979	SEALER - silicone grease pack	1
8	55-8994	SCREW - ground	1
	55-8995	WASHER - ground	1
9	91-9021	COVER - terminal box	1
10	55-8911	SCREW - compressor	4
11	55-8912	FLATWASHER (13 mm)	4
12	55-9012	WASHER - vibration damper	4
13	55-9013	SPACER	4
14	55-7360	FLATWASHER (12 mm)	4
15	55-8992	NUT	4
16	41-4523	SWITCH - hpco (blue bandwrap)	1
17	41-2447	SENSOR - head temperature	1
18	41-530	SWITCH - hpco (red bandwrap)	1
19	55-9171	SCREW - valve	2
20	55-6999	LOCKWASHER	2
21	55-9172	WASHER - sealing	2
22	55-7344	NUT	2
23	66-7812	ADAPTER - highside	1
24	66-6610	FITTING - highside	1
25	66-7182	CAP - fitting	1
26	66-8054	ADAPTER (lowside)	1
27	66-6607	FITTING - lowside	1
28	66-7183	CAP - fitting	1
29	66-1916	VALVE - suction	1
30	33-727	O-RING	1
31	40-781	CABLE - power	1




COMPRESSOR GROUP - HERMETIC



REF	PART#	DESCRIPTION	QTY
1	102-671	COMPRESSOR - scroll (hermetic)	1
	203-516	OIL - compressor	1
2	91-9021	COVER - terminal box	1
	40-779	KIT - gasket & grease	1
3	33-2951	•• GASKET - power connector	1
	33-2979	•• SEALER - silicone grease pack	1
4	55-8994	•• SCREW - ground	1
	55-8995	•• WASHER - ground	1
5	40-776	KIT - thermistor	1
6	55-8911	SCREW - compressor	4
7	55-8912	FLATWASHER (13 mm)	4
8	55-9012	WASHER - vibration damper	4
	91-1754	PAD (plastic)	4
9	55-9013	SPACER	4
10	55-7360	FLATWASHER (12 mm)	4
11	55-8992	NUT	4
12	40-781	KIT - power cord	1






HUMIDITY CONTROL (OPTION 098033)



REF	PART#	DESCRIPTION	QTY
1	66-9032	VALVE - solenoid (humidity control)	1
	504-977	KIT - repair (Danfoss, normally closed, no stem)	1
	41-2399	COIL - liquid line valve (w/ connector)	1
	41-5460	•• COIL	1
2	66-9159	TUBE (replaces valve)	1
3	41-5635	SENSOR - humidity	1
	41-2838	HARNESS - sensor	1
4	55-1203	CLAMP - sensor	2
	55-8991	SPACER - clamp	2
	55-9173	SCREW - clamp	2




MODULATION VALVE ASSEMBLY



REF	PART#	DESCRIPTION	QTY
1	60-203	KIT - repair	1
2	44-5175	• COIL	1
3	66-7791	SCREEN - inlet strainer (1.375 dia tube)	1
	66-7790	SCREEN - inlet strainer (1.125 dia tube)	1






ELECTRICAL COMPONENTS (UNITS w/ 3 EVAP FANS)



REF	PART#	DESCRIPTION	QTY
1	41-2447	SENSOR - head temperature	1
2	40-781	CABLE - power	1
3	40-871	KIT - sensor (supply air, return air & evap coil, graded)	3
4	41-2503	CABLE - power (11-4 cable)	1
	45-1320	CABLE - power (10-4 cable)	1
5	41-1976	PLUG - power (Minnekes)	1
	44-4051	PLUG - power (MIPCO)	1
	41-2820	PLUG - power (ESL)	1
	44-9891	TERMINAL - pin (cable end)	3
	44-6310	TERMINAL - pin (plug end)	4
6	66-8367	VALVE - solenoid (liquid injection)	1
	41-767	• COIL	1
7	66-9195	VALVE - solenoid	1
	41-767	• COIL	1
8	104-639	MOTOR - condenser fan (see 147B4)	1
9	41-3116	HARNESS - condenser	1
10	104-691	MOTOR - evaporator (see 147B5)	3
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
11	41-3112	HARNESS - evaporator & heaters	1
12	45-1791	HEATER - evaporator	6
13	41-4021	SENSOR - ungraded (condenser coil, ambient temp & optional humidity sensor)	2
	91-2197	BRACKET - sensor	2
14	66-7865	VALVE - modulation (see 123A8)	1
15	91-8142	BRACKET - heater (CSR 40)	1
	91-8634	BRACKET - heater (CSR 40 SL)	1
16	91-8467	BRACKET - heater (CSR 40)	2
	91-8629	BRACKET - heater (CSR 40 SL)	1
17	91-8140	SPRING - heater	6
18	NSS	BOX - control (see 147B6)	1
19	41-530	SWITCH - hpco (red bandwrap)	1
20	41-4523	SWITCH - hpco (blue bandwrap)	1
21	102-796	COMPRESSOR - scroll (see 146E1)	1
	102-671	COMPRESSOR - scroll (hermetic, see 152A4)	1
22	41-2517	HARNESS - main (see 146D9)	1
23	66-9032	VALVE - solenoid (dehumidity, optional)	1
24	91-6988	BRACKET - cable restraint	1
25	41-3401	THERMOSTAT	1
	55-9166	SCREW - thermostat	2
26	41-3341	SENSOR - defrost	1




Revised 4/7/04


ELECTRICAL COMPONENTS (UNITS w/ 2 EVAP FANS)



REF	PART#	DESCRIPTION	QTY
1	102-671	COMPRESSOR - scroll (hermetic, see 152A4)	1
2	40-781	CABLE - power	1
3	40-871	KIT - sensor (supply air, return air & evaporator coil, graded)	3
4	41-2503	CABLE - power (11-4 cable)	1
5	41-1976	PLUG - power (Minnekes)	1
	44-9890	TERMINAL - pin (cable end)	3
	44-6310	TERMINAL - pin (plug end)	4
6	45-1791	HEATER - evaporator (see 152F11)	6
7	66-7865	VALVE - modulation (see 123A8)	1
8	104-689	MOTOR - condenser fan (see 147B4)	1
9	41-3116	HARNESS - condenser	1
10	104-691	MOTOR - evaporator (see 152F11)	2
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
11	41-3115	HARNESS - heaters (see 152F11)	1
12	41-4021	SENSOR - ungraded (condenser coil, ambient temperature & optional humidity sensor)	2
	91-2197	BRACKET - sensor	2
13	NSS	BOX - control (see 147B6)	1
14	41-2517	HARNESS - main (see 146D9)	1
15	91-6988	BRACKET - cable restraint	1




REF	PART#	DESCRIPTION	QTY
1	98-5443	BOX - control	1
	55-6994	SCREW - box	4
	55-7075	FLATWASHER	4
	55-8877	WASHER (nylon)	4
2	99-6093	MOUNT - cable	5
	55-2330	BANDWRAP	5
	55-7862	SCREW - mount	5
	55-7368	FLATWASHER	5
	55-7665	NUT	5
3	55-5257	CONNECTOR - harness	3
4	55-5900	CONNECTOR - harness	3
5	33-1435	GROMMET - connector	2
6	33-2753	GROMMET - connector (0.25 id)	1
7	NSS	COVER - control box (see 146F6)	1
8	55-6147	CLAMP - harness	1
9	91-8988	PLACARD - wiring	1
	91-8989	PLACARD - schematic	1
	91-8990	NAMEPLATE - schematic	3
10	41-2517	HARNESS - main (see 146D9)	1
11	41-2518	HARNESS - sensor (see 146D9)	1
12	91-8693	NAMEPLATE - on/off	1
13	41-2170	HARNESS - switch	1
	44-6560	SWITCH - on/off	1
14	44-739	BOOT - switch	1
15	NSS	TRAY - high voltage (see 146F5 or 149B1)	1
16	91-8553	NAMEPLATE - controller setup	1
17	41-2406	CAP - dust	1
	99-3685	CHAIN - cap	1
18	91-8672	NAMEPLATE - schematic	1
19	204-918	HARNESS - communication (Deutsch)	1
	204-974	HARNESS - communication (bayonet connector)	1
	204-975	HARNESS - communication (threaded connector)	1
20	91-8589	NAMEPLATE - Control Box Layout	1
21	55-8907	CONNECTOR - harness	1
	55-8908	LOCKNUT	1
	33-3838	GROMMET	1
22	41-2575	HARNESS - adapter (cannon bayonet connector)	1
	41-2576	HARNESS - adapter (cannon threaded connector)	1





REF	PART#	DESCRIPTION	QTY
1	91-8662	PANEL - high voltage	1
2	91-8147	BRACKET - power module	1
	55-7862	SCREW - bracket	3
	55-7369	LOCKWASHER	4
3	45-1806	MODULE - power (CRR units, see 145F1)	1
4	41-2129	TRANSFORMER	1
	55-7369	LOCKWASHER	4
	55-7698	NUT	5
5	41-2208	TAP - thermo bus	1
6	41-2209	TERMINATOR	1
7	91-8661	BRACKET - emergency bypass	1
8	41-2210	PC BOARD - emergency bypass	1
	99-7849	STRIP - gasket (25 ft)	A/R
	55-8723	SCREW - bracket	4
9	91-8538	NAMEPLATE - emergency bypass	1
10	45-1853	MODULE - mP-D output	1
11	41-2446	CONTACTOR	7
12	44-8813	INTERLOCK	2
13	41-2520	SPACER - contactor	2
14	41-2701	MODULE - current sense (w/ filter)	1
	41-2401	MODULE - current sense	1
15	41-2521	BREAKER - circuit	1
16	91-8204	RAIL - din	1
	55-7862	SCREW - rail	6
	55-7369	LOCKWASHER	6
	55-7697	FLATWASHER	6
17	41-2690	HARNESS - contactor	1
18	41-2319	CONNECTOR - receptacle (12 pin)	1
19	99-6093	MOUNT - cable tie	2
	55-2864	RIVET - mount	2
	55-2332	BANDWRAP	18
20	91-8737	BLOCK - grounding	4
21	41-2689	HARNESS - output module	1
22	41-2407	• PLUG (35 pin)	1
23	41-2493	• PLUG (12 socket)	1
24	41-2492	CONNECTOR - receptacle (16 pin)	1
25	41-2249	• PLUG (3 socket)	1
26	41-2522	HARNESS - power module	1
27	41-2495	CONNECTOR - plug (6 socket)	1
	41-2494	CONNECTOR - receptacle (6 pin)	1




Revised 7/9/02

HIGH VOLTAGE TRAY - HUMIDITY (OPTION 098036)



REF	PART#	DESCRIPTION	QTY
1	91-8662	PANEL - high voltage	1
2	91-8147	BRACKET - power module	1
	55-7862	SCREW - bracket	3
	55-7369	LOCKWASHER	4
	55-7031	LOCKWASHER (internal tooth)	1
3	45-1806	MODULE - power (see 145F1)	1
	55-9195	SCREW - module	5
	55-8987	LOCKWASHER (internal tooth)	5
	55-8410	FLATWASHER	5
	91-8415	NAMEPLATE - fuses	1
4	41-2129	TRANSFORMER	1
	55-7698	LOCKWASHER	4
	55-7031	FLATWASHER	3
5	41-2208	TAP - thermo bus	1
	55-7367	NUT	5
	55-7370	LOCKWASHER	7
6	41-2209	TERMINATOR	1
7	91-8661	BRACKET - emergency bypass	1
8	41-2210	PC BOARD - emergency bypass	1
	99-7849	STRIP - gasket (25 ft)	A/R
	55-8723	SCREW - bracket	4
9	91-8538	NAMEPLATE - emergency bypass	1
10	45-1711	MODULE - mP-D output	1
11	41-2446	CONTACTOR	8
12	44-8813	INTERLOCK	2
13	41-2520	SPACER - contactor	2
14	41-2401	MODULE - current sense	1
15	41-2521	BREAKER - circuit	1
16	91-8204	RAIL - din	1
	55-7862	SCREW - rail	6
	55-7369	LOCKWASHER	2
	55-7697	FLATWASHER	2
17	41-2690	HARNESS - contactor	1
18	41-2319	CONNECTOR - receptacle (12 pin)	1
19	99-6093	MOUNT - cable tie	2
	55-2864	RIVET - mount	2
	55-2332	BANDWRAP	18
20	91-8737	BLOCK - grounding	4
21	41-2689	HARNESS - output module	1
22	41-2407	• PLUG (35 pin)	1
23	41-2493	• PLUG (12 socket)	1
24	41-2492	CONNECTOR - receptacle (16 pin)	1




Revised 7/9/02

HIGH VOLTAGE TRAY - HUMIDITY (OPTION 098036)



REF	PART#	DESCRIPTION	QTY
25	41-2249	• PLUG (3 socket)	1
26	41-2689	HARNESS - output module	1
27	41-2495	CONNECTOR - plug (6 socket)	1
	41-2494	CONNECTOR - receptacle (6 pin)	1
28	99-7834	NAMEPLATE - Caution	1




Revised 5/12/98

POWER MODULE CIRCUIT BOARD (CSR)



REF	PART#	DESCRIPTION	QTY
1	45-1806	MODULE - power	1
2	41-1932	FUSE (1 amp)	3
3	41-2543	FUSE (2 amp)	2
4	44-9524	FUSE (3 amp)	6
5	41-1292	FUSE (5 amp)	2






MAIN & SENSOR HARNESS




REF	PART#	DESCRIPTION	QTY
1	41-2517	HARNESS - main	1
2	55-8661	CONNECTOR - harness	1
	55-8662	• NUT - connector	1
3	41-2405	CONNECTOR - receptacle (data port, 5 pin)	1
4	41-2524	RECEPTACLE - sensor harness (24 pin)	1
5	41-2247	RECEPTACLE - current transformer (6 pin)	1
6	41-2249	PLUG - thermo bus (3 socket)	1
7	41-1946	RECEPTACLE - power module CN4 (36 pin)	1
8	41-2319	CONNECTOR - receptacle (12 pin, power module CN1 & CN8)	1
9	41-2248	• RECEPTACLE - power module CN6 (18 pin)	1
10	41-743	CONNECTOR (17 pin, A connector)	1
11	41-224	STRAIN RELIEF - connector (14 pin)	1
	55-7617	CLAMP (plastic)	1
12	41-747	• LOCKRING	2
13	41-744	CONNECTOR (23 pin, B connector)	1
14	41-225	STRAIN RELIEF - connector (19 pin)	2
	55-7618	CLAMP (plastic)	2
15	41-748	• LOCKRING	2
16	41-745	CONNECTOR (37 pin, D connector)	1
17	41-2518	HARNESS - sensor	1
18	41-2402	CONNECTOR - plug (28 pin, C connector)	1
19	44-8779	CLAMP - cable	1
20	41-2519	CONNECTOR - plug (24 socket, main harness)	1
21	91-8717	PLACARD - wiring	1
22	91-8718	PLACARD - schematic	1
23	91-8719	NAMEPLATE - schematic	1
24	91-8660	PLATE - harness	2
	55-9030	RIVET - plate	4



REF	PART#	DESCRIPTION	QTY
1	845-1949	CONTROLLER - mP-D	1
	92-179	BEZEL - controller	1
	55-7748	SCREW - controller	10
2	203-439	BATTERY - lithium	1
3	91-8716	DOOR - control box	1
4	33-2981	GASKET - door (340mm & 481mm)	A/R
5	55-6147	CLAMP - harness	1
	55-7034	NUT	1
	55-7370	LOCKWASHER	1
	55-7033	FLATWASHER	2
6	91-8738	NAMEPLATE - Operating Instructions	1
7	55-6994	SCREW - door latch	1
8	55-7075	FLATWASHER	2
9	99-8151	SPACER	1
10	99-8162	ROLLER - door latch	1
	203-392	SEALER - antiseize	A/R
11	55-7170	LOCKWASHER	1
12	55-7042	NUT	1
13	91-8658	HINGE - cover to box	2
	55-7748	SCREW - hinge	4
	55-7033	FLATWASHER	8
	55-7034	NUT	4
14	91-8256	PIN - hinge	2
15	91-8659	LATCH - door	1
	55-6994	SCREW - latch	1
	55-7075	FLATWASHER	2
	55-2363	LOCKWASHER	1
	55-7042	NUT	1
16	55-9029	SPACER - latch	1
	203-392	SEALER - antiseize	A/R







WEATHER PACK CONNECTORS





REF	PART#	DESCRIPTION	QTY
1	44-5836	TERMINAL - male (14-16 gauge)	A/R
	44-5883	TERMINAL - male (18-20 gauge)	A/R
	44-8851	TERMINAL - male (22 gauge)	A/R
2	44-8681	SEAL (red, 0.066 - 0.079 id)	A/R
	44-5885	SEAL (green, 0.087 - 0.110 id, 18-20 gauge)	A/R
	44-5837	SEAL (gray, 0.110 - 0.137 id, 14-16 gauge)	A/R
	44-6324	SEAL (blue, 0.137 - 0.165 id, 12-14 gauge)	A/R
	44-7812	PLUG - cavity (green, no hole)	A/R
3	44-7330	SHROUD (1 pin)	1
4	44-7327	CONNECTOR - tower (1 pin)	1
5	44-5839	TERMINAL (14-16 gauge, female)	A/R
	44-5884	TERMINAL (18-20 gauge, female)	A/R
	44-8853	TERMINAL (22 gauge, female)	A/R
6	44-5835	SHROUD (2 pin)	1
7	44-5838	CONNECTOR - tower (2 pin)	1
8	44-9569	SHROUD (3 pin)	1
9	44-6959	CONNECTOR - tower (3 pin)	1
10	44-7880	SHROUD (4 pin)	1
11	44-7881	CONNECTOR - tower (4 pin)	1
12	44-8294	SHROUD (6 pin)	1
13	44-7872	CONNECTOR - tower (6 pin)	1
14	44-7884	SHROUD (22 pin)	1
15	44-7829	CONNECTOR - tower (22 pin)	1
16	44-7811	LOCK - secondary	2
17	41-1527	CONNECTOR - tower (4 pin)	1
18	41-1310	SHROUD (4 pin)	1
19	204-623	TOOL - pin removal	1
20	204-624	TOOL - terminal crimper	1























DEUTSCH IN-LINE CONNECTORS



REF	PART#	DESCRIPTION	QTY
1	44-9700	TERMINAL - socket (w/ 6 in wire lead)	2
	44-9587	TERMINAL - socket (without wire)	2
2	44-9585	PLUG (2 pin, w/ seal)	1
3	33-2392	SEAL	1
4	44-9586	WEDGE	1
5	44-9590	WEDGE	1
6	44-9589	RECEPTACLE (2 pin)	1
7	44-9701	TERMINAL - pin (w/ 6 in wire lead)	2
	44-9591	PIN - terminal (w/o wire)	2
8	44-9631	CONNECTOR (3 pin, w/ seal)	1
9	33-2393	SEAL	1
10	44-9536	WEDGE	1
11	44-9545	WEDGE	1
12	44-9544	RECEPTACLE (3 pin)	1
13	44-8935	PLUG (4 pin, w/ seal)	1
14	33-2394	SEAL	1
15	44-8936	WEDGE	1
16	44-8918	WEDGE	1
17	44-8915	RECEPTACLE (4 pin)	1
18	44-8920	CONNECTOR (6 pin, w/ seal)	1
19	33-2395	SEAL	1
20	44-8921	WEDGE	1
21	44-8917	WEDGE	1
22	44-8914	CONNECTOR (6 pin)	1
23	44-9903	PLUG (8 pin, w/ seal)	1
24	33-2396	SEAL	1
25	44-9902	WEDGE	1
26	44-9901	WEDGE	1
27	44-9900	RECEPTACLE (8 pin)	1
28	44-9600	PLUG (12 pin, w/ seal)	1
29	33-2397	SEAL	1
30	44-9601	WEDGE	1
31	44-9905	WEDGE	1
32	44-9904	RECEPTACLE (12 pin)	1
33	41-2323	PLUG - assembly (w/ 6 in wires)	1
34	41-2322	RECEPTACLE - assembly (w/ 6 in wires)	1
35	41-2325	PLUG - assembly (w/ 6 in wires)	1
36	41-2324	RECEPTACLE - assembly (w/ 6 in wires)	1
37	41-2327	PLUG - assembly (w/ 6 in wires)	1
38	41-2326	RECEPTACLE - assembly (w/ 6 in wires)	1
39	44-9602	PIN - sealing	A/R
40	44-9906	TAB - mounting (for all connectors except the 8 pin connector)	A/R






DEUTSCH IN-LINE CONNECTORS




REF	PART#	DESCRIPTION	QTY
41	44-9907	TAB - mounting (for 8 pin connector only)	A/R
42	204-703	KIT - crimper (w/ terminals)	1
	204-1038	• TOOL - crimper	1
	204-799	• TOOL - wedge remover	1






RECORDING THERMOMETER (OPTION 098025)



REF	PART#	DESCRIPTION	QTY
1	45-1830	THERMOMETER - recording (31 day, see 147B2)	1
	45-1834	THERMOMETER - 7 day (recording, see 147G13)	1
	55-7172	SCREW - recorder	4
	55-6996	LOCKWASHER	4
	55-6995	FLATWASHER	4
2	91-8705	BOX - recorder	1
	55-7341	SCREW - box	4
	55-6988	FLATWASHER	4
	55-8953	WASHER (nylon)	4
3	91-4218	PLATE - box (bottom)	1
	55-7340	SCREW - plate	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
4	33-451	GROMMET	1
5	99-7230	GUIDE - latch	1
6	55-7169	SCREW - guide (12 mm)	1
7	55-8720	SCREW - guide (25 mm)	1
8	55-7033	FLATWASHER	4
9	55-7404	LOCKWASHER	1
10	55-9444	WASHER - insulating (nylon)	4
11	55-7034	NUT	4
12	91-5005	LATCH - cover	1
	55-2988	RIVET - latch	2
13	91-5006	BRACKET - latch	1
	55-7340	SCREW - bracket	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
14	98-7209	COVER - recorder (incl items 15, 16 & 17)	1
15	91-5007	PLATE - keeper	1
	55-2988	RIVET - plate	2
16	91-8707	• WINDOW	1
17	33-3008	GASKET - cover	4
	91-4219	HINGE SET - left	1
18	91-8708	• HINGE - right (w/ pin)	1
19	91-8725	HINGE - right (w/o pin)	1
	55-7169	SCREW - hinge	8
	55-7033	FLATWASHER	8
	55-7404	LOCKWASHER	8
	91-4220	HINGE SET - right	1






Revised 8/30/05

RECORDING THERMOMETER (OPTION 098025)



REF	PART#	DESCRIPTION	QTY
20	91-8709	HINGE - left (w/ pin)	1
21	91-8726	HINGE - left (w/o pin)	1




Revised 2/2/06

RECORDING THERMOMETER - 31 DAY FAHRENHEIT



REF	PART#	DESCRIPTION	QTY
	45-1830	THERMOMETER (31 day, F)	1
1	44-5644	• ELEMENT - thermo (1/2 od, 7.5 in lg bulb, 10 ft capillary)	1
	44-2339	• ELEMENT - thermo (3/8 od, 14 in lg bulb, 10 ft capillary)	1
2	91-8217	• ROD - push	1
3	33-2962	• O-RING	1
4	41-2216	• MECHANISM	1
5	44-2966	DRIVE - chart (31 day)	1
6	55-5099	• NUT, CLIP & CORD	1
7	41-2218	• PLATEN	1
8	55-8955	• KEY - winding	1
9	91-2205	• KIT - stylus	1
10	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1






THERMOMETER - 7 DAY FAHRENHEIT



REF	PART#	DESCRIPTION	QTY
	45-1834	THERMOMETER - 7 day (F)	1
1	41-2219	• ELEMENT - thermo (3/8 od, 14 lg bulb, 10 ft capillary)	1
3	33-2962	• O-RING	1
4	41-2216	• MECHANISM	1
5	41-2224	DRIVE - chart (7 day)	1
6	55-5099	• NUT, CLIP & CORD	1
7	41-2218	• PLATEN	1
8	55-8955	• KEY - winding	1
9	91-2205	• KIT - stylus	1
10	203-179	CHART (7 day, -20 to +85 Fahrenheit, box of 50)	1






Revised 3/1/06

RECORDING THERMOMETER (OPTION 098026 & 098030)



REF	PART#	DESCRIPTION	QTY
1	45-1830	THERMOMETER - recording (31 day, Partlow, 098025, see 147B2)	1
	45-1831	THERMOMETER - recording (31 day, Saginomiya, battery, 098026, see 147B9)	1
	45-1832	THERMOMETER - recording (31 day, Saginomiya, AC power, 098030, see 147B9)	1
	55-7172	SCREW - recorder	4
	55-6996	LOCKWASHER	4
	55-6995	FLATWASHER	4
2	91-8705	BOX - recorder	1
	55-7341	SCREW - box	4
	55-6988	FLATWASHER	4
	55-8953	WASHER (nylon)	4
3	91-4218	PLATE - box (bottom)	1
	55-7340	SCREW - plate	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
4	33-451	GROMMET	1
5	99-7230	GUIDE - latch	1
6	55-7169	SCREW - guide (12 mm)	1
7	55-8720	SCREW - guide (25 mm)	1
8	55-7033	FLATWASHER	4
9	55-7464	LOCKWASHER	1
10	55-9444	WASHER - insulating (nylon)	4
11	55-7034	NUT	4
12	91-5005	LATCH - cover	1
	55-2988	RIVET - latch	2
13	91-5006	BRACKET - latch	1
	55-7340	SCREW - bracket	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
14	98-7209	COVER - recorder (incl items 15, 16 & 17)	1
15	91-5007	PLATE - keeper	1
	55-2988	RIVET - plate	2
16	91-8707	WINDOW	1
17	33-3008	GASKET - cover	4
	91-4219	HINGE SET - left	1
18	91-8708	• HINGE - right (w/ pin)	1
19	91-8725	• HINGE - right (w/o pin)	1
20	91-8709	• HINGE - left (w/ pin)	1






Revised 3/1/06

RECORDING THERMOMETER (OPTION 098026 & 098030)



147B8

REF	PART#	DESCRIPTION	QTY
21	91-8726	HINGE - left (w/o pin)	1
	55-7169	SCREW - hinge	8
	55-7033	FLATWASHER	8
	55-7404	LOCKWASHER	8
	91-4220	HINGE SET - right	1
22	203-180	CHART (31 day, -20 to +80 F, box of 50)	1
	203-252	CHART (31 day, -30 to +25 C, box of 50)	1
	203-219	CHART (31 day, -25 to +25 C, box of 50)	1




Revised 3/1/06


RECORDING THERMOMETER (OPTION 098026)




REF	PART#	DESCRIPTION	QTY
	45-1831	THERMOMETER - recording (Saginomiya, 31 day battery)	1
	45-1832	THERMOMETER - recording (Saginomiya, 31 day, AC power)	1
1	44-9780	• ELEMENT	1
2	44-9781	• INDICATOR - volt	1
3	44-7782	• TIMER	1
4	509-911	PLATE - recorder	1
5	505-390	NUT - chart	1
6	41-4382	ARM - pen lift	1
7	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1
	203-252	CHART (31 day, -30 to +25 C, box of 50)	1
	203-219	CHART (31 day, -25 to +25 C, box of 50)	1



SIMPSON LEAD (OPTION 098027)




REF	PART#	DESCRIPTION	QTY
1	204-209	LEAD - thermistor	1
2	91-8702	CAP - probe	1
3	91-8703	BRACKET - lead	1
4	44-5114	POST - binding	1
5	33-2960	GASKET	1




BATTERY CHARGER GROUP (OPTION 098029)



REF	PART#	DESCRIPTION	QTY
1	91-8710	BRACKET - battery charger	1
	55-7752	SCREW - bracket	4
	55-6995	FLATWASHER	4
	55-8877	WASHER (nylon)	4
2	91-8711	BOX - battery charger	1
	55-6994	SCREW - box	2
	55-6996	LOCKWASHER	2
	55-6995	FLATWASHER	2
3	55-8720	SCREW - ground	1
	55-3008	WASHER - sealing	1
	55-7370	LOCKWASHER	2
	55-7033	FLATWASHER	1
	55-7367	NUT	2
4	44-6591	CHARGER - battery	1
5	91-8712	BRACKET - battery charger	1
	55-7034	NUT - bracket	2
	55-7033	FLATWASHER	2
6	44-5534	BOARD - terminal	1
	55-7665	NUT - board	2
	55-7368	FLATWASHER	2
7	91-6202	NAMEPLATE	1
8	91-6205	NAMEPLATE	1
9	91-8713	COVER - box	1
	55-7035	SCREW - cover	1
	55-6995	FLATWASHER	1
	55-7479	WASHER - special	1
10	55-5111	CONNECTOR - harness grip	1
11	40-534	HARNESS - battery charger	1
12	203-525	BATTERY (12V)	1
13	44-5835	CONNECTOR - harness	1
14	91-8714	BRACKET - battery	1
	55-7752	SCREW - bracket	2
	55-6995	FLATWASHER	2
	55-8877	WASHER (nylon)	2
15	99-6968	STRIP - sealing (0.12 x 1 x 50 ft)	A/R
	99-8562	STRIP - gasket (battery, 3/8 thk x 25 ft)	A/R
16	99-8986	STRIP - gasket (cover, 25 ft)	A/R
17	55-6997	NUT - captive	1




TRANSFRESH GROUP (OPTION 098021)



REF	PART#	DESCRIPTION	QTY
1	98-5320	GRILLE - evaporator	1
2	91-8715	BOX - Transfresh	1
	55-2264	RIVET - box	4
3	33-3043	GASKET - rub strip	1
4	41-2537	TRANSFORMER	1
5	41-2538	HARNESS	1
6	NSS	DOOR - assembly (not available from Thermo King)	1






Revised 12/3/03

TRANSFORMER GROUP (098024, 098040, 098041, 098043, 098071, 098123, 098128)



148G2

REF	PART#	DESCRIPTION	QTY
1	45-1859	TRANSFORMER	1
2	41-1977	RECEPTACLE - power (32 amp, 440V)	1
	55-2995	SCREW - receptacle	4
	55-2964	• LOCKWASHER	2
	55-2001	• FLATWASHER	2
3	55-5919	CONNECTOR - grip	1
	55-2636	NUT - connector	1
4	41-3083	CABLE - power (69 ft)	1
5	91-9508	INSULATOR	2
6	55-7341	SCREW - transformer	2
	55-8891	SCREW - transformer	4
	55-7085	FLATWASHER	6
	55-7342	LOCKWASHER	6
7	91-6988	BRACKET - cable restraint (current units)	1
8	55-9164	SCREW - cable	1
	55-7357	FLATWASHER	1
	55-7344	NUT	1
9	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
	55-7170	LOCKWASHER	4
10	91-3238	BRACKET - cable (early units)	1
	55-7172	SCREW - bracket	3
	55-6995	FLATWASHER	6
	55-7042	NUT	3
11	44-3828	PLUG - power (50 amp)	1
	44-5133	PLUG - power (60 amp, orange)	1
	41-3429	PLUG - power (50 amp, blue)	1
	33-2482	BUSHING - plug	1




REMOTE MONITOR (OPTION 098039)



REF	PART#	DESCRIPTION	QTY
1	41-2556	HARNESS - remote monitor	1
2	44-5537	SOCKET - relay	1
3	44-6822	SOCKET - monitor	1
	55-8382	SCREW - relay socket	6
	55-8410	FLATWASHER	12
	55-9057	LOCKWASHER	6
	55-7749	NUT	6
	55-9174	RIVET - monitor socket	4
	55-8410	WASHER	4
4	33-2630	GASKET - socket	1
5	41-896	RELAY - mini	3
6	92-206	CAP - dust	1






Revised 12/29/98

REMOTE MONITOR BOX (IRMU TK COMM OPTION 098051)



REF	PART#	DESCRIPTION	QTY
1	91-125	COVER - box	1
2	33-2632	GASKET - cover	1
3	55-2977	SCREW - cover	1
	55-2086	FLATWASHER	1
	55-3319	WASHER - sealing	1
4	99-5454	NAMEPLATE - Caution 460 Volt	1
5	91-9227	MONITOR - remote pc board	1
6	41-2813	BOARD - pc (low voltage)	1
7	41-2814	BOARD - pc (high voltage)	1
	55-3256	SCREW - board	10
	55-2998	FLATWASHER	2
8	41-2815	TRANSFORMER	1
	55-4223	NUT - transformer	4
	55-2201	FLATWASHER	4
9	91-9228	BARRIER - isolation	1
10	41-2816	HARNESS - low voltage	1
11	41-2817	HARNESS - high voltage	1
12	91-9229	BOX - remote monitor	1
	55-7042	NUT - box	4
	55-6995	FLATWASHER	4
13	44-7342	BOARD - terminal (7 terminal)	1
14	44-7341	BOARD - terminal (6 terminal)	1
	55-2748	SCREW - block	4
	55-3023	WASHER - sealing	4
	55-2201	FLATWASHER	4
	55-4223	NUT	4
15	55-5111	CONNECTOR - harness	2
16	41-2819	CABLE - power (remote monitor)	1
17	55-3059	NUT - captive	1
18	91-8472	BRACKET - upper	1
19	91-8471	BRACKET - lower	1
	55-7042	NUT - box to bracket	4
	55-6995	FLATWASHER	4
	55-2993	LOCKWASHER (internal tooth)	2
	55-2086	FLATWASHER	1
	55-1801	NUT - ground	1
20	41-2818	HARNESS - data	1
21	204-636	REMOVER - integrated circuit	1
22	204-622	WRIST STRAP - electrostatic	1
23	204-635	INSTALLER - integrated circuit	1




HUMIDITY COMPONENTS (OPTION 098100)



REF	PART#	DESCRIPTION	QTY
1	11-9085	COMPRESSOR - humidity	1
2	91-9002	PLATE - compressor	1
3	55-7339	NUT - compressor	4
	55-7085	FLATWASHER	4
4	55-2561	NIPPLE - compressor to nozzle	1
5	11-9084	NOZZLE - liquid spray	1
6	11-4860	ELBOW - hose (1/4)	2
7	10-243	KIT - sleeve & eyelet (1/4)	2
8	11-4841	NUT - hose (1/4)	2
9	11-4367	HOSE - supply & over flow (1/4 od x 35 ft lg)	A/R
10	41-3117	HARNESS - humidity compressor	2
11	41-5635	SENSOR - humidity	1
12	91-9003	FILTER	1
	91-6236	SCREEN	1
	91-6237	ADAPTER - outlet	1
13	55-6905	FITTING - barb (1/2 mpt, poly)	1
14	11-8983	HOSE - drain	2
15	55-9208	CONNECTOR - T-hose	1
16	11-9082	TANK - humidity	1
17	11-9083	CAP - tank	1
18	41-2691	HARNESS - tank heater	1
19	55-9149	SPACER - tank	4
20	55-4359	NIPPLE	1
21	55-7151	DRAIN COCK	1






CONDENSER COMPONENTS (UNITS w/ 3 EVAP FANS)



REF	PART#	DESCRIPTION	QTY
1	98-5326	FRAME - unit	1
	98-5543	FRAME - unit (option 098110, w/ fly screen)	1
2	91-8108	BRACKET - frame	1
	55-6993	SCREW - bracket	3
	55-6988	FLATWASHER	6
	55-8882	WASHER (nylon)	3
	55-7339	NUT	3
	55-6993	SCREW - bracket	3
	55-7085	FLATWASHER	6
	55-8882	WASHER (nylon)	6
	55-7825	NUT	3
3	91-9504	PLATE - cable storage (front)	1
	55-7172	SCREW - plate (16 mm)	2
	55-7035	SCREW - plate (25 mm)	2
	55-7042	NUT	2
	55-7075	FLATWASHER	6
	55-9054	WASHER (nylon)	6
4	91-8205	CAP - retainer	1
5	98-5226	GRILLE - condenser	1
	55-6994	SCREW - grille	4
	55-6995	FLATWASHER	4
	55-8877	WASHER - insulation	4
	55-9054	WASHER - insulation	4
6	509-755	DOOR - evaporator	1
	33-3968	GASKET - door	1
	92-2995	HINGE - evap door	3
	51-620	RIVET - hinge	12
7	91-8133	KNOB - door	1
8	55-7035	SCREW - knob	3
9	91-8199	SPRING	3
10	55-7354	NUT	3
11	55-8877	WASHER (nylon)	3
12	91-9041	LATCH	3
	55-2864	RIVET - latch	6
13	91-8134	ISOLATOR	3
	55-7341	SCREW - door	6
	55-7085	FLATWASHER	6
	55-8882	WASHER (nylon)	6
14	509-1654	HINGE	3
15	91-8256	PIN - hinge (w/ snap)	3
16	98-5199	DOOR - heater access	1
	33-2958	GASKET - door	1






Revised 8/12/04

CONDENSER COMPONENTS (UNITS w/ 3 EVAP FANS)



REF	PART#	DESCRIPTION	QTY
	55-6993	SCREW - door	8
	55-7085	FLATWASHER	8
	55-8882	WASHER (nylon)	8
17	91-8195	KEEPER - door	3
	55-7172	SCREW - keeper	6
	55-6995	FLATWASHER	6
	55-8933	WASHER (nylon)	6
18	91-8694	NAMEPLATE - Caution, Fan	1
19	91-8474	PLATE - guard	1
	55-7341	SCREW - plate (20 mm)	2
	55-6987	SCREW - plate (30 mm)	2
	55-6988	FLATWASHER	4
	55-8953	WASHER (nylon)	6
20	509-937	STRAP - door	1
	55-9173	SCREW - strap	1
	55-7089	FLATWASHER	2
21	91-9039	HOOK - strap	1
	55-3065	CLAMP - hook	1
	55-9166	SCREW - clamp	1
22	91-8728	PLATE - thermostat cover	1
	55-7341	SCREW - plate	3
	55-6988	FLATWASHER	3
	55-8953	WASHER (nylon)	3
23	33-3002	GASKET - door	1






CONDENSER COMPONENTS (UNITS w/ 2 EVAP FANS)




REF	PART#	DESCRIPTION	QTY
1	91-8195	KEEPER - door latch	2
	55-9312	SCREW - keeper (TIR seal)	4
	55-6995	WASHER	4
	55-9054	WASHER (nylon)	4
	55-8877	WASHER (nylon)	4
2	91-8108	BRACKET - frame	1
	55-6993	SCREW - bracket	3
	55-6988	WASHER	6
	55-8882	WASHER (nylon)	6
	55-9380	NUT	3
3	91-9504	PLATE - cable storage (front)	1
	55-9168	NUT	2
	55-9054	WASHER (nylon)	6
	55-6994	SCREW - plate	2
	55-6695	FLATWASHER	6
	55-8933	WASHER (nylon)	6
4	Not Used		
5	98-5925	GRILLE - condenser	1
	55-8910	SCREW - grille	4
	55-7075	FLATWASHER	4
	55-9054	WASHER (nylon)	4
6	98-6518	DOOR - evaporator	1
	92-2995	HINGE - evap door	2
	51-620	RIVET - hinge	8
7	91-9040	• KNOB	2
8	55-7035	• SCREW - door	2
9	91-8199	• SPRING	2
10	55-7354	• NUT	2
11	55-9054	WASHER (nylon)	2
12	91-9041	• LATCH - door	2
	55-2864	• RIVET - latch	4
13	91-8134	INSULATOR - latch	2
14	509-1654	• HINGE	2
	55-9313	SCREW - hinge (TIR seal)	4
	55-8882	WASHER (nylon)	4
15	91-8256	• PIN - hinge (w/ snap)	2
16	98-5199	DOOR - heater section	1
	55-6993	SCREW - door	4
	55-9313	SCREW - door (TIR seal)	1
	55-8882	WASHER (nylon)	8






Revised 1/21/05

CONDENSER COMPONENTS (UNITS w/ 2 EVAP FANS)




REF	PART#	DESCRIPTION	QTY
	55-7085	WASHER	8
17	98-5478	FRAME - condenser	1
18	33-3968	GASKET - evaporator door	1
19	33-3002	GASKET - door	1
20	33-2983	GASKET - unit	1
21	91-8728	COVER (instead of thermometer)	1
	55-7391	SCREW - cover	3
	55-6988	FLATWASHER	3
22	91-8664	PLATE - guard	1
	55-7341	SCREW - plate (20 mm)	2
	55-6993	SCREW - plate (25 mm)	1
	55-6988	FLATWASHER	3
	55-8953	WASHER (nylon)	3
23	91-9039	HOOK - strap	1
	55-3065	CLAMP - hook	1
	55-9166	SCREW - clamp	1
24	509-937	STRAP - door	1
	55-9173	SCREW - strap	1
	55-7089	FLATWASHER	2
25	91-9912	ORIFICE - condenser	1
	55-7035	SCREW - orifice	4
	55-7075	FLATWASHER	4
	55-3045	WASHER - dome	4
	55-8849	NUT - captive	4
26	83-257	GROMMET	2
27	91-9511	NAMEPLATE - TK	1
28	91-9949	PORT - injection	2
	55-9211	RIVET - port	4
29	91-9950	HOUSING - relief valve	1
	55-9211	RIVET - housing	4
30	91-9951	VALVE - pressure relief	1
31	91-9952	PORT - purge	1
	55-9211	RIVET - port	2






REF	PART#	DESCRIPTION	QTY
1	91-8098	RETAINER - probe	1
2	509-964	CAP - retainer (w/o hole)	1
3	91-8702	CAP - retainer (w/ hole)	1
4	33-2960	GASKET - retainer	1
5	91-9754	POCKET - sensor	1
6	55-6409	CONNECTOR - sensor	1
7	91-9754	POCKET - sensor	2



AIR VENT (40 FT CONTAINERS)




REF	PART#	DESCRIPTION	QTY
	91-8252	VENT - air (complete)	1
1	91-9048	BRACKET - air vent handle	1
2	51-1426	SCREW - handle	1
	51-1474	• SCREW (M8 x 1.25 x 65, ss)	1
	55-9541	WASHER (nylon)	4
	51-1427	• NUT	1
3	91-8100	• SPRING	1
4	92-440	NAMEPLATE - Do Not Open Below 0 C	1
5	91-8102	HANDLE - air vent	1
6	77-2467	BEARING - slide	1
7	91-8104	BRACKET - handle	1
8	51-1428	• NUT	2
	51-1429	• LOCKWASHER	1
	51-1430	• FLATWASHER	1
9	51-1431	• NUT - wing	1
10	91-8103	DISK - air vent	1
11	33-4255	GASKET - air vent	1
12	91-8105	PLATE - air vent	1
	55-7172	SCREW - plate	4
	55-7075	• FLATWASHER	4
	55-9541	WASHER (nylon)	4
13	33-2944	GASKET - air vent	1
14	91-8663	• PROTECTOR - edge	1
15	91-8106	• PIN - hinge	1
16	91-8107	NAMEPLATE - Do Not Open Below 0 C	1
17	55-9168	ADAPTER - hose	1
18	92-411	HINGE - air vent	1
	51-619	SCREW - vent	8
	55-8933	WASHER - insulator (6.4 id)	4
	55-7075	FLATWASHER	4
	55-9054	WASHER - insulator (8.4 id)	6
	51-167	FLATWASHER	6
	55-7339	NUT	6



EVAPORATOR PANELS (UNITS w/ 3 EVAP FANS)



REF	PART#	DESCRIPTION	QTY
1	91-8258	PLATE - rear (bottom)	1
	98-5556	PLATE - rear (bottom, SL units)	1
	55-2264	RIVET - plate	36
2	98-5335	PLATE - rear (top)	1
	98-5555	PLATE - rear (top, SL units)	1
	55-8937	SCREW - plate	26
3	98-5200	GRILLE - evaporator (CRR 40 & CSR 40)	1
	91-8627	GRILLE - evaporator (CSR 40SL)	1
	509-1766	GRILLE - evaporator (CRR 20)	1
	55-2264	RIVET - grille	17
4	98-5925	CHANNEL - Z (CRR 40 & CSR 40)	3
	509-1772	CHANNEL - Z (CSR 40 SL)	3
	55-9055	RIVET - channel	21
5	33-2983	GASKET - unit	1
6	91-8760	PANEL - USDA receptacle (CSR 20 & 40 SL)	1
	91-8645	PANEL - USDA receptacle (CRR 40 & CSR 40)	1
	55-9055	RIVET - panel	4
7	41-2405	CONNECTOR - receptacle (5 pin)	1
	41-2575	HARNESS - adapter (cannon bayonet connector)	1
	41-2576	HARNESS - adapter (cannon threaded connector)	1
	55-8382	SCREW - receptacle	4
	55-8410	FLATWASHER	8
	55-7864	NUT	4
8	41-2406	CAP - dust	1
9	99-3685	CHAIN - cap	5
10	41-2541	RECEPTACLE (3 pin)	4
	55-2262	RIVET - receptacle	16
	55-8410	FLATWASHER	16
11	44-9602	PIN - sealing	5
12	41-890	CAP - dust	4
13	91-8135	CHANNEL - air (CRR-40 & CSR-40)	1
	509-1762	CHANNEL - fresh air (CSR 40 SL)	1
	203-389	SEALER - polyurethane	A/R
	55-8891	SCREW - channel	6
14	91-8141	INLET - fresh air	1
	55-2270	RIVET - inlet	10
	203-389	SEALER - polyurethane	A/R
15	91-8136	CHANNEL - fresh air (CRR 40 & CSR 40)	1
	509-1764	CHANNEL - fresh air (CRR 20)	1
	55-2270	RIVET - channel	8
16	91-8734	NAMEPLATE - USDA Connections	1




Revised 10/27/03

EVAPORATOR PANELS (UNITS w/ 3 EVAP FANS)




REF	PART#	DESCRIPTION	QTY
17	41-3107	SENSOR - USDA (options 098078, 098109 & 098126, 14 m lg)	2



EVAPORATOR PANELS (UNITS w/ 2 EVAP FANS)



REF	PART#	DESCRIPTION	QTY
1	509-557	PLATE - rear (bottom)	1
	55-2264	RIVET - plate	36
2	509-473	PLATE - rear (top)	1
	55-8937	SCREW - plate	26
3	98-5480	GRILLE - evaporator	1
	98-5523	GRILLE - evaporator (Transfresh)	1
	55-2264	RIVET - grille	17
4	91-8097	CHANNEL - Z (CSR 40)	1
	509-1772	CHANNEL - Z (CSR 40 SL)	3
	55-9055	RIVET - channel	21
5	33-2983	GASKET - unit	1
	91-8645	PANEL - USDA receptacle (CRR 40)	1
6	91-8760	PANEL - USDA receptacle (CRR 20)	1
	55-9055	RIVET - panel	4
7	41-2405	CONNECTOR - receptacle (5 pin)	1
	41-2575	HARNESS - adapter (cannon bayonet connector)	1
	41-2576	HARNESS - adapter (cannon threaded connector)	1
	55-8382	SCREW - receptacle	4
	55-8410	FLATWASHER	8
	55-7864	NUT	4
8	41-2406	CAP - dust	1
9	99-3685	CHAIN - cap	5
10	41-890	RECEPTACLE (3 pin)	4
	55-2262	RIVET - receptacle	16
	55-8410	FLATWASHER	16
11	44-9602	PIN - sealing	5
12	41-2539	CAP - dust	4
13	91-9329	CHANNEL - air	1
	203-389	SEALER - polyurethane	A/R
	55-8891	SCREW - channel	6
14	91-9330	INLET - fresh air	1
	55-2270	RIVET - inlet	10
	203-389	SEALER - polyurethane	A/R
15	91-9331	CHANNEL - fresh air	1
	55-2270	RIVET - channel	8
16	91-8734	NAMEPLATE - USDA Connections	1
17	41-3107	SENSOR - USDA (option 098078)	2




Revised 9/15/98

TRANSFRESH GROUP (OPTION 098038)




REF	PART#	DESCRIPTION	QTY
1	98-5320	GRILLE - evaporator	1
2	91-8715	BOX - Transfresh	1
	55-7713	RIVET - box	4
3	41-2554	CABLE - Transfresh (red bandwrap, 160 in lg)	1
4	41-2555	CABLE - Transfresh (green bandwrap, 120 in lg)	1





REF	PART#	DESCRIPTION	QTY
1	91-8244	BRACKET - hose	1
2	99-3281	MOUNT - cable tie	5
	55-2260	RIVET - anchor	5
3	55-2686	CLAMP - hose	2
4	55-8891	SCREW - bracket	2
5	55-9208	CONNECTOR - T-hose	1
6	55-2330	BANDWRAP	6
7	11-8983	HOSE - flex	1





REF	PART#	DESCRIPTION	QTY
1	91-8475	NAMEPLATE - TK (crest)	1
2	91-8756	NAMEPLATE - Thermo King	1
3	91-8665	NAMEPLATE - Smart Reefer	1
4	91-8154	NAMEPLATE - R404A	1
5	91-8694	NAMEPLATE - Fan Start Automatically	1
6	99-7834	NAMEPLATE - Caution	1
7	91-8746	NAMEPLATE - Ingersoll Rand	1
8	91-8738	NAMEPLATE - Operating Instructions	1
9	91-8697	NAMEPLATE - Transfresh Data A3	1
10	91-8696	NAMEPLATE - Transfresh Scrubber A5	1
11	509-1150	NAMEPLATE - Air Vent	1
12	91-9441	NAMEPLATE - Air Vent Handle	1
13	91-8734	NAMEPLATE - USDA Connections	1
14	509-1157	NAMEPLATE - USDA Sensors	1
15	91-8202	NAMEPLATE - arrow	3
16	91-8589	NAMEPLATE - Control Box Layout	1
17	91-8695	NAMEPLATE - Warning, Hot Components	1
18	91-8755	NAMEPLATE - Temperature Conversion	1
19	91-8673	NAMEPLATE - Crowley Secure Cable	1
20	91-8674	NAMEPLATE - Crowley service	1
21	91-8675	NAMEPLATE - Crowley Service Log	1

10-243	80	33-2983	88, 94, 98	41-2503	30, 32
102-671	18, 24, 30, 32	33-3002	84, 88	41-2517	30, 32, 34, 44
102-796	14, 22, 30	33-3007	14	41-2518	34, 44
104-639	30	33-3008	54, 62	41-2519	44
104-689	8, 32	33-3043	72	41-2520	36, 38
104-691	10, 12, 30, 32	33-3044	12	41-2521	36, 38
11-4367	80	33-3215	10, 12	41-2522	36
11-4841	80	33-367	8	41-2524	44
11-4860	80	33-3838	10, 12, 34	41-2537	72
	80, 102		82, 88		72
11-8983	-	33-3968	-	41-2538	
11-9082	80	33-4255	92	41-2539	98
11-9083	80	33-451	54, 62	41-2541	94
11-9084	80	33-566	16	41-2543	42
11-9085	80	33-727	22	41-2554	100
20-166	22	40-534	70	41-2555	100
203-179	60	40-776	24	41-2556	76
203-180	58, 64, 66	40-779	22, 24	41-2575	34, 94, 98
203-219	64, 66	40-781	22, 24, 30, 32	41-2576	34, 94, 98
203-252	64, 66	40-871	30, 32	41-2689	36, 38, 40
203-389	94, 98	41-1292	42	41-2690	36, 38
203-392	46	41-1310	48	41-2691	80
203-392	46	41-1510	48	41-2701	36
203-516	22, 24	41-1932	42	41-2813	78
203-525	70	41-1946	44	41-2814	78
204-1038	52	41-1976	30, 32	41-2815	78
204-209	68	41-1977	74	41-2816	78
204-622	78	41-2129	36, 38	41-2817	78
204-623	48	41-2170	34	41-2818	78
204-624	48	41-2208	36, 38	41-2819	78
204-635	78	41-2209	36, 38	41-2820	30
204-636	78	41-2210	36, 38	41-2838	26
204-703	52	41-2216	58, 60	41-2841	18
204-799	52	41-2218	58, 60	41-3083	74
204-918	34	41-2219	60	41-3107	96, 98
			60		
204-974	34	41-2224		41-3112	10, 30
204-975	34	41-224	44	41-3113	12
33-1015	16	41-2247	44	41-3114	12
33-1435	34	41-2248	44	41-3115	32
33-1936	14	41-2249	36, 40, 44	41-3116	8, 30, 32
33-2392	50	41-225	44	41-3117	80
33-2393	50	41-2319	36, 38, 44	41-3341	30
33-2394	50	41-2322	50	41-3401	30
33-2395	50	41-2323	50	41-3429	74
33-2396	50	41-2324	50	41-4021	30, 32
33-2397	50	41-2325	50	41-4382	66
33-2482	74	41-2326	50	41-4523	22, 30
33-2630	76	41-2327	50	41-530	22, 30
33-2632	78	41-2399	16, 18, 26	41-5460	26
33-2753	34	41-2401	36, 38	41-5635	26, 80
	22	41-2402	44		44
33-2805				41-743	
33-2944	92	41-2405	44, 94, 98	41-744	44
33-2946	10, 12	41-2406	34, 94, 98	41-745	44
33-2950	8	41-2407	36, 38	41-747	44
33-2951	22, 24	41-2446	36, 38	41-748	44
33-2958	82	41-2447	22, 30	41-767	14, 16, 20, 30
33-2960	68, 90	41-2492	36, 38	41-890	94, 98
33-2962	58, 60	41-2493	36, 38	41-896	76
33-2979	22, 24	41-2494	36, 40	44-2339	58
33-2981	46	41-2495	36, 40	44-2966	58
			•		

44 2020	74	44.0500	50	EE 2001	74
44-3828	74	44-9590	50	55-2001	74
44-4051	30	44-9591	50	55-2086	78
44-5114	68	44-9600	50	55-2201	78
44-5133	74	44-9601	50	55-2260	102
44-5175	28	44-9602	50, 94, 98	55-2262	94, 98
44-5534	70	44-9631	50	55-2264	72, 94, 98
44-5537	76	44-9700	50	55-2270	94, 98
44-5644	58	44-9701	50	55-2296	16, 18
44-5835	48, 70	44-9780	66	55-2324	10
44-5836	48	44-9781	66	55-2330	12, 34, 102
44-5837	48	44-9890	32	55-2332	12, 36, 38
44-5838	48	44-9891	30	55-2363	46
44-5839	48	44-9900	50	55-2561	80
44-5883	48	44-9901	50	55-2636	74
44-5884	48	44-9902	50	55-2686	102
44-5885	48	44-9903	50	55-2748	78
44-6310	30, 32	44-9904	50	55-2864	36, 38, 82, 8 6
44-6324	48	44-9905	50	55-2964	74
44-6560	34	44-9906	50	55-2977	78
44-6591	70	44-9907	52	55-2988	54, 62
44-6822	76	45-1320	30	55-2993	78
44-6959	48	45-1711	38	55-2995	74
44-7327	48	45-1791	12, 30, 32	55-2998	78
44-7330	48	45-1806	36, 38, 42	55-3008	70
44-7341	78	45-1830	54, 58, 62	55-3023	78
44-7342	78	45-1831	62, 66	55-3045	88
44-739	34	45-1832	62, 66	55-3059	78
44-7782	66	45-1834	54, 60	55-3065	84, 88
44-7811	48	45-1853	36	55-3136	12
44-7812	48	45-1859	74	55-3250	20
44-7829	48	504-977	26	55-3251	18
44-7872	48	505-390	66	55-3256	78
44-7880	48	508-165	10	55-3319	78
44-7881	48	509-1150	104	55-3680	14, 22
44-7884	48		104		78
	48	509-1157		55-4223 55-4250	
44-8294		509-1654	82, 86	55-4359 55-4300	80
44-8340	8, 10	509-1762	94	55-4390	14, 18
44-8681	48	509-1764	94	55-5099	58, 60
44-8779	44	509-1766	94	55-5111	70, 78
44-8813	36, 38	509-1772	94, 98	55-5257	34
44-8851	48	509-473	98	55-5900	34
44-8853	48	509-557	98	55-5919	74
44-8914	50	509-755	82	55-6147	34, 46
44-8915	50	509-911	66	55-6218	14
44-8917	50	509-937	84, 88	55-6409	90
44-8918	50	509-964	90	55-6695	86
44-8920	50	51-1426	92	55-6905	80
44-8921	50	51-1427	92	55-6987	84
44-8935	50	51-1428	92	55-6988	8, 10, 16, 18, 54, 62, 82,
44-8936	50	51-1429	92		84, 86, 88
44-9524	42	51-1430	92	55-6993	8, 10, 12, 16, 18, 82, 84,
44-9536	50	51-1431	92	55 5550	86, 88
44-9544	50	51-1 4 51 51-1474	92	55-6994	8, 14, 18, 34, 46, 70, 82,
44-9545	50	51-1474	92	00 0004	86
				55 600E	
44-9569	48	51-619	92	55-6995	8, 54, 62, 70, 74, 78, 82,
44-9585	50	51-620	82, 86	FF 0000	84, 86
44-9586	50	55-1203	26	55-6996	54, 62, 70
44-9587	50	55-1659	18	55-6997	70
44-9589	50	55-1801	78	55-6999	22

55-7033 46, 54, 62, 64, 70 55-8910 86 66-7302 14 55-7034 46, 54, 62, 70 55-8912 22, 24 66-7333 20 55-7042 81, 14, 18, 46, 74, 78, 82 55-8912 22, 24 66-7780 28 55-7076 81, 14, 18, 44, 67, 74, 82 55-8912 22, 24 66-7781 28 55-7078 8, 14, 16, 18, 34, 46, 74, 78, 82 55-8912 29, 98 66-7865 14, 20, 30, 32 55-7085 12, 74, 80, 82, 84, 88 55-8913 14, 16 66-8054 22 55-7059 84, 88 55-8914 14, 16 66-8054 22 55-7151 80 55-8915 14, 16 66-8047 14 55-71710 46, 74 55-8955 58, 60 66-8473 14 55-71710 46, 74 55-8981 28 66-8047 14 55-73740 46, 74 55-8982 22, 24 66-9001 14 55-7331 44, 22 55-8982 22, 24 66-901 14 <	55-7031	38	55-8908	8, 10, 34	66-7183	22
65-7034 46, 54, 62, 70 55-8911 22, 24 66-7533 20 55-7042 8, 170, 82, 86, 88 55-8917 14 66-7791 28 55-7068 8, 10, 12 55-8937 94, 98 66-7865 14, 20, 30, 32 55-7065 8, 14, 16, 18, 34, 46, 74, 55-8937 94, 98 66-7861 14, 20, 30, 32 55-7095 82, 86, 88, 92 55-8950 14, 16 66-7861 14, 20, 30, 32 55-7095 84, 88 55-8951 14, 16 66-8067 16, 20, 30 55-7161 80 55-8956 54, 62, 84, 88 66-367 14 55-7171 80, 67, 46, 64 55-8986 10 66-8767 14 55-71721 81, 18, 54, 62, 74, 82, 55-8981 22, 24 66-9004 14 55-7331 84, 92 55-8994 22, 24 66-9018 14 55-7341 54, 62, 74, 82, 84, 88 55-902 22, 24 66-9018 14 55-7332 80, 12, 27, 4 55-903 44 66-902 14, 18 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
55-7042 8, 70, 82, 86, 88 55-8912 22, 24 66-7791 28 55-7042 8, 14, 18, 46, 74, 78, 82 55-8917 14 66-7791 28 55-7075 8, 14, 16, 18, 34, 46, 74, 55-8937 94, 98 66-7865 14, 20, 30, 32 82, 86, 88, 92 55-8950 14, 16 66-7981 14 55-7085 12, 74, 80, 82, 84, 88 55-8951 14, 16 66-8054 22 55-7089 84, 88 55-8951 14, 16 66-8054 22 55-7181 80						
55-7042						
65-7066 8, 10, 12 55-8933 94, 86 92 66-7812 22 55-7075 82, 86, 88, 92 55-8951 14, 16 66-7981 14, 20, 30, 32 55-7085 12, 74, 80, 82, 84, 88 55-8951 14, 16 66-7981 14, 20, 30 55-7161 80 55-8955 58, 60 66-8367 14, 20, 30 55-71710 46, 74 55-8961 10 66-877 14 55-71710 46, 74 55-8961 28 66-8014 14 55-7373 8, 12, 80, 82, 92 55-8991 22 24 66-9016 14, 18 55-7339 8, 12, 80, 82, 92 55-8995 22, 24 66-9019 16 55-7341 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9019 16 55-7342 54, 62, 82, 86 55-9030 44 66-9021 14 55-7357 74 55-9053 14, 18 66-9022 14 55-7367 74 55-9053 14, 18 66-9022						
65-70750 8, 14, 16, 18, 34, 46, 74, 55-8937 94, 98 66-7865 14, 20, 30, 32 55-7085 12, 74, 80, 82, 84, 88 55-8950 14, 16 66-7891 14 55-7085 12, 74, 80, 82, 84, 88 55-8951 54, 62, 84, 88 66-8367 16, 20, 30 55-7169 54, 62, 64 55-8966 10 66-8767 14 55-71712 16, 18, 54, 62, 74, 82, 55-8981 28 66-9004 14 55-7172 16, 18, 54, 62, 74, 82, 55-8991 22, 24 66-9016 14, 18 55-7340 54, 62 55-8995 22, 24 66-9016 14, 18 55-7341 54, 62 55-8995 22, 24 66-9018 14 55-7342 8, 12, 74 55-9013 22, 24 66-9019 14 55-7354 54, 62, 74, 82, 84, 88 56-9029 46 66-9020 14, 18 55-7354 54, 62, 82, 86 55-9013 22, 24 66-9021 14 55-7360 38, 70 55-9055 14, 18 66-9023 14						
82, 86, 88, 89, 22 55-8950 14, 16 66-8961 14 55-7089 84, 88 55-8951 55-8951 66-8054 22 55-7169 84, 88 55-8953 54, 62, 84, 88 66-8367 16, 20, 30 55-71710 46, 74 55-8967 38 66-8811 14 55-71710 46, 74 55-8967 38 66-8811 14 55-71710 46, 74 55-8967 38 66-8811 14 55-71710 46, 74 55-8967 38 66-8811 14 55-73730 8, 12, 80, 82, 92 55-8994 22, 24 66-9016 14, 18 55-7341 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9019 16 55-7341 54, 62, 82, 86 55-9030 44 66-9022 14 55-7357 74 55-9053 14, 18 66-9022 14 55-7360 22, 24 55-9053 14, 18 66-9022 14 55-7367 74 55-9057 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
65-70865 12, 74, 80, 82, 84, 88 55-8951 14, 16 66-8054 22 55-7089 84, 88 55-8955 58, 60 66-8367 14 55-7170 54, 62, 64 55-8956 10 66-8767 14 55-71712 16, 18, 54, 62, 74, 82, 55-8991 26 66-9004 14 55-7339 8, 12, 80, 82, 92 55-8994 22, 24 66-9016 14, 18 55-7331 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9016 14, 18 55-7341 54, 62, 74, 82, 84, 88 55-9013 22, 24 66-9012 14 55-7342 8, 12, 74 55-9013 22, 24 66-9021 14 55-7354 54, 62, 82, 86 55-9030 44 66-9022 14 55-7356 22, 24 55-9055 74 66-9023 14 55-7357 38, 70 55-9055 49, 88 66-9022 14 55-7368 36, 38 55-914 80 66-9020 16, 18 55-73786 <td>00 / 0/ 0</td> <td></td> <td></td> <td></td> <td></td> <td></td>	00 / 0/ 0					
65-7089 84, 88 55-8953 54, 62, 84, 88 66-8367 16, 20, 30 55-7169 54, 62, 64 55-8956 560 66-8473 14 55-7170 46, 74 55-8987 38 66-8811 14 55-71710 46, 74 55-8987 38 66-8811 14 55-71710 46, 74 55-8981 26 66-9004 14 55-77310 54, 62, 74, 82, 84, 88 55-8991 22, 24 66-9018 14, 18 55-7340 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9019 16 55-7341 54, 62, 82, 84, 85-9012 22, 24 66-9020 14, 18 55-7344 22, 74 55-9053 44 66-9021 14 55-7357 74 55-9054 8, 82, 86, 92 66-9022 14 55-7367 74 55-9054 4, 88 66-9029 16 55-7367 74 55-9055 94, 98 66-9026 16 55-7368 34, 70	55-7085					
55-71515 80 55-8955 58, 60 66-8473 14 55-7169 54, 62, 64 55-8986 10 66-8767 14 55-7170 46, 74 55-8987 38 66-8811 14 55-71721 16, 18, 54, 62, 74, 82, 55-8991 26 66-9006 14, 18 55-7339 8, 12, 80, 82, 92 55-8994 22, 24 66-9016 14, 18 55-7340 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9019 16 55-7341 54, 62, 74, 82, 84, 88 55-9013 22, 24 66-9021 14 55-7342 8, 12, 74 55-9013 22, 24 66-9021 14 55-7354 54, 62, 82, 86 55-9030 44 66-9022 14 55-73567 74 55-9053 14, 18 66-9024 14 55-7367 74 55-9053 49, 98 66-9026 16 55-7368 36, 38 55-914 80 66-9026 16, 18 55-7368 36, 38						
55-7169 54, 62, 64 55-8986 10 66-8767 14 55-7170 46, 74 55-8987 38 66-8811 14 55-7170 16, 18, 54, 62, 74, 82, 55-8991 26 66-9016 14, 18 55-7340 54, 62 55-8995 22, 24 66-9018 14 55-7341 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9020 14, 18 55-7342 8, 12, 74 55-9012 22, 24 66-9020 14, 18 55-7343 8, 12, 74 55-9013 22, 24 66-9021 14 55-7343 8, 12, 74 55-9013 22, 24 66-9021 14 55-7344 22, 74 55-9014 66-9022 14 55-7357 74 55-9053 14, 18 66-9024 14 55-7367 38, 70 55-9055 94, 98 66-9027 16, 20 55-7368 34, 70 55-9162 12 66-9022 16, 18 55-7389 36, 38 59-918 8						
55-7170 46, 74 55-891 26 66-9004 14 55-7172 16, 18, 54, 62, 74, 82, 55-8991 26 66-9004 14 55-7339 8, 12, 80, 82, 92 55-8994 22, 24 66-9018 14 55-7340 54, 62 55-8995 22, 24 66-9019 16 55-7341 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9020 14, 18 55-7342 8, 12, 74 55-9012 22, 24 66-9021 14 55-7354 54, 62, 82, 86 55-9030 44 66-9023 14 55-7360 22, 24 55-9054 8, 82, 86, 92 66-9026 16 55-7367 38, 70 55-9055 94, 98 66-9027 16, 18 55-7368 36, 38 55-9149 80 66-9030 16, 18 55-7378 38, 70 55-9164 74 66-903 16, 18 55-7389 36, 38 55-9149 80 66-903 16, 18 55-7391 88						
65-7172 16, 18, 54, 62, 74, 82, 55-8991 26 66-90016 14, 18 55-7330 8, 12, 80, 82, 92 55-8994 22, 24 66-9018 14 55-7340 54, 62 55-8994 22, 24 66-9019 16 55-7341 54, 62, 74, 82, 84, 88 55-9013 22, 24 66-9021 14, 18 55-7342 8, 12, 74 55-9013 22, 24 66-9021 14 55-7344 22, 74 55-9029 46 66-9022 14 55-7357 74 55-9053 14, 18 66-9024 14 55-7357 74 55-9053 14, 18 66-9024 14 55-7367 38, 70 55-9055 94, 98 66-9026 16, 20 55-7368 34, 70 55-9067 76 66-9029 16, 18 55-73780 38, 46, 70 55-9162 12 66-9032 16, 18, 26, 30 55-7439 38 55-9164 74 66-9032 16, 18, 26, 30 55-7404 54, 62, 64						
84, 92 55-8994 22, 24 66-9016 14, 18 55-7330 8, 12, 80, 82, 92 55-8995 22, 24 66-9018 14 55-7341 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9020 14, 18 55-7342 8, 12, 74 55-9013 22, 24 66-9021 14 55-7354 54, 62, 82, 86 55-9030 44 66-9022 14 55-7360 22, 24 55-9053 14, 18 66-9024 14 55-7360 32, 24 55-9054 8, 82, 86, 92 66-9026 16 55-7360 38, 70 55-9057 76 66-9029 16, 18 55-7368 34, 70 55-9149 80 66-9029 16, 18 55-73786 36, 38 55-9164 74 66-9030 16, 18 55-73786 36, 67 55-9162 12 66-9032 16, 18, 26, 30 55-73786 20 55-9164 74 66-9033 14 55-7377 88 55-9174						
55-7339 8, 12, 80, 82, 92 55-8995 22, 24 66-9018 14 55-7340 54, 62 74, 82, 84, 88 55-9012 22, 24 66-9020 14, 18 55-7341 8, 12, 74 55-9013 22, 24 66-9021 14 55-7342 8, 12, 74 55-9030 44 66-9022 14 55-7357 74 55-9053 14, 18 66-9022 14 55-7367 74 55-9053 14, 18 66-9022 14 55-7367 38, 70 55-9055 94, 98 66-9027 16, 20 55-7368 34, 70 55-9057 76 66-9029 16, 18 55-7370 38, 46, 70 55-9162 12 66-9030 16, 18 55-7391 88 62, 64 55-9166 30, 84, 88 66-903 16, 18 55-7404 54, 62, 64 55-9168 36, 92 66-903 16, 18 55-7617 70 55-9172 22 66-9037 16 55-7						
55-7340 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9020 14, 18 55-7341 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9020 14, 18 55-7342 8, 12, 74 55-9029 46 66-9022 14 55-7357 74 55-9053 14, 18 66-9024 14 55-7360 22, 24 55-9054 8, 82, 86, 92 66-9024 14 55-7360 22, 24 55-9057 76 66-9029 16, 18 55-7368 34, 70 55-9057 76 66-9029 16, 18 55-7369 36, 38 55-9149 80 66-9030 16, 18 55-7373 38, 46, 70 55-9164 74 66-9033 16, 18, 26, 30 55-7386 36, 38 55-9166 30, 84, 88 66-9034 16, 18, 26, 30 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7617 44 55-9172 22 66-9036 16, 20 55-76	55-7339					
65-7341 54, 62, 74, 82, 84, 88 55-9012 22, 24 66-9020 14, 18 55-7324 22, 74 55-9039 46 66-9021 14 55-7354 54, 62, 82, 86 55-9030 44 66-9023 14 55-7357 74 55-9053 14, 18 66-9024 14 55-7367 22, 24 55-9055 94, 98 66-9027 16, 20 55-7367 38, 70 55-9057 76 66-9029 16, 18 55-7368 34, 70 55-9057 76 66-9029 16, 18 55-7370 38, 46, 70 55-9162 12 66-9030 16, 18 55-7386 20 55-9164 74 66-9033 16, 18 55-7404 54, 62, 64 55-9164 74 66-9033 16, 18 55-7479 70 55-9172 22 66-9035 16, 18 55-7617 44 55-9174 22 66-9037 16 55-7617 44 55-9174 <						
55-7342 8, 12, 74 55-9029 46 66-9021 14 55-7354 54, 62, 82, 86 55-9030 44 66-9022 14 55-7357 74 55-9053 14, 18 66-9024 14 55-7360 22, 24 55-9054 8, 82, 86, 92 66-9026 16 55-7367 38, 70 55-9057 76 66-9029 16, 18 55-7368 34, 70 55-9057 76 66-9029 16, 18 55-7370 38, 46, 70 55-9162 12 66-9032 16, 18, 26, 30 55-7386 20 55-9164 74 66-9033 14 55-7386 20 55-9168 86, 92 66-9032 16, 18, 26, 30 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7404 54, 62, 64 55-9173 22 66-9036 16, 20 55-7464 62 55-9174 22 66-9036 16, 20 55-7617 70 55-9173<		•				
55-7344 22, 74 55-9029 46 66-9022 14 55-7357 74 65-9053 14, 18 66-9024 14 55-7367 74 55-9053 14, 18 66-9024 14 55-7367 38, 70 55-9054 8, 82, 86, 92 66-9026 16 55-7368 34, 70 55-9057 76 66-9029 16, 18 55-7389 36, 38 55-9149 80 66-9030 16, 18 55-7362 20 55-9164 74 66-9033 16, 18, 26, 30 55-7391 88 55-9164 74 66-9033 14 55-7404 54, 62, 64 55-9168 36, 92 66-9034 16, 18 55-7479 70 55-9172 22 66-9035 16, 18 55-7617 44 55-9173 26, 84, 88 66-9155 16, 18 55-7686 34, 70 55-9173 28, 84, 88 66-9155 16, 18, 26 55-7697 36, 38 55-9217						
55-7354 54, 62, 82, 86 55-9030 44 66-9024 14 55-7357 74 55-9054 8, 82, 86, 92 66-9026 16 55-7367 38, 70 55-9055 94, 98 66-9027 16, 20 55-7368 34, 70 55-9057 76 66-9029 16, 18 55-7369 36, 38 55-9149 80 66-9030 16, 18 55-7370 38, 46, 70 55-9162 12 66-9032 16, 18, 26, 30 55-7386 20 55-9164 74 66-9033 14 55-7386 20 55-9166 30, 84, 88 66-9034 16, 18 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7404 54, 62, 64 55-9172 22 66-9037 16 55-7464 62 55-9172 22 66-9037 16 55-7617 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7618 44 55-913<						
55-7357 74 55-9053 14, 18 66-9024 14 55-7360 22, 24 55-9054 8, 82, 86, 92 66-9026 16 55-7367 38, 70 55-9057 76 66-9029 16, 18 55-7369 36, 38 55-9149 80 66-9032 16, 18 55-7378 20 55-9162 12 66-9032 16, 18, 26, 30 55-7386 20 55-9164 74 66-9032 16, 18, 26, 30 55-7391 88 55-9166 30, 84, 88 66-9034 16, 18 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7479 70 55-9172 22 66-9036 16, 20 55-7618 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7658 34, 70 55-9173 26, 84, 88 66-9181 14, 22 55-7698 36, 38 55-9218 80, 102 66-9306 18 55-7749 76 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td></t<>						
55-7360 22, 24 55-9054 8, 82, 86, 92 66-9026 16, 20 55-7367 38, 70 55-9057 76 66-9029 16, 18 55-7369 36, 38 55-9149 80 66-9030 16, 18 55-7370 38, 46, 70 55-9162 12 66-9033 14 55-7391 88 55-9166 30, 84, 88 66-9034 16, 18 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7404 54, 62, 64 55-9172 22 66-9036 16, 20 55-7479 70 55-9172 22 66-9037 16 55-7617 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7618 44 55-9174 76 66-9159 14, 20, 30 55-7697 36, 38 55-9195 38 66-9159 14, 20, 30 55-7698 36, 38 55-9211 86 66-9419 20 55-7749 76 55-9312						
55-7367 38, 70 55-9055 94, 98 66-9027 16, 20 55-7368 34, 70 55-9057 76 66-9029 16, 18 55-7370 38, 46, 70 55-9162 12 66-9032 16, 18, 26, 30 55-7386 20 55-9164 74 66-9033 14 55-7391 88 55-9168 30, 84, 88 66-9034 16, 18 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7464 62 55-9171 22 66-9036 16, 20 55-7479 70 55-9172 22 66-9037 16 55-7618 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7665 34, 70 55-918 38 66-9159 14, 20, 30 55-7697 36, 38 55-9217 76 66-9181 14, 22 55-7687 36, 38 55-9311 88 66-9307 16 55-7748 46 55-9312						
55-7368 34, 70 55-9057 76 66-9029 16, 18 55-73780 36, 38 55-9149 80 66-9032 16, 18, 26, 30 55-73786 20 55-9164 74 66-9033 14 55-7391 88 55-9166 30, 84, 88 66-9034 16, 18 55-7404 54, 62, 64 55-9168 86, 92 66-9036 16, 18 55-7479 70 55-9171 22 66-9037 16 55-7479 70 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7617 44 55-9174 76 66-9181 14, 22 55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7697 36, 38 55-9218 80, 102 66-9306 18 55-7665 34, 70 55-917 12 66-9140 20 55-7749 36, 38 55-9218 80, 102 66-9306 18 55-77527 36, 38 55-9318		-				
55-7369 36, 38 55-9149 80 66-9030 16, 18 55-7370 38, 46, 70 55-9162 12 66-9032 16, 18, 26, 30 55-7381 88 55-9166 30, 84, 88 66-9034 16, 18 55-7404 54, 62, 64 55-9168 36, 92 66-9035 16, 18 55-7464 62 55-9171 22 66-9036 16, 20 55-7479 70 55-9172 22 66-9037 16 55-7618 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7618 44 55-9174 76 66-9181 14, 22 55-7665 34, 70 55-9173 38 66-9181 14, 22 55-7685 34, 70 55-9208 80, 102 66-9306 18 55-7689 36, 38 55-9217 72 66-9306 18 66-9307 16 65-7713 100 55-9312 86 66-9420 20 55-7782 70 55-9313 86 66-9421 18						
55-7370 38, 46, 70 55-9162 12 66-9032 16, 18, 26, 30 55-7386 20 55-9164 74 66-9033 14 55-7391 88 55-9166 30, 84, 88 66-9034 16, 18 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7464 62 55-9171 22 66-9037 16 55-7479 70 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7617 44 55-9174 76 66-9181 14, 22 55-7618 44 55-9174 76 66-9181 14, 22 55-7697 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9195 14, 20, 30 55-7748 46 55-9312 86 66-9420 20 55-7785 82 55-9444 54, 62 66-9421 18 55-7862 34, 36, 38 55-9541						
55-7386 20 55-9164 74 66-9033 14 55-7391 88 55-9166 30, 84, 88 66-9035 16, 18 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7464 62 55-9171 22 66-9037 16 55-7479 70 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7617 44 55-9174 76 66-9181 14, 20, 30 55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7697 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9419 20 55-7749 76 55-9312 86 66-9420 20 55-7748 46 55-9313 86 66-9420 20 55-7852 82 55-9313 86 66-9421 18 55-7862 84 94, 98 60-203 28 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
55-7391 88 55-9166 30, 84, 88 66-9034 16, 18 55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7464 62 55-9172 22 66-9037 16 55-7479 70 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7618 44 55-9174 76 66-9181 14, 22 55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7667 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9307 16 55-7713 100 55-9217 12 66-9419 20 55-7748 46 55-9312 86 66-9420 20 55-7752 70 55-9380 10, 86 66-9421 18 55-7862 34, 36, 38 55-9444 54, 62 66-9423 18 55-7884 94, 98 60-225 8, 14, 18 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
55-7404 54, 62, 64 55-9168 86, 92 66-9035 16, 18 55-7464 62 55-9171 22 66-9036 16, 20 55-7479 70 55-9172 22 66-9037 16 55-7617 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7618 44 55-9174 76 66-9181 14, 22 55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7697 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9307 16 55-7749 76 55-9312 86 66-9419 20 55-7749 76 55-9313 86 66-9420 20 55-7749 76 55-9313 86 66-9421 18 55-7752 70 55-9380 10, 86 66-9422 18 55-7862 34, 36, 38 55-9541 92 66-9423<						
55-7464 62 55-9171 22 66-9036 16, 20 55-7479 70 55-9172 22 66-9037 16 55-7617 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7618 44 55-9174 76 66-9181 14, 22 55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7697 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9307 16 55-7713 100 55-9217 12 66-9419 20 55-7748 46 55-9312 86 66-9420 20 55-7752 70 55-9330 10, 86 66-9421 18 55-7825 82 55-9444 54, 62 66-9423 18 55-88137 8 60-203 28 66-9424 18 55-8318 14, 18 60-272 16 66-9426						
55-7479 70 55-9172 22 66-9037 16 55-7617 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7618 44 55-9174 76 66-9181 14, 22 55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7697 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9307 16 55-7713 100 55-9217 12 66-9419 20 55-7749 76 55-9312 86 66-9420 20 55-7749 76 55-9313 86 66-9421 18 55-7752 70 55-9380 10, 86 66-9422 18 55-7865 82 55-9444 54, 62 66-9423 18 55-7864 94, 98 60-203 28 66-9425 18 55-8317 8 60-225 8, 14, 18 66-9427 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td></t<>						
55-7617 44 55-9173 26, 84, 88 66-9159 16, 18, 26 55-7618 44 55-9174 76 66-9181 14, 22 55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7697 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9307 16 55-7713 100 55-9217 12 66-9419 20 55-7748 46 55-9312 86 66-9420 20 55-7752 70 55-9380 10, 86 66-9422 18 55-7862 82 55-9444 54, 62 66-9423 18 55-7864 94, 98 60-203 28 66-9424 18 55-8137 8 60-272 16 66-9426 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8661 44 61-160 20 67-1028						
55-7618 44 55-9174 76 66-9181 14, 22 55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7697 36, 38 55-9208 80, 102 66-9307 16 55-7698 36, 38 55-9217 12 66-9307 16 55-7713 100 55-9217 12 66-9419 20 55-7748 46 55-9312 86 66-9420 20 55-7749 76 55-9313 86 66-9421 18 55-7825 82 55-9380 10, 86 66-9422 18 55-7862 34, 36, 38 55-9541 92 66-9423 18 55-7862 34, 36, 38 55-9541 92 66-9424 18 55-7864 94, 98 60-203 28 66-9425 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8410 38, 76, 94, 98 61-1243 16 66-9428 <td></td> <td></td> <td></td> <td></td> <td></td> <td>16, 18, 26</td>						16, 18, 26
55-7665 34, 70 55-9195 38 66-9195 14, 20, 30 55-7697 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9307 16 55-7713 100 55-9217 12 66-9419 20 55-7748 46 55-9312 86 66-9420 20 55-7749 76 55-9313 86 66-9421 18 55-7825 70 55-9380 10, 86 66-9422 18 55-7862 34, 36, 38 55-9541 92 66-9423 18 55-7864 94, 98 60-203 28 66-9425 18 55-8317 8 60-272 16 66-9426 18 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8661 44 61-160 20 67-1504 16 55-8723 36, 38 66-2170 14 67-1537 14						
55-7697 36, 38 55-9208 80, 102 66-9306 18 55-7698 36, 38 55-9211 88 66-9307 16 55-7713 100 55-9217 12 66-9419 20 55-7748 46 55-9312 86 66-9420 20 55-7749 76 55-9380 10, 86 66-9421 18 55-7752 70 55-9380 10, 86 66-9422 18 55-7825 82 55-9444 54, 62 66-9423 18 55-7862 34, 36, 38 55-9541 92 66-9424 18 55-7864 94, 98 60-203 28 66-9425 18 55-8316 14, 18 60-285 8, 14, 18 66-9426 18 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8661 44 61-160 20 67-1504 16 55-8720 54, 62, 70 66-1916 14, 22 67-1537	55-7665	34, 70	55-9195			
55-7698 36, 38 55-9211 88 66-9307 16 55-7713 100 55-9217 12 66-9419 20 55-7748 46 55-9312 86 66-9420 20 55-7749 76 55-9313 86 66-9421 18 55-7752 70 55-9380 10, 86 66-9422 18 55-7825 82 55-9444 54, 62 66-9422 18 55-7862 34, 36, 38 55-9541 92 66-9424 18 55-7864 94, 98 60-203 28 66-9425 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8610 44 61-160 20 67-1028 14, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8849 88 66-2170 14 67-1549 18<	55-7697		55-9208	80, 102		
55-7713 100 55-9217 12 66-9419 20 55-7748 46 55-9312 86 66-9420 20 55-7749 76 55-9313 86 66-9421 18 55-7752 70 55-9380 10, 86 66-9422 18 55-7825 82 55-9444 54, 62 66-9423 18 55-7862 34, 36, 38 55-9541 92 66-9424 18 55-7864 94, 98 60-203 28 66-9425 18 55-8317 8 60-272 16 66-9426 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8661 44 61-160 20 67-1028 14, 18 55-8723 36, 38 66-2170 14 67-1537 14 55-8849 88 66-2170 14 67-1549 18			55-9211		66-9307	
55-7748 46 55-9312 86 66-9420 20 55-7749 76 55-9313 86 66-9421 18 55-7752 70 55-9380 10, 86 66-9422 18 55-7825 82 55-9444 54, 62 66-9423 18 55-7862 34, 36, 38 55-9541 92 66-9424 18 55-7864 94, 98 60-203 28 66-9425 18 55-8137 8 60-272 16 66-9426 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8873 36, 38 66-2170 14 67-1558						
55-7752 70 55-9380 10, 86 66-9422 18 55-7825 82 55-9444 54, 62 66-9423 18 55-7862 34, 36, 38 55-9541 92 66-9424 18 55-7864 94, 98 60-203 28 66-9425 18 55-8137 8 60-272 16 66-9426 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-160 20 67-1504 16 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8849 88 66-2170 14 67-1549 18 55-8882 16, 18, 82, 84, 86 66-3942 14, 22 67-7981 20 55-88903 10, 12, 74, 94, 98, 102 66-6603 14	55-7748	46	55-9312	86	66-9420	20
55-7825 82 55-9444 54, 62 66-9423 18 55-7862 34, 36, 38 55-9541 92 66-9424 18 55-7864 94, 98 60-203 28 66-9425 18 55-8137 8 60-272 16 66-9426 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-160 20 67-1504 16 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8873 36, 38 66-2170 14 67-1549 18 55-88877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-88891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-660	55-7749	76	55-9313	86	66-9421	18
55-7862 34, 36, 38 55-9541 92 66-9424 18 55-7864 94, 98 60-203 28 66-9425 18 55-8137 8 60-272 16 66-9426 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-160 20 67-1504 16 55-8662 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8903 10, 12, 74, 94, 98, 102 66-6603 14 <td>55-7752</td> <td>70</td> <td>55-9380</td> <td>10, 86</td> <td>66-9422</td> <td>18</td>	55-7752	70	55-9380	10, 86	66-9422	18
55-7864 94, 98 60-203 28 66-9425 18 55-8137 8 60-272 16 66-9426 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-160 20 67-1504 16 55-8662 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8882 16, 18, 82, 84, 86 66-3942 14, 22 67-7981 20 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 <td>55-7825</td> <td>82</td> <td>55-9444</td> <td>54, 62</td> <td>66-9423</td> <td>18</td>	55-7825	82	55-9444	54, 62	66-9423	18
55-8137 8 60-272 16 66-9426 18 55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-160 20 67-1504 16 55-8662 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8903 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-7862	34, 36, 38	55-9541	92	66-9424	18
55-8316 14, 18 60-285 8, 14, 18 66-9427 20 55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-160 20 67-1504 16 55-8662 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8903 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-7864	94, 98	60-203	28	66-9425	18
55-8382 76, 94, 98 61-1243 16 66-9428 18 55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-160 20 67-1504 16 55-8662 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8993 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8137	8	60-272	16	66-9426	18
55-8410 38, 76, 94, 98 61-159 20 67-1028 14, 18 55-8661 44 61-160 20 67-1504 16 55-8662 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8316	14, 18	60-285	8, 14, 18	66-9427	20
55-8661 44 61-160 20 67-1504 16 55-8662 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8382	76, 94, 98	61-1243	16	66-9428	18
55-8662 44 61-443 16, 18 67-1532 16, 18 55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8410	38, 76, 94, 98	61-159	20	67-1028	14, 18
55-8720 54, 62, 70 66-1916 14, 22 67-1537 14 55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8661	44	61-160	20	67-1504	16
55-8723 36, 38 66-2170 14 67-1549 18 55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8662	44	61-443	16, 18	67-1532	16, 18
55-8849 88 66-3015 22 67-1558 12, 16, 18 55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8720		66-1916	14, 22	67-1537	14
55-8877 14, 18, 34, 70, 82, 86 66-3942 14, 22 67-7981 20 55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8723	36, 38	66-2170		67-1549	18
55-8882 16, 18, 82, 84, 86 66-4341 16 70-191 8 55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8849		66-3015	22	67-1558	12, 16, 18
55-8891 10, 12, 74, 94, 98, 102 66-6603 14 77-1401 10, 12, 30, 32 55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8877		66-3942		67-7981	
55-8903 10, 12 66-6607 22 77-1498 10, 12, 30, 32 55-8904 8, 10, 12 66-6610 14, 22 77-2467 92						
55-8904 8, 10, 12 66-6610 14, 22 77-2467 92	55-8891	10, 12, 74, 94, 98, 102	66-6603		77-1401	10, 12, 30, 32
	55-8903		66-6607		77-1498	10, 12, 30, 32
55-8907 8, 10, 12, 34 66-7182 22 77-2583 8						
	55-8907	8, 10, 12, 34	66-7182	22	77-2583	8

78-1078	10	91-8474	84	91-9039	84, 88
78-1101	10	91-8475	104	91-9040	86
78-1117	12	91-8538	36, 38	91-9041	82, 86
78-1173	8	91-8553	34	91-9048	92
83-257	88	91-8589	34, 104	91-9227	78
845-1949	46	91-8627	94	91-9228	78
91-125	78	91-8628	10	91-9229	78
91-1754	24	91-8629	30	91-9328	12
91-2197	30, 32	91-8634	30	91-9329	98
91-2205	58, 60	91-8645	94, 98	91-9330	98
91-3238	74	91-8658	46	91-9331	98
91-4218	54, 62	91-8659	46	91-9441	104
91-4219	54, 62	91-8660	44	91-9504	82, 86
91-4220	54, 64	91-8661	36, 38	91-9508	74
91-5005	54, 62	91-8662	36, 38	91-9511	88
91-5006	54, 62	91-8663	92	91-9754	90
91-5007	54, 62	91-8664	88	91-9912	88
91-6202	70	91-8665	104	91-9949	88
91-6205	70	91-8672	34	91-9950	88
91-6236	80	91-8673	104	91-9951	88
91-6237	80	91-8674	104	91-9952	88
91-6988	30, 32, 74	91-8675	104	92-179	46
91-8097	98	91-8693	34	92-206	76
91-8098	90	91-8694	84, 104	92-2208	10
91-8100	92	91-8695	104	92-2209	10
91-8102	92	91-8696	104	92-2331	12
91-8103	92	91-8697	104	92-2332	12
91-8104	92	91-8702	68, 90	92-2995	82, 86
91-8105	92	91-8703	68	92-411	92
91-8106	92	91-8705	54, 62	92-440	92
91-8107	92	91-8707	54, 62	98-5199	82, 86
91-8108	82, 86	91-8708	54, 62	98-5200	94
91-8133	82	91-8709	56, 62	98-5226	82
91-8134	82, 86	91-8710	70	98-5320	72, 100
91-8135	94	91-8711	70	98-5326	82
91-8136	94	91-8712	70	98-5335	94
91-8140	12, 30	91-8713	70	98-5403	10
91-8141	94	91-8714	70	98-5443	34
91-8142	12, 30	91-8715	72, 100	98-5475	12
91-8147	36, 38	91-8716	46	98-5478	88
91-8154	104	91-8717	44	98-5480	98
91-8195	84, 86	91-8718	44	98-5523	98
91-8199	82, 86	91-8719	44	98-5543	82
91-8202	104	91-8725	54, 62 56, 64	98-5555	94
91-8204 91-8205	36, 38	91-8726 91-8728	56, 64	98-5556	94
91-8205	82 58		84, 88 94, 98, 104	98-5925	8, 86, 94 86
91-8244	102	91-8734 91-8737	36, 38	98-6518 98-7209	54, 62
91-8252	92	91-8738	46, 104	99-3281	102
91-8256	46, 82, 86	91-8746	104	99-3685	34, 94, 98
91-8258	94	91-8755	104	99-4931	12
91-8236	38	91-8756	104	99-5454	78
91-8466	10, 12	91-8760	94, 98	99-6093	34, 36, 38
91-8467	12, 30	91-8988	34	99-6968	70
91-8468	16, 18	91-8989	34	99-7230	54, 62
91-8469	16, 18	91-8990	34	99-7834	40, 104
91-8470	14	91-9002	80	99-7849	36, 38
91-8471	78	91-9003	80	99-8151	46
91-8472	78	91-9021	22, 24	99-8162	46
- · · · · · ·		J. 3321	, - ·		

INDEX NUMERICAL BY PART NUMBER

99-8562 **8, 70** 99-8986 **70**

INDEX NUMERICAL BY PART NUMBER

A	CAP - tank 80	ELEMENT 66
ADAPTER 16, 22	CAP - valve 14, 22	ELEMENT - thermo 58, 60
ADAPTER - highside 22	CHAIN - cap 34, 94, 98	_
ADAPTER - hose 92	CHANNEL - air 94, 98	F
ADAPTER - outlet 80	CHANNEL - fresh air 94, 98	FAN - condenser 8
ARM - pen lift 66	CHANNEL - Z 94, 98	FAN - evaporator 10, 12
•	CHARGER - battery 70	FILTER 14, 80
В	CHART 58, 60, 64, 66	FITTING - barb 80
BANDWRAP 12 , 34 , 36 , 38 , 102	CLAMP 44	FITTING - highside 14, 22
BARRIER - isolation 78	CLAMP - cable 44	FITTING - lowside 22
BATTERY 70	CLAMP - exchanger 16, 18	FLATWASHER 8, 10, 12, 14, 16, 18
BATTERY - lithium 46	CLAMP - harness 34, 46	22, 24, 34, 36, 38, 46,
BEARING - opposite end 10, 12, 30,	CLAMP - hook 84 , 88	54, 62, 64, 70, 74, 76,
32	CLAMP - hose 102	78, 80, 82, 84, 86, 88,
BEARING - shaft end 10, 12, 30, 32	CLAMP - sensor 26	92, 94, 98
BEARING - slide 92	COIL 14, 16, 20, 26, 28, 30	FRAME - condenser 88
BEZEL - controller 46	COIL - condenser 8, 14, 18	FRAME - unit 82
BLOCK - coil 12	COIL - evaporator 12, 16, 18	FUSE 42
BLOCK - grounding 36, 38	COLL - liquid line valve 16, 18, 26	G
BOARD - pc 78	COMPRESSOR - humidity 80	
BOARD - terminal 70, 78	COMPRESSOR - scroll 14, 18, 22, 24,	GASKET 14, 68
BOOT - switch 34	30, 32	GASKET - air vent 92
BOX - battery charger 70	CONNECTOR 44, 50	GASKET - coil 8
BOX - control 30, 32, 34	CONNECTOR - grip 74	GASKET - cover 54 , 62 , 78
BOX - recorder 54 , 62	CONNECTOR - harness 10, 34, 44,	GASKET - door 46 , 82 , 84 , 88
BOX - remote monitor 78	70, 78	GASKET - evaporator door 88
BOX - Transfresh 72, 100	CONNECTOR - harness grip 70 CONNECTOR - harness & sensor 12	GASKET - power connector 22 , 24 GASKET - retainer 90
BRACKET - air vent handle 92		
BRACKET - battery 70	CONNECTOR recentage 36, 38, 40	GASKET - rub strip 72 GASKET - socket 76
BRACKET - battery charger 70	CONNECTOR - receptacle 36 , 38 , 40 , 44 , 94 , 98	GASKET - socket 76 GASKET - unit 88, 94, 98
BRACKET - cable 74	CONNECTOR - sensor 90	GASKET - valve 22
BRACKET - cable restraint 30, 32, 74	CONNECTOR - T-hose 80 , 102	GRILLE - condenser 82, 86
BRACKET - emergency bypass 36, 38	CONNECTOR - tower 48	GRILLE - evaporator 72 , 94 , 98 , 100
BRACKET - exchanger 16, 18	CONTACTOR 36, 38	GRIP - cable 8
BRACKET - frame 82, 86	CONTROLLER - mP-D 46	GROMMET 8, 10, 12, 34, 54, 62, 88
BRACKET - handle 92	COUPLING 14, 16, 22	GROMMET - connector 34
BRACKET - heater 12, 30 BRACKET - hose 102	COVER 88	GUARD - condenser fan 8
BRACKET - Hose 102 BRACKET - latch 54, 62	COVER - box 70, 78	GUIDE - latch 54, 62
BRACKET - lead 68	COVER - control box 34	, , , , , , , , , , , , , , , , , , ,
BRACKET - lead 66	COVER - recorder 54, 62	Н
BRACKET - lower 78	COVER - terminal box 22, 24	HANDLE - air vent 92
BRACKET - motor 10, 12	·	HANGER - dehydrator 14, 18
BRACKET - motor mount 10	D	HANGER - filter 14
BRACKET - power module 36 , 38	DEHYDRATOR 14, 18	HARNESS 72
BRACKET - right 12	DEHYDRATOR/OIL FILTER 16	HARNESS - adapter 34, 94, 98
BRACKET - sensor 30, 32	DISK - air vent 92	HARNESS - battery charger 70
BRACKET - upper 78	DOOR - assembly 72	HARNESS - communication 34
BREAKER - circuit 36, 38	DOOR - control box 46	HARNESS - condenser 30, 32
BUSHING - plug 74	DOOR - evaporator 82, 86	HARNESS - condenser fan motor 8
. 5	DOOR - heater access 82	HARNESS - contactor 36, 38
C	DOOR - heater section 86	HARNESS - data 78
CABLE - power 22 , 30 , 32 , 74 , 78	DRAIN COCK 80	HARNESS - evap fan 12
CABLE - Transfresh 100	DRIVE - chart 58, 60	HARNESS - evaporator & heaters 30
CAP - dust 34, 76, 94, 98	_	HARNESS - fan motor 10
CAP - fitting 22	E	HARNESS - heaters 32
CAP - probe 68	ELBOW 20	HARNESS - high voltage 78
CAP - retainer 82, 90	ELBOW - discharge 18	HARNESS - humidity compressor 80
CAP - screw 12	ELBOW - hose 80	HARNESS - low voltage 78

HARNESS - main 30, 32, 34, 44	LOCK - secondary 48	98, 104
HARNESS - output module 36, 38, 40	LOCKNUT 8, 10, 34	NAMEPLATE - USDA Sensors 104
HARNESS - power module 36	LOCKRING 44	NAMEPLATE - Warning, Hot
HARNESS - remote monitor 76	LOCKWASHER 8, 10, 12, 22, 36, 38,	Components 104
HARNESS - sensor 26, 34, 44	46, 54, 62, 64, 70, 74,	NIPPLE 80
HARNESS - switch 34	76, 78, 92	NIPPLE - compressor to nozzle 80
HARNESS - tank heater 80	. 5, . 5, 52	NOZZLE - liquid spray 80
HEAT EXCHANGER 14, 18	M	NUT 8, 10, 12, 14, 16, 18, 22, 24, 3
HEATER 12	MECHANISM 58, 60	
		36, 38, 46, 54, 62, 70,
HEATER - evaporator 30, 32	MODULE - current sense 36, 38	74, 76, 78, 82, 86, 92,
HINGE 82 , 86	MODULE - mP-D output 36, 38	94, 98
HINGE - air vent 92	MODULE - power 36 , 38 , 42	NUT - board 70
HINGE - cover to box 46	MONITOR - remote pc board 78	NUT - box 78
HINGE - evap door 82, 86	MOTOR - blower 10	NUT - box to bracket 78
HINGE - left 56 , 62 , 64	MOTOR - condenser fan 8, 30, 32	NUT - bracket 70
HINGE - right 54, 62	MOTOR - evaporator 30, 32	NUT - captive 70, 78, 88
HINGE SET - left 54, 62	MOTOR - fan 12	NUT - chart 66
HINGE SET - right 54, 64	MOUNT - cable 34	NUT - compressor 80
HOOK - strap 84, 88	MOUNT - cable tie 36 , 38 , 102	NUT - connector 44, 74
HOSE - drain 80		NUT - ground 78
HOSE - flex 102	N	NUT - hose 80
HOSE - supply & over flow 80	NAMEPLATE 70	NUT - transformer 78
HOUSING - relief valve 88	NAMEPLATE - Air Vent 104	NUT - wing 92
HUB - fan 8	NAMEPLATE - Air Vent Handle 104	NUT, CLIP & CORD 58, 60
110b - Iaii o	NAMEPLATE - arrow 12, 104	NOT, CEIT & COND 30, 00
1	NAMEPLATE - and 12, 104 NAMEPLATE - Caution 40, 104	0
INDICATOR well CC	-	
INDICATOR - volt 66	NAMEPLATE - Caution 460 Volt 78	OIL - compressor 22, 24
INLET - fresh air 94, 98	NAMEPLATE - Caution, Fan 84	ORIFICE - condenser 88
INSERT - threaded 10	NAMEPLATE - Control Box Layout 34,	O-RING 14 , 16 , 22 , 58 , 60
INSTALLER - integrated circuit 78	104	n
INSULATOR 74	NAMEPLATE - controller setup 34	P
		P PAD 24
INSULATOR 74	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104	
INSULATOR 74 INSULATOR - latch 86	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable	PAD 24
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104	PAD 24 PANEL - high voltage 36, 38
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36,	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACE - air vent 92
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - fan hub 8	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - gasket & grease 22, 24	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - on/off 34	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - compressor 80
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - fan hub 8 KIT - gasket & grease 22, 24 KIT - power cord 24	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - on/off 34 NAMEPLATE - Operating Instructions	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - guard 84, 88
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - on/off 34 NAMEPLATE - Operating Instructions 46, 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - compressor 80 PLATE - guard 84, 88 PLATE - harness 44
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - fan hub 8 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - compressor 80 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - sleeve & eyelet 80	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104 NAMEPLATE - Schematic 34, 44	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - fan hub 8 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACE - air vent 92 PLATE - air vent 92 PLATE - cable storage 82, 86 PLATE - compressor 80 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98 PLATE - recorder 66
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - sleeve & eyelet 80	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104 NAMEPLATE - Schematic 34, 44	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - sleeve & eyelet 80 KIT - stylus 58, 60	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104 NAMEPLATE - Schematic 34, 44 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Temperature Conversion 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACE - air vent 92 PLATE - air vent 92 PLATE - cable storage 82, 86 PLATE - compressor 80 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98 PLATE - recorder 66
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - stylus 58, 60 KIT - thermistor 24	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104 NAMEPLATE - Schematic 34, 44 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Temperature	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - recorder 66 PLATE - thermostat cover 84
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - stylus 58, 60 KIT - thermistor 24 KNOB 86 KNOB - door 82	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104 NAMEPLATE - Schematic 34, 44 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Temperature Conversion 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - compressor 80 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98 PLATE - recorder 66 PLATE - thermostat cover 84 PLATEN 58, 60
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - fan hub 8 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - stylus 58, 60 KIT - thermistor 24 KNOB 86	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104 NAMEPLATE - Schematic 34, 44 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Temperature Conversion 104 NAMEPLATE - Thermo King 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - compressor 80 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98 PLATE - recorder 66 PLATE - thermostat cover 84 PLATEN 58, 60 PLUG 36, 38, 40, 50 PLUG - assembly 50
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - stylus 58, 60 KIT - thermistor 24 KNOB 86 KNOB - door 82	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - R404A 104 NAMEPLATE - Schematic 34, 44 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Temperature Conversion 104 NAMEPLATE - Thermo King 104 NAMEPLATE - Thermo King 104 NAMEPLATE - TK 88, 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - compressor 80 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98 PLATE - recorder 66 PLATE - thermostat cover 84 PLATEN 58, 60 PLUG 36, 38, 40, 50 PLUG - assembly 50 PLUG - cavity 48
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - fan hub 8 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - sleeve & eyelet 80 KIT - stylus 58, 60 KIT - thermistor 24 KNOB 86 KNOB - door 82 L LATCH 82	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - Schematic 34, 44 NAMEPLATE - Schematic 34, 44 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Temperature Conversion 104 NAMEPLATE - Thermo King 104 NAMEPLATE - TK 88, 104 NAMEPLATE - Transfresh Data A3 104	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - cable storage 82, 86 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98 PLATE - recorder 66 PLATE - thermostat cover 84 PLATE - thermostat cover 84 PLATEN 58, 60 PLUG 36, 38, 40, 50 PLUG - cavity 48 PLUG - power 30, 32, 74
INSULATOR 74 INSULATOR - latch 86 INTERLOCK 36, 38 ISOLATOR 82 K KEEPER - door 84 KEEPER - door latch 86 KEY - fan 10 KEY - winding 58, 60 KIT - compressor 22 KIT - crimper 52 KIT - dehydrator/oil filter conversion 16 KIT - fan hub 8 KIT - gasket & grease 22, 24 KIT - power cord 24 KIT - repair 26, 28 KIT - sensor 30, 32 KIT - sleeve & eyelet 80 KIT - stylus 58, 60 KIT - thermistor 24 KNOB 86 KNOB - door 82	NAMEPLATE - controller setup 34 NAMEPLATE - Crowley Secure Cable 104 NAMEPLATE - Crowley service 104 NAMEPLATE - Crowley Service Log 104 NAMEPLATE - Do Not Open Below 0 C 92 NAMEPLATE - emergency bypass 36, 38 NAMEPLATE - Fan Start Automatically 104 NAMEPLATE - fuses 38 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Ingersoll Rand 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - Operating Instructions 46, 104 NAMEPLATE - Schematic 34, 44 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Smart Reefer 104 NAMEPLATE - Temperature Conversion 104 NAMEPLATE - Thermo King 104 NAMEPLATE - TK 88, 104 NAMEPLATE - Transfresh Data A3	PAD 24 PANEL - high voltage 36, 38 PANEL - USDA receptacle 94, 98 PC BOARD - emergency bypass 36, 38 PIN - hinge 46, 82, 86, 92 PIN - sealing 50, 94, 98 PIN - terminal 50 PLACARD - schematic 34, 44 PLACARD - wiring 34, 44 PLATE - air vent 92 PLATE - box 54, 62 PLATE - cable storage 82, 86 PLATE - compressor 80 PLATE - guard 84, 88 PLATE - harness 44 PLATE - keeper 54, 62 PLATE - rear 94, 98 PLATE - recorder 66 PLATE - thermostat cover 84 PLATEN 58, 60 PLUG 36, 38, 40, 50 PLUG - assembly 50 PLUG - cavity 48

INDEX ALPHABETICAL BY DESCRIPTION

PORT - purge 88	SCREW - guard 8	IEE 14, 16, 18
POST - binding 68	SCREW - guide 54, 62	TERMINAL 48
PROTECTOR - edge 92	SCREW - handle 92	TERMINAL - male 48
3	SCREW - hinge 46, 54, 64, 86	TERMINAL - motor 10
R	SCREW - hub to shaft 8	TERMINAL - pin 30, 32, 50
RAIL - din 36, 38	SCREW - keeper 84, 86	TERMINAL - socket 50
RECEPTACLE 50 , 94 , 98	SCREW - knob 82	TERMINAL - splice 8
RECEPTACLE - assembly 50	SCREW - latch 46	TERMINATOR 36, 38
RECEPTACLE - current transformer	SCREW - module 38	THERMOMETER 58
44	SCREW - motor 8 , 10 , 12	THERMOMETER - 7 day 54, 60
RECEPTACLE - power 74	SCREW - mount 34	THERMOMETER - recording 54 , 62 ,
RECEPTACLE - power module CN4	SCREW - orifice 88	66
44	SCREW - plate 54, 62, 82, 84, 86, 88,	THERMOSTAT 30
RECEPTACLE - power module CN6	92, 94, 98	TIMER 66
44	SCREW - rail 36, 38	TOOL - crimper 52
RECEPTACLE - sensor harness 44	•	TOOL - pin removal 48
	SCREW - receiver 14, 18	
RELAY - mini 76	SCREW - receptacle 74 , 94 , 98	TOOL - terminal crimper 48
REMOVER - integrated circuit 78	SCREW - recorder 54, 62	TOOL - wedge remover 52
RETAINER - probe 90	SCREW - relay socket 76	TRANSFORMER 36 , 38 , 72 , 74 , 78
RIVET - anchor 102	SCREW - strap 84, 88	TRAY - high voltage 34
RIVET - box 72 , 100	SCREW - thermostat 30	TRIM - edge guard 12
RIVET - bracket 12	SCREW - transformer 74	TUBE 16 , 18 , 26
RIVET - channel 94, 98	SCREW - valve 22	TUBE - coil to receiver tank 14, 18
RIVET - grille 94, 98	SCREW - vent 92	TUBE - compressor to coil 22
- · · · · · · · · · · · · · · · · · · ·	SEAL 48, 50	TUBE - coupling to valve 16, 20
RIVET - haveing 88	•	
RIVET - housing 88	SEALER - antiseize 46	TUBE - dehydrator to exchanger 16, 18
RIVET - inlet 94, 98	SEALER - polyurethane 94, 98	TUBE - discharge process 18
RIVET - latch 54 , 62 , 82 , 86	SEALER - silicone grease pack 22, 24	TUBE - elbow to compressor 20
RIVET - monitor socket 76	SENSOR - defrost 30	TUBE - elbow to valve 18
RIVET - mount 36, 38	SENSOR - head temperature 22, 30	TUBE - equalizer 16, 20
RIVET - panel 94, 98	SENSOR - humidity 26, 80	TUBE - exchanger to evaporator 14, 18
RIVET - plate 44, 54, 62, 94, 98	SENSOR - ungraded 30, 32	TUBE - exchanger to tee 14, 18
RIVET - port 88	SENSOR - USDA 96, 98	TUBE - exchanger to valve 14, 20
RIVET - receptacle 94, 98	SHOULDER 14, 16	TUBE - expansion valve to tee 16 , 18
RIVET - shroud 12	SHROUD 48	TUBE - liquid 16 , 18
ROD - push 58	SHROUD - evaporator 12	TUBE - modulation valve to suction
ROLLER - door latch 46	SIGHT GLASS 14	valve 14, 20
c	SOCKET - monitor 76	TUBE - receiver to dehydrator 14, 18
S	SOCKET - relay 76	TUBE - receiver to valve 16, 20
SCREEN 80	SPACER 14, 18, 22, 24, 46	TUBE - suction process 20
SCREEN - inlet strainer 28	SPACER - clamp 26	TUBE - tee to evaporator 16, 18
SCREW 16, 18, 92	SPACER - contactor 36, 38	TUBE - tee to expansion valve 14, 18
SCREW - block 78	SPACER - hanger 14	TUBE - tee to valve 14
SCREW - board 78	SPACER - latch 46	TUBE - valve to coil 14
SCREW - box 34 , 54 , 62 , 70	SPACER - tank 80	TUBE - valve to compressor 16, 20
		TUBE - valve to evaporator 16, 18
SCREW - bracket 10, 12, 16, 18, 36,	SPRING 12, 82, 86, 92	TOBE - valve to evaporator 10, 16
38, 54, 62, 70, 74, 82,	SPRING - heater 30	V
86, 102	STRAIN RELIEF - connector 44	-
SCREW - cable 74	STRAP - door 84, 88	VALVE 14, 20
SCREW - channel 94, 98	STRIP - gasket 8, 36, 38, 70	VALVE - angle 14
SCREW - clamp 26, 84, 88	STRIP - sealing 70	VALVE - discharge 14, 22
SCREW - coil 8, 12	SWITCH - hpco 18, 22, 30	VALVE - expansion 16, 18
SCREW - compressor 22, 24	SWITCH - on/off 34	VALVE - modulation 14, 20, 30, 32
SCREW - controller 46		VALVE - pressure relief 88
SCREW - cover 70 , 78 , 88	T	VALVE - relief 14, 18
SCREW - door 82 , 84 , 86	TAB - mounting 50 , 52	VALVE - solenoid 14 , 16 , 18 , 20 , 26 ,
SCREW - door latch 46	TANK - humidity 80	30
SCREW - grille 82, 86		
SCREW - ground 22 , 24 , 70	TANK - receiver 14, 18 TAP - thermo bus 36, 38	VALVE - suction 14, 22 VENT - air 92

W

WASHER **8**, **14**, **18**, **34**, **54**, **62**, **70**, **76**, **82**, **84**, **86**, **88**, **92**

WASHER - dome 88 WASHER - ground 22, 24 WASHER - insulating 54, 62

WASHER - insulation 82

WASHER - insulator 92

WASHER - sealing 22, 70, 78

WASHER - special 70

WASHER - vibration damper 22, 24

WEDGE **50** WINDOW **54, 62**

WRIST STRAP - electrostatic 78