
MAGNUM

TK 51745-2.0



Printed (March 23, 2006)

Copyright @ 2002 - Thermo King Corp. - Minneapolis, MN U.S.A. Electronically printed in U.S.A.

General Information

Tables of Contents

This Parts Manual contains a numerical table of contents listing each assembly name, its associated Grid number and page number. The numerical table of contents is arranged numerically by Grid number. There are references in a parts list referring to other Grid numbers, the numerical table of contents is arranged to facilitate finding the referenced illustrations. At the rear of this parts manual are two indexes, a numerical and alphabetical. The indexes contain all of the part numbers and descriptions which appear in this manual.

Assemblies and Subassemblies

When parts are indented in the description list, they are preceded with a bullet (•). This indicates that the part(s) is available separately or included in an assembly.

GRID NO. 67D6 SWITCH PANEL ASSEMBLY

REF	PART#	DESCRIPTION	QTY
	45-1239	PANEL - assy, switch	1
1	99-1960	• PANEL	1
	99-6280	• • NAMEPLATE - panel	1
2	33-743	• GASKET	1

For example: the switch panel nameplate (99-6280) is available separately, available as part of the switch panel (99-1960) and with the panel assembly (45-1239).


ABBREVIATIONS The following abbreviations appear in parts manuals

В	AC	current as required accumulator adjusting aluminum alternator ampere assembly board bearing breaker	F	(continued) evap. evaporator exch exchanger exp expansion ext external F. Farenheit fill fillister fi fuel injection fl flare fpt female pipe thread tt ft feet ftg fitting	O P	os oversized od outside diameter pcb printed circuit
D	C	clockwise counter- clockwise camshaft compressor condenser connecting, connector cylinder defrost degree dehydrator	H I	hex	S	req required rpm revolutions per minute sec second sld solder soc hd solder solder soc hd solenoid spl special sq square ss stainless steel std standard stl steel suct suction sw switch
E	DC	direct current discharge differential Extended Maintenance Interval European Economic Community	N	lg long mm milimeter mpt male pipe thread mod modulating neg negative No number NS not supplied NSS not sold separately	U V	term terminal temp temperature thk thick us undersize vib vibrasorber W watt w/ with w/o without

MAGNUM

Contents


Name	Grid	Page
MAGNUM REFERENCE SHEET		
AIR VENT (40 FT CONTAINERS)		
RECORDING THERMOMETER - 31 DAY FAHRENHEIT		
RECORDING THERMOMETER (OPTION 098026 & 098030)		
RECORDING THERMOMETER (OPTION 098026)	147B9	
TRANSFORMER GROUP (098024, 098040, 098041, 098043,		
098071, 098123, 098128)		
WATER COOLED CONDENSER		
AIR VENT (20 FT CONTAINERS)		
USDA RECEPTACLES		
HIGH VOLTAGE TRAY		
REMOTE MONITOR OPTION (098182 CSR; 098144 CRR; 098182		
CSR)	158A5	
GAUGE GROUP (OPTION 098140)		
AFAM MP3000 (OPTION 098166)	158H7	
USDA DOWNLOAD PANEL (DEUTSCH CONNECTORS)		
EVAPORATOR PANELS		
DEFROST DRAIN		
REFRIGERATION COMPONENTS		
CONDENSER FAN GROUP		
EVAPORATOR FAN GROUP (MAGNUM 40)		
COMPRESSOR GROUP (SERVICE VALVES)		
ELECTRICAL COMPONENTS		
CONTROL BOX		
NAMEPLATES		
CONTROL BOX DOOR (MP3000-A w/ RMM)		
EVAPORATOR FAN GROUP (THREE FANS)		
CONDENSER COMPONENTS (20 ft CONTAINER, THREE FANS)		
REFRIGERATION COMPONENTS (WCC, SERVICE VALVES)		
CONDENSER COMPONENTS		
DEFROST DRAIN		
REFRIGERATION COMPONENTS (SERVICE VALVES)		
USDA DOWNLOAD PANEL (4-PIN DEUTSCH CONNECTORS)		
AIR VENT (40 FT CONTAINERS)		
ELECTRONIC CHART RECORDER		
AIR VENT (AFAM MP3000)	213D3	



MAGNUM REFERENCE SHEET




B/M	DESCRIPTION	Date
098916	MAGNUM 20	11/02
098922	MAGNUM 40	11/02
098924	MAGNUM - 924	1/04
098525	MAGNUM 40 w/ AFAM+	11/02
098528	MAGNUM	11/02
098934	MAGNUM 40 SL	11/02
098540	MAGNUM	2/06
098546	MAGNUM	2/06
098547	MAGNUM	2/06
098552	MAGNUM	2/06
098553	MAGNUM	2/06
098554	MAGNUM	2/06



CONDENSER FAN GROUP




REF	PART#	DESCRIPTION	QTY
1	60-285	COIL - condenser	1
	33-2950	GASKET (10 x 15 mm)	A/R
	51-1442	SCREW - coil	7
	51-167	FLATWASHER	7
	55-9054	WASHER (nylon)	7
2	78-1167	FAN - condenser (21.6 in, 500 mm dia, 30 deg pitch, 8 blade)	1
3	104-697	MOTOR - condenser fan (0.75 hp)	1
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	51-1443	SCREW - motor	4
	51-1444	FLATWASHER	8
	51-1429	LOCKWASHER	4
	51-1427	NUT	4
4	55-5900	GRIP - cable	1
5	33-367	GROMMET	1
6	41-2953	HARNESS - condenser fan	1



EVAPORATOR FAN GROUP (MAGNUM 40)



REF	PART#	DESCRIPTION	QTY
1	98-6566	HOUSING - evaporator (14/355 fans)	1
2	92-2779	BRACKET - motor (left)	2
3	92-2332	BRACKET - motor (right)	2
	98-6562	HOUSING - evaporator (12/305 fans)	1
	55-9162	RIVET - housing	10
4	33-3215	GROMMET (47 mm)	1
5	33-3044	TRIM - edge guard	A/R
6	55-5900	CONNECTOR - harness & sensor	2
7	78-1117	FAN - evaporator (14 in, 355 mm dia, ccw)	2
	78-1349	FAN - evaporator (12 in, 305 mm dia, ccw)	2
	78-1524	FAN - evaporator (top air, 14 in, 355 mm dia, cw)	2
8	NSS	COIL - evaporator (see Refrigeration Group)	1
	55-8891	SCREW - coil	9
	55-9217	CAP - screw	3
9	91-9328	BLOCK - coil	2
10	41-4018	HARNESS - evaporator fan (MAGNUM)	1
	41-3685	HARNESS - evaporator fan (MAGNUM SL-40)	1
11	104-691	MOTOR - fan	2
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	51-1443	SCREW - motor	8
	55-7066	LOCKWASHER (external tooth)	2
	55-7342	LOCKWASHER	6
	55-7085	FLATWASHER	8
	92-425	NUTSTRIP	4
12	99-4931	NAMEPLATE - Arrow	1
13	91-8466	BRACKET - motor	2
	55-8559	SCREW - bracket	8
	51-1444	FLATWASHER	16
	51-1429	LOCKWASHER	8
	55-7339	NUT	8
14	92-458	FILTER - gas sensor	1
15	33-2946	GROMMET (37 mm)	6
16	92-2775	COVER - tube	1
	55-7172	SCREW - cover	3
	55-8877	WASHER (nylon)	3
	55-7075	FLATWASHER	3
17	33-367	GROMMET	3
18	92-456	BRACKET - sensor	1
	55-7035	SCREW - sensor	2
	55-7075	FLATWASHER	2
	55-8877	WASHER - insulating	2




Revised 3/22/06

EVAPORATOR FAN GROUP (MAGNUM 40)




REF	PART#	DESCRIPTION	QTY
	92-2587	NUTSTRIP - bracket	1
19	41-3409	SENSOR - gas (O2/CO2)	1
	41-5814	SENSOR - gas (CO2 only)	1
20	11-4367	HOSE - sensor (1/4 od x 35 ft lg)	A/R
21	33-3838	GROMMET (22 mm)	1



EVAPORATOR FAN GROUP (THREE FANS)



REF	PART#	DESCRIPTION	QTY
1	104-691	MOTOR - fan	3
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
	55-6993	SCREW - motor (25 mm)	12
	55-8903	SCREW - motor (22 mm)	12
	55-8904	FLATWASHER	12
	55-8805	LOCKWASHER	15
	55-7339	NUT	12
	55-8986	INSERT - threaded	12
2	78-1196	FAN - evaporator (10 in, 254 mm dia)	3
3	91-8466	BRACKET - motor	3
	55-8903	SCREW - bracket	12
	55-6988	FLATWASHER	21
4	98-6564	BRACKET - motor mount	1
5	92-2790	BRACKET - motor	3
6	92-2791	BRACKET - motor	3
	55-8891	SCREW - bracket	17
7	33-3215	GROMMET (47 mm)	1
8	33-2946	GROMMET (37 mm)	7
9	33-3838	GROMMET (22 mm)	1
10	55-2324	KEY - fan	3
11	67-1922	COIL - evaporator	1
	55-8891	SCREW - coil	18
	55-7342	LOCKWASHER	18
	55-7066	FLATWASHER	6
	55-9217	CAP - screw	9
12	91-9328	BLOCK - coil	2
13	55-8907	CONNECTOR - harness	3
	55-8908	NUT	3
14	41-4002	HARNESS - evaporator fan	1
15	51-270	CONNECTOR - grip (sensor)	1
16	92-2778	COVER - tube	1
	55-7172	SCREW - cover	3
	55-8872	WASHER (nylon)	3
	55-7075	FLATWASHER	3
17	33-367	GROMMET	3




REFRIGERATION COMPONENTS



REF	PART#	DESCRIPTION	QTY
1	102-795	COMPRESSOR - scroll (see 180E1)	1
2	66-9181	TUBE - valve to coil (units w/ valves)	1
	61-175	TUBE - flange to coil (units w/ flanges)	1
3	60-285	COIL - condenser	1
	55-7035	SCREW - coil	8
	51-167	FLATWASHER	7
	55-9054	WASHER	8
4	67-1890	TANK - receiver	1
5	66-7812	FITTING - high side	1
	66-7182	•• CAP - fitting	1
6	61-1852	TUBE - coil to receiver tank	1
7	506-364	PLUG - fusable	1
8	61-1853	TUBE - tank to dehydrator	1
9	66-8811	• INDICATOR - liquid	1
	33-3007	• O-RING	1
10	61-786	DEHYDRATOR (o-ring seal)	1
	33-3007	O-RING	2
11	55-4390	HANGER - dehydrator	1
	55-8316	SCREW - hanger	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
12	61-1848	TUBE - filter	1
	55-302	NUT - filter	1
13	61-1844	TUBE - dehydrator to tee	1
14	61-1845	TUBE - tee to valve	1
15	67-1889	HEAT EXCHANGER - economizer	1
16	92-2588	BRACKET - exchanger	1
17	92-2589	COVER - exchanger	1
	55-6994	SCREW - cover	2
	55-7075	FLATWASHER	4
	55-7042	NUT	2
18	61-1843	TUBE - tee to exchanger	1
19	55-3251	TEE (3/8)	1
20	41-5103	VALVE - solenoid (vapor injection)	1
21	41-3301	COIL - valve	1
22	61-1846	TUBE - valve to expansion	1
23	61-1847	TUBE - expansion valve to tee	1
24	66-9906	VALVE - expansion (economizer)	1
25	61-1849	TUBE - liquid injection	1
	55-8951	SHOULDER	1
	55-8950	NUT - o-ring seal	1






REFRIGERATION COMPONENTS




26 27	33-566 61-1850	O-RING	1
	61-1850		1
		TUBE - valve to evaporator	1
28	67-1923	COIL - evaporator (14.7/374 wide, MAGNUM)	1
	67-1921	COIL - evaporator (13.0/330 wide, MAGNUM SL-40)	1
	67-1922	COIL - evaporator (11.3/286 wide, MAGNUM SL-20)	1
	55-6993	SCREW (25 mm)	8
	55-8882	FLATWASHER (8.4 mm)	14
	55-6988	FLATWASHER (8.4 mm id)	14
29	61-2117	TUBE - coil to valve (units w/ service valves)	1
	61-1839	TUBE - coil to flange (units w/ flanged compressor)	1
30	Not Used		
31	66-874	FITTING - flare	1
	66-6607	FITTING - low side	1
	66-7183	CAP - charge port (blue)	1
	66-8054	ADAPTER	1
32	41-4473	SWITCH - Ipco	1
33	61-1840	TUBE - suction to valve	1
34	61-2057	VALVE - digital	1
35	61-2058	TUBE - valve to compressor	1
36	61-2162	ADAPTER - compressor	1
37	91-4774	CLAMP - suction tube	1
38	91-1779	CLAMP - strap	1
	55-7027	SCREW - clamp	2
	55-7075	FLATWASHER	2
39	55-6388	CLAMP - tube (3/8)	3
	91-759	CLAMP - tube (1/2)	1
	55-8915	SPACER (18 mm)	4
	55-7029	SCREW - clamp (65 mm)	2
	55-8993	SCREW - clamp (50 mm)	2
	55-9027	WASHER (nylon)	2
40	55-2296	TEE (1/2)	1
41	61-2051	TUBE - tee to distributor	2
42	61-443	VALVE - expansion	1
43	61-2048	TUBE - equalizer	1
	61-2054	TUBE - equalizer (MAGNUM 20)	1
44	61-2049	TUBE - expansion valve to tee	1
	61-2052	TUBE - expansion valve to tee (MAGNUM 20)	1
45	61-2050	TUBE - expansion valve to inlet	1
	61-2053	TUBE - expansion valve to inlet (MAGNUM 20)	1



REFRIGERATION COMPONENTS (SERVICE VALVES)




REF	PART#	DESCRIPTION	QTY
1	102-795	COMPRESSOR - scroll (see 180E1)	1
	92-2229	SPACER - compressor	1
2	61-2477	TUBE - valve to coil	1
3	60-285	COIL - condenser	1
4	61-2467	TUBE - valve to coil	1
5	61-2162	ADAPTER - compressor	1
6	33-3912	SEAL - teflon fiber	1
7	67-1991	TANK - receiver	1
8	66-7812	CAP - fitting	1
	66-7182	•• CAP - fitting	1
9	66-8811	INDICATOR - liquid	1
	33-3007	• O-RING	1
10	506-364	PLUG - fusable	1
11	61-2238	TUBE - receiver to dehydrator	1
12	61-2569	TUBE - receiver to condenser	1
	51-273	NUT - receiver tank	2
	55-9027	WASHER - insulating	4
	55-7347	LOCKWASHER	2
13	55-6730	CLAMP - tube	2
	55-7372	SCREW - clamp	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
14	61-2475	TUBE - receiver to dehydrator	1
	203-454	MASTIC - heat transfer	A/R
15	61-786	DEHYDRATOR	1
16	55-4390	CLAMP - dehydrator	1
	55-8464	SCREW - clamp	1
	51-167	FLATWASHER	1
	55-9054	WASHER - insulating	1
	55-8316	SCREW - dehydrator	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
17	61-1848	TUBE - filter	1
18	61-2473	TUBE - filter to tee	1
19	55-3251	TEE	1
20	61-2471	TUBE - tee to exchanger	1
21	67-1889	HEAT EXCHANGER - economizer	1
	92-3547	INSULATION - heat exchanger	1
22	61-2472	TUBE - tee to valve	1
	91-758	CLAMP - tube	1
	55-9912	SCREW - clamp	1



REFRIGERATION COMPONENTS (SERVICE VALVES)



REF	PART#	DESCRIPTION	QTY
	55-7075	FLATWASHER	2
	55-8915	SPACER	1
23	61-2470	VALVE - solenoid (vapor injection)	1
24	41-5460	COIL - valve	1
25	61-2469	TUBE - valve to expansion	1
26	66-9906	VALVE - expansion (economizer)	1
27	61-1847	TUBE - expansion valve to exchanger	1
28	61-2474	TUBE - liquid injection	1
	55-8951	SHOULDER	1
	55-8950	NUT - o-ring seal	1
	92-3548	INSULATION - tube (24.5 in lg)	1
	92-3549	INSULATION - tube (19.0 in lg)	1
	91-1800	CLAMP - tube	2
	55-7372	SCREW - clamp	1
	55-7042	NUT	1
29	61-2476	TUBE - tx bulb	1
30	92-3391	BRACKET - heat exchanger	1
	92-3550	INSULATION - mylar	1
31	61-2464	TUBE - suction (before 4/05)	1
	61-3502	TUBE - suction (4/05 & after)	1
	92-3551	INSULATION - tube (42.1 in lg)	1
	92-3552	INSULATION - tube (5.5 in lg)	1
32	61-2466	TUBE - suction to ball valve	1
33	61-2465	VALVE - ball	1
34	61-2057	VALVE (PWM)	1
35	66-874	FITTING - flare	1
	66-6607	FITTING - low side	1
	66-7183	CAP - charge port (blue)	1
	66-8054	ADAPTER	1
36	41-4473	SWITCH - Ipco	1
37	33-566	O-RING	1
38	61-2468	TUBE - heat exchanger to evaporator	1
	92-3553	INSULATION - tube (14.1 in lg)	1
39	61-2050	TUBE - exchanger to coil (#2)	1
40	61-443	VALVE - expansion	1
	92-2228	SPACER - clamp	1
	55-6388	CLAMP - valve	1
	55-9759	SCREW - clamp	1
	55-8316	SCREW - dehydrator clamp	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
41	61-2048	TUBE - equalizer	1




REFRIGERATION COMPONENTS (SERVICE VALVES)



REF	PART#	DESCRIPTION	QTY
42	61-2049	TUBE - expansion valve to tee	1
43	55-2296	TEE	1
44	61-2051	TUBE - tee to distributor	1
45	67-1923	COIL - evaporator (14.7/374 wide, see 180D9)	1
	67-1921	COIL - evaporator (13.0/330 wide, MAGNUM SL-40, see 183B4)	1
	67-1922	COIL - evaporator (11.3/286 wide, MAGNUM SL-20, see 183B6)	1
46	41-6150	TRANSDUCER - suction (200 psi)	1
47	41-6151	TRANSDUCER - discharge (500 psi)	1






REFRIGERATION COMPONENTS (WCC, SERVICE VALVES)



REF	PART#	DESCRIPTION	QTY
1	102-795	COMPRESSOR - scroll (see 180E1)	1
2	61-2477	TUBE - valve to coil	1
3	60-285	COIL - condenser	1
4	61-2467	TUBE - valve to compressor	1
5	61-2162	ADAPTER - compressor	1
6	33-3912	SEAL - teflon fiber	1
	66-7543	TUBE (0.500 od x 1.880 lg cu)	1
	66-9447	TUBE (0.500 od x 2.250 lg cu)	1
7	67-1575	TANK - water cooled condenser (see 154E13)	1
8	61-3504	TUBE - condenser to tee	1
9	61-3525	VALVE - ball	1
10	61-3542	TUBE - valve to dehydrator	1
11	61-1305	TUBE - condenser to condenser	1
12	61-786	DEHYDRATOR (o-ring seal)	1
	55-4390	CLAMP - dehydrator	1
	51-1440	SCREW - clamp	1
	51-1441	FLATWASHER	2
	51-1425	NUT	1
13	61-3503	TUBE - filter	1
14	55-3251	TEE	1
15	61-2471	TUBE - tee to exchanger	1
16	67-1889	HEAT EXCHANGER - economizer	1
17	61-2472	TUBE - tee to valve	1
18	61-2470	VALVE - solenoid (vapor injection)	1
19	41-5460	COIL - valve	1
20	61-2469	TUBE - valve to expansion	1
21	66-9906	VALVE - expansion (econimizer)	1
22	61-1847	TUBE - expansion valve to exchanger	1
23	61-2474	TUBE - liquid injection	1
	55-8951	SHOULDER	1
	55-8950	NUT - o-ring seal	1
25	61-2050	TUBE - exchanger to coil (#2)	1
26	61-443	VALVE - expansion	1
	92-2228	SPACER - clamp	1
	55-6388	CLAMP - valve	1
	51-1439	SCREW - clamp	1
27	61-2048	TUBE - equalizer	1
28	61-2049	TUBE - expansion valve to tee	1
29	55-2296	TEE	1
30	61-2051	TUBE - tee to distributor	1
31	67-1923	COIL - evaporator (14.7/374 wide, see 180D9)	1






REFRIGERATION COMPONENTS (WCC, SERVICE VALVES)




REF	PART#	DESCRIPTION	QTY
	67-1921	COIL - evaporator (13.0/330 wide, MAGNUM SL-40, see 183B4)	1
	67-1922	COIL - evaporator (11.3/286 wide, MAGNUM SL-20, see 183B6)	1
32	61-2464	TUBE - suction (before 4/05)	1
	61-3502	TUBE - suction (4/05 & after)	1
33	66-8054	ADAPTER	1
34	41-4473	SWITCH - Ipco	1
35	61-2466	TUBE - suction to ball valve	1
36	61-2465	VALVE - ball	1
37	61-2057	VALVE (PWM)	1
38	33-566	O-RING	1
39	92-3391	BRACKET - heat exchanger	1
	51-1442	SCREW - bracket	2
	55-9054	WASHER - insulating	2
	51-167	FLATWASHER	2
40	61-3508	TUBE - coil to dehydrator (units w/o WCC)	1
41	41-6150	TRANSDUCER - suction (200 psi)	1
42	41-6151	TRANSDUCER - discharge (500 psi)	1



COMPRESSOR GROUP (SERVICE VALVES)




REF	PART#	DESCRIPTION	QTY
1	102-795	COMPRESSOR - scroll	1
	203-516	OIL - compressor	A/R
	40-779	KIT - gasket & grease	1
2	33-2951	GASKET - power connector	1
	33-2979	SEALER - silicone grease pack	1
3	55-8994	SCREW - ground	1
	55-8995	WASHER - ground	1
4	91-9021	COVER - terminal box	1
5	40-786	KIT - power cord	1
6	51-1433	SCREW - compressor	4
7	51-1435	FLATWASHER (12 mm)	4
8	55-9012	WASHER - vibration damper	4
9	55-9013	SPACER (before 1/03)	4
	51-1432	SPACER (1/03 & after)	4
10	51-1436	FLATWASHER (13 mm)	4
11	51-1434	NUT	4
12	41-4004	SWITCH - hpco	1
	203-393	SEALER - thread (red)	A/R
13	66-7812	ADAPTER - highside	1
	66-6610	FITTING - highside	1
	66-7182	CAP - fitting	1
	203-393	SEALER - thread (red)	A/R
14	66-8054	ELBOW - low side	1
	66-6607	FITTING - low side	1
	66-7183	CAP - fitting	1
15	33-727	O-RING - suction	1
16	51-1438	SCREW - flange	2
17	55-7066	LOCKWASHER	2
18	33-2805	GASKET - flange	1
19	51-1437	SCREW - discharge valve	2
20	51-358	WASHER - sealing	2
21	61-2119	VALVE - discharge	1
22	40-776	KIT - thermistor	1
23	61-2118	VALVE - suction	1
24	55-3364	PLUG	1



WATER COOLED CONDENSER




REF	PART#	DESCRIPTION	QTY
1	67-1575	TANK - water cooled condenser	1
2	66-8811	INDICATOR	1
3	33-3007	O-RING	1
4	66-6610	FITTING - high side	1
5	66-7182	CAP - fitting	1
6	506-364	PLUG - fusible	1
	203-393	SEALER - locking	A/R
	51-1467	SCREW - tank	4
	51-1429	LOCKWASHER	4
	51-1430	FLATWASHER	4
7	66-4788	COUPLING - outlet	1
	203-385	SEALER - removable	A/R
8	91-6627	CAP - dust cover	1
9	55-1827	PLUG - outlet	1
10	91-6628	CAP - dust cover	1
11	61-3504	TUBE - condenser to filter	1
12	61-3525	VALVE - ball	1
13	61-3542	TUBE - valve to dehydrator	1
14	61-1305	TUBE - condenser to condenser	1
15	91-759	CLAMP - tube	2
	51-1462	SCREW - clamp	1
16	55-6730	CLAMP - tube	6
	55-7035	SCREW - clamp	2
	51-167	FLATWASHER	4
17	66-7543	TUBE - stub (1.88 lg)	1
18	66-9447	TUBE - stub (2.25 lg)	1



GAUGE GROUP (OPTION 098140)




REF	PART#	DESCRIPTION	QTY
1	92-219	PLATE - guard (w/ gauge)	1
2	33-3212	GASKET - gauge	1
3	66-9194	GAUGE - suction pressure	1
	55-8382	SCREW - gauge	3
	55-7830	FLATWASHER	3
	55-9086	WASHER - insulating	3
	55-7864	NUT	3
4	33-768	GASKET - round	2
5	61-154	TUBE - gauge (w/ activator)	1



ELECTRICAL COMPONENTS



REF	PART#	DESCRIPTION	QTY
1	40-791	KIT - sensor (universal)	A/R
2	41-4018	HARNESS - evaporator (two fan, see 180D9)	1
	41-4002	HARNESS - evaporator (three fan, see 183B6)	1
3	92-2777	BRACKET - power cable (11/4 cable)	1
	92-5660	BRACKET - power cable (10/4 cable)	1
	55-7172	SCREW - bracket	2
	55-7176	LOCKWASHER	2
	55-7075	FLATWASHER	2
4	45-1992	CABLE - power (19.2 meters, 63 ft, 11/4 ga)	1
	45-237	CABLE - power (24 meters, 78 ft, 10/4 ga)	1
5	41-1976	PLUG - power (Minnekes)	1
	44-4051	• PLUG - power (10/4)	1
	44-9891	• TERMINAL - pin	7
6	41-4473	SWITCH - Ipco	1
7	91-8140	SPRING - heater	6
8	41-2838	HARNESS - sensor (humidity, MPC)	1
9	104-697	MOTOR - condenser fan (see 180D8)	1
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
10	41-2953	HARNESS - condenser fan (see 180D8)	1
11	104-691	MOTOR - evaporator fan (two fan see 180D9, three fan see 183B6)	A/R
	77-1498	BEARING - shaft end	1
	77-1401	BEARING - opposite end	1
12	41-3593	HARNESS - control box	1
13	45-1927	HEATER (680W, 2 meter leads)	6
14	91-8142	BRACKET - heater (15.4/404 long, MAGNUM)	1
	91-8634	BRACKET - heater (13.6/347 long, MAGNUM SL-40)	1
	92-234	BRACKET - heater (12.3/313 long, MAGNUM SL-40)	1
15	91-8467	BRACKET - heater (13.8/350 long, MAGNUM)	2
	91-8629	BRACKET - heater (12.0 long, MAGNUM SL-40)	2
	92-235	BRACKET - heater (11.4/290 long, MAGNUM SL-20)	2
	55-8891	SCREW - bracket	11
16	41-5103	VALVE - solenoid	1
	41-3301	COIL - valve	1
17	41-3401	THERMOSTAT - defrost termination	1
	51-336	SCREW - thermostat	2
18	102-795	COMPRESSOR - scroll (see 180E1)	1
19	NSS	BOX - control (see 158A3)	1
20	40-782	CABLE - compressor	1
21	41-4004	SWITCH - hpco	1
22	61-2057	VALVE - digital	1




ELECTRICAL COMPONENTS




REF	PART#	DESCRIPTION	QTY
23	41-5635	SENSOR - humidity	1
24	NSS	PANEL - USDA receptacle (see 173B1)	1
	NSS	PANEL - USDA receptacle (see 183B3, SL-40 & 20)	1
25	40-776	KIT - thermistor	1
26	51-270	CONNECTOR - liquid tite	1
27	41-6150	TRANSDUCER - suction (200 psi)	1
28	41-6151	TRANSDUCER - discharge (200 psi)	1






REF	PART#	DESCRIPTION	QTY
1	92-236	BRACKET - diagram	1
	55-3272	RIVET - bracket	4
2	92-237	BRACKET (w/ receptacle)	2
	55-2074	NUT - speed	4
	55-9166	SCREW - bracket	4
	55-9444	WASHER - insulating (nylon)	4
3	45-2010	BOARD - relay (MP3000 A)	1
4	504-514	• RELAY - power	6
	92-860	CLIP - relay	6
5	504-970	• FUSE (20A)	3
6	41-3430	HOLDER - fuse	3
	51-336	SCREW - relay board	6
7	41-3402	CABLE - retriever plug (Deutsch, see 212G6)	1
	41-2583	CABLE - retriever plug (Cannon, see 212G6)	1
	55-9322	RIVET - plug	4
	41-2406	CAP - plug	1
	99-3685	CHAIN - cap	1
8	92-238	HINGE - cover	2
	55-7172	SCREW - hinge	4
	51-618	INSULATOR	2
	51-1423	FLATWASHER	4
	51-1424	LOCKWASHER	2
	55-7042	NUT	4
9	55-9346	PLUG - seal	2
10	91-9833	NAMEPLATE - Caution	1
11	91-9272	NAMEPLATE - On/Off	1
12	41-3686	CONNECTOR - liquid tite	1
13	55-5900	FITTING - harness	5
14	55-5257	FITTING - harness	2
15	41-3595	SWITCH - On/Off (unit & cond fan)	2
	92-239	BOOT - switch	1
17	41-2832	CONNECTOR - plug (2 pin, short circuit)	1
	41-3596	BLOCK - terminal (4 pole)	1
	41-3597	BLOCK - terminal (5 pole)	1
	41-3598	BLOCK - terminal (8 pole)	1
	41-3851	BLOCK - terminal (12 pole)	1
	41-3599	BLOCK - terminal (14 pole)	1
	41-3608	BLOCK - terminal (18 pole)	1
18	NSS	DOOR - controller (see 183B5 & 188E8)	1
19	203-509	BATTERY (12V, 1.9 AH)	1
	55-9759	SCREW - battery	1
	55-6995	FLATWASHER	2






REF	PART#	DESCRIPTION	QTY
	55-7042	NUT	1
20	33-3837	GASKET - cover	1
21	33-3838	GROMMET	1
22	98-5454	BOX - control	1
	55-6994	SCREW - control box	4
	51-167	FLATWASHER	4
	55-9054	WASHER - insulator	4
23	33-3215	GROMMET	3
24	NSS	TRAY - high voltage (see 158A1)	1
25	41-3335	CABLE - battery	1
	41-4527	CONNECTOR (7 pin)	1
	44-6381	CONNECTOR (2 pin)	2
26	309-3066	RAIL - terminal block	1
	55-7169	SCREW - rail	2
	55-7033	FLATWASHER	2
	51-619	WASHER - insulator	2
	55-7034	NUT	2
27	41-3687	TERMINAL - stop clip	2
28	41-5105	PLATE - end terminal	1
29	41-3688	BLOCK - terminal	6
30	41-3703	CONNECTOR - cross	1
31	44-9359	FUSE (7.5 amp)	1
32	92-5520	BRACKET - battery	1
	55-2988	RIVET - bracket	1





REF	PART#	DESCRIPTION	QTY
1	92-3445	PLATE - bottom	1
	51-1421	SCREW - plate to box	4
	51-619	WASHER - insulator	4
	55-6995	FLATWASHER	4
	51-1423	LOCKWASHER	4
	51-1425	NUT	4
2	41-5104	BREAKER - circuit (25 amp)	1
3	41-3605	CONTACTOR (CI 25)	2
4	41-3317	TRANSFORMER	1
	55-9396	SCREW - transformer	4
5	91-9914	RAIL - din (60 mm)	1
6	91-9915	RAIL - din (125 mm)	1
7	55-9166	SCREW (pan hd)	11
	55-7370	LOCKWASHER	6
8	41-3604	INTERLOCK	1
9	41-5309	CONTACTOR - auxiliary (4 pin remote option, see 158A5)	2




CONTROL BOX DOOR (MP3000-A w/ RMM)



REF	PART#	DESCRIPTION	QTY
1	98-6784	DOOR - control box (complete, includes 1 thru 6, 8, 9, 10 & 13)	1
	91-9380	DOOR - control box	1
2	41-4142	• KEYPAD (MP3000)	1
3	91-9381	HINGE - door	2
	51-1418	• SCREW - hinge	4
	55-9444	• WASHER (nylon)	4
	51-1420	• WASHER	8
	51-1419	• NUT	4
4	55-9392	• INSULATOR - hinge	2
5	55-8919	• RETAINER - screw	2
6	55-9393	SCREW - door (knurled)	2
	51-1470	SCREW - door (Phillips)	2
7	45-2009	CONTROLLER (MP3000-A)	1
8	44-6777	• FUSE (2 amp)	2
9	41-4919	DISPLAY - controller	1
10	203-506	BATTERY - lithium	1
	51-1419	NUT - controller	4
	55-8919	LOCKWASHER	2
	55-9444	WASHER - insulating (nylon)	4
11	41-3602	CABLE - connecting (25 pin, No. 1 & 3)	2
12	41-3603	CABLE - connecting (RMM, option 098158, 098159)	1
13	55-9395	ADAPTER - push-on	1
	51-1419	NUT	1
14	91-9382	NAMEPLATE - Warning, Power Off	1
15	92-3446	NAMEPLATE - Phase Select	1
16	41-2835	CABLE - connecting (No. 2)	1
17	845-1898	MODEM (RMM, option 098158, 098159)	1
	41-3601	MODEM (MPC - 2000, 098983)	1
18	41-3335	CONNECTOR (7 pin)	1
19	92-3554	GASKET - controller	1





Revised 12/3/03


TRANSFORMER GROUP (098024, 098040, 098041, 098043, 098071, 098123, 098128)



148G2

REF	PART#	DESCRIPTION	QTY
1	45-1859	TRANSFORMER	1
2	41-1977	RECEPTACLE - power (32 amp, 440V)	1
	55-2995	SCREW - receptacle	4
	55-2964	• LOCKWASHER	2
	55-2001	• FLATWASHER	2
3	55-5919	CONNECTOR - grip	1
	55-2636	NUT - connector	1
4	41-3083	CABLE - power (69 ft)	1
5	91-9508	INSULATOR	2
6	55-7341	SCREW - transformer	2
	55-8891	SCREW - transformer	4
	55-7085	FLATWASHER	6
	55-7342	LOCKWASHER	6
7	91-6988	BRACKET - cable restraint (current units)	1
8	55-9164	SCREW - cable	1
	55-7357	FLATWASHER	1
	55-7344	NUT	1
9	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
	55-7170	LOCKWASHER	4
10	91-3238	BRACKET - cable (early units)	1
	55-7172	SCREW - bracket	3
	55-6995	FLATWASHER	6
	55-7042	NUT	3
11	44-3828	PLUG - power (50 amp)	1
	44-5133	PLUG - power (60 amp, orange)	1
	41-3429	PLUG - power (50 amp, blue)	1
	33-2482	BUSHING - plug	1






RECORDING THERMOMETER (OPTION 098026 & 098030)



REF	PART#	DESCRIPTION	QTY
1	45-1830	THERMOMETER - recording (31 day, Partlow, 098025, see 147B2)	1
	45-1831	THERMOMETER - recording (31 day, Saginomiya, battery, 098026, see 147B9)	1
	45-1832	THERMOMETER - recording (31 day, Saginomiya, AC power, 098030, see 147B9)	1
	55-7172	SCREW - recorder	4
	55-6996	LOCKWASHER	4
	55-6995	FLATWASHER	4
2	91-8705	BOX - recorder	1
	55-7341	SCREW - box	4
	55-6988	FLATWASHER	4
	55-8953	WASHER (nylon)	4
3	91-4218	PLATE - box (bottom)	1
	55-7340	SCREW - plate	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
4	33-451	GROMMET	1
5	99-7230	GUIDE - latch	1
6	55-7169	SCREW - guide (12 mm)	1
7	55-8720	SCREW - guide (25 mm)	1
8	55-7033	FLATWASHER	4
9	55-7464	LOCKWASHER	1
10	55-9444	WASHER - insulating (nylon)	4
11	55-7034	NUT	4
12	91-5005	LATCH - cover	1
	55-2988	RIVET - latch	2
13	91-5006	BRACKET - latch	1
	55-7340	SCREW - bracket	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
14	98-7209	COVER - recorder (incl items 15, 16 & 17)	1
15	91-5007	PLATE - keeper	1
	55-2988	RIVET - plate	2
16	91-8707	WINDOW	1
17	33-3008	GASKET - cover	4
	91-4219	HINGE SET - left	1
18	91-8708	HINGE - right (w/ pin)	1
19	91-8725	• HINGE - right (w/o pin)	1
20	91-8709	• HINGE - left (w/ pin)	1






RECORDING THERMOMETER (OPTION 098026 & 098030)



147B8

REF	PART#	DESCRIPTION	QTY
21	91-8726	HINGE - left (w/o pin)	1
	55-7169	SCREW - hinge	8
	55-7033	FLATWASHER	8
	55-7404	LOCKWASHER	8
	91-4220	HINGE SET - right	1
22	203-180	CHART (31 day, -20 to +80 F, box of 50)	1
	203-252	CHART (31 day, -30 to +25 C, box of 50)	1
	203-219	CHART (31 day, -25 to +25 C, box of 50)	1




Revised 2/2/06

RECORDING THERMOMETER - 31 DAY FAHRENHEIT




REF	PART#	DESCRIPTION	QTY
	45-1830	THERMOMETER (31 day, F)	1
1	44-5644	• ELEMENT - thermo (1/2 od, 7.5 in lg bulb, 10 ft capillary)	1
	44-2339	• ELEMENT - thermo (3/8 od, 14 in lg bulb, 10 ft capillary)	1
2	91-8217	• ROD - push	1
3	33-2962	• O-RING	1
4	41-2216	• MECHANISM	1
5	44-2966	DRIVE - chart (31 day)	1
6	55-5099	• NUT, CLIP & CORD	1
7	41-2218	• PLATEN	1
8	55-8955	• KEY - winding	1
9	91-2205	• KIT - stylus	1
10	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1



RECORDING THERMOMETER (OPTION 098026)




REF	PART#	DESCRIPTION	QTY
	45-1831	THERMOMETER - recording (Saginomiya, 31 day battery)	1
	45-1832	THERMOMETER - recording (Saginomiya, 31 day, AC power)	1
1	44-9780	• ELEMENT	1
2	44-9781	• INDICATOR - volt	1
3	44-7782	• TIMER	1
4	509-911	PLATE - recorder	1
5	505-390	NUT - chart	1
6	41-4382	ARM - pen lift	1
7	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1
	203-252	CHART (31 day, -30 to +25 C, box of 50)	1
	203-219	CHART (31 day, -25 to +25 C, box of 50)	1



ELECTRONIC CHART RECORDER



REF	PART#	DESCRIPTION	QTY
1	45-2012	THERMOMETER - recording (31 day)	1
	55-7172	SCREW - recorder	4
	55-7170	LOCKWASHER	4
	55-7075	FLATWASHER	4
2	91-8705	BOX - recorder	1
	55-7341	SCREW - box	4
	55-6988	FLATWASHER	4
	55-8953	WASHER - insulating	4
3	92-5547	PLATE - box (bottom)	1
4	91-5006	BRACKET - latch	1
	55-7036	SCREW - plate	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
5	99-7230	GUIDE - latch	1
6	55-9002	SCREW - guide (30 mm)	1
7	55-7340	SCREW - guide (16 mm)	1
8	55-7033	FLATWASHER	4
9	55-9054	LOCKWASHER	1
10	55-9444	WASHER - insulating	4
11	55-7034	NUT	4
12	91-5005	LATCH - cover	1
	55-2988	RIVET - latch	2
13	33-367	GROMMET	1
	55-7354	NUT	2
14	98-7209	COVER - recorder	1
15	91-5007	PLATE - keeper	1
	55-2988	RIVET - plate	2
16	91-8707	• WINDOW	1
17	33-3008	GASKET - cover	4
18	91-8708	HINGE - right (w/ pin)	1
19	91-8725	HINGE - right (w/o pin)	1
20	91-8709	HINGE - left (w/ pin)	1
21	91-8726	HINGE - left (w/o pin)	1
	55-7340	SCREW - hinge	8
	55-7033	FLATWASHER	8
	55-7404	LOCKWASHER	8
22	203-546	CHART - thermometer (31 day)	1




Revised 2/25/04

REMOTE MONITOR OPTION (098182 CSR; 098144 CRR; 098182 CSR)




REF	PART#	DESCRIPTION	QTY
1	41-3606	HARNESS - remote monitor	1
2	41-3607	• RECEPTACLE (4 pin)	1
	55-9322	RIVET - receptacle	4
3	92-206	CAP - plug	1
	55-9323	RIVET - cap	1
4	41-5309	CONTACTOR - auxiliary (CSR units)	2





REF	PART#	DESCRIPTION	QTY
	41-3336	PANEL - USDA, assembly	1
1	91-9834	PANEL - USDA receptacle	1
2	41-3585	CONNECTOR (12 pin)	1
3	41-3586	RECEPTACLE (5 pin, cannon, bayonet)	1
4	41-3587	RECEPTACLE (4 pin, cannon, bayonet)	3
	55-9322	RIVET - receptacle	16
5	41-3588	CAP - receptacle	4
	55-3272	• RIVET - cap	4
6	92-206	• CAP - plug	1
	55-9211	RIVET - panel	4
7	41-5405	SENSOR - PT100 (4 pin, cannon, bayonet)	4
8	41-2853	CABLE & PLUG - retriever (cannon threaded)	1






USDA DOWNLOAD PANEL (DEUTSCH CONNECTORS)



REF	PART#	DESCRIPTION	QTY
1	91-9834	PANEL - USDA receptacle (before 4/00)	1
	92-428	PANEL - USDA receptacle (4/00 & after)	1
	55-3272	RIVET - panel	4
2	41-2406	CAP - dust	1
3	99-3685	CHAIN - cap	1
4	41-3588	CAP - dust	3
	55-9322	RIVET - cap	4
5	304-2772	RECEPTACLE (3 pin, Deutsch)	3
	55-9322	RIVET - connector	16
6	41-2405	RECEPTACLE (5 pin, Deutsch)	1
7	55-9402	PLUG - spare hole	1
8	41-3585	CONNECTOR - plug (12 pin)	1
9	92-243	NAMEPLATE - data download USDA	1
10	41-3107	SENSOR (3 pin, Deutsch, 14 m, NTC)	4
11	41-3402	CABLE & PLUG - retreiver (Deutsch)	1






USDA DOWNLOAD PANEL (4-PIN DEUTSCH CONNECTORS)




REF	PART#	DESCRIPTION	QTY
1	92-428	PANEL - USDA receptacle	1
	51-1448	RIVET - panel	4
2	41-2406	CAP - dust	1
3	99-3685	CHAIN - cap	1
4	41-3588	CAP - dust	4
	55-9323	RIVET - cap	5
5	41-3587	RECEPTACLE (4 pin, Deutsch)	4
	55-9322	RIVET - connector	16
6	41-5416	CONNECTOR - plug (16 pin)	1
7	92-243	NAMEPLATE - data download (USDA)	1
8	41-3107	SENSOR (3 pin, Deutsch, 14 m, NTC)	4
9	41-3402	CABLE & PLUG - retreiver (Deutsch)	1



CONDENSER COMPONENTS

REF	PART#	DESCRIPTION	QTY
1	91-8195	KEEPER - door latch	2
	51-1459	SCREW - keeper	4
	51-1464	WASHER	4
	55-9054	WASHER (vinyl)	4
2	91-8108	BRACKET - frame	1
	51-1442	SCREW - bracket	5
	51-1464	FLATWASHER	5
	55-9054	WASHER (nylon)	5
	51-1425	NUT	3
3	98-6236	PLATE - cable storage (units w/ water cooled cond)	1
	98-6560	PLATE - cable storage (units w/o water cooled cond)	1
	51-1425	NUT	2
	55-9054	WASHER (nylon)	4
	51-1464	FLATWASHER	4
4	91-8474	PLATE - guard	1
	55-7341	SCREW - plate	3
	51-1464	FLATWASHER	6
	55-9054	WASHER - insulation	6
	55-7339	NUT	3
5	98-5925	GRILLE - condenser (see 189C4)	1
	33-3043	GASKET - rubber extrusion	1
	51-1445	SCREW - grille	4
	51-1464	FLATWASHER	4
	55-9054	WASHER (nylon)	4
6	98-6518	DOOR - evaporator	1
	98-7430	DOOR - evaporator (Transfresh, see 212G0)	1
7	91-9040	• KNOB	2
8	51-1460	SCREW - door (TIR seal)	2
9	91-8199	• SPRING	2
10	55-7354	• NUT	2
11	51-619	WASHER (nylon)	2
12	91-9041	• LATCH - door	2
	55-3101	RIVET - latch	4
13	91-8134	INSULATOR - latch	2
14	91-9039	• HOOK - strap	1
15	509-937	• STRAP - door	1
	51-801	SCREW - strap	1
	51-167	• FLATWASHER	2
16	91-8256	PIN - hinge (w/snap)	2
17	509-1654	HINGE - frame	2
	1	ı	




CONDENSER COMPONENTS



REF	PART#	DESCRIPTION	QTY
	51-1460	SCREW - hinge (TIR seal)	4
	55-9541	WASHER (nylon)	4
18	33-3969	GASKET - evaporator door	1
19	91-8475	NAMEPLATE - TK	1
20	33-2983	GASKET - unit	1
21	91-8728	COVER (instead of thermometer)	1
	51-1467	SCREW - cover	3
	55-6988	FLATWASHER	3
22	92-891	BRACKET - safety hook	1
	55-8559	SCREW - bracket	4
	55-7085	FLATWASHER	8
	55-9541	WASHER (nylon)	8
23	98-6771	FRAME - condenser (Maersk, WCC)	1
	98-7418	FRAME - condenser (w/ nitrogen ports)	1
	98-7410	FRAME - condenser (WCC)	1
	98-7424	FRAME - condenser	1
	98-7446	FRAME - condenser (Transfresh)	1
24	91-9754	POCKET - sensor	2
25	91-9949	PORT - injection (optional)	2
	51-1448	RIVET - port	4
26	91-9950	HOUSING - relief valve	1
	51-1448	RIVET - housing	4
27	91-9951	VALVE - pressure relief	1
28	61-2271	VALVE - vacuum	1






CONDENSER COMPONENTS (20 ft CONTAINER, THREE FANS)



REF	PART#	DESCRIPTION	QTY
1	91-8195	KEEPER - door latch	3
	55-9312	SCREW - keeper (TIR seal)	6
	55-6995	WASHER	6
	55-9054	WASHER (nylon)	6
	55-8877	WASHER (nylon)	6
2	91-8108	BRACKET - frame	1
	55-6993	SCREW - bracket	3
	55-6988	WASHER	6
	55-8882	WASHER (nylon)	6
	55-9380	NUT	3
3	91-6560	PLATE - cable storage (front)	1
	55-9168	NUT	2
	55-9054	WASHER (nylon)	6
	55-6994	SCREW - plate	2
	55-6695	FLATWASHER	6
	55-8933	WASHER (nylon)	6
4	91-8474	PLATE - guard	1
	55-7341	SCREW - plate (20 mm)	2
	55-6993	SCREW - plate (25 mm)	2
	55-7339	NUT	6
	55-8904	FLATWASHER	6
	55-8953	WASHER - insulation	6
5	98-5925	GRILLE - condenser	1
	55-6994	SCREW - grille	4
	55-6995	FLATWASHER	4
	55-9054	WASHER (nylon)	4
6	509-755	DOOR - evaporator	1
	92-2995	HINGE - evap door	3
	51-620	RIVET - hinge	12
7	91-9040	KNOB	3
8	55-7035	SCREW - door	3
9	91-8199	SPRING	3
10	55-7354	NUT	3
11	55-9054	WASHER (nylon)	3
12	91-9041	LATCH - door	3
	55-2864	RIVET - latch	6
13	91-8134	INSULATOR - latch	3
14	509-1654	HINGE	3
	55-9313	SCREW - hinge (TIR seal)	6
	55-8882	WASHER (nylon)	6
15	91-8256	PIN - hinge (w/ snap)	3
16	92-891	BRACKET - safety hook	1






Revised 3/1/06


CONDENSER COMPONENTS (20 ft CONTAINER, THREE FANS)



REF	PART#	DESCRIPTION	QTY	
	55-6993	SCREW - bracket	4	
	55-7085	WASHER	8	
	55-8882	WASHER (nylon)	8	
17	98-6563	FRAME - condenser	1	
18	33-3968	GASKET - evaporator door	1	
19	91-9511	NAMEPLATE - TK	1	
20	33-2983	GASKET - unit	1	
21	91-8728	COVER (instead of thermometer)	1	
	55-7391	SCREW - cover	3	
	55-6988	FLATWASHER	3	
22	91-9039	HOOK - strap	1	
	55-3065	CLAMP - hook	1	
	55-9166	SCREW - clamp	1	
23	509-937	STRAP - door	1	
	55-9173	SCREW - strap	1	
	55-7089	FLATWASHER	2	
24	91-9754	POCKET - sensor	2	




AIR VENT (40 FT CONTAINERS)



REF	PART#	DESCRIPTION	QTY
	91-8252	VENT - air (complete)	1
1	91-9048	BRACKET - air vent handle	1
2	51-1426	SCREW - handle	1
	51-1474	• SCREW (M8 x 1.25 x 65, ss)	1
	55-9541	WASHER (nylon)	4
	51-1427	• NUT	1
3	91-8100	• SPRING	1
4	92-440	NAMEPLATE - Do Not Open Below 0 C	1
5	91-8102	HANDLE - air vent	1
6	77-2467	BEARING - slide	1
7	91-8104	BRACKET - handle	1
8	51-1428	• NUT	2
	51-1429	• LOCKWASHER	1
	51-1430	• FLATWASHER	1
9	51-1431	• NUT - wing	1
10	91-8103	DISK - air vent	1
11	33-4255	GASKET - air vent	1
12	91-8105	PLATE - air vent	1
	55-7172	SCREW - plate	4
	55-7075	• FLATWASHER	4
	55-9541	WASHER (nylon)	4
13	33-2944	GASKET - air vent	1
14	91-8663	• PROTECTOR - edge	1
15	91-8106	• PIN - hinge	1
16	91-8107	NAMEPLATE - Do Not Open Below 0 C	1
17	55-9168	ADAPTER - hose	1
18	92-411	HINGE - air vent	1
	51-619	SCREW - vent	8
	55-8933	WASHER - insulator (6.4 id)	4
	55-7075	FLATWASHER	4
	55-9054	WASHER - insulator (8.4 id)	6
	51-167	FLATWASHER	6
	55-7339	NUT	6






AIR VENT (40 FT CONTAINERS)



REF	PART#	DESCRIPTION	QTY
1	91-9048	BRACKET - air vent handle	1
2	55-9442	SCREW - handle	1
	55-9541	WASHER - insulation	4
	51-1427	NUT	1
3	91-8100	SPRING	1
4	41-5666	DEVICE - door position sensor	1
5	91-8102	HANDLE - air vent	1
6	51-1458	SCREW - disk	1
7	91-8104	BRACKET - handle	1
8	51-1211	NUT	2
	51-1429	LOCKWASHER	1
	51-1430	FLATWASHER	1
	55-9541	WASHER - insulating	3
9	51-1431	NUT - wing	1
10	91-8103	DISK - air vent	1
11	33-4255	GASKET - air vent	1
12	509-753	PLATE - air vent	1
	55-7172	SCREW - plate	4
	55-7075	FLATWASHER	4
	55-8877	WASHER (nylon)	4
13	33-2944	GASKET - air vent	1
14	91-8663	PROTECTOR - edge	1
15	91-8106	PIN - hinge	1
16	92-440	NAMEPLATE - Do Not Open Below 0 C	1
17	55-9168	ADAPTER - hose	1
18	92-411	HINGE - air vent	1
	55-6994	SCREW - vent hinge	8
	51-167	FLATWASHER	4
	55-9541	WASHER - insulator (8.4 id)	6
	55-7339	NUT	6






AIR VENT (20 FT CONTAINERS)



REF	PART#	DESCRIPTION	QTY		
1	55-7349	SCREW - air vent	1		
2	92-240	PLATE - air vent	1		
3	33-3214	GASKET - air vent	1		
	55-7172	SCREW	6		
	55-7075	FLATWASHER	6		
	55-8877	WASHER (nylon)	6		
4	92-241	LABEL - air ventilation	1		
5	91-8103	DISK - air vent	1		
6	33-2967	• GASKET	1		
7	55-7342	LOCKWASHER	1		
8	55-7825	NUT	2		
9	92-242	BEARING - slide	1		
10	55-7085	FLATWASHER	1		
11	55-8888	NUT - wing	1		
12	55-9168	BARB - hose adapter	1		
13	55-8886	WASHER (nylon)			






AFAM MP3000 (OPTION 098166)




REF	PART#	DESCRIPTION	QTY
1	92-412	BRACKET - motor box	1
	55-7172	SCREW - bracket	2
	51-167	WASHER	2
	51-619	WASHER - insulator	2
2	92-415	GRILLE - fresh air	1
	55-7172	SCREW - grille	3
	51-167	WASHER	3
	51-619	WASHER - insulator	3
3	92-416	BRACKET - receptacle	1
	55-7172	SCREW - bracket	2
4	33-3264	GASKET - receptacle (10 x 10)	1
5	92-414	HOUSING - motor	1
	55-7404	LOCKWASHER	4
	55-7033	FLATWASHER	4
	55-7367	NUT	4
6	33-314	GROMMET	1
7	92-413	BRACKET - mechanical stop	1
	55-7862	SCREW - bracket	4
	203-393	SEALER - thread	A/R
8	41-3674	MOTOR - damper (24VDC)	1
9	41-2832	CONNECTOR - plug (2 pin)	1
10	92-418	LINKAGE	1
11	92-417	LINKAGE	1
	55-7027	SCREW - linkage	2
	55-8893	WASHER	4
	55-7042	NUT	2
12	55-3537	PIN - cotter	2
13	55-9338	WASHER - shoulder	1
14	92-419	ROD - linkage	1
15	11-4929	BALL JOINT	1
	92-5521	BALL JOINT	1
16	55-9437	RETAINER - pin	1
17	92-420	VENT - air	1
18	33-3265	GASKET - air vent	1
19	92-411	HINGE - plate	1
20	91-8106	PIN - hinge (w/ snap)	1
21	41-3583	BOARD - interface (AFAM+)	1
22	41-3584	CABLE - AFAM/AFAM+	1




AIR VENT (AFAM MP3000)




REF	PART#	DESCRIPTION	QTY
1	92-5685	BRACKET - air vent	1
	55-6994	SCREW - bracket	2
	51-619	WASHER - insulator	2
	51-167	FLATWASHER	2
2	33-3264	GASKET	1
3	92-5686	BRACKET - rear	1
	51-1445	SCREW - bracket	2
	51-1464	FLATWASHER	2
	55-9054	WASHER - insulator	2
4	51-1496	PIN - clevis	2
5	77-2870	BEARING	4
6	55-2550	PIN - cotter	2
7	41-7238	ACTUATOR	1
8	92-5687	DOOR - AFAM	1
9	91-8106	PIN - hinge	1
10	33-3265	GASKET - air vent	1
11	92-416	BRACKET - grille	1
	51-1445	SCREW - bracket	2
	55-9054	WASHER - insulator	2
	51-1464	FLATWASHER	2
12	92-415	GRILLE - fresh air	1
	51-1422	SCREW - grille	3
	41-1441	FLATWASHER	3
	51-619	WASHER - insulator	3
13	41-3583	BOARD - interface	1
14	41-3584	CABLE - AFAM/AFAM+	1
15	92-5201	LABEL - AFAM door position	1




EVAPORATOR PANELS




REF	PART# DESCRIPTION		QTY	
1	98-5773	PLATE - rear (bottom)	1	
2	98-5772	PLATE - rear (top)	1	
	51-336	SCREW - plate	23	
	55-9444	WASHER - insulating	23	
	55-3136	RIVET - plate	29	
3	98-5774	GRILLE - evaporator (MAGNUM)	1	
	98-5923	GRILLE - evaporator (MAGNUM 924)	1	
	98-6556	GRILLE - evaporator (MAGNUM 40-SL)	1	
	98-6565	GRILLE - evaporator (MAGNUM 20)	1	
	55-3136	RIVET - grille	17	
4	92-427	CHANNEL - Z (100 mm deep)	5	
	92-2774	CHANNEL - Z (57 mm deep)	5	
	91-9922	CHANNEL - Z (MAGNUM 20)	5	
	51-621	RIVET - channel	39	
5	NSS	PANEL - USDA receptacle (see 157H2 & 189D7)	1	
6	92-2773	CHANNEL - air (MAGNUM)	1	
	91-9923	CHANNEL - air (MAGNUM SL 40 & 20)	1	
	203-389	SEALER - polyurethane	A/R	
	55-8891	SCREW - channel	6	
7	91-9330	INLET - fresh air (MAGNUM)	1	
	91-9924	INLET - fresh air (MAGNUM SL 40 & 20)	1	
	55-9323	RIVET - inlet	10	
	203-389	SEALER - polyurethane	A/R	
8	91-9331	CHANNEL - fresh air	1	
	55-9323	RIVET - channel	8	
9	98-5775	PLATE - cover (Transfresh)	1	
	55-7713	RIVET - plate		
10	41-2554	CABLE - Transfresh (option 098150)	1	
11	41-2555	CABLE - Transfresh (option 098150)		
12	41-5405	SENSOR - PT100 (option 098106)		
13	92-722	PLATE - cover	1	
	55-2262	RIVET - plate	6	





REF	PART#	DESCRIPTION	QTY	
1	91-8244	BRACKET - hose	1	
2	99-3281	MOUNT - cable tie	5	
	55-2260	RIVET - mount	5	
3	55-2686	CLAMP - hose	2	
4	55-8891	SCREW - bracket	2	
5	55-9208	CONNECTOR - T (hose)	1	
6	55-2330	BANDWRAP	6	
7	11-8983	HOSE - flex	1	
8	11-9575	T-DRAIN	1	
	11-9735	T-DRAIN (after 9/03)	1	
9	11-9576	HOSE - flex (11/01 & after)	A/R	





REF	PART#	DESCRIPTION	QTY
1	98-5925	GRILLE - condenser (see 189C2)	1
2	33-3043	GASKET - grille (extrusion)	1
3	11-9734	HOSE - drain (29 mm id, cut as required)	A/R
	11-9576	HOSE - drain (21 mm id, cut as required)	A/R
4	55-2330	BANDWRAP	A/R
5	11-9735	TEE - drain hose	1







THERMO KING

WARNING

FANS START AUTOMATICALLY



5

WARNING **Hot Components**

Compressor discharge may be hot!

DATA DOWNLOAD

9



6

CONSULT MAINTENANCE MANUAL FOR PRECAUTIONS BEFORE WELDING ON CONTAINER OR REFRIGERATION UNIT.

- Disconnect all power to the refrigeration unit
- Disconnect all quick-disconnect wire harnesses Switch all of the electrical circuit breakers in the control
- box to the OFF position.
 Weld unit and/or container per normal welding procedures. Keep ground return electrode as close to the area to be welded as practical. This will reduce the likelihood of stray welding currents passing through any electrical or electronic circuits.
- When the weld ing operation is completed, the unit power cables, wiring and circuit breakers must be restored to their normal condition.

10

◆ USDA #1/ SPARE 1 DO NOT **OPEN BELOW** 0°C 32°F 150 m³/h 90 CFM USDA #2/ 55% 225 m³/h 135CFM • 80% USDA #3/ 280 m³/h 165CFM < PULP/ SPARE 5 100% 15

CLOSED⁶ CO2 ADAPTER' DO NOT OPEN BELOW 0°C 15 m³/h 9 CFM • 5% ²³ 75 m³/h ²³ 45 CFM**●** 25% 100 m³/h

60 CFM35%

16

125m3/h

75 CFM◀ 45%

°C -+85 +86 -+80 -+75 -+70 -+65 -+60 --+55 -+50 -+45 -+40 +30 +30 -+ 25 -+20 —+10 ~+5 **—**n ---10

WARNING!

TURN POWER OFF BEFORE DISCONNECTING DATALOGGER OR CONTROLLER.

TRANSFRESH DATA CONNECTOR **A** 3

11

TRANSFRESH SCRUBBER CONNECTOR A 5

12

VARNING 🗘

Do Not Operate Scroll Compressor with Service or Receiver Tank Valves Closed. **Compressor Damage Will** Occur.

13

▲WARNUNG ▲ WARNING ▲ ADVERTENCIA Vergewissem Sie sich, dass der Container vor dem Eintreten belüftet ist, Cerciórese de que el contenedor esté ventilado antes de entrar Puede encontrarse en condiciones de poco Make sure container is vented before entering, may contain low oxygen condition. um Sauerstoffmange auszuschließen! ▲ 주의 ▲ 警告 ▲ 整性 들어가기전에 콘테이너에 통 중이 되여있는지 확인하십시 實務必在進入之前對容 たかどうか確認して下さい 器進行過度。 低酸素状態になるかもし 오. 저산소 상태가 발생할 수 可能存在低氢狀況 있습니다. れません。 14

COMPRESSOR FILLED WITH ESTER OIL

PART No: 203-433 4

DOOR POSITION CLOSED

> > 17

REF	PART#	DESCRIPTION	QTY
1	91-8475	NAMEPLATE - TK (crest)	1
2	92-863	NAMEPLATE - IR logo	1
3	91-9778	NAMEPLATE - Thermo King	1
4	91-8154	NAMEPLATE - R404A	1
5	91-8694	NAMEPLATE - Warning, Fan Start	1
6	91-8695	NAMEPLATE - Warning, Hot Components	1
7	509-1653	NAMEPLATE - Temperature Conversion	1
8	91-9382	NAMEPLATE - Warning	1
9	92-243	NAMEPLATE - USDA Connections	1
10	92-1218	NAMEPLATE - Weld	1
11	91-8697	NAMEPLATE - Data A3	1
12	91-8696	NAMEPLATE - Scrubber A5	1
13	91-9596	NAMEPLATE - Warning, Scroll Compressor	1
14	92-2585	NAMEPLATE - Warning, Low Oxygen	1
15	92-440	NAMEPLATE - Air Vent Handle	1
16	91-9831	NAMEPLATE - Air Vent Door	1
17	92-2586	NAMEPLATE - AFAM Door Position	1

102-795	14, 18, 24, 28, 34	41-1441	82	41-4527	40
104-691	8, 12, 34	41-1976	34	41-4919	44
104-697	6, 34	41-1977	46	41-5103	14, 34
11-4367	10	41-2216	52	41-5104	42
11-4929	80	41-2218	52	41-5105	40
11-8983	86	41-2405	62	41-5309	42, 58
11-9575	86	41-2406	38, 62, 64	41-5405	60, 84
11-9576	86, 88	41-2554	84	41-5416	64
11-9734	88	41-2555	84	41-5460	20, 24
11-9735	86, 88	41-2583	38	41-5635	36
		41-2832			
203-180	50, 52, 54		38, 80	41-5666	76
203-219	50, 54	41-2835	44	41-5814	10
203-252	50, 54	41-2838	34	41-6150	22, 26, 36
203-385	30	41-2853	60	41-6151	22, 26, 36
203-389	84	41-2953	6, 34	41-7238	82
203-393	28, 30, 80	41-3083	46	44-2339	52
203-454	18	41-3107	62, 64	44-2966	52
203-506	44	41-3301	14, 34	44-3828	46
203-509	38	41-3317	42	44-4051	34
203-516	28	41-3335	40, 44	44-5133	46
203-546	56	41-3336	60 [°]	44-5644	52
304-2772	62	41-3401	34	44-6381	40
309-3066	40	41-3402	38, 62, 64	44-6777	44
33-2482	46	41-3409	10	44-7782	54
33-2805	28	41-3429	46	44-9359	40
33-2944	74, 76	41-3429	38	44-9780	54
33-2946	8, 12	41-3583	80, 82	44-9781	54
33-2950	6	41-3584	80, 82	44-9891	34
33-2951	28	41-3585	60, 62	45-1830	48, 52
33-2962	52	41-3586	60	45-1831	48, 54
33-2967	78	41-3587	60, 64	45-1832	48, 54
33-2979	28	41-3588	60, 62, 64	45-1859	46
33-2983	68, 72	41-3593	34	45-1927	34
33-3007	14, 18, 30	41-3595	38	45-1992	34
33-3008	48, 56	41-3596	38	45-2009	44
33-3043	66, 88	41-3597	38	45-2010	38
33-3044	8	41-3598	38	45-2012	56
33-314	80	41-3599	38	45-237	34
33-3212	32	41-3601	44	504-514	38
33-3214	78	41-3602	44	504-970	38
33-3215	8, 12, 40	41-3603	44	505-390	54
33-3264	80, 82	41-3604	42	506-364	14, 18, 30
33-3265	80, 82	41-3605	42	509-1653	90
33-367	6, 8, 12, 56	41-3606	58	509-1654	66, 70
33-3837	40	41-3607	58	509-753	76
33-3838	10, 12, 40	41-3608	38	509-755	70 54
33-3912	18, 24	41-3674	80	509-911	54
33-3968	72	41-3685	8	509-937	66, 72
33-3969	68	41-3686	38	51-1211	76
33-4255	74, 76	41-3687	40	51-1418	44
33-451	48	41-3688	40	51-1419	44
33-566	16, 20, 26	41-3703	40	51-1420	44
33-727	28	41-3851	38	51-1421	42
33-768	32	41-4002	12, 34	51-1422	82
40-776	28, 36	41-4004	28, 34	51-1423	38, 42
40-779	28	41-4018	8, 34	51-1424	38
40-782	34	41-4142	44	51-1425	24, 42, 66
40-786	28	41-4382	54	51-1426	74
40-791	34	41-4473	16, 20, 26, 34	51-1427	6, 74, 76
			,,, • .	J	-,, . •

F4 4400	74	<i>EE</i> 2070	20 00 02	<i>FF</i> 0070	40
51-1428	74	55-3272	38, 60, 62	55-8872	12
51-1429	6, 8, 30, 74, 76	55-3364	28	55-8877	8, 70, 76, 78
51-1430	30, 74, 76	55-3537	80	55-8882	16, 70, 72
51-1431	74, 76	55-4390	14, 18, 24	55-8886	78
51-1432	28	55-5099	52	55-8888	78
51-1433	28	55-5257	38	55-8891	8, 12, 34, 46, 84, 86
51-1434	28	55-5900	6, 8, 38	55-8893	80
51-1435	28	55-5919	46	55-8903	12
51-1436	28	55-6388	16, 20, 24	55-8904	12, 70
51-1437	28	55-6695	70	55-8907	12
51-1438	28	55-6730	18, 30	55-8908	12
51-1439	24	55-6988	12, 16, 48, 56, 68, 70, 72	55-8915	16, 20
51-1440	24	55-6993	12, 16, 70, 72	55-8919	44
51-1441	24	55-6994	14, 40, 70, 76, 82	55-8933	70, 74
51-1442	6, 26, 66	55-6995	38, 42, 46, 48, 70	55-8950	14, 20, 24
51-1443	6, 8	55-6996	48	55-8951	14, 20, 24
51-1444	6, 8	55-7027	16, 80	55-8953	48, 56, 70
51-1445	66, 82	55-7029	16	55-8955	52
51-1448	64, 68	55-7033	40, 48, 50, 56, 80	55-8986	12
51-1458	76	55-7034	40, 48, 56	55-8993	16
51-1459	66	55-7035 55-7036	8, 14, 30, 70	55-8994 55-8995	28
51-1460	66, 68	55-7036	56	55-8995	28
51-1462	30	55-7042	14, 18, 20, 38, 40, 46, 80		56
51-1464	66, 82	55-7066	8, 12, 28	55-9012	28
51-1467	30, 68	55-7075	8, 12, 14, 16, 18, 20, 34,		28
51-1470	44		46, 56, 74, 76, 78	55-9027	16, 18
51-1474	74	55-7085	8, 46, 68, 72, 78	55-9054	6, 14, 18, 26, 40, 56, 66,
51-1496	82	55-7089	72		70, 74, 82
51-167	6, 14, 18, 26, 30, 40, 66,	55-7169	40, 48, 50	55-9086	32
	74, 76, 80, 82	55-7170	46, 56	55-9162	8
51-270	12, 36	55-7172	8, 12, 34, 38, 46, 48, 56,	55-9164	46
51-273	18		74, 76, 78, 80	55-9166	38, 42, 72
51-336	34, 38, 84	55-7176	34	55-9168	70, 74, 76, 78
51-358	28	55-7339	8, 12, 66, 70, 74, 76	55-9173	72
51-618	38	55-7340	48, 56	55-9208	86
51-619	40, 42, 66, 74, 80, 82	55-7341	46, 48, 56, 66, 70	55-9211	60
51-620	70	55-7342	8, 12, 46, 78	55-9217	8, 12
51-621	84	55-7344	46	55-9312	70
51-801	66	55-7347	18	55-9313	70
55-1827	30	55-7349	78	55-9322	38, 58, 60, 62, 64
55-2001	46	55-7354	48, 56, 66, 70	55-9323	58, 64, 84
55-2074	38	55-7357	46	55-9338	80
55-2260	86	55-7367	80	55-9346	38
55-2262	84	55-7370	42	55-9380	70
55-2296	16, 22, 24	55-7372	18, 20	55-9392	44
55-2324	12	55-7391	72	55-9393	44
	86, 88	55-7404	48, 50, 56, 80		44
55-2330 55-2550				55-9395 55-0306	42
	82	55-7464 55-7712	48	55-9396	
55-2636	46	55-7713	84	55-9402	62
55-2686	86	55-7825	78	55-9437	80
55-2864	70	55-7830	32	55-9442	76
55-2964	46	55-7862	80	55-9444	38, 44, 48, 56, 84
55-2988	40, 48, 56	55-7864	32	55-9541	68, 74, 76
55-2995	46	55-8316	14, 18, 20	55-9759	20, 38
55-302	14	55-8382	32	55-9912	18
55-3065	72	55-8464	18	60-285	6, 14, 18, 24
55-3101	66	55-8559	8, 68	61-1305	24, 30
55-3136	84	55-8720	48	61-154	32
55-3251	14, 18, 24	55-8805	12	61-175	14

61-1839	16	66-8811	14, 18, 30	91-8474	66, 70
61-1840	16	66-9181	14	91-8475	68, 90
61-1843	14	66-9194	32	91-8629	34
61-1844	14	66-9447	24, 30	91-8634	34
61-1845	14	66-9906	14, 20, 24	91-8663	74, 76
61-1846	14				
		67-1575	24, 30	91-8694	90
61-1847	14, 20, 24	67-1889	14, 18, 24	91-8695	90
61-1848	14, 18	67-1890	14	91-8696	90
61-1849	14	67-1921	16, 22, 26	91-8697	90
61-1850	16	67-1922	12, 16, 22, 26	91-8705	48, 56
61-1852	14	67-1923	16, 22, 24	91-8707	48, 56
61-1853	14	67-1991	18	91-8708	48, 56
61-2048	16, 20, 24	77-1401	6, 8, 12, 34	91-8709	48, 56
61-2049	16, 22, 24	77-1498	6, 8, 12, 34	91-8725	48, 56
61-2050	16, 20, 24	77-2467	74	91-8726	50, 56
61-2051	16, 22, 24	77-2870	82	91-8728	68, 72
61-2052	16	78-1117	8	91-9021	28
61-2053	16	78-1167	6	91-9039	66, 72
61-2054	16	78-1196	12	91-9040	66, 70
61-2057	16, 20, 26, 34	78-1349	8	91-9041	66, 70
61-2058	16	78-1524	8	91-9048	74, 76
61-2117	16	845-1898	44	91-9272	38
61-2118	28	91-1779	16	91-9328	8, 12
61-2119	28	91-1800	20	91-9330	84
61-2162	16, 18, 24	91-2205	52	91-9331	84
61-2238	18	91-3238	46	91-9380	44
61-2271	68	91-4218	48	91-9381	44
61-2464	20, 26	91-4219	48	91-9382	44, 90
61-2465	20, 26	91-4220	50	91-9508	46
61-2466	20, 26	91-4774	16	91-9511	72
61-2467	18, 24	91-5005	48, 56	91-9596	90
61-2468	20	91-5006	48, 56	91-9754	68, 72
61-2469	20, 24	91-5007	48, 56	91-9778	90
61-2470	20, 24	91-6560	70	91-9831	90
61-2471	18, 24	91-6627	30	91-9833	38
61-2472	18, 24	91-6628	30	91-9834	60, 62
61-2473	18	91-6988	46	91-9914	42
61-2474	20, 24	91-758	18	91-9915	42
61-2475	18	91-759	16, 30	91-9922	84
61-2476	20	91-8100	74, 76	91-9923	84
61-2477	18, 24	91-8102	74, 76	91-9924	84
61-2569	18	91-8103	74, 76, 78	91-9949	68
61-3502	20, 26	91-8104	74, 76	91-9950	68
61-3503	24	91-8105	74	91-9951	68
61-3504	24, 30	91-8106	74, 76, 80, 82	92-1218	90
61-3508	26	91-8107	74	92-206	58, 60
61-3525	24, 30	91-8108	66, 70	92-219	32
61-3542	24, 30	91-8134	66, 70	92-2228	20, 24
61-443	16, 20, 24	91-8140	34	92-2229	18
61-786	14, 18, 24	91-8142	34	92-2332	8
66-4788	30	91-8154	90	92-234	34
66-6607	16, 20, 28				
		91-8195	66, 70 66, 70	92-235	34
66-6610	28, 30	91-8199	66, 70	92-236	38
66-7182	14, 18, 28, 30	91-8217	52	92-237	38
66-7183	16, 20, 28	91-8244	86	92-238	38
66-7543	24, 30	91-8252	74	92-239	38
66-7812	14, 18, 28	91-8256	66, 70	92-240	78
66-8054	16, 20, 26, 28	91-8466	8, 12	92-241	78
66-874	16, 20	91-8467	34	92-242	78

92-243	62, 64, 90	98-5923	84
92-2585	90	98-5925	66, 70, 88
92-2586	90	98-6236	66
92-2587	10	98-6518	66
92-2588	14	98-6556	84
92-2589	14	98-6560	66
92-2773	84	98-6562	8
92-2774	84	98-6563	72
92-2775	8	98-6564	12
92-2777	34	98-6565	84
-			
92-2778	12	98-6566	8
92-2779	8	98-6771	68
92-2790	12	98-6784	44
92-2791	12	98-7209	48, 56
92-2995	70	98-7410	68
92-3391	20, 26	98-7418	68
92-3445	42	98-7424	68
92-3446	44	98-7430	66
92-3547	18	98-7446	68
92-3548	20	99-3281	86
92-3549	20	99-3685	38, 62, 64
92-3550	20	99-4931	8
92-3551	20	99-7230	48, 56
92-3552	20		,
92-3553	20		
92-3554	44		
92-411	74, 76, 80		
92-412	80		
92-413	80		
92-414	80		
92-415	80, 82		
92-416	80, 82		
92-417	80		
92-418	80		
92-419	80		
	80		
92-420			
92-425	8		
92-427	84		
92-428	62, 64		
92-440	74, 76, 90		
92-456	8		
92-458	8		
92-5201	82		
92-5520	40		
92-5521	80		
92-5547	56		
92-5660	34		
92-5685	82		
92-5686	82		
92-5687	82		
92-722	84		
92-860	38		
92-863	90		
92-891	68, 70		
98-5454	40		
98-5772	84		
98-5773	84		
98-5774	84		
98-5775	84		

A	CABLE - retriever plug 38	E
ACTUATOR 82	CABLE - Transfresh 84	ELBOW - low side 28
ADAPTER 16, 20, 26	CABLE & PLUG - retreiver 62, 64	ELEMENT 54
ADAPTER - compressor 16, 18, 24	CABLE & PLUG - retriever 60	ELEMENT - thermo 52
ADAPTER - highside 28	CAP - charge port 16, 20	
ADAPTER - hose 74, 76	CAP - dust 62, 64	F
ADAPTER - push-on 44	CAP - dust cover 30	FAN - condenser 6
ARM - pen lift 54	CAP - fitting 14, 18, 28, 30	FAN - evaporator 8, 12
Artivi - peri liit 34	CAP - plug 38, 58, 60	
В	CAP - receptacle 60	FILTER - gas sensor 8
	CAP - screw 8, 12	FITTING - flare 16, 20
BALL JOINT 80	CHAIN - cap 38 , 62 , 64	FITTING - harness 38
BANDWRAP 86, 88	CHANNEL - air 84	FITTING - high side 14, 30
BARB - hose adapter 78	CHANNEL - fresh air 84	FITTING - highside 28
BATTERY 38	CHANNEL - Z 84	FITTING - low side 16, 20, 28
BATTERY - lithium 44	CHART 50 , 52 , 54	FLATWASHER 6, 8, 12, 14, 16, 18,
BEARING 82	CHART - thermometer 56	20, 24, 26, 28, 30, 32,
BEARING - opposite end 6, 8, 12, 34		34, 38, 40, 42, 46, 48,
BEARING - shaft end 6, 8, 12, 34	CLAMP - dehydrator 18, 24	50, 56, 66, 68, 70, 72,
BEARING - slide 74, 78	CLAMP - hook 72	74, 76, 78, 80, 82
BLOCK - coil 8, 12	CLAMP - hose 86	FRAME - condenser 68, 72
BLOCK - terminal 38, 40	CLAMP - strap 16	FUSE 38 , 40 , 44
BOARD - interface 80, 82	CLAMP - suction tube 16	_
BOARD - relay 38	CLAMP - tube 16 , 18 , 20 , 30	G
BOOT - switch 38	CLAMP - valve 20, 24	GASKET 6, 78, 82
BOX - control 34, 40	CLIP - relay 38	GASKET - air vent 74 , 76 , 78 , 80 , 82
BOX - recorder 48, 56	COIL - condenser 6 , 14 , 18 , 24	GASKET - controller 44
BRACKET 38	COIL - evaporator 8 , 12 , 16 , 22 , 24 , 26	GASKET - cover 40, 48, 56
BRACKET - air vent 82	COIL - valve 14, 20, 24, 34	GASKET - evaporator door 68, 72
BRACKET - air vent handle 74, 76	COMPRESSOR - scroll 14 , 18 , 24 , 28 ,	GASKET - flange 28
BRACKET - battery 40	34	GASKET - gauge 32
BRACKET - cable 46	CONNECTOR 40 , 44 , 60	GASKET - grille 88
BRACKET - cable restraint 46	CONNECTOR - cross 40	GASKET - power connector 28
BRACKET - diagram 38	CONNECTOR - grip 12, 46	GASKET - receptacle 80
BRACKET - exchanger 14	CONNECTOR - harness 12	GASKET - round 32
BRACKET - frame 66, 70	CONNECTOR - harness & sensor 8	GASKET - rubber extrusion 66
BRACKET - grille 82	CONNECTOR - liquid tite 36, 38	GASKET - unit 68, 72
BRACKET - handle 74, 76	CONNECTOR - plug 38, 62, 64, 80	GAUGE - suction pressure 32
BRACKET - heat exchanger 20, 26	CONNECTOR - T 86	GRILLE - condenser 66 , 70 , 88
BRACKET - heater 34	CONTACTOR 42	GRILLE - evaporator 84
BRACKET - hose 86	CONTACTOR - auxiliary 42, 58	GRILLE - fresh air 80, 82
	CONTROLLER 44	
BRACKET - latch 48, 56	COUPLING - outlet 30	GRIP - cable 6
BRACKET - mechanical stop 80	COVER 68, 72	GROMMET 6, 8, 10, 12, 40, 48, 56, 80
BRACKET - motor 8, 12	COVER - exchanger 14	GUIDE - latch 48, 56
BRACKET - motor box 80	COVER - recorder 48, 56	Н
BRACKET - motor mount 12	COVER - terminal box 28	
BRACKET - power cable 34	COVER - tube 8, 12	HANDLE - air vent 74, 76
BRACKET - rear 82	00 VER 1450 0, 12	HANGER - dehydrator 14
BRACKET - receptacle 80	D	HARNESS - condenser fan 6, 34
BRACKET - safety hook 68, 70	DEHYDRATOR 14 , 18 , 24	HARNESS - control box 34
BRACKET - sensor 8	DEVICE - door position sensor 76	HARNESS - evaporator 34
BREAKER - circuit 42		HARNESS - evaporator fan 8, 12
BUSHING - plug 46	DISK - air vent 74, 76, 78	HARNESS - remote monitor 58
C	DISPLAY - controller 44	HARNESS - sensor 34
С	DOOR - AFAM 82	HEAT EXCHANGER - economizer 14,
CABLE - AFAM/AFAM+ 80, 82	DOOR - controller 38	18, 24
CABLE - battery 40	DOOR - controller 38	HEATER 34
CABLE - compressor 34	DOOR - evaporator 66, 70	HINGE 70
CABLE - connecting 44	DRIVE - chart 52	HINGE - air vent 74, 76
CABLE - power 34. 46		HINGE - cover 38

INDEX ALPHABETICAL BY DESCRIPTION

HINGE - door 44 HINGE - evap door 70	MOTOR - evaporator fan 34 MOTOR - fan 8, 12	PANEL - USDA, assembly 60 PIN - clevis 82
HINGE - frame 66	MOUNT - cable tie 86	PIN - cotter 80, 82
HINGE - left 48, 50, 56	NI.	PIN - hinge 66 , 70 , 74 , 76 , 80 , 82
HINGE - plate 80	N	PLATE - air vent 74 , 76 , 78
HINGE - right 48, 56	NAMEPLATE - AFAM Door Position 90	
HINGE SET - left 48	NAMEPLATE - Air Vent Door 90	PLATE - box 48 , 56
HINGE SET - right 50	NAMEPLATE - Arrow 2	PLATE - cable storage 66 , 70
HOLDER - fuse 38	NAMEPLATE - Arrow 8 NAMEPLATE - Caution 38	PLATE - cover 84 PLATE - end terminal 40
HOOK - strap 66, 72 HOSE - drain 88	NAMEPLATE - Caution 36 NAMEPLATE - Data A3 90	PLATE - end terminal 40 PLATE - guard 32 , 66 , 70
HOSE - flex 86	NAMEPLATE - data download 64	PLATE - keeper 48 , 56
HOSE - sensor 10	NAMEPLATE - data download USDA	PLATE - rear 84
HOUSING - evaporator 8	62	PLATE - recorder 54
HOUSING - motor 80	NAMEPLATE - Do Not Open Below 0 C	PLATEN 52
HOUSING - relief valve 68	74, 76	PLUG 28
•	NAMEPLATE - IR logo 90	PLUG - fusable 14, 18
I	NAMEPLATE - On/Off 38	PLUG - fusible 30
INDICATOR 30	NAMEPLATE - Phase Select 44	PLUG - outlet 30
INDICATOR - liquid 14, 18	NAMEPLATE - R404A 90	PLUG - power 34, 46
INDICATOR - volt 54	NAMEPLATE - Scrubber A5 90	PLUG - seal 38
INLET - fresh air 84	NAMEPLATE - Temperature	PLUG - spare hole 62
INSERT - threaded 12	Conversion 90	POCKET - sensor 68, 72
INSULATION - heat exchanger 18 INSULATION - mylar 20	NAMEPLATE - Thermo King 90 NAMEPLATE - TK 68, 72, 90	PORT - injection 68
INSULATION - tube 20	NAMEPLATE - TK 66, 72, 90 NAMEPLATE - USDA Connections 90	PROTECTOR - edge 74, 76
INSULATION 1 table 20	NAMEPLATE - Warning 90	R
INSULATOR - hinge 44	NAMEPLATE - Warning, Fan Start 90	RAIL - din 42
INSULATOR - latch 66, 70	NAMEPLATE - Warning, Hot	RAIL - terminal block 40
INTERLOCK 42	Components 90	RECEPTACLE 58, 60, 62, 64
	NAMEPLATE - Warning, Low Oxygen	RECEPTACLE - power 46
K	90	RELAY - power 38
KEEPER - door latch 66, 70	NAMEPLATE - Warning, Power Off 44	
KEY - fan 12	NAMEPLATE - Warning, Scroll	RETAINER - screw 44
KEY - winding 52	Compressor 90	RIVET - bracket 38, 40
KEYPAD 44	NAMEPLATE - Weld 90	RIVET - cap 58 , 60 , 62 , 64
KIT - gasket & grease 28	NUT 6, 8, 12, 14, 18, 20, 24, 28, 32,	RIVET - channel 84
KIT - power cord 28 KIT - sensor 34	38, 40, 42, 44, 46, 48, 56, 66, 70, 74, 76, 78, 80	RIVET - connector 62 , 64
KII - SEIISUI 34		
KIT - etylue 52		
KIT - stylus 52 KIT - thermistor 28, 36	NUT - chart 54	RIVET - hinge 70
KIT - thermistor 28, 36	NUT - chart 54 NUT - connector 46	RIVET - hinge 70 RIVET - housing 8, 68
	NUT - chart 54 NUT - connector 46 NUT - controller 44	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84
KIT - thermistor 28, 36	NUT - chart 54 NUT - connector 46	RIVET - hinge 70 RIVET - housing 8, 68
KIT - thermistor 28 , 36 KNOB 66 , 70	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70
KIT - thermistor 28, 36 KNOB 66, 70	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30,	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60 ROD - linkage 80
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30, 34, 38, 42, 44, 46, 48,	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10 NUT, CLIP & CORD 52	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30,	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10 NUT, CLIP & CORD 52	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60 ROD - linkage 80 ROD - push 52
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30, 34, 38, 42, 44, 46, 48, 50, 56, 74, 76, 78, 80	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10 NUT, CLIP & CORD 52 O OIL - compressor 28	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60 ROD - linkage 80 ROD - push 52
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30, 34, 38, 42, 44, 46, 48, 50, 56, 74, 76, 78, 80 M	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10 NUT, CLIP & CORD 52 O OIL - compressor 28 O-RING 14, 16, 18, 20, 26, 30, 52	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60 ROD - linkage 80 ROD - push 52 S SCREW 16, 42, 74, 78
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30, 34, 38, 42, 44, 46, 48, 50, 56, 74, 76, 78, 80 M MASTIC - heat transfer 18	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10 NUT, CLIP & CORD 52 O OIL - compressor 28	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60 ROD - linkage 80 ROD - push 52 S SCREW 16, 42, 74, 78 SCREW - air vent 78
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30, 34, 38, 42, 44, 46, 48, 50, 56, 74, 76, 78, 80 M	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10 NUT, CLIP & CORD 52 O OIL - compressor 28 O-RING 14, 16, 18, 20, 26, 30, 52	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60 ROD - linkage 80 ROD - push 52 S SCREW 16, 42, 74, 78
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30, 34, 38, 42, 44, 46, 48, 50, 56, 74, 76, 78, 80 M MASTIC - heat transfer 18 MECHANISM 52	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10 NUT, CLIP & CORD 52 O OIL - compressor 28 O-RING 14, 16, 18, 20, 26, 30, 52 O-RING - suction 28	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plate 48, 56, 84 RIVET - port 68 RIVET - receptacle 58, 60 ROD - linkage 80 ROD - push 52 S SCREW 16, 42, 74, 78 SCREW - air vent 78 SCREW - box 48, 56
KIT - thermistor 28, 36 KNOB 66, 70 L LABEL - AFAM door position 82 LABEL - air ventilation 78 LATCH - cover 48, 56 LATCH - door 66, 70 LINKAGE 80 LOCKWASHER 6, 8, 12, 18, 28, 30, 34, 38, 42, 44, 46, 48, 50, 56, 74, 76, 78, 80 M MASTIC - heat transfer 18 MECHANISM 52 MODEM 44	NUT - chart 54 NUT - connector 46 NUT - controller 44 NUT - filter 14 NUT - o-ring seal 14, 20, 24 NUT - receiver tank 18 NUT - speed 38 NUT - wing 74, 76, 78 NUTSTRIP 8 NUTSTRIP - bracket 10 NUT, CLIP & CORD 52 O OIL - compressor 28 O-RING 14, 16, 18, 20, 26, 30, 52 O-RING - suction 28 P	RIVET - hinge 70 RIVET - housing 8, 68 RIVET - inlet 84 RIVET - latch 48, 56, 66, 70 RIVET - mount 86 RIVET - panel 60, 62, 64 RIVET - plate 48, 56, 84 RIVET - plate 48, 56, 84 RIVET - plug 38 RIVET - port 68 RIVET - receptacle 58, 60 ROD - linkage 80 ROD - push 52 S SCREW 16, 42, 74, 78 SCREW - air vent 78 SCREW - battery 38

82, 86	т	V
SCREW - cable 46		VALVE 20, 26
SCREW - channel 84	TANK - receiver 14, 18	
SCREW - clamp 16, 18, 20, 24, 30, 72	TANK - water cooled condenser 24 , 30 T-DRAIN 86	
SCREW - coil 6, 8, 12, 14	TEE 14, 16, 18, 22, 24	VALVE - digital 16, 34 VALVE - discharge 28
SCREW - compressor 28	TEE - drain hose 88	VALVE - discharge 20 VALVE - expansion 14, 16, 20, 24
SCREW - control box 40	TERMINAL - pin 34	
SCREW - cover 8, 12, 14, 68, 72		VALVE - pressure relief 68 VALVE - solenoid 14, 20, 24, 34
SCREW - dehydrator 18	TERMINAL - stop clip 40 THERMOMETER 52	VALVE - solehold 14, 20, 24, 34 VALVE - suction 28
SCREW - dehydrator clamp 20	THERMOMETER - recording 48, 54,	VALVE - vacuum 68
SCREW - discharge valve 28	56	VENT - air 74, 80
SCREW - disk 76	THERMOSTAT - defrost termination	VEIVI - all 14, 00
SCREW - door 44, 66, 70	34	W
SCREW - flange 28	TIMER 54	WASHER 6, 8, 12, 14, 16, 44, 48, 66,
SCREW - gauge 32	TRANSDUCER - discharge 22, 26, 36	68, 70, 72, 74, 76, 78, 80
SCREW - grille 66, 70, 80, 82	TRANSDUCER - suction 22 , 26 , 36	WASHER - ground 28
SCREW - ground 28	TRANSFORMER 42 , 46	WASHER - insulating 8 , 18 , 26 , 32 , 38 ,
SCREW - guide 48, 56	TRAY - high voltage 40	44, 48, 56, 76, 84
SCREW - handle 74, 76	TRIM - edge guard 8	WASHER - insulation 66 , 70 , 76
SCREW - hanger 14	TUBE 24	WASHER - insulator 40 , 42 , 74 , 76 ,
SCREW - hinge 38, 44, 50, 56, 68, 70	TUBE - coil to dehydrator 26	80, 82
SCREW - keeper 66, 70	TUBE - coil to flange 16	WASHER - sealing 28
SCREW - linkage 80	TUBE - coil to receiver tank 14	WASHER - shoulder 80
SCREW - motor 6, 8, 12	TUBE - coil to valve 16	WASHER - vibration damper 28
SCREW - plate 48, 56, 66, 70, 74, 76,	TUBE - condenser to condenser 24, 30	•
84	TUBE - condenser to filter 30	
SCREW - plate to box 42	TUBE - condenser to tee 24	
SCREW - rail 40	TUBE - dehydrator to tee 14	
SCREW - receptacle 46	TUBE - equalizer 16, 20, 24	
SCREW - recorder 48, 56	TUBE - exchanger to coil 20, 24	
SCREW - relay board 38	TUBE - expansion valve to exchanger	
SCREW - sensor 8	20, 24	
SCREW - strap 66, 72	TUBE - expansion valve to inlet 16	
SCREW - tank 30	TUBE - expansion valve to tee 14, 16,	
SCREW - thermostat 34	22, 24	
SCREW - transformer 42 , 46	TUBE - filter 14, 18, 24	
SCREW - vent 74	TUBE - filter to tee 18	
SCREW - vent hinge 76	TUBE - flange to coil 14	
SEAL - teflon fiber 18, 24	TUBE - gauge 32	
SEALER - locking 30	TUBE - heat exchanger to evaporator	
SEALER - polyurethane 84	20	
SEALER - removable 30	TUBE - liquid injection 14, 20, 24	
SEALER - silicone grease pack 28	TUBE - receiver to condenser 18	
SEALER - thread 28, 80	TUBE - receiver to dehydrator 18	
SENSOR 62, 64	TUBE - stub 30	
SENSOR - gas 10	TUBE - suction 20, 26	
SENSOR - humidity 36 SENSOR - PT100 60, 84	TUBE - suction to ball valve 20, 26	
SHOULDER 14, 20, 24	TUBE - suction to valve 16	
SPACER 16 , 20 , 28	TUBE - tank to dehydrator 14	
SPACER - clamp 20 , 24	TUBE - tee to distributor 16, 22, 24	
SPACER - compressor 18	TUBE - tee to exchanger 14, 18, 24	
SPRING 66 , 70 , 74 , 76	TUBE - tee to valve 14 , 18 , 24	
SPRING - heater 34	TUBE - tx bulb 20	
STRAP - door 66, 72	TUBE - valve to coil 14, 18, 24	
SWITCH - hpco 28, 34	TUBE - valve to dehydrator 24, 30	
SWITCH - lpco 16, 20, 26, 34	TUBE - valve to dehydrator 24, 30	
SWITCH - On/Off 38	TUBE - valve to evaporator 16	
	TUBE - valve to expansion 14, 20, 24	

INDEX ALPHABETICAL BY DESCRIPTION