

Container Refrigeration Unit

Model 69NT40-469



SERVICE PARTS LIST CONTAINER REFRIGERATION UNIT

MODEL 69NT40-469

CONTENTS

Intr	oducti	on	i			
Ord	dering	Instructions	i			
Let	ter De	signations	i			
Мо	del Ch	nart	i			
1.	Quick	List – Clamps, Filter-drier, Fuse, Ty-raps, And Wire Terminals	1			
2.	Tools					
3.	Refriç	geration Unit Assembly	2			
	3.1	Refrigeration Unit – Front	2			
	3.2	Control Box Door	4			
	3.3	Control Box	6			
	3.4	Control Box – High Voltage Shield Removed	8			
	3.5	Condenser Fan Motor And Coil Section	10			
	3.6	Receiver And Tubing Section	12			
	3.7	Evaporator Fan Motor And Access Panel Section	14			
	3.8	Evaporator Coil Section – Rear Panels Removed	16			
	3.9	Evaporator Coil Section – Rear Panels Attached	18			
	3.10	Recording Thermometer (Partlow)	19			
	3.11	Thermostatic Expansion Valve – Alco	20			
	3.12	Suction Solenoid Valve	21			
	3.13	Suction Modulation Valve	22			
	3.14	Makeup Air Cover	23			
	3.15	Compressor Mounting And Gauges	24			
	3.16	Voltage Option	26			
	3.17	Labels and Decals	28			
4.	Compressor – Motor Assembly					
	4.1	Service Replacement Compressor	31			
	4.2	Terminal Mounting And Junction Box Group	31			
	4.3	Service Valve Group	31			
	4.4	Compressor – Motor Body Group	31			
	4.5	Pump End Group	32			
	4.6	Crankshaft, Rod And Piston Group	32			
	4.7	Valve Plate Group	32			
	4.8	Gasket Set	33			



SERVICE PARTS LIST

INTRODUCTION

This parts list identifies service replacement parts for the Carrier Transicold Container Model listed in the Model Chart below.

ORDERING INSTRUCTIONS

All orders and inquiries for parts must include: Model, Unit Serial Number, Part Number, description of part as shown on list and quantity required. Address all correspondence for parts to the following address:

> CARRIER TRANSICOLD DIVISION Replacement Component Group TR-20, P.O. Box 4805 Syracuse, New York 13221

LETTER DESIGNATIONS

The following letter designations are used to classify parts throughout this list:

A/R	As Required.	P	Suffix P added to part number means part is available in packaged quantity only. Example:
NLO	No Longer Offered.		P/N34-00373-01P10 is a package of 10 P/N 34-00373-01. Use part number and P suffix
NS	Not Shown in the illustration.		when ordering.
NSA	Non-Stock Assembly – order components listed	PL	Purchase Locally.
	under the assembly.	SST	Stainless Steel –
NSI	Non-Stock Item – may be available on special order.		300 Series unless otherwise specified.
		SV	Suffix SV – added to part number designates
NSS	Not Sold Separately – order next higher assembly or kit.		service replacement part.

MODEL CHART

MODEL	Hinged Rear Panels	Two Speed Evaporator Fan Motors	Water-Cooled Condenser	Receiver	Power Transformer	Suction & Discharge Gauges	Dual Voltage Compressor
69NT40-469-7	_	_	_	Χ	_	_	Χ

A - Provision for water-cooled condenser. If water-cooled condenser is added, refrigerant charge will change.

B – Provision for step-up power transformer.

X – Designates item provided.


PART NO. DESCRIPTION

1. QUICK LIST CL	AMPS, FILTER-DRIER, FUSE, TY-RAPS, AND WIRE TERMINALS
34-00373-51P10	Clamp, Tube, 1/4 – SST
34-00373-53P10	Clamp, Tube, 3/8 – SST
34-00373-05P10	Clamp, Tube, 1/2 – SST
34-00373-07P10	Clamp, Tube, 5/8 – SST
34-00373-59P10	Clamp, Tube, 3/4 - SST
34-00373-11P10	Clamp, Tube, 7/8 - SST
34-00373-65P10	Clamp, Tube, 1-1/8 – SST
34-00373-67P10	
	Clamp, Tube, 1-1/4 – SST
34-00373-69P10	Clamp, Tube, 1-3/8 – SST
34-00373-71P10	Clamp, Tube, 1-1/2 - SST
22-00066-01P25	Connector, Butt End, Wire Range – 22 to 16 Gauge
22-00066-02P25	Connector, Butt End, Wire Range – 16 to 14 Gauge
22-00066-03P25	Connector, Butt End, Wire Range – 12 to 10 Gauge
22-00041-00P25	Connector, Closed End, Wire Range – 22 to 14 Gauge
22-00041-02P25	Connector, Closed End, Wire Range – 18 to 10 Gauge
66U1-7472-1	Filter-Drier
HY10FJ006-P05	Fuse, Glass – 6 amp
22-00060-20P05	Fuse, Glass – 3 amp
22-01140-01P25	Ring Terminal, #6, Wire Range – 12 to 10 Gauge
22-01140-02P25	Ring Terminal, #10, Wire Range – 12 to 10 Gauge
22-01140-04P25	Ring Terminal, 3/8, Wire Range – 12 to 10 Gauge
22-00119-04P25	Ring Terminal, 1/4, Wire Range – 12 to 10 Gauge
22-00120-04P25	Ring Terminal, #10, Wire Range – 16 to 14 Gauge
22-00120-041 25 22-00120-07P25	
	Ring Terminal, 5/16, Wire Range – 16 to 14 Gauge
22-00121-07P25	Ring Terminal, #10, Wire Range – 22 to 16 Gauge
22-01139-04P25	Ring Terminal, 3/8, Wire Range – 16 to 14 Gauge
22-01141-01P25	Spade Terminal, .032 x .250, Wire Range – 16 to 14 Gauge
22-00595-01P25	Spade Terminal, 3/8, Wire Range – 12 to 10 Gauge
22-01106-00F25	Spiral Wrap, 1/4 inch Diameter x 25 ft Long
22-01107-00F25	Spiral Wrap, 1/2 inch Diameter x 25 ft Long
66U1-3803-P10	
	Tube, Heat Shrink, 1/4 ID x 2.12 inches Ig
44-01043-05P25	Ty-Raps, 5-1/2 inches Long
44-01043-07P25	Ty-Raps, 11 inches Long
22-50007 Series	Wire Markers
07-00292	SW20 Compressor Oil, Castrol Icematic (Quart)
07-00293-00	Sealant, Pipe (Used to seal fittings on unit with R-134a)
2. TOOLS	
	Town eveture Tector (Cimpson Mater)
07-00013	Temperature Tester (Simpson Meter)
07-00013-01	Temperature Test Lead (15 Foot)
07-00013-02	Temperature Test Lead (50 Foot)
07-00013-03	Adapter, Males (Both Ends) (Use with Temperature Tester)
07-00015	Case, Carrying (Used with 07-00013)
07-00219	Wrench, Compressor Sight Glass
07-00221	Inspection Light with Mirror
07-00228	Volt-Ohmmeter, Digital
07-00228	
	Amprobe Clamp (Used with 07-00228)
07-00238	Wrench, Service Valve
07-00243	Volt-Ohmmeter, Digital (Fluke)
07-00254-00	Pin Extender, Plug Connector
07-00263-00	Pliers, Crimping (Used for compressor terminal block replacement)
07-00264-00	Grip, Wire Vise (Used for compressor terminal block replacement)
07-00268-00	Crimper, Micro Contact Pins
07-00208-00	Kit, Static Dissipative (Used for working on electronic components)
07-00291-00	Ground Strap, Wrist – Disposable (Used for working on electronic components)
07-00294-00	Gauge Set, Manifold (For R-134a)
07-00295-00	Detector, Leak
07-00297-00	Extractor, Integrated Circuit (For Eprom removal)
07-00298-00	Insertion, Integrated Circuit (For Eprom installation and pin straightener)
	. 3 , 1 = = = = = = 5

1


3. REFRIGERATION UNIT ASSEMBLY

3.1 REFRIGERATION UNIT -- FRONT



ITEM	PART NO.	DESCRIPTION	QTY
3.1	REFRIGERATION UNIT	Γ FRONT	
1	_	Panel, Access & Evaporator Fan Motor – Refer to Section 3.7	_
2	_	Labels and Decals – Refer to Section 3.17	_
3	_	Valve, Thermostatic Expansion (Location) – Refer to Section 3.11	_
4	_	Box, Control – Refer to Sections 3.2 thru 3.4	_
5	_	Coil, Condenser – Refer to Section 3.5	_
6	_	Receiver and Tubing – Refer to Section 3.6	_
7	_	Compressor – Refer to Sections 3.15 & 4	_
8	_	Cables, Power – Refer to Section 3.16	_
9	_	Guard, Compressor – Refer to Section 3.15	_
10	_	Cover, Makeup Air – Refer to Section 3.14	_
11	_	Thermometer, Recording – Refer to Section 3.10	_
12	_	Condenser Fan Motor & Fan – Refer to Section 3.5	_


3.2 CONTROL BOX DOOR



HINGE -- SECTIONAL VIEW


ITE	M PART NO.	DESCRIPTION	QTY
3.2	CONTROL BOX DOOR		
1	66U1-6811-10	Screw, Retaining	2
2	34-01226-00	Washer, Retaining	2
3	34-06053-02	Washer, Mylar, 3/8 ID x 1.00 OD	2
4	69NT40-818-21	Door Assembly – Includes:	1
NS	42-01083-00	Gasket	1
5	58-01180-01F50	Seal Rubber (50 ft, Cut to length)	A/R
6	69NT35-4574	Panel, Switch	1
7	69NT35-3413	Label, CB1, CB2	1
8	69NT35-4013	Label, Switch, (RM, MD, ST)	1
9	69NT35-4002	Label, Controlled Air Temperature (NSI)	1
10	69NT35-3164	Label, Warning	1
11	44-01116-00	Hinge	2
12		Protector, Mylar	2
13	66U1-2403	Screw, Machine, #10-24 x 1/2 lg - SST (NSI)	4
14		Plate, Nut	2
15	58-04101-00	Protector, Mylar	2
16		Washer, Mylar, 1/4 ID x 5/8 OD	4
17		Washer, Flat, #10 - SST (NSI)	4
18		Washer, Lock, #10 - SST (NSI)	4
19		Receptacle, Remote Monitoring (Plastic) – Optional	1
NS		Plug, Remote Monitoring – Optional	1
20		Gasket, Receptacle	1
21	22-02341-01	Cap and Chain (RM)	1
22		Screw, Round Head, #4-40 x 5/8 lg - SST (NSI)	4
23		Locknut, #4-40 - SST (NSI)	4
24		Switch, Toggle (MDS)	1
25		Seal, Bushing	2
NS		Adapter Strip	1
26		Switch, Toggle (On – Off)	1
27		Label, Status Indicator (NSI)	1
28		Indicator, Status (4 Light Bar)	1
29	69NT35-5524	Label, Operating Instruction	1

3.3 CONTROL BOX




ITEI	M PART NO.	DESCRIPTION	QTY
3.3	CONTROL BOX		
1 NS	69NT40-427 NSS	Switch Assembly (TDS & TSS) – Includes: Connector	1
2	10-01142-03	Switch, Push Button (TDS)	1
3	10-01146-01	Switch, Toggle (TSS)	1
4	69NT35-8453	Label, Switch (TSS,SDS,TDS,DIS) (NSI)	1
5	69NT40-437-1	Switch Assembly, Rotary (DIS) – Includes:	1
6	10-01132-01	Switch, Rotary	1
7	66U1-9522	Knob	1
8	69NT35-297-3	Shield, High Voltage – Includes:	1
9	66U1-3442-2	Stud, 1/4 Turn	2
10	66U1-9212-1	Retainer	2
11	69NT20-373-142	Plate Assembly, Schematic & Diagram (NSI)	1
12	66CH1-1022-4	Label, Danger – High Voltage	1
13	34-01142-01	Receptacle	2
14	66U1-6832-4	Rivet, Blind, 1/8 Diameter, Grip Range – 1/32 - 1/8 – SST (NSI)	4
15	22-01324	Fuse Block	1
16	HY10FJ006	Fuse, 6 amp	2 2
17	66U1-6651-19	Screw, Pan Head, #6-32 x 7/16 lg — SST (NSI)	2 1
18	69NT35-4172	Label, Danger – High Voltage (NSI)	1
19 20	22-02249 AT39JA101	Temperature Selector (_F/_C) Nut, Hex, #8-32 - SST (NSI)	1 1
21	66U1-5331-4	Washer, Lock, #8 – SST (NSI)	4 8
22	66U1-6651-7	Screw, Pan Head, #8-32 x 3/8 lg - SST (NSI)	8
NS	69NT40-417-3	Switch Assembly (For use with digital display) – Optional – Includes:	1
23	10-01133-02	Switch, Scale Selector (SSS)	1
24	10-01135-02	Switch, Set Temperature Display (SDS)	1
NS	22-02306-01	Plug	1
NS	22-02305-01	Contact, Socket	1
25	22-02352-00	Block, Terminal	1

3.4 CONTROL BOX -- HIGH VOLTAGE SHIELD REMOVED



ITEM	PART NO.	DESCRIPTION	QTY
3.4 C	ONTROL BOX HIG	H VOLTAGE SHIELD REMOVED	
1 1 2 2 3 3 4 5 6 7 8 9 10	12-01059-10 12-01059-30 12-01058-10 12-01058-30 12-01085-00 12-01085-20 22-00060-20 — 69NT35-6952 69NT35-1447 10-00304-32 66U1-2403 AU27JR131 66U1-9222	Board, Power Supply and IRS Board, Power Supply and IRS – Remanufactured Board, Timing and Current Control Board, Timing and Current Control – Remanufactured Board, Temperature Control – Remanufactured Board, Temperature Control – Remanufactured Fuse, 3 amp Indicator, Status – Refer to Section 3.2 Angle, Status Indicator (NSI) Shield, Status Indicator (NSI) Contactor, Condenser/Evaporator Fan Motor and Heater (CF, EF & HR) Screw, Hex Head, #10-24 x 1/2 lg – SST (NSI) Washer, Lock, #10 – SST (NSI) Receptates	16 16 2
12 13 14 NS 15 16 17 18 19 20 21 22 23 24 25 26 27 27	10-00304-33 10-00331-00 10-00331-21 NSS 10-00277-00 66U1-6651-20 AU27JR081 66U1-1723-3 66U1-6651-19 AC39QA163 66U1-2353 10-01161-00 58-00950-00 66U1-5331-4 66U1-6651-22 AT39JA171 12-01073-00SV 12-01073-20	Contactor, Compressor (C) Voltage Switch Knob – Includes: Screw, Handle Circuit Breaker – 230 vac, 50 amp (CB2) Screw, Pan Head, #6-32 x 5/16 lg – SST Washer, Lock, #6 – SST Circuit Breaker – 460 vac (CB2) Screw, Pan Head, #6-32 x 7/16 lg – SST (NSI) Screw, Binding Head, 1/4-20 x 5/16 lg – Brass (For Terminals) (NSI) Transformer, Control (TR) Transformer, Current Limiting (CLT) – Optional Cover, Plastic - Transformer Mounting (For use with CLT) Washer, Lock, #8 – SST (NSI) Screw, Pan Head, #8-32 x 3/4 lg – SST (NSI) Locknut, Hex Head, 1/4-20 – SST (NSI) Display, Digital – Optional Display, Digital – Remanufactured	1 1 1 1 4 4 1 4 6 1 1 A/R A/R 1 1
28 29 30 31 32 33 34 NS NS	69NT40-447-1 22-02306-00 58-01181-02 58-01181-03 10-00220-02 22-02269-11 66U1-9592-3 07-50001 07-50003-01	Plug, Harness (For Digital Display) – Includes: Plug (6 position) Standoff (For use with digital display) Standoff (For use with digital display) Relay Board, Main Printed Circuit Standoff Humiseal, 12 oz. Lubricant, Contact	1 1 4 4 4 1 10 A/R A/R


3.5 CONDENSER FAN MOTOR AND COIL SECTION



3.5 CONDENSER FAN MOTOR AND COIL SECTION


1	69NT43-148	Cover, Condenser Coil	1
2	66U1-2403	Screw, Hex Head, #10-24 x 1/2 lg - SST (NSI)	A/R
3	66U1-5321-8	Washer, Flat, #10 - SST (NSI)	A/R
4	69NT35-2692	Washer, Fender, .063 Thick - SST (NSI)	A/R
5	66U1-5331-3	Washer, Lock, #10 - SST (NSI)	A/R
6	69NT42-108-SV	Coil, Condenser – Copper (Includes Mylar washers and protectors)	1
7	66U1-5361-25	Capscrew, Hex Head, 1/4-20 x 3/4 lg - SST (NSI)	11
8	66U1-5321-7	Washer, Flat, 1/4 – SST	11
9	58-50013-02	Washer, Mylar, 1/4 ID x 3/4 OD	A/R
10	58-50013-04	Washer, Mylar, 1/4 ID x 1.00 OD	A/R
NS	34-06053-05	Washer, Mylar, 13/64 ID x 39/64 OD	A/R
NS	58-04026-00	Protector, Mylar (Apply between coil mounting & frame RH side)	1
NS	58-04026-03	Protector, Mylar (Apply to top side center coil mounting)	1
NS	58-04026-04	Protector, Mylar (Apply between coil mounting & frame, RH & LH side	es) 2 2 2 1
NS	58-04026-06	Protector, Mylar (Apply to center between frame & coil & coil cover)	2
NS	58-04026-08	Protector, Mylar (Apply to top side of coil bracket, RH & LH sides)	2
NS	58-04026-09	Protector, Mylar (Apply under coil center bracket attached to frame)	1
NS	58-04026-10	Protector, Mylar (Apply between coil & coil cover, RH & LH sides)	2 1
NS	58-04026-11	Protector, Mylar (Apply between coil mounting & frame LH side)	
11	69NT40-847-2	Grille, Condenser – Includes:	1
12	34-01150-04	Stud (1/4 Turn)	2
13	34-01150-30	Washer, Retaining	2 2 2 2 1
14	34-01150-31	Receptacle	2
15	69NT35-1482	Hinge, Condenser Fan Grille	2
16	69NT40-837-1	Venturi, Condenser Fan	
NS	66U1-6832-1	Rivet, Blind, 5/32 Diameter, Grip Range – 1/8-1/4 – SST (NSI)	A/R
17	38-00142-01	Fan, Condenser – SST – Includes:	1
18	PL	Set Screw, Square Head, 5/16-24 x 5/8 lg - SST	2
19	54-00516-00SV	Motor, Condenser Fan – Includes:	1
NS	04-50020-00	Bearing	2 1
NS	02-50088-00	Capacitor	
20	PL	Key, 3/16 Square x 1-3/8 lg – SST	1
21	66U1-5361	Screw, Hex Head/Washer, 5/16-18 x 1.25 - SST	4
22	34-01181-01	Washer, Flat, 5/16 – SST (NSI)	8
23	58-50013-00	Washer, Mylar	
24	34-00667-12	Locknut, 5/16-18 – SST (NSI)	4
25	69NT35-6112	Protector, Condenser Fan Motor Mounting	2

3.6 RECEIVER AND TUBING SECTION




ITE	M PART NO.	DESCRIPTION	QTY
3.6	RECEIVER AND TUBI	NG SECTION	
1	66U1-8552	Valve, Liquid Line – Includes:	1
2	40-00086-04	Cap, Flare - 1/4	1
3	17-21002-01	Cap, Valve	1
4	40-00519-01	Elbow, Swivel, 90_ 1/4 Flare x M15 - Brass	1
5	40-00520-01	Coupling, M15 – Brass – Includes:	1
6	40-00520-03	Cap, Service Port	1
7	14-00202-00	Indicator, Moisture – Liquid (Brass)	1
8	66U1-7472-1	Filter-Drier	1
9	69NP20-1031	Clamp, Filter-Drier – Includes:	1
NS	58-50014-00F16	Gasket, Clamp (16 FT, cut to length)	A/R
10	66U1-5361-25	Screw, Hex Head, 1/4-20 x 3/4 lg - SST (NSI)	2
11	34-06053-03	Washer, Mylar, 1/4 ID x 1.00 OD	2
12	14-00195-03	Valve, High Side Pressure Relief	1
13	66U1-5321-7	Washer, Flat, 1/4 – SST	A/R
14	58-04026-05	Protector	1
15	58-00956-00	Protector, Mylar	2
16	69NT40-937	Receiver (Optional) - Painted Steel - Includes:	1
16	69NT40-977-1	Receiver (Optional) - SST - Includes:	1
NS	14-00111	Glass, Sight	2
17	12-01072-01SV	Sensor, Supply Temperature (STS)	1
18	14-00204-00	Valve, Pressure Regulator	1
19	_	Valve, Modulating Solenoid – Refer to Section 3.11	_
20	_	Valve, Suction Solenoid – Refer to Section 3.12	_
21	14-00189-01	Valve, Quench, Thermostatic Expansion	1

3.7 EVAPORATOR FAN MOTOR AND ACCESS PANEL SECTION



ITEN	M PART NO.	DESCRIPTION	QTY
3.7	EVAPORATOR FAN M	NOTOR AND ACCESS PANEL SECTION	
1	69NT40-908-1	Panel, Access – Includes:	2
2	42-01082	Gasket	1
2	66U1-8115-F20	Gasket, Access Panel Seal – Adhesive Back, Pressure Sensitive,	
		4 x 1/2 thick (20 ft, Cut to size)	A/R
4	AA06JA170	Capscrew, Hex Head, 1/4-20 x 1.00 lg - SST	24
5	AN96OC416	Washer, Flat, 1/4 – SST	24
6	58-50013-03	Washer, Mylar, 1/4 ID X 1/2 OD	24
7	69NT40-898-1	Panel, Access – Includes:	1
8	42-01081	Gasket	1
9	69NT35-1173	Bracket, Motor Mount	2
10	66U1-5361	Capscrew, Hex Head, 5/16-18 x 1-1/4 lg - SST (NSI)	4
11	34-01181-01	Washer, Flat, 5/16 – SST (NSI)	8
12	34-00667-12	Locknut, 5/16-18 - SST (NSI)	4
13	54-00507-00	Motor, Evaporator Fan – Includes:	2
NS	04-50021-00	Bearing	2
NS	22-50087-00	Capacitor	1
14	PL	Key, 3/16 x 3/16 x 1-3/8 lg - SST	2
15	38-00126	Fan, Evaporator (EFM-1) – Includes:	1
15	38-00125	Fan, Evaporator (EFM-2) – Includes:	1
NS	PL	Setscrews, 5/16-24 x 5/8 lg - SST	2
16	66U1-5361-7	Bolt, Hex Head, 3/8-16 x 1.00 lg - SST (NSI)	8
17	66U1-5321-5	Washer, Flat, 3/8 – SST (NSI)	8
18	AU11JR241	Washer, Lock, 3/8 - SST	8


3.8 EVAPORATOR COIL SECTION -- REAR PANELS REMOVED



ITEN	/I PART NO.	DESCRIPTION	QTY
3.8	EVAPORATOR COIL S	SECTION REAR PANELS REMOVED	
1	69NT20-553	Shield Assembly, Rain – Humidistat (NSI) – Optional	1
2	12-01066	Humidistat (HCS) – Optional	1
3	12-01072-01SV	Sensor, Thermistor (RTS)	1
4	_	Sensor, Thermistor – Temp. Recorder (Refer to Section 3.10)	_
5	12-01063	Thermostat, Suction Solenoid	1
6	66U1-6912-8	Thermostat, Defrost Termination, 75_F (24_C) (DTT)	1
7	34-01178-22	Capscrew, Hex Head, #8-32 x 1/2 lg - SST (NSI)	4
8	66U1-5331-4	Washer, Lock, #8 - SST (NSI)	4
9	66U1-6912-7	Thermostat, Heat Termination, 130_F (54_C) (HTT)	1
10	AA06JA166	Capscrew, Hex Head, 1/4-20 x 1/2 lg - SST (NSI)	1
11	34-00667-11	Washer, Lock, 1/4 - SST (NSI)	9
*12	69NT42-968-1	Coil, Evaporator	1
NS	69NT35-6522	Retainer	1
13	66U1-5361-25	Screw, Hex Head, 1/4-20 x 3/4 lg - SST (NSI)	9
14	66U1-5321-7	Washer, Flat, 1/4 – SST	6
15	66U1-7452-3	Screw, Lag, Hex Head, 1/4-10 x 2.00 lg - SST	6
16	24-00003	Heater, Drain Pan (DPH)	1
17	66U1-2683-4	Heaters, Evaporator Coil	4
NS	69NT35-6532	Clip, Heater	4
18	65-00144-00	Exchanger, Heat	1
19	34-00655-10	Capscrew, Hex Head, 1/4-20 x 1-1/4 lg - SST (NSI)	4
20	69NT35-2692-1	Washer, Fender, 1/4 x 1/16 thick - SST (NSI)	4
21	58-00616-00	Plug, Hole, Nylon – Black (For 2.00 Dia. hole located on fan deck)	A/R


^{*} Note: Does not include thermostats or heaters.

3.9 EVAPORATOR COIL SECTION -- REAR PANELS ATTACHED




1	69NT40-614	Grille, Top	1
2	66U1-6832-1	Rivet, Blind, 5/16 Diameter, Grip Range – 1/8-1/4 (NSI)	A/R
3	69NT40-624-4	Panel Assembly, Upper – Includes:	1
NS	NSS	Drain Pan, Side	2
NS	NSS	Drain Pan, Center	1
4	66U1-6832-6	Rivet, Blind, 1/4 Diameter, Grip Range – 1/8-3/16 (NSI)	A/R
5	66U1-6832-3	Rivet, Blind, 1/4 Diameter, Grip Range – 3/16-1/4 (NSI)	A/R
6	69NT35-9744-3	Panel, Bottom	1
7	69NT35-9744-2	Panel, Bottom, Left-hand Side	1
8	66U1-2403	Screw, Machine, Truss Head, #10-24 x 1/2 lg - SST (NSI)	19
9	69NT35-2692	Washer, Fender, #10 x 1.00 OD - SST (NSI)	19
NS	66U1-8075-F25	Gasket (25 ft, Cut to length)	A/R

3.10 RECORDING THERMOMETER (PARTLOW)




_	12-01076-00	Recording Thermometer – Includes:	_
1	09-00265-00	Cover Assembly (Bottom Latch) - Includes:	1
NS	09-00100-01	Seal, Cover - Rubber	1
NS	09-00100-02	Gasket, Cover Glass	1
2	09-00101	Glass, Cover	1
NS	09-00102	Catch Assembly, Cover	2
3	09-00104-05	Stylus Kit – Includes:	1
4	NSS	Screw, Round Head, #2-56 x 3/16 lg	2
5	09-00147	Mechanism Assembly	1
6	09-00112	Push Rod (Includes Šetscrews)	1
7	09-00115	Clip, Key Mounting	1
8	09-00114	Key, Clock Winding	1
9	09-00119	Nut and Chain, Chart (Sonceboz Clock)	1
9	09-00180-00	Nut and Chain, Chart (Gluck Clock)	1
10	PL	Screw, Round Head #6-32 x 5/16	7
11	09-00116	Platen, Chart	1
12	09-00118	Flange, Chart Drive (Sonceboz)	1
12	09-00180-01	Flange, Chart Drive (Gluck)	1
13	09-00123	Clock, 31 Day, CCW (Counterclockwise)	1
14	09-00132	Stand, Mounting, Chart Drive	1
15	09-00267-00	Case (Top Hinge)	1
16	09-00137	O-Ring, Element Flange	4
17	09-00209	Element, 9 ft lg – Includes:	1
NS	09-00222	Sensor, Thermistor (Accessory 344 and Jack) – 15 ft lg	1
NS	22-02243	Pin (Use with Partlow Thermister Assembly)	3
18	09-00136	Screw, Flange (NSI)	2
NS	09-00128	Charts _F - 31 Day (Box of 50) (-20_F to +80_F)	A/R
NS	09-00128-01	Charts _C - 31 Day (Box of 50) (-25_C to +25_C)	A/R

3.11 THERMOSTATIC EXPANSION VALVE -- Alco



1	14-01104-12	Kit, Repair – Includes:	1
2	NSS	Power Head Assembly and Gasket, Item 5	1
3	NSS	Cage Assembly and Gasket, Item 6	1
4	66U1-6225	Gasket Set, Universal – Includes:	1
5	NSS	Gasket, Body Flange A625-4A	2
6	NSS	Gasket, Seat – A625-2A	1
7	66U1-1214-13	Flange, Body (NSI)	1
NS	40-00529-00	Coupling, M8 – Brass – Includes:	1
NS	40-00520-02	Cap, Service Port	1


3.12 SUCTION SOLENOID VALVE



ALCO

1	14-00192-00	Solenoid Valve, Suction – Includes:	1
2	17-40408-02	Cap, Snap	1
3	14-50027-00	Coil	1
4	14-50025-00	Kit, Repair	1
5	14-50026-00	Kit, Repair Diaphragm	1


3.13 SUCTION MODULATION VALVE



1	14-50021-01	Kit, Enclosing Tube & Coil Housing – Includes:	1
2	14-50021-03	Nut, Coil – Includes:	1
3	NSS	Nut, Coil	1
4	NSS	O-Ring, Coil Nut	1
5	14-50021-04	Housing, Čoil – Includes:	1
6	NSS	Housing, Coil	1
*7	NSS	Plate, Coil Bottom	1
8	NSS	O-Ring, Coil Bottom Plate	1
9	NSS	Sleeve, Solenoid Coil	1
10	NSS	Tube Assembly, Coil Plate & Enclosing	1
11	14-01100-01	Valve, Suction Modulaton – Includes:	1
12	14-50021-02	Coil, Solenoid – Includes:	1
9	NSS	Sleeve, Solenoid Coil	1

* NOTE: Item 7, Coil Bottom Plate is only supplied in Kit 14-50021-04 as a separate item for use on early style Enclosing Tube Assemblies.


3.14 MAKEUP AIR COVER



69NT40-976


1	69NT40-976	Cover, Makeup Air – Includes:	1
2	66U1-5321-7	Washer, Flat, 1/4 - SST	1
3	34-06092-00	Nut, Hex, 1/4-20 UNC-2B - SST (NSI)	1
4	69NT35-2322-5	Gasket, Cover (NSI)	1
5	69NT35-2322-10	Gasket, Cover (NSI)	1

3.15 COMPRESSOR MOUNTING AND GAUGES



COMPRESSOR FOOT CUTAWAY VIEW

CENTER CYLINDER HEAD VIEW




UNIT SECTIONAL VIEW

3.15 COMPRESSOR MOUNTING AND GAUGES


1	_	Compressor – Refer to Section 4	_
2	14-01093-00	Snubber Assembly	1
3	66U1-6942-6	Switch, High Pressure	1
4	69NT41-543	Tube Assembly, High Pressure)	1
5	69NT41-303-2	Tube Assembly, Low Pressure \ Used with pressure gauges	1
6	69NT40-942	Stiffener Assembly	1
NS	66U1-5381-1	Screw, Hex Head, #10-24 x 3/4 lg - SST \ Used to mount	2
NS	66U1-5321-8	Washer, Flat, #10 – SST (NSI) stiffener assembly	2
7	69NT40-912	Bracket Assembly, Gauge – Optional	1
8	12-01124-01	Gauge, Suction Pressure – Optional	1
9	12-01125-01	Gauge, Discharge Pressure – Optional	1
10	CA21JA051	Tee, 1/4 NPT (NŠI)	1
11	06DA403-844	Valve Assembly, Core, Check – Brass Used with pressure gauges	2
12	14-00195-02	Valve, Low Side Pressure Relief	1
NS	_	Valve, High Side Pressure Relief – Refer to Section 3.6	_
13	40-00249-01	Tee, Male, 1/4 fpt x 1/4 fpt x 1/4 mpt - Brass (NSI)	1
14	69NT35-6132	Protector (Compressor to Compressor Base)	1
15	AU11JR241	Washer, Lock, 3/8 - SST	2
16	AA06JA232	Capscrew, Hex Head, 3/8-16 x 1-1/4 lg - SST (NSI)	2 2 2
17	34-00829-13	Washer, Flat, 3/8 – SST	2
18	58-50013-00	Washer, Mylar, 3/8 ID x 1.00 OD	2
19	69NT43-108	Base, Compressor	1
NS	66U1-5361-7	Bolt, Hex Head, 3/8-16 x 1.00 lg – SST (NSI) Used to mount	7
NS	66U1-5321-5	Washer, Flat, 3/8 – SST (NSI) compressor base	7
NS	AU11JR241	wasner, Lock, 3/8 – 551 to unit frame	7
NS	58-50013-00	Washer, Mylar, 3/8 ID x 1.00 OD /	7
20	66U1-5361-3	Capscrew, 7/16-14 x 2-3/4 lg - SST (NSI)	2 2 4
21	34-00667-14	Locknut, 7/16-14 – SST (NSI)	2
22	66U1-5321	Washer, Flat, 7/16 - SST	
23	58-50013-01	Washer, Mylar, 1/2 ID x 1-1/8 OD	2
24	69NT35-3573	Panel, Guard (NSI)	1
25	66U1-5371-14	Screw, Hex Head, 1/4-20 x 3/4 lg - SST (NSI)	1
26	58-50013-02	Washer, Mylar, 3/8 ID x 1-1/4 OD	A/R
27	66U1-5321-7	Washer, Flat, 1/4 – SST	A/R
28	66U1-5361-11	Capscrew, Hex Head, 1/4-20 x 1-1/2 lg - SST (NSI)	A/R
29	34-00667-11	Locknut, Hex Head, 1/4-20 – SST (NSI)	A/R
30	69NT35-3104-1	Guard, Compressor	1
NS	07-00292-00	Oil, Compressor (Quart)	A/R

3.16 VOLTAGE OPTION




ITEN	M PART NO.	DESCRIPTION	QTY
3.16	VOLTAGE OPTION		
1	58-01214-00	Plug, Hole, Dupont Zytel – Black (For 3/8 to 13/32 diameter hole)	A/R
2	58-01213-00	Plug, Hole, Nylon – Black (For 1/4 diameter hole in doghouse wall)	A/R
3	69NT35-3253-SV	Cover, Voltage Selector Switch – Includes:	1
4	66U1-2803	Hinge (Čut to length)	1
5	66U1-9102-2	Rivet, Hollow, 3/32 Diameter, Grip Range - 5/16 - 3/8 - SST	3
6	66U1-5381-1	Screw, Hex Head, Thread Cutting, #10-24 x 3/4 lg - SST	2
7	58-50013-04	Washer, Mylar, 0.25 ID x 1.00 OD	2
8	34-00373-11	Clamp, Cushioned, Tube, 7/8 OD	1
9	34-00373-59	Clamp, Cushioned, Tube, 3/4 OD	1
10	66U1-9782-1	Cable, Power (460 vac, Extra Heavy Duty Black) (NSI)	1
11	22-02378-00	Plug, Power (460 vac) MENNEKES	1
NS	22-02324-01	Bushing (for P/N 22-02378-00) (NSI)	4

3.17 LABELS AND DECALS




ITE	M PART NO.	DESCRIPTION	QTY
3.17	LABELS AND DECALS		
1	62-02531-00	Decal, Carrier Transicold	1
2	66U1-8912	Label, Direction Arrow	1
3	-	Label, Fan Warning – Refer to Section 3.2	_
4	-	Label, Operating Instruction (NSI) – Refer to Section 3.2	_
5	69NT35-8143	Label, Voltage Selector (VS) (NSI)	1
6	_	Label, CB1, CB2 – Refer to Section 3.2	-
7	62-02444-01	Label, Charge with R-134a Only (NSI)	1
8	62-02458-00	Label, POE Compressor Oil	1
9	62-02530-00	Label, R-134a – Ozone Protection (NSI)	1
10	66CH1-1002-33	Label, Arrow (NSI)	1
11	69NT35-5323	Label, Air Exchange (NSI)	1
NS	_	Plate Assembly, Schematic & Diagram – Refer to Section 3.3	_



ITEM	PART NO.	DESCRIPTION	QTY
4.1 S	ERVICE REPLACEME 18-00048-21SV	Compressor, 41 CFM, 230/460 vac/3 ph/60 hz	1
valve		NOTE Motor – Compressor is sold without terminal box and cover, and without s ds). Customer should retain the original terminal box and valves for	
4.2 TI	ERMINAL MOUNTING	S AND JUNCTION BOX GROUP	
2 3 4 5 5 2 6 7 8 NS NS	69NT20-2083 66U1-2403 66U1-5331-3 69NT20-513-SV 69NT20-513-1SV 69NT20-2083 AD61JA124 17-40093-02 17-40093-01 76-00355 76-00384 17-40075-05 34-06053-05	Cover, Junction Box Screw, Hex Head, #10-24 x 1/2 lg (cover to box) Washer, Lock, #10 (cover to box) (NSI) Box, Junction (Located on Front of Compressor) – Includes: Box, Junction (Located on Back of Compressor) – Includes: Cover, Junction Box Screw, Pan Head, #10-32 x 3/8 lg (box to compressor) (NSI) Terminal, Compressor (5 Terminals) Terminal, Compressor (6 Terminals) Kit, Compressor Terminal Wiring Kit, Compressor Terminal Wiring (Dual Voltage or Dual/Single Voltage Gasket, Terminal Plate Washer, Mylar	1 2 2 1 1 1 2 1 1 1 1 1 1 1 1 1 1
4.3 S	ERVICE VALVE GROU	*	
11 12 13 14 15 NS 16 17 18 NS 19 20 21 22 23 24	40-00524-00 40-00520-00 40-00520-02 14-01042-03 17-10812-00 17-10811-05 14-01042-04 17-10812-00 17-10806-02 17-10811-05 66U1-5361-46 17-40013 40-00520-01 40-00520-03	Elbow, 1/4 NPTF x M13 – Brass Coupling, M13 – Brass – Includes: Cap, Service Port Valve, Suction Shut-Off, 1-1/8 ODS – Includes: Cap, Seal Gasket, Seal Cap Gasket, Suction Service Valve Valve, Discharge Shut-Off, 7/8 ODS – Includes: Cap, Seal Gasket, Seal Cap Gasket, Seal Cap Gasket, Discharge Service Valve Bolt, Hex Head, 5/16-18 x 1-7/8 lg – SST (NSI) Gasket, Bolt, 5/16 Elbow, 1/8 NPTF x M15 – Brass Coupling, M15 – Brass – Includes: Cap, Service Port	1 1 1 1 1 1 1 1 1 2 2 1 1
	OMPRESSOR MOT		
NS 29 30 31 32 33 34 35 36 37 38 39 40 41 42	- 17-21040 17-40016-01 17-40018 17-55001 17-40034-05 17-40020-01 17-40021 17-44011 17-10218 17-10218-02 17-20004 17-40029-05 34-00306-10	Gasket Set (Refer to Section 4.8) Head, Cylinder – Side Bank (Shaved Head) Head, Cylinder – Center Bank Screw, Hex Head – Center Head, 3/8-16 x 3.00 lg – SAE Grade 5 Gasket, Cylinder Head (Side Bank) Screw, Hex Head, 3/8-16 x 2.00 lg – SAE Grade 5 Screw, Hex Head, 3/8-16 x 1.00 lg – SAE Grade 5 Screen Assembly, Oil Filter Tube, Oil Suction Valve, Oil Relief Sight Glass Package, Oil Level – Includes: Gasket, Sight Glass Cover, Motor End (NSI) Gasket, Motor End Cover Screw, Hex Head, 7/16-14 x 1-1/4 lg – SAE Grade 5 (NSI)	2 1 8 2 12 4 1 1 1 1 1 1 1

ITEM	PART NO.	DESCRIPTION	QTY
4.4	COMPRESSOR MOT	OR BODY GROUP (CONTINUED)	
43 44 45 46 47 48 49 50 51	17-40032 17-40033-05 17-40034-05 17-20005 PL 17-40042 17-21063-00 PL 17-55006	Plate, Bottom Gasket, Bottom Plate Screw, Hex Head, 3/8-16 x 2.00 lg - SAE Grade 5 Strainer Assembly, Suction (NSI) Plug, Pipe, Oil Fill, 1/4 Check Valve Assembly, Oil Return Plate, Screen Hold Down Pipe Plug (High & Low Pressure Connection and Oil Drain), 1/4-18 NPT Gasket, Cylinder Head (Center)	1 2 22 1 1 1 1 3 1
	PUMP END GROUP		
60 61 62 63 64	17-40037-05 17-40019 17-21070-00 17-55009-01 17-40078-05	Screw, Hex Head, Bearing Head, 3/8-16 x 1.00 lg — SAE Grade 5 Gasket, Capscrew, 3/8 Bearing Head & Gear Oil Pump Package Washer, Thrust Gasket, Cover Plate	8 8 1 1 1
4.6	CRANKSHAFT, ROD AI	ND PISTON GROUP	
70 71 72 73 74 75 76 77 78 79 80 81 82 82 NS 83	N/A 17-40059 17-40048 34-01110 17-10831 17-40046 17-40044 17-44115-01 17-44115-20 NSS 17-40052-00 17-40053 17-40055 17-40056 17-55023 17-40057 17-55008	Crankshaft Washer, Thrust Pin, Spiral, 5/32 Diameter x 5/8 lg Key, Rotor Drive Washer, Rotor (NSI) Washer, Star, Rotor, 5/8 (NSI) Tube Assembly, Equalizer (NSI) Piston & Pin Pkg (Standard) – Includes: Piston & Pin Pkg (+0.020) – Includes: Piston Pin, Piston Retainer, Piston Pin Ring, Compression (For Standard & +0.020 inch Piston) Connecting Rod and Cap Assembly (Standard) – Includes: Connecting Rod and Cap Assembly (+0.010) – Includes: Pin, Dowel Capscrew – Special (Epoxy Coated)	1 1 2 1 1 1 6 A/R 1 1 2 12 6 6 2 2
4.7 90 NS 91 92 93 94 95 96 97 32 51 98 99	NSS NSS 17-44112-01 NSS NSS 17-40086 17-40087 17-44113-00 17-10715 17-44111-00 17-40083 17-55001 17-55006 17-55002 17-40057	Package, Valve Plate Assembly (Center and Side Banks Canted) - Includes: Plate Assembly, Valve - Includes: Plate, Valve Valve, Discharge Valve, Stop Discharge Screw, Hex Head, 1/4-28 x 3/8 lg Washer, Lock, 1/4 Valve, Suction Spring, Suction Valve Positioning Gasket, Cylinder Head (Side Bank) Gasket, Cylinder Head (Center) Gasket, Valve Plate Pin, Dowel (Valve Plate)	3 1 1 2 2 4 4 2 2 1 1 1 12

4.8 GASKET SET



*_	17-55020-20	Gasket Set – Includes:	1
1	17-40005-05	Gasket, Suction Service Valve (4 Bolt)	1
2	17-44004-05	Gasket, Shaft Seal (05G)	1
3	17-44007-06	Gasket, Valve Plate (05G)	3
4	17-44001-06	Gasket, End Flange (05G) – Includes:	1
5	17-44014	Gasket, Flange Spacer (05G)	2
6	17-55001	Gasket, Cylinder Head – Right and Left (Standard)	2
7	17-55002	Gasket, Valve Plate	3
8	17-55006	Gasket, Cylinder Head – Center	1
9	17-55005	Gasket, Cylinder Head – Right and Left (Hot Gas Bypass Unloader)	2
10	17-40316	Gasket, Oil Supply Tube (O-Ring, 05D)	1
11	17-10218-02	Gasket, Sight Glass	2
12	17-40104-07	Gasket, Unloader Body	2
13	17-40075-05	Gasket, Oil Pump Cover	1
14	17-10811-05	Gasket, Service Valve (2 Bolt)	2
*15	17-40033-05	Gasket, Bottom Plate	1
16	17-40078-05	Gasket, Pump End Bearing Head	1
17	17-40319-05	Shaft Seal (05D)	1
18	17-40029-05	Gasket, Motor End Cover	1
19	17-21042-00	Gasket, Cylinder Head (Suction Cutoff Unloader)	2

* NOTE: When ordering a Gasket Set (P/N 17-55020-20) be aware that it includes one (1) of item15 and for a Container Unit the quantity required is two (2).