

Mobility Axiom — Mabilis na Gabay

Kailangan sa PC na ito

Item	Kailangan?	Tala
Windows 10/11 (64-bit)	Oo	Admin rights para sa Docker
Node.js	Hindi	Kasama na sa pack (<code>Mobility-Axiom\tools\node\</code>)
Docker Desktop	Oo (VC)	I-download
Internet	Unang install	Docker image para sa Video Conference

I-install (isang beses)

1. **I-unzip** ang buong delivery folder (hal. `C:\Mobility-Trial\`).
2. I-install ang **Docker Desktop** mula sa link sa itaas. Patakbuhin — hintayin ang whale icon.
3. I-double-click ang `Install-Mobility.bat` (root ng pack).
4. Sa bawat paggamit, i-double-click ang `** Start Mobility.bat**` .

Huwag patakbuhin ang `npm install` — naka-bundle na ang dependencies.

Unang login

Field	Value
URL	<code>http://:3888</code>
Username	<code>global</code>
Password	<code>global123</code>

BWC online (maikli)

1. **Settings** → **Server Config** → **Network** — set server IPv4 → **Save server settings**.
2. **Settings** → **Server Config** → **BWCs** — add Device ID + officer name → **Save BWC list**.
3. On each BWC SIP screen — enter values from **Type on BWC** (IPv4 only).
4. Wait ~30s — device shows **Online** in fleet list.

Video Conference (telepono)

1. Install **MobilityConference-1.5.6.apk** on Android.
2. Server URL = same as dashboard (<http://:3888>).
3. Sign in → open room → Join with camera.

Trial license

5 BWC · 10 dashboard users · 1 year.

Full steps: **Configuration Manual** in this folder.