

Mobility Axiom — Panduan Singkat

Yang dibutuhkan di PC ini

Item	Wajib?	Catatan
Windows 10/11 (64-bit)	Ya	Hak admin untuk Docker
Node.js	Tidak	Sudah termasuk (<code>Mobility-Axiom\tools\node\</code>)
Docker Desktop	Ya (VC)	Unduh
Internet	Instal pertama	Unduh image Docker untuk Video Conference

Instal (sekali)

1. **Ekstrak** folder pengiriman penuh (mis. `C:\Mobility-Trial\`).
2. Instal **Docker Desktop** dari tautan di atas. Jalankan Docker — tunggu ikon paus stabil.
3. Klik dua kali `Install-Mobility.bat` (folder akar paket).
4. Setiap kali pakai, klik dua kali `** Start Mobility.bat**` .

Jangan jalankan `npm install` — dependensi sudah ada di paket.

Login pertama

Field	Value
URL	<code>http://:3888</code>
Nama pengguna	<code>global</code>
Kata sandi	<code>global123</code>

BWC online (ringkas)

1. **Settings** → **Server Config** → **Network** — set server IPv4 → **Save server settings**.
2. **Settings** → **Server Config** → **BWCs** — add Device ID + officer name → **Save BWC list**.
3. On each BWC SIP screen — enter values from **Type on BWC** (IPv4 only).
4. Wait ~30s — device shows **Online** in fleet list.

Video Conference (ponsel)

1. Install **MobilityConference-1.5.6.apk** on Android.
2. Server URL = same as dashboard (<http://:3888>).
3. Sign in → open room → Join with camera.

Lisensi uji coba

5 BWC · 10 dashboard users · 1 year.

Full steps: **Configuration Manual** in this folder.