

Power Cycling Your Foxtel Box

- 1. Turn your Foxtel Box off at the power point
- 2. Remove the power cable from behind your Foxtel box
- 3. Wait 30 seconds.
- 4. Re connect your power cable to the Foxtel box.
- 5. Turn the Foxtel box back on at the power point.
- 6. Allow up to 3 minutes for the Foxtel box to re set.