«enumeration» DeploymentStateKind

notYetInstalled installed inService outOfService removed

«enumeration»

AssetLifecycleStateKind

manufactured

purchased

disposedOf

received

retired

«Compound»

- outOfServiceDate: DateTime [0..1]

- inServiceDate: DateTime [0..1]
- notYetInstalledDate: DateTime [0..1]

DeploymentDate

- installedDate: DateTime [0..1]

- removedDate: DateTime [0..1]

«Compound» LifecycleDate

- installationDate: Date [0..1]
- manufacturedDate: Date [0..1]
- purchaseDate: Date [0..1]
- receivedDate: Date [0..1]
- removalDate: Date [0..1]
- retiredDate: Date [0..1] +

«enumeration» InUseStateKind

inUse readyForUse notReadyForUse

«Compound» **InUseDate**

- inUseDate: Date [0..1]
- notReadyForUseDate: Date [0..1]
- readyForUseDate: Date [0..1]

«enumeration» RetiredReasonKind

environmental excessiveMaintenance facilitiesUpgrade failed obsolescence other sold

AssetDeployment

- breakerApplication: BreakerApplicationKind [0..1]
- deploymentDate: DeploymentDate [0..1]
- deploymentState: DeploymentStateKind [0..1]
- facilityKind: FacilityKind [0..1]
- likelihoodOfFailure: Integer [0..1]
- transformerApplication: TransformerApplicationKind [0..1]
 - 0..1 +AssetDeployment
 - 0..1 +Asset

IdentifiedObject

IdentifiedObject

Asset

- acceptanceTest: AcceptanceTest [0..1]
- baselineCondition: String [0..1]
- baselineLossOfLife: PerCent [0..1]
- critical: Boolean [0..1]
- electronicAddress: ElectronicAddress [0..1]
- inUseDate: InUseDate [0..1]
- inUseState: InUseStateKind [0..1]
- kind: AssetKind [0..1]
- lifecycleDate: LifecycleDate [0..1]
- lifecycleState: AssetLifecycleStateKind [0..1]
- lotNumber: String [0..1]
- position: String [0..1]
- purchasePrice: Money [0..1]
- retiredReason: RetiredReasonKind [0..1]
- serialNumber: String [0..1]
- status: Status [0..1]
- type: String [0..1]
- utcNumber: String [0..1]

0...3 +Assets +AssetContainer 0..1

AssetContainer