An example of a simple association.
VoltageLevel objects are assigned to
a BaseVoltage but are not contained or
aggregated into the BaseVoltage.

IdentifiedObject	+BaseVoltage	+VoltageLevel	*EquipmentContainer*
Core::BaseVoltage	1	0..*	**Core::VoltageLevel**