«CIMDatatype» ActivePowerPerCurrentFlow

- + multiplier: UnitMultiplier [0..1] + unit: UnitSymbol [0..1] = WPerA {readOnly} + value: Float [0..1]