












TP1 TestMosi_DI
MOSI_DI

TP2 TestMiso_DI
MISO_DO

TP3 Test SCLK
SCLK

TP4 Test CS_SD
CS_SD

TP5 Test CS
CS



BME280






photo sensor

microphone
and amplifier

Sheet: /ESP_32_C3_02/sensors/
File: sensors.kicad_sch



Title:

Size: A4 Date:


KiCad E.D.A. 10.0.1

Rev:
Id: 3/4

oled display connector(I2C)



Reset and Boot buttons



Auto program

DTR	RTS-->	EN	IO0
1	1	1	1
0	0	1	1
1	0	0	1
0	1	1	0

Sheet: /ESP_32_C3_02/interface/
File: user_interface.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 10.0.1

Rev:

Id: 4/4