MBO and Scheduler User Manual

Written by: Zach Scheider

1 MBO and Scheduler

1.1 Start Screen



Figure 1: Start Screen for the MBO and Scheduler.

1.1.1 Choose a Line

• Line Selection Radio-buttons - Clicking on the appropriate radio-button will select which line will be used.

1.1.2 Choose a Schedule

• Click on a button to decide whether you want to view the drivers' or trains' schedule for the line that you selected before.

1.2 Schedule Views




Figure 2: Views of the drivers' and trains' schedules.

1.2.1 Personnel Schedule

Row Headings

 This will display the drivers' names. Clicking on one will display more information about that particular driver.

Column Headings

• The time is displayed in the column headings.

Table Data

- Inside each cell is the train the driver is operating.
- The cells are color coded to display more information.
 - Orange means that the driver is scheduled for a break during that time block.
 - Purple means that the driver is scheduled to take their lunch during that time block.

1.2.2 Train Schedule

Row Headings

• This will display the trains' IDs. Clicking on one will display more information about that particular train.

Column Headings

• This will display the Stations' names. Clicking on one will display more information about that particular station.

Table Data

• Inside each cell is the time that the train will arrive at the station.

1.3 Driver View




Figure 3: Views of a particular driver's schedule.

Column Headings

• The time, train ID, station, and break status are displayed in the column headings.

1.3.1 Time

• Inside each cell is the time that the driver will arrive at the station.

1.3.2 Train

• Inside each cell is the train that the driver will be operating.

1.3.3 Station

• Inside each cell is the station that the driver will arrive at.

1.3.4 Break

• Inside each cell is the break status of driver during that block.

1.4 Station View




Figure 4: Views of a particular station's schedule.

Column Headings

• The time, train ID, Inbound/Outbound status are displayed in the column headings.

1.4.1 Time

• Inside each cell is the time that a train will arrive at the station.

1.4.2 Train

• Inside each cell is the train that will arrive at the station.

1.4.3 Inbound/Outbound

• These cells tell the user whether the train is Inbound to the station or Outbound from the station.