STEADY OPEN-CHANNEL FLOW 1

RIVER MECHANICS OPEN-CHANNEL HYDRAULICS (CE5312)

Dr. Yuan Jing,


Department of Civil and Environmental Engineering

Office: E2-05-20

Phone: 65162160

Email: ceeyuan@nus.edu.sg

Some terminologies



x: streamwise direction


y: direction \perp bottom

h: water depth

A: Cross-section area

P: Wetted perimeter [L]

Prismatic channel: constant cross-section



$$A = f(h)$$

$$P = f(h)$$

Non-prismatic channel

$$A = f(x, h)$$

$$P = f(x, h)$$

Hydraulic radius


$$R_h = \frac{A}{P}$$
: hydraulic radius

A characteristic length scale

Table 1-1. Properties of typical channel cross sections

Section	Area, A	Wetted Perimeter, P	Hydraulic radius, R	Top width, B	Hydraulic depth, I	D
Rectangular	$B_{o}y$	$B_o + 2y$	$\frac{B_o y}{B_o + 2y}$	B_o	у	В ₀
Trapezoidal	$(B_o + sy)y$	$B_o + 2y\sqrt{1+s^2}$	$\frac{(B_o + sy)y}{B_o + 2y\sqrt{1+s^2}}$	$B_o + 2sy$	$\frac{(B_o + sy)y}{B_o + 2sy}$	B _Q → 1
Triangular	sy^2	$2y\sqrt{1+s^2}$	$\frac{sy}{2\sqrt{1+s^2}}$	2sy	0.5y	1
Circular $\frac{1}{8}$	$\frac{1}{2}(\theta - \sin \theta)D_o^2$	$rac{1}{2} heta D_o$	$\frac{1}{4} \left(1 - \frac{\sin \theta}{\theta} \right) D_o$	$D_o \sin \frac{1}{2} \theta$	$\big(\frac{\theta-\sin\theta}{\sin\frac{1}{2}\theta}\big)\frac{D_O}{8}$	D ₀


Velocity distribution in open channels



$$Q = \int_A q_{\perp} dA$$
: Discharge $[L^3 / T]$

$$V = \frac{Q}{A}$$
: average velocity


Velocity reduces to zero at boundaries



Velocity is not uniformly distributed, but usually we are interested in the total discharge (or the average velocity), not the spatial variation

The spatial variation is not dramatic, so we can treat the flow as well-behaved or spatially uniform

Pressure distribution




Bernoulli equation perpendicular to streamlines:

$$\frac{dp}{dy} = -\rho g \cos \beta$$

$$p = 0, @ y = h$$

$$\Rightarrow p = \rho g \cos \beta (h - y) \Rightarrow p \approx \rho g (h - y)$$

Basic hydraulic formula



$$\tau_{s} = \rho g R_{h} S_{o}$$

Interpretation: for steady uniform flow, gravity is balanced by bottom resistance

How do we relate bottom shear stress to flow?

Let us consider what we have obtained for PIPE FLOW.

Factors related to pipe-wall shear stress?

$$V = \frac{Q}{A}$$

Pipe geometry

D (diameter)

 k_s (surface roughness)

$$\nu$$
 (viscosity)

 ρ (density)

$$\tau_s \sim F(D, \rho, \nu, V, k_s)$$



Dimensional analysis

$$\tau_s = \frac{1}{8} f \rho V^2$$

Riveted steel

Galvanized iron

Wrought iron

Drawn tubing

Concrete

Cast iron

Wood

$$f = f(\frac{k_s}{D}, \text{Re} = \frac{DV}{V})$$

Darcy-Weisbach friction factor

 $k_{s}[mm]$

0.3 - 3

0.3

0.26

0.15

0.046

0.0015

3

Friction factor for turbulent pipe flows

Rough pipes:

$$\tau_s = \frac{1}{8} f \rho V^2, f = f(\frac{k_s}{D}, \text{Re})$$

No simple analytical way to get f(k/D, Re)


So we do experiments!

 \triangleright For each k/D, we can get a curve for f(Re)



Figure 1 Johann Nikuradse around 1925 at KWI, Göttingen

Nikuradse's experiment: rough pipes



Moody diagram: the $f = f(\frac{k_s}{D}, \text{Re})$ for turbulent pipe flows




Figure 7.13 Moody diagram. (From L. F. Moody, Trans. ASME, Vol. 66, 1944.)


How to use Moody for open-channel flow?

Given: V, h, v, k_s

 $h-->R_h(h)$

Find: f, τ_s

 $D --> 4R_h(h)$



Use Moody diagram: Given: ρ, ν, k_s, h, S_0

Given: ρ, ν, k_s, h, S_0 $h \longrightarrow R_h(h), A(h)$ $\tau_s = \rho g R_h S_0$

Find: Q




Figure 7.13 Moody diagram. (From L. F. Moody, Trans. ASME, Vol. 66, 1944.)

Guess, $f^{(1)}$

$$V^{(1)} = \sqrt{\frac{8\tau_s}{f^{(1)}\rho}}$$

$$Re^{(1)} = \frac{4R_h V^{(1)}}{v}$$

$$f^{(2)} = Moody(Re^{(1)}, \frac{k_s}{4R_h})$$

$$V^{(2)} = \sqrt{\frac{8\tau_s}{f^{(2)}\rho}}$$

• • •

until
$$V^{(n+1)} = V^{(n)}$$

$$Q = VA(h)$$

Chezy Equation




French engineer 1718-1798

$$V = C\sqrt{R_h}\sqrt{S_o}$$

 $C = \text{Chezy's Coefficient} \sim [L^{1/2} / T]$

Manning Equation



ROBERT MANNING

Irish accountant! 1816-1897

$$V = \frac{1}{n} R_h^{2/3} \sqrt{S_o}$$

 $n = \text{Manning's coefficient}^{\square}$ $\sim [L^{-1/3} \cdot T]$

Inconsistent but widely used

Table 4-1. Typical values* of Manning 1

Material	n
Metals	
Steel	0.012
Cast iron	0.013
Corrugated metal	0.025
Non-metals	
Lucite	0.009
Glass	0.010
Cement	0.011
Concrete	0.013
Wood	0.012
Clay	0.013
Brickwork	0.013
Gunite	0.019
Masonary	0.025
Rock cuts	0.035
Natural streams	
Clean and straight	0.030
Bottom: gravel, cobbles and boulders	0.040
Bottom: cobbles with large boulders	0.050

Chezy Vs. Manning Vs. Darcy-Weisbach

$$\frac{1}{8}f\rho V^{2} = \rho g R_{h} S_{o}$$

$$C = \sqrt{\frac{8g}{f}}$$
D.W.
$$n = 0.038 \cdot k_{s}^{1/6} \text{ [SI unit]}$$

$$V = \frac{1}{n} R_{h}^{2/3} \sqrt{S_{o}}$$
Chezy
$$C = \frac{1}{n} R_{h}^{1/6}$$
Manning

For smooth bottom, we use D.W. or Chezy, NOT Manning

Discharge for steady uniform flow


Manning:
$$Q = \frac{1}{n} \frac{A(h)^{5/3}}{P(h)^{2/3}} \sqrt{S_o}$$

Manning:
$$Q = \frac{1}{n} \frac{A(h)^{5/3}}{P(h)^{2/3}} \sqrt{S_o}$$
 $Q = f(h, S_0, bottom)$

For steady uniform flow, the discharge is a function of depth, slope and bottom condition

- Depth and slope determine gravity, which is the driving force
- Bottom condition determines the bottom resistance, which is the balancing force


Compound channel



$$Q = \sum Q_n = \sum \frac{1}{n_n} A_n \left(\frac{A_n}{P_n}\right)^{2/3} \sqrt{S_o}$$

Practice

Water flows in a long straight channel with a trapezoidal cross-section. The bottom drops 1.6 m per km. The horizontal bottom is finished concrete (n=0.012) and the sides are clay lined (n = 0.026). Find Q



Normal depth

$$Q = f(h, S_0, bottom) \implies h = F(Q, S_0, bottom)$$

The depth for steady uniform flow with a given discharge in an open channel with specified slope and bottom condition.

Normal depth calculation: Manning

Manning:
$$Q = \frac{1}{n} \frac{A(h)^{5/3}}{P(h)^{2/3}} \sqrt{S_o}$$



$$K(h) = \frac{A(h)^{5/3}}{P(h)^{2/3}} = \frac{nQ}{\sqrt{S_o}}$$

Normal depth calculation: D.W.

Given: k_s , Q, S_0

Find: h_n

$$V = \sqrt{\frac{8g}{f}} \sqrt{R_h} \sqrt{S_0} \Longrightarrow \frac{fQ^2}{8gS_0} = R_h A^2$$




Figure 7.13 Moody diagram. (From L. F. Moody, Trans. ASME, Vol. 66, 1944.

Guess, $f^{(1)}$

$$\frac{f^{(1)}Q^2}{8gS_0} = R_h^{(1)} \left(A^{(1)}\right)^2 \Rightarrow h^{(1)}, R_h^{(1)}, V^{(1)} = \frac{Q}{A^{(1)}}$$

$$f^{(2)} = Moody(\frac{4R_h^{(1)}V^{(1)}}{v}, \frac{k_s}{4R_h^{(1)}})$$

• • •

$$\operatorname{until} f^{(n+1)} = f^{(n)}$$


Rating curve


$$K(h) = \frac{A(h)^{5/3}}{P(h)^{2/3}} = \frac{nQ}{\sqrt{S_o}}$$



$$Q = \frac{\sqrt{S_o}}{n} K(h)$$

Not a golden rule!





d L. L. Sanders (1998) A Manual of Field Hydrogeology

Normal depth In rectangular channel

Using Manning's equation:
$$h_n = \left(\frac{Qn}{\sqrt{S_o}b}\right)^{3/5} \left(1 + 2h_n / b\right)^{2/5}$$


Iterative solution:

$$h^{(n+1)} = \left(\frac{Qn}{\sqrt{S_o b}}\right)^{3/5} \left(1 + 2h^{(n)} / b\right)^{2/5}$$
, staring with $h^{(0)} = 0$

Energy grade line and hydraulic grade line

For steady uniform open-channel flow:

- Energy grade line is parallel to free surface, and with V²/2g above.
- Hydraulic grade line is identical to free surface



Energy equation for steady uniform flow

$$\frac{\partial H}{\partial x} = -S_f$$

change of total water head, $\partial H/\partial x$, is due to bottom flow resistance, S_f

It's actually equivalent to the Basic Hydraulic Formula.

