



DAILY MATERIAL SCHEDULE

JOB TICKET · PRINT ONE PER CREW

JOB / PROJECT

Lakes Crossing

JOB NUMBER

6618

CUSTOMER

Washoe Painting

PREPARED BY

Your name

■ MATERIAL ORDER SUMMARY

10 materials

MATERIAL		TOTAL NEEDED
☐	1 14/15	2
☐	2 Cabosil	2
☐	3 Polycrete	1
☐	4 Sand	1
☐	5 Extreme bond primer	5
☐	6 Duraflex #4 Pigmented	1
☐	7 Chips	22
☐	8 Duraflex #4 clear	1
☐	9 Duraflex #4	1
☐	10 Resultile AT	3

LEAD SIGNATURE

DATE

SALES SIGNATURE

DATE

DAY 1 OF 7

DAY 1

1 ITEM

CREW: 4 · HOURS: 8 · SQ FT: 1,085 · LINEAR FT: 418 · WTC: WTC 1

■ WORK TO COMPLETE

- 1 (1) Prep floor 100% (2) Patch floor and joints 100%

■ SCOPE NOTES

(1) Use terrco and hand grinders to prep the concrete in all 9 rooms and 1 bathroom. Averaging 120 Sqft per room. (2) Use 14/15 and cabosil to patch in all joints, cracks and holes.

■ MATERIALS NEEDED

MATERIAL	QTY	NOTES
☐ 14/15 W/Cabosil	1 (kit: 3 gallon)	Mils: NA · Coverage: Varies · Mix time: 3 minutes · Mix speed: medium

DAY 2 OF 7

DAY 2

2 ITEMS

CREW: 4 · HOURS: 8 · SQ FT: 1,562 · WTC: WTC 1

■ WORK TO COMPLETE

- 1 (1) Install Urethane floor 100%

■ SCOPE NOTES

Put tape up and take down as you are coating. Put tape up daily do not leave. (1) Set up mix station, Make marks on wall for footages, Use a number 2 cam on guage rake, Use loop roller, Let material glass off 2 minutes (this varies) and broadcast sand to refusal approx 20 sqft in bathroom only

■ MATERIALS NEEDED

MATERIAL	QTY	NOTES
☐ Polycrete	1 (kit: 1 kit)	Mils: 3/16" · Coverage: 45 Sqft per kit · Mix time: 3 minutes · Mix speed: medium
☐ Sand	1 (kit: 100 Lbs)	Coverage: .75 lbs per foot

DAY 3 OF 7

DAY 3

3 ITEMS

CREW: 4 · HOURS: 8 · SQ FT: 1,562 · LINEAR FT: 600 · WTC: WTC 1

■ WORK TO COMPLETE

- 1 (1) Quick grind urethane to smooth out 100% (2) Instal 3/4" Cant bead 100% (3) Prime walls 100%

■ SCOPE NOTES

Put tape up and take down as you are coating. Put tape up daily do not leave. (1) Pick up sand lightly grind edges and the floor only if it is needed to make it look uniform, (2) Install a 3/4" radius at the floor to wall transition with epoxy and cabosil and a 1/4" radius on the inside corners of the walls only in bathroom (3) Once radius is complete prime the walls with the primer.

■ MATERIALS NEEDED

MATERIAL	QTY	NOTES
☐ 14/15	1 (kit: 3 gallon)	Mils: NA · Coverage: 50LF per gallon mixed · Mix time: 3 minutes · Mix speed: medium
☐ Cabosil	1 (kit: 22lbs)	Mils: NA · Coverage: NA · Mix time: NA · Mix speed: NA
☐ Extreme bond primer	5 (kit: 1 gallon)	Mils: 4 · Coverage: 350 Sqft per gallon · Mix time: Medium · Mix speed: NA

DAY 4 OF 7

DAY 4-5

2 ITEMS

CREW: 4 · HOURS: 8 · SQ FT: 1,562 · WTC: WTC 1

■ WORK TO COMPLETE

- 1 (1) Install first broadcast coat on walls and floor 50% each day if needed

■ SCOPE NOTES

Put tape up and take down as you are coating. Put tape up daily do not leave. Make sure to put tape on the ceiling to protect it .(1) Use the pigmented #4 resin on wall and floor and broadcast the chips on the floor and wall with the hopper gun.

■ MATERIALS NEEDED

MATERIAL	QTY	NOTES
☐ Duraflex #4 Pigmented	1 (kit: 18 gallons)	Mils: 13 · Coverage: 125 Sqft per gallon · Mix time: 3 minutes · Mix speed: medium
☐ Chips	11 (kit: 40lb)	Mils: NA · Coverage: .15lb per foot · Mix time: NA · Mix speed: NA

DAY 5 OF 7

DAY 6-7

2 ITEMS

CREW: 4 · HOURS: 8 · SQ FT: 1,562 · WTC: WTC 1

■ WORK TO COMPLETE

- 1 (1) Install second broadcast coat on floor and walls 50% each day if needed

■ SCOPE NOTES

Put tape up and take down as you are coating. Put tape up daily do not leave. Scrape the walls and floor pick up excess chips do not discard. Apply #4 clear on the walls and floor and re broadcast the floor and the walls with the hopper gun.

■ MATERIALS NEEDED

MATERIAL	QTY	NOTES
☐ Duraflex #4 clear	1 (kit: 13 gallons)	Mils: 13 · Coverage: 125 Sqft per gallon · Mix time: 3 minutes · Mix speed: medium
☐ Chips	11 (kit: 40lb)	Mils: NA · Coverage: .15lb per foot · Mix time: NA · Mix speed: NA

DAY 6 OF 7

DAY 8

1 ITEM

CREW: 4 · HOURS: 8 · SQ FT: 1,562 · WTC: WTC 1

■ WORK TO COMPLETE

- 1 (1) Grout coat floor and walls 100%

■ SCOPE NOTES

Put tape up and take down as you are coating. Put tape up daily do not leave. Sand the walls with the drywall sanders and the floors with the slow speeds using 36 grit sand paper to knock off the sharp edges. Use the #4 clear as a grout coat on the walls then on the floor

■ MATERIALS NEEDED

MATERIAL	QTY	NOTES
☐ Duraflex #4	1 (kit: 13 gallons)	Mils: 13 · Coverage: 125 Sqft per gallon · Mix time: 3 minutes · Mix speed: Medium

CREW: 4 · HOURS: 8 · SQ FT: 1,562 · WTC: WTC 1

WORK TO COMPLETE

- 1
- (1) Top coat floor and walls 100%

SCOPE NOTES

Put tape up and take down as you are coating. Put tape up daily do not leave. Dip and roll the resutile AT on the walls then onto the floor. Becareful to watch for runs and drips. Make sure to remove the tape from the top of the wall protecting the ceiling when done

MATERIALS NEEDED

MATERIAL	QTY	NOTES
☐ Resultile AT	3 (kit: 1.3 gallon)	Coverage: 650 Sqft per kit · Mix time: 3 minutes · Mix speed: medium