MODULE 6: Instruction Set Architecture

Lecture 6.3 Addressing

Prepared By:

- Scott F. Midkiff, PhD
- Luiz A. DaSilva, PhD
- Kendall E. Giles, PhD

Electrical and Computer Engineering
Virginia Tech



Lecture 6.3 Objectives

- Explain the motivation for an instruction architecture to support multiple addressing modes
- Describe the operation of common addressing modes:
 - Immediate
 - Direct
 - Register
 - Indirect
 - Register indirect
 - Indexed or based



Motivation for Addressing Modes

- Different addressing modes can be used to reference memory locations and operands
- Provides both efficiency and clarity in coding at the assembly language level
- Provides efficiency in execution at the machine code level
- Example (fictitious):

```
ADD R1,R2,R4! Address of next element
```

LOAD R4,R5 ! R5 := next element

can be re-written using just one instruction

```
LOAD R1+R2,R5 ! %r5 := next element
```



Some Notation

X: the value X

(Rn): the contents of register Rn

M[X]: memory location with address X

(M[X]): the contents of the memory location with address X



General Addressing Modes

Addressing Mode	Syntax	Meaning
Immediate	#X	X
Direct	X	(M[X])
Register	Rn	(Rn)
Indirect	(X)	(M[(M[X])])
Register Indirect	(Rn)	(M[(Rn)])
Indexed or Based	(Rm + X)	(M[(Rm) + X])
Stack		(M[(SP)])

There are other variations



Immediate Addressing Mode

- The instruction contains the operand value
- Operand value must be known at assembly time since it is part of the instruction
- Example:
 - ADD #-4,R4 Immediate operand negative 4 is added to the contents of R4

Addressing Mode	Syntax	Meaning
Immediate	#X	X

Direct Addressing Mode

- Instruction contains the address of the operand
- Address must be known at assembly time
- Example:
 - LOAD 800,R1

Addressing Mode	Syntax	Meaning
Direct	X	(M[X])



Register Addressing Mode

- Instruction specifies a register and the register contains the operand value
- Example:
 - ADD #5,R1 Contents of R1 are used as an operand

Addressing Mode	Syntax	Meaning
Register	Rn	(Rn)



As a checkpoint of your understanding, please pause the video and make sure you can do the following:

- Explain the motivation for an instruction architecture to support multiple addressing modes
- Describe the operation of Immediate, Direct, and Register Addressing modes

If you have any difficulties, please review the lecture video before continuing.

Indirect Addressing Mode

- Instruction contains the address of a pointer stored in memory that points to the operand
- Pointer address must be known at assembly time, but the operand address can be changed dynamically by changing the contents of the pointer
- Not commonly implemented since it requires two accesses to memory
 - First access to retrieve contents of pointer
 - Second access, using pointer contents as the address, to load or store operand



Indirect Addressing Mode (2)

Example:

 ADD (800),R1 – Contents of memory location 800 used to address a memory location; contents of that location are added to R1 and stored in R1

Addressing Mode	Syntax	Meaning
Indirect	(X)	(M[(M[X])])



Register Indirect Addressing Mode

- Instruction specifies a register and the register contains the memory address of the operand
- Allows location of operand to be changed at execution time
- Unlike the standard indirect (or memory indirect) addressing mode, requires just one access to memory
- Example
 - LOAD (R1),R2 -- Contents of R1 used to address memory; contents of the memory location moved to R2

Addressing Mode	Syntax	Meaning
Register Indirect	(Rn)	M[(Rn)]



Based or Indexed Addressing Mode

- Instruction specifies an operand and a register, with the sum of the operand and the register contents specifying the memory address of the operand
- Indexed addressing
 - Operand specifies a block of memory and the register is incremented (or decremented) to index into the block
 - Need long operand and short index register value
- Based addressing
 - Register specifies a block of memory (the base) and the operand provides an offset in the base
 - Need long base register and short operand as offset



Based or Indexed (2)

- Example
 - LOAD (R1+800),R2 800 is added to the contents of R1 to determine memory location; contents of memory location are stored in R2

Addressing Mode	Syntax	Meaning
Indexed or Based	(Rm + X)	(M[(Rm) + X])

Instruction Implications

- The machine instruction (and, hence, assembly instructions) has to specify the addressing mode to be used
- This can be implied by the operation, for example...
 - LOAD 800,R1 for direct addressing
 - LOADI 800,R1 for immediate addressing
- This can be specified by a field in the machine instruction and by special syntax in the assembly statement, for example:
 - LOAD 800,R1 for direct addressing
 - LOAD #800,R1 for immediate addressing





As a checkpoint of your understanding, please pause the video and make sure you can do the following:

 Describe the operation of Indirect, Register Indirect, and Based or Indexed Addressing modes

If you have any difficulties, please review the lecture video before continuing.



Summary

- Examined general addressing modes
 - Immediate
 - Direct
 - Register
 - Indirect
 - Register indirect
 - Indexed or based



MODULE 6: Instruction Set Architecture

Lecture 6.3 Addressing

Prepared By:

- Scott F. Midkiff, PhD
- · Luiz A. DaSilva, PhD
- Kendall E. Giles, PhD
 Electrical and Computer Engineering

Virginia Tech