MODULE 2: Data Representation

Lecture 2.5 Character Codes

Prepared By:

- Scott F. Midkiff, PhD
- · Luiz A. DaSilva, PhD
- Kendall E. Giles, PhD

Electrical and Computer Engineering
Virginia Tech



Lecture 2.5 Objectives

- Describe the purpose of binary coded decimal (BCD) representation and other decimal codes
- Convert decimal values to and from binary coded decimal
- Describe the purpose and basic features of ASCII, EBCDIC, and Unicode character codes
- Using a table, be able to convert to and from ASCII character codes



Decimal Codes

- Sometimes we want to operate directly on decimal values
 - Avoids conversions
 - Special-purpose systems
- Binary coded decimal (BCD) is the usual scheme
 - Four bits per decimal digit (0000=0 to 1001=9)
 - Six combinations not used (1010 to 1111)
- There are also other schemes



Example Decimal Codes (1)

	BCD	2-4-2-1	Excess-3	Gray
0	0000	0000	0011	0010
1	0001	0001	0100	0110
2	0010	0010	0101	0111
3	0011	0011	0110	0101
4	0100	0100	0111	0100
5	0101	1011	1000	1100
6	0110	1100	1001	1101
7	0111	1101	1010	1111
8	1000	1110	1011	1110
9	1001	1111	1100	1010



Example Decimal Codes (2)

- 2421 and Excess-3 are self-complementary codes
 - Complementing the bits gives the 9's complement
 - Excess-3 example: 6 = 1001, 3 = 0110
- BCD and 2421 are weighted codes
 - For 2421, each position is assigned a weight (2-4-2-1)
 - Standard BCD is an 8-4-2-1 code
- Gray code is an unweighted code with the special property that adjacent values differ in just one bit
 - This property makes it a cyclic code



BCD Examples (1)

- Represent (4509)₁₀ as a BCD value
 - -4 = 0100
 - -5 = 0101
 - -0 = 0000
 - -9 = 1001
- So, $(4509)_{10} = (0100\ 0101\ 0000\ 1001)_{BCD}$
- Note that this representation is less compact than radix-2
- · Combinations 1010, 1011, 1100, 1101, 1110, 1111 are "wasted" in BCD

BCD Examples (2)

- What is (0100 1001 1000 0100)_{BCD} in decimal?
 - $-(0100)_2 = 4$
 - $-(1001)_2 = 9$
 - $-(1000)_2 = 8$
 - $-(0100)_2 = 4$
- So, $(0100\ 1001\ 1000\ 0100\)_{BCD} = (4984)_{10}$



As a checkpoint of your understanding, please pause the video and make sure you can do the following:

• Represent (5490)₁₀ as a BCD value

If you have any difficulties, please review the lecture video before continuing.



Non-Numeric Data

- Computers need to represent more than just numbers
 - Alphabetic characters and other symbols
 - Numerals (versus numbers)
 - Special control codes (e.g., backspace, carriage return)
- ASCII is the most widely used code for this purpose
- Unicode is growing in use
- EBCDIC used in IBM mainframe systems



ASCII (1)

- ASCII: American Standard Code for Information Interchange
- Widely used for exchange of data and internal representation
- Seven bits (sometimes 8 to extend the character set or for 1 error check bit)
- Used for
 - "Printing" characters (0...9a...zA...Z!@#\$...)
 - "Control" characters (CR, BS, SP, ESC, ...)



ASCII (2)

Example ASCII codes

Α	100 0001	(41) ₁₆
a	110 0001	(61) ₁₆
DEL	111 1111	(7F) ₁₆
ESC	001 1011	$(1B)_{16}$
0	011 0000	(30) ₁₆
9	011 1001	(39) ₁₆

EBCDIC

- EBCDIC: Extended Binary Coded Decimal Interchange Code
- Less widely used than ASCII; used mainly in IBM mainframes
- 8-bit code
- Has more control characters than ASCII



Unicode

- ASCII and EBCDIC support the Latin character set typically used in computers, but cannot represent many alphabets used in the world
- Unicode designed to address this problem and is now an industry standard
- UTF-16 is a 16-bit code that represents many more characters than ASCII or EBCDIC
- · Can represent many special printable characters (such as à, ê, æ, ü, etc.)





As a checkpoint of your understanding, please pause the video and make sure you can do the following:

What is the binary value and hexadecimal value for the ASCII character "9"?

If you have any difficulties, please review the lecture video before continuing.



Summary

- Computers and special-purpose digital systems sometimes represent decimal values in decimal form
 - Four bits used to represent a decimal digit (0, 1, ..., 9)
 - Intel x86 math co-processor architecture supports 20-digit (80 bit) "Packed Decimal" format
- Other weighted and unweighted codes may also be used to represent decimal values
- Computers must represent non-numeric data including characters and special control codes
- Commonly used non-numeric codes: ASCII (7 bits), EBCDIC (8 bits), Unicode (16 bits)



MODULE 2: Data Representation

Lecture 2.5 Character Codes

Prepared By:

- Scott F. Midkiff, PhD
- · Luiz A. DaSilva, PhD
- Kendall E. Giles, PhD

Electrical and Computer Engineering
Virginia Tech

