Part 5: Acquisition

Building a GPS receiver from scratch

Chris Doble

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
- 2 Finding parameters
- Parameter space
- Determining presence

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
- Pinding parameters
- Parameter space
- Determining presence

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
- 2 Finding parameters
- Parameter space
- Determining presence

• To decode satellite i's navigation message bit, calculate

$$\int_{t_0}^{t_0+0.001} r(t) P \hat{R} N_i(t) \, dt$$

where t_0 is a point in time and r(t) is the received signal

• To decode satellite i's navigation message bit, calculate

$$\int_{t_0}^{t_0+0.001} r(t) P \hat{R} N_i(t) \, dt$$

where t_0 is a point in time and r(t) is the received signal

ullet PRN codes aligned \Rightarrow navigation message bit

• To decode satellite i's navigation message bit, calculate

$$\int_{t_0}^{t_0+0.001} r(t) P \hat{R} N_i(t) \, dt$$

where t_0 is a point in time and r(t) is the received signal

- ullet PRN codes aligned \Rightarrow navigation message bit
- $\bullet \ \mathsf{PRN} \ \mathsf{codes} \ \mathsf{misaligned} \Rightarrow \mathsf{noise} \\$

• To decode satellite i's navigation message bit, calculate

$$\int_{t_0}^{t_0+0.001} r(t) P \hat{R} N_i(t) \, dt$$

where t_0 is a point in time and r(t) is the received signal

- PRN codes aligned ⇒ navigation message bit
- PRN codes misaligned ⇒ noise
- In order to align them, we need to know the phase

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
- 2 Finding parameters
- Parameter space
- Determining presence

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
 - Modulation signal, misaligned PRN code
 - Modulation signal, aligned PRN code
 - Modulated signal, not frequency shifted
 - Modulated signal, frequency shifted
- 2 Finding parameters
- Parameter space
- 4 Determining presence

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
 - Modulation signal, misaligned PRN code
 - Modulation signal, aligned PRN code
 - Modulated signal, not frequency shifted
 - Modulated signal, frequency shifted
- 2 Finding parameters
- Parameter space
- 4 Determining presence

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
 - Modulation signal, misaligned PRN code
 - Modulation signal, aligned PRN code
 - Modulated signal, not frequency shifted
 - Modulated signal, frequency shifted
- Pinding parameters
- Parameter space
- 4 Determining presence

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
 - Modulation signal, misaligned PRN code
 - Modulation signal, aligned PRN code
 - Modulated signal, not frequency shifted
 - Modulated signal, frequency shifted
- 2 Finding parameters
- Parameter space
- 4 Determining presence

• $\hat{D}_i(t)P\hat{R}N_i(t)f(t)$

- $\hat{D}_i(t)P\hat{R}N_i(t)f(t)$
- Bandpass sampling results in $f(t) \Rightarrow Ae^{j\phi}$

- $\hat{D}_i(t)P\hat{R}N_i(t)f(t)$
- Bandpass sampling results in $f(t) \Rightarrow Ae^{j\phi}$
- ullet Samples will be equal to $\pm Ae^{j\phi}$

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
 - Modulation signal, misaligned PRN code
 - Modulation signal, aligned PRN code
 - Modulated signal, not frequency shifted
 - Modulated signal, frequency shifted
- 2 Finding parameters
- 3 Parameter space
- 4 Determining presence

• $\hat{D}_i(t)P\hat{R}N_i(t)g(t)$

- $\hat{D}_i(t)P\hat{R}N_i(t)g(t)$
- A frequency shifted signal ⇔ a signal with a constantly changing phase

- $\hat{D}_i(t)P\hat{R}N_i(t)g(t)$
- A frequency shifted signal ⇔ a signal with a constantly changing phase
- Bandpass sampling results in $g(t) \Rightarrow Ae^{j(2\pi\Delta f t + \phi)} = Ae^{j\phi}e^{j2\pi\Delta f t}$

- $\hat{D}_i(t)P\hat{R}N_i(t)g(t)$
- ullet A frequency shifted signal \Leftrightarrow a signal with a constantly changing phase
- ullet Bandpass sampling results in $g(t) \Rightarrow Ae^{j(2\pi\Delta f t + \phi)} = Ae^{j\phi}e^{j2\pi\Delta f t}$
- Samples will be equal to $\pm Ae^{j\phi}e^{j2\pi\Delta ft}$

Recovering the signal

Chris Doble Part 5: Acquisition 14 / 23

Recovering the signal


ullet Undo the rotation by multiplying each sample by $e^{-j2\pi\Delta ft}$


Recovering the signal

- ullet Undo the rotation by multiplying each sample by $e^{-j2\pi\Delta ft}$
- ullet This is called carrier wipeoff and it's why we need to know Δf

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
- 2 Finding parameters
- Parameter space
- Determining presence

Chris Doble Part 5: Acquisition 15/23





• We want to calculate the correlation over a 10 ms period

- We want to calculate the correlation over a 10 ms period
- There's a higher chance that the navigation message bit will change

- We want to calculate the correlation over a 10 ms period
- There's a higher chance that the navigation message bit will change
- If it does, some samples will cancel each other out ⇒ smaller correlation

- We want to calculate the correlation over a 10 ms period
- There's a higher chance that the navigation message bit will change
- If it does, some samples will cancel each other out \Rightarrow smaller correlation
- ullet Calculate correlation over 10×1 ms periods, add their magnitudes

- We want to calculate the correlation over a 10 ms period
- There's a higher chance that the navigation message bit will change
- If it does, some samples will cancel each other out \Rightarrow smaller correlation
- \bullet Calculate correlation over $10\times 1\,\text{ms}$ periods, add their magnitudes
- This is called non-coherent integration

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
- 2 Finding parameters
- Parameter space
- Determining presence

Chris Doble Part 5: Acquisition 18 / 23

•
$$f_s = 2.046 \, \mathrm{MHz} \Rightarrow 2046 \, \mathrm{samples/ms}$$

- $f_s = 2.046 \, \text{MHz} \Rightarrow 2046 \, \text{samples/ms}$
- PRN code is 1023 bits long, repeats once per ms

PRN code phase

- $f_s = 2.046 \, \text{MHz} \Rightarrow 2046 \, \text{samples/ms}$
- PRN code is 1023 bits long, repeats once per ms
- Upsample the PRN code to be 2046 half-bits long

PRN code phase

- $f_s = 2.046 \, \text{MHz} \Rightarrow 2046 \, \text{samples/ms}$
- PRN code is 1023 bits long, repeats once per ms
- Upsample the PRN code to be 2046 half-bits long
- There are 2046 phases to check

Chris Doble Part 5: Acquisition 20 / 23

 \bullet Δf due to satellite motion $\pm 4.9\,\mathrm{kHz}$

- Δf due to satellite motion $\pm 4.9 \, \text{kHz}$
- Δf due to Earth's rotation $\pm 2.4 \, \text{kHz}$

- Δf due to satellite motion $\pm 4.9 \, \text{kHz}$
- Δf due to Earth's rotation $\pm 2.4 \, \text{kHz}$
- Δf due to receiver motion $\pm 150\,\mathrm{Hz}$

- Δf due to satellite motion $\pm 4.9 \, \text{kHz}$
- Δf due to Earth's rotation $\pm 2.4 \, \text{kHz}$
- ullet Δf due to receiver motion $\pm 150\,\mathrm{Hz}$
- $\Delta t_{\rm total} \approx \pm 7.5 \, {\rm kHz}$

Topics

- Parameters
 - PRN code phase
 - Carrier wave frequency shift
- 2 Finding parameters
- Parameter space
- 4 Determining presence

On startup, find the best parameters and signal strength for every satellite

- On startup, find the best parameters and signal strength for every satellite
- Compare the signal strength with a threshold

- On startup, find the best parameters and signal strength for every satellite
- Compare the signal strength with a threshold
- \odot If it's greater \Rightarrow present

- On startup, find the best parameters and signal strength for every satellite
- 2 Compare the signal strength with a threshold
- **3** If it's greater \Rightarrow present
- \bigcirc If it's smaller \Rightarrow absent

- On startup, find the best parameters and signal strength for every satellite
- Compare the signal strength with a threshold
- **3** If it's greater \Rightarrow present
- Periodically try to acquire satellites we're not tracking

Chris Doble Part 5: Acquisition 23 / 23

• Two required parameters

- Two required parameters
 - \bullet PRN code phase \Rightarrow align the PRN codes

- Two required parameters
 - PRN code phase \Rightarrow align the PRN codes
 - ullet Carrier frequency shift \Rightarrow undo the effects of frequency shift (carrier wipeoff)

Chris Doble Part 5: Acquisition 23 / 23

- Two required parameters
 - PRN code phase \Rightarrow align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force

- Two required parameters
 - PRN code phase \Rightarrow align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force
- Size of the parameter space

- Two required parameters
 - PRN code phase \Rightarrow align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force
- Size of the parameter space
 - PRN code phase \Rightarrow [0, 2046)

- Two required parameters
 - PRN code phase \Rightarrow align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force
- Size of the parameter space
 - PRN code phase \Rightarrow [0, 2046)
 - Carrier frequency shift $\Rightarrow \pm 7.5 \, \text{kHz}$

- Two required parameters
 - PRN code phase \Rightarrow align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force
- Size of the parameter space
 - PRN code phase \Rightarrow [0, 2046)
 - Carrier frequency shift $\Rightarrow \pm 7.5 \, \text{kHz}$
- Determining presence

- Two required parameters
 - PRN code phase \Rightarrow align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force
- Size of the parameter space
 - PRN code phase \Rightarrow [0, 2046)
 - Carrier frequency shift $\Rightarrow \pm 7.5\,\mathrm{kHz}$
- Determining presence
 - Calculate the best parameters and signal strength

- Two required parameters
 - PRN code phase ⇒ align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force
- Size of the parameter space
 - PRN code phase \Rightarrow [0, 2046)
 - Carrier frequency shift $\Rightarrow \pm 7.5\,\mathrm{kHz}$
- Determining presence
 - Calculate the best parameters and signal strength
 - Compare the signal strength against a threshold

- Two required parameters
 - PRN code phase ⇒ align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force
- Size of the parameter space
 - PRN code phase \Rightarrow [0, 2046)
 - Carrier frequency shift $\Rightarrow \pm 7.5\,\mathrm{kHz}$
- Determining presence
 - Calculate the best parameters and signal strength
 - Compare the signal strength against a threshold
 - **3** If above the threshold \Rightarrow present

- Two required parameters
 - PRN code phase ⇒ align the PRN codes
 - Carrier frequency shift ⇒ undo the effects of frequency shift (carrier wipeoff)
- These parameters are found by brute force
- Size of the parameter space
 - PRN code phase \Rightarrow [0, 2046)
 - Carrier frequency shift $\Rightarrow \pm 7.5\,\mathrm{kHz}$
- Determining presence
 - Calculate the best parameters and signal strength
 - Compare the signal strength against a threshold
 - If above the threshold ⇒ present
 - lacktriangledown If below the threshold \Rightarrow absent, check again later