

Topic 14

Solution of Nonlinear Dynamic Response—Part II

Contents:

- Mode superposition analysis in nonlinear dynamics
- Substructuring in nonlinear dynamics, a schematic example of a building on a flexible foundation
- Study of analyses to demonstrate characteristics of procedures for nonlinear dynamic solutions
- Example analysis: Wave propagation in a rod
- Example analysis: Dynamic response of a three degree of freedom system using the central difference method
- Example analysis: Ten-story tapered tower subjected to blast loading
- Example analysis: Simple pendulum undergoing large displacements
- Example analysis: Pipe whip solution
- Example analysis: Control rod drive housing with lower support
- Example analysis: Spherical cap under uniform pressure loading
- Example analysis: Solution of fluid-structure interaction problem

Textbook:

Sections 9.3.1, 9.3.2, 9.3.3, 9.5.3, 8.2.4

Examples:

9.6, 9.7, 9.8, 9.11

References:

The use of the nonlinear dynamic analysis techniques is described with example solutions in

Bathe, K. J., "Finite Element Formulation, Modeling and Solution of Nonlinear Dynamic Problems," Chapter in *Numerical Methods for Partial Differential Equations*, (Parter, S. V., ed.), Academic Press, 1979.

Bathe, K. J., and S. Gracewski, "On Nonlinear Dynamic Analysis Using Substructuring and Mode Superposition," *Computers & Structures*, 13, 699–707, 1981.

Ishizaki, T., and K. J. Bathe, "On Finite Element Large Displacement and Elastic-Plastic Dynamic Analysis of Shell Structures," *Computers & Structures*, 12, 309–318, 1980.

THE SOLUTION OF
THE DYNAMIC EQUILIB-
RIUM EQUATIONS CAN
BE ACHIEVED USING

- DIRECT INTEGRATION METHODS
 - EXPLICIT INTEGR.
 - IMPLICIT INTEGR.
- MODE SUPERPOSITION
- SUBSTRUCTURING

WE DISCUSS THESE TECHNIQUES BRIEFLY IN THIS LECTURE

EXAMPLES

- | EX.1 WAVE PROPAGA-
TION IN A ROD
- | EX.2 RESPONSE OF A
3 D.O.F. SYSTEM
- | EX.3 ANALYSIS OF
TEN STORY
TAPERED TOWER
- | EX.4 ANALYSIS OF
PENDULUM
- | EX.5 PIPE WHIP
RESPONSE SOLUTION

SLIDES REGARDING

- ANALYSIS OF CRD HOUSING
- SOLUTION OF RESPONSE OF SPHERICAL CAP
- ANALYSIS OF FLUID-STRUCTURE INTERACTION PROBLEM (PIPE TEST)
- THE DETAILS OF THESE PROBLEM SOLUTIONS ARE GIVEN IN THE PAPERS, SEE STUDY GUIDE

Transparency
14-1Mode superposition:

- The modes of vibration change due to the nonlinearities, however we can employ the modes at a particular time as basis vectors (generalized displacements) to express the response.
- This method is effective when, in nonlinear analysis,
 - the response lies in only a few vibration modes (displacement patterns)
 - the system has only local nonlinearities

Transparency
14-2

The governing equations in implicit time integration are (assuming no damping matrix)

$$\underline{M}^{t+\Delta t} \ddot{\underline{U}}^{(k)} + \tau \underline{K} \Delta \underline{U}^{(k)} = \underline{R}^{t+\Delta t} - \underline{F}^{(k-1)}$$

Let now $\tau = 0$, hence the method of solution corresponds to the initial stress method.

Using

$$\underline{U}^{t+\Delta t} = \sum_{i=r}^s \underline{\phi}_i^{t+\Delta t} \underline{x}_i$$

$${}^0 \underline{K} \underline{\phi}_i = \omega_i^2 \underline{M} \underline{\phi}_i$$

The modal transformation gives

$$\ddot{\underline{X}}^{(k)} + \underline{\Omega}^2 \Delta \underline{X}^{(k)} = \underline{\Phi}^T \underbrace{(\dot{\underline{R}} - \underline{F}^{(k-1)})}_{\text{equations cannot be solved individually over the time span}}$$

Coupling!

where

$$\underline{\Omega}^2 = \begin{bmatrix} \omega_r^2 \\ \dots \\ \omega_s^2 \end{bmatrix}$$

$$\underline{\Phi} = [\underline{\phi}_r \dots \underline{\phi}_s]$$

$$\dot{\underline{X}}^T = [\dot{x}_r \dots \dot{x}_s]$$

Transparency
14-3

Typical problem:



Pipe whip: Elastic-plastic pipe
Elastic-plastic stop


- Nonlinearities in pipe and stop. But the displacements are reasonably well contained in a few modes of the linear (initial) system.

Transparency
14-4

Transparency
14-5


Substructuring

- Procedure is used with implicit time integration. All linear degrees of freedom can be condensed out prior to the incremental solution.
- Used for local nonlinearities:
Contact problems
Nonlinear support problems




Transparency
14-6

Example:




Ten story
building



Finite element
model

- – “master” node
- – substructure internal node

Substructure
model

Transparency
14-7

Here

$$\hat{K}^t = \left(K + \frac{4}{\Delta t^2} M \right) + \hat{K}_{\text{nonlinear}}$$


↓ ↓ ↓
 all linear element contributions total mass matrix all nonlinear stiffness effects

$$= \hat{K} + \hat{K}_{\text{nonlinear}}$$

Transparency
14-8

Transparency
14-9

After condensing out all substructure internal degrees of freedom, we obtain a smaller system of equations:

Transparency
14-10

Major steps in solution:

- Prior to step-by-step solution, establish \hat{K} for all mass and constant stiffness contributions. Statically condense out internal substructure degrees of freedom to obtain \hat{K}_c .

We note that


$$\underbrace{\hat{K}_c^t}_{\text{condensed}} = \underbrace{\hat{K}_c}_{\substack{\text{from } \hat{K} = K + \frac{4}{\Delta t^2} M \\ \text{all linear element contributions}}} + \underbrace{\hat{K}_{\text{nonlinear}}}_{\text{all nonlinear effects}}$$

total mass matrix

- For each time step solution (and each equilibrium iteration):
 - Update condensed matrix, \hat{K}_c , for nonlinearities.
 - Establish complete load vector for all degrees of freedom and condense out substructure internal degrees of freedom.
 - Solve for master dof displacements, velocities, accelerations and calculate all substructure dof disp., vel., acc.
The substructure internal nodal disp., vel., acc. are needed to calculate the complete load vector (corresponding to all dof).

**Transparency
14-11**


Solution procedure for each time step (and iteration):



**Transparency
14-12**

Transparency
14-13Example: Wave propagation in a rod



Uniform, freely floating rod



$$\begin{aligned}L &= 1.0 \text{ m} \\A &= 0.01 \text{ m}^2 \\ \rho &= 1000 \text{ kg/m}^3 \\ E &= 2.0 \times 10^9 \text{ Pa}\end{aligned}$$

Transparency
14-14


Consider the compressive force at a point at the center of the rod:

The exact solution for the force at point A is shown below. t^* = time for stress wave to travel through the rod

We now use a finite element mesh of ten 2-node truss elements to obtain the compressive force at point A.

**Transparency
14-15**

All elements uniformly spaced



Central difference method:

- The critical time step for this problem is

$$\Delta t_{cr} = L_e / c = t^* \left(\frac{1}{\text{number of elements}} \right)$$

$\Delta t > \Delta t_{cr}$ will produce an unstable solution

- We need to use the initial conditions as follows:


$$\begin{aligned} M^0 \ddot{U} + K^0 U &= R^0 \\ \downarrow \\ {}^0 \ddot{U}_i &= \frac{{}^0 R_i}{m_{ii}} \end{aligned}$$

**Transparency
14-16**


Transparency
14-17

- Using a time step equal to Δt_{cr} , we obtain the correct result:

- For this special case the exact solution is obtained

Transparency
14-18

- Using a time step equal to $\frac{1}{2} \Delta t_{cr}$, the solution is stable, but highly inaccurate.




Now consider the use of the trapezoidal rule:

- A stable solution is obtained with any choice of Δt .
- Either a consistent or lumped mass matrix may be used. We employ a lumped mass matrix in this analysis.

Transparency
14-19

Trapezoidal rule, $\Delta t = \Delta t_{cr}|_{CDM}$, initial conditions computed using $\underline{M}^0 \ddot{\underline{U}} = {}^0 \underline{R}$.

— The solution is inaccurate.




Transparency
14-20

Transparency
14-21


Trapezoidal rule, $\Delta t = \Delta t_{cr}|_{CDM}$, zero initial conditions.

— Almost same solution is obtained.


Transparency
14-22

Trapezoidal rule, $\Delta t = 2\Delta t_{cr}|_{CDM}$

— The solution is stable, although inaccurate.




Trapezoidal rule, $\Delta t = \frac{1}{2} \Delta t_{cr}|_{CDM}$





Transparency
14-23

The same phenomena are observed when a mesh of one hundred 2-node truss elements is employed.

— Here $\Delta t_{cr} = t^*/100$



Transparency
14-24

Transparency
14-25Trapezoidal rule, $\Delta t = \Delta t_{cr}|_{CDM}$ Transparency
14-26Now consider a two-dimensional model
of the rod:

For this mesh, $\Delta t_{cr} \neq t^*/(10 \text{ elements})$
because the element width is less than
the element length.

Transparency
14-27


If $\Delta t = t^*/(10 \text{ elements})$ is used, the solution diverges

— In element 5,

$$|\tau_{zz}| > \left(\frac{1000 \text{ N}}{0.01 \text{ m}^2} \right)$$

at $t = 1.9 t^*$

Example: Dynamic response of three degree-of-freedom system using central difference method

Transparency
14-28


$$\begin{aligned} k_L &= 1 \text{ lbf/ft} \\ m &= 1 \text{ slug} \end{aligned}$$

$${}^0\ddot{x}_1 = {}^0\ddot{x}_2 = {}^0\ddot{x}_3 = 0$$

$${}^0\dot{x}_1 = 0.555 \text{ ft/sec}$$

$${}^0\dot{x}_2 = 1.000 \text{ ft/sec}$$

$${}^0\dot{x}_3 = 1.247 \text{ ft/sec}$$




$$(\Delta t_{\text{crit}})_{\text{linear}} = 1.11 \text{ sec}$$

$$(\Delta t_{\text{crit}})_{\text{nonlinear}} = 0.14 \text{ sec}$$


Transparency
14-29

Results: Response of right mass




Transparency
14-30

Response of center mass:



Response of left mass:

Transparency
14-31




- : $\Delta = 0.05$ sec.
- : $\Delta = 0.15$ sec.


Force (lbf) in center truss:

Transparency
14-32

TIME	$\Delta t = 0.05$	$\Delta t = 0.15$
9.0	-0.666	-0.700
12.0	-0.804	-0.877
15.0	0.504	0.503
18.0	0.648	-0.100
21.0	-0.132	-0.059
24.0	-0.922	0.550

Transparency
14-33Example: 10 story tapered towerTransparency
14-34

Applied load (blast):



Purpose of analysis:

- Determine displacements, velocities at top of tower.
- Determine moments at base of tower.

Transparency
14-35

We use the trapezoidal rule and a lumped mass matrix in the following analysis.

We must make two decisions:

- Choose mesh (specifically the number of elements employed).
- Choose time step Δt .

Transparency
14-36

These two choices are closely related:

The mesh and time step to be used depend on the loading applied.

Transparency
14-37

Some observations:

- The choice of mesh determines the highest natural frequency (and corresponding mode shape) that is accurately represented in the finite element analysis.
- The choice of time step determines the highest frequency of the finite element mesh in which the response is accurately integrated during the time integration.

Transparency
14-38

- Hence, it is most effective to choose the mesh and time step such that the highest frequency accurately “integrated” is equal to the highest frequency accurately represented by the mesh.
- The applied loading can be represented as a Fourier series which displays the important frequencies to be accurately represented by the mesh.

Consider the Fourier representation of the load function:

$$f(t) = \frac{a_0}{2} + \sum_{n=1}^{\infty} (a_n \cos(2\pi f_n t) + b_n \sin(2\pi f_n t))$$

Including terms up to


case 1: $f_n = 17$ Hz

case 2: $f_n = 30$ Hz

The loading function is represented as shown next.

**Transparency
14-39**


Fourier approximation including terms up to 17 Hz:



**Transparency
14-40**

Transparency
14-41

Fourier approximation including terms up to 30 Hz:

Transparency
14-42

- We choose a 30 element mesh, a 60 element mesh and a 120 element mesh. All elements are 2-node Hermitian beam elements.

30 elements	60 elements	120 elements

Determine "accurate" natural frequencies represented by 30 element mesh:

From eigenvalue solutions of the 30 and 60 element meshes, we find

Transparency
14-43

mode number	natural frequencies (Hz)	
	30 element mesh	60 element mesh
1	1.914	1.914
2	4.815	4.828
3	8.416	8.480
4	12.38	12.58
5	16.79	17.27
6	21.45	22.47
7	26.18	28.08
8	30.56	29.80

↑ accurate
↓ inaccurate

Calculate time step:

$$T_{co} = \frac{1}{17} \text{ Hz} = .059 \text{ sec}$$

$$\Delta t = \frac{1}{20} T_{co} = .003 \text{ sec}$$

- A smaller time step would accurately "integrate" frequencies, which are not accurately represented by the mesh.
- A larger time step would not accurately "integrate" all frequencies which are accurately represented by the mesh.


Transparency
14-44

Transparency
14-45

Determine “accurate” natural frequencies represented by 60 element mesh:

From eigenvalue solutions of the 60 and 120 element meshes, we find

mode number	natural frequencies (Hz)	
	60 element mesh	120 element mesh
5	17.27	17.28
6	22.47	22.49
7	28.08	28.14
8	29.80	29.75
9	32.73	33.85
10	33.73	35.06
11	36.30	38.96


Transparency
14-46

Calculate time step:

$$T_{co} = \frac{1}{30} \text{ Hz} = .033 \text{ sec}$$

$$\Delta t = \frac{1}{20} T_{co} = .0017 \text{ sec}$$


- The meshes chosen correspond to the Fourier approximations discussed earlier:

30 element mesh \longleftrightarrow Fourier approximation including terms up to 17 Hz.

60 element mesh \longleftrightarrow Fourier approximation including terms up to 30 Hz.


Pictorially, at time 200 milliseconds, we have (note that the displacements are amplified for visibility):

Transparency
14-47




Pictorially, at time 400 milliseconds, we have (note that the displacements are amplified for visibility):

Transparency
14-48




Transparency
14-49


Consider the moment reaction at the base of the tower:

Transparency
14-50

Consider the horizontal displacement at the top of the tower:



Consider the horizontal velocity at the top of the tower:




Transparency
14-51

Comments:

- The high-frequency oscillation observed in the moment reaction from the 60 element mesh is probably inaccurate. We note that the frequency of the oscillation is about 110 Hz (this can be seen directly from the graph).
- The obtained solutions for the horizontal displacement at the top of the tower are virtually identical.

Transparency
14-52

Transparency
14-53Example: Simple pendulum undergoing large displacements


One truss element with tip concentrated mass is employed.

Transparency
14-54

Calculation of dynamic response:

- The trapezoidal rule is used to integrate the time response.
- Full Newton iterations are used to reestablish equilibrium during every time step.
- Convergence tolerance:
 $ETOL = 10^{-7}$
(a tight tolerance)


Choose $\Delta t = 0.1$ sec. The following response is obtained:



**Transparency
14-55**

The strain in the truss is plotted:

- An instability is observed.



**Transparency
14-56**


Transparency
14-57

- The instability is unchanged when we tighten our convergence tolerances.
- The instability is also observed when the BFGS algorithm is employed.
- Recall that the trapezoidal rule is unconditionally stable only in linear analysis.

Transparency
14-58


Choose $\Delta t = 0.025$ sec, using the original tolerance and the full Newton algorithm (without line searches).

- The analysis runs to completion.




The strain in the truss is stable:

Transparency
14-59




It is important that equilibrium be accurately satisfied at the end of each time step:

Transparency
14-60




Transparency
14-61

Although the solution obtained without equilibrium iterations is highly inaccurate, the solution is stable:

Transparency
14-62


Example: Pipe whip analysis:



all dimensions in inches

- Determine the transient response when a step load P is suddenly applied.

Finite element model:

Transparency
14-63

- The truss element incorporates a 3 inch gap.

Material properties:

Transparency
14-64

Pipe: $E = 2.698 \times 10^7$ psi
 $\nu = 0.3$
 $\sigma_y = 2.914 \times 10^4$ psi
 $E_T = 0$
 $\rho = 8.62 \times 10^{-3} \frac{\text{slug}}{\text{in}^3} = 7.18 \times 10^{-4} \frac{\text{lbf}\cdot\text{sec}^2}{\text{in}^4}$

Restraint: $E = 2.99 \times 10^7$ psi
 $\sigma_y = 3.80 \times 10^4$ psi
 $E_T = 0$

Transparency
14-65

The analysis is performed using

- Mode superposition (2 modes)
- Direct time integration

We use, for each analysis,

- Trapezoidal rule
- Consistent mass matrix

A convergence tolerance of
 $ETOL = 10^{-7}$ is employed.


Transparency
14-66

Eigenvalue solution :

Mode 1, natural frequency = 8.5 Hz



Mode 2, natural frequency = 53 Hz



Choice of time step:

We want to accurately integrate the first two modes:


$$\Delta t \doteq \frac{1}{20} T_{co} = \frac{1}{20} \left(\frac{1}{(\text{frequency of mode 2})} \right)$$

$$= .001 \text{ sec}$$

Note: This estimate is based solely on a linear analysis (i.e., before the pipe hits the restraint and while the pipe is still elastic).

**Transparency
14-67**


Determine the tip displacement:




**Transparency
14-68**


Transparency
14-69

Determine the moment at the built-in end of the beam:




**Slide
14-1**


Analysis of CRD housing with lower support

**Slide
14-2**



CRD housing tip deflection

Slide
14-3


$$\begin{aligned}R &= 22.27 \text{ in.} \\h &= 0.41 \text{ in.} \\\theta &= 26.67^\circ\end{aligned}$$

$$\begin{aligned}E &= 1.05 \times 10^7 \text{ lb/in}^2 \\v &= 0.3 \\\sigma_y &= 2.4 \times 10^4 \text{ lb/in}^2 \\E_T &= 2.1 \times 10^5 \text{ lb/in}^2 \\\rho &= 9.8 \times 10^{-2} \text{ lb/in}^3\end{aligned}$$

Ten 8-node axisymmetric els.
Newmark inte ($\delta = 0.55$, $\alpha = 0.276$)
 2×2 Gauss integration
consistent mass
 $\Delta t = 10\mu\text{sec}$, T.L.




Spherical cap nodes under uniform pressure loading

Slide
14-4


Dynamic elastic-plastic response of a spherical cap,
 p deformation independent

**Slide
14-5**




Response of the cap using consistent and lumped mass idealization

**Slide
14-6**




Effect of numbers of Gauss integration points on the cap response predicted


**Slide
14-7**




Analysis of fluid—structure interaction problem
(pipe test)

**Slide
14-8**



**Slide
14-9**


Finite element model

**Slide
14-10**


Topic 15

Use of Elastic Constitutive Relations in Total Lagrangian Formulation

Contents:

- Basic considerations in modeling material response
- Linear and nonlinear elasticity
- Isotropic and orthotropic materials
- One-dimensional example, large strain conditions
- The case of large displacement/small strain analysis, discussion of effectiveness using the total Lagrangian formulation
- Hyperelastic material model (Mooney-Rivlin) for analysis of rubber-type materials
- Example analysis: Solution of a rubber tensile test specimen
- Example analysis: Solution of a rubber sheet with a hole

Textbook:

6.4, 6.4.1

Reference:

The solution of the rubber sheet with a hole is given in

Bathe, K. J., E. Ramm, and E. L. Wilson, "Finite Element Formulations for Large Deformation Dynamic Analysis," *International Journal for Numerical Methods in Engineering*, 9, 353–386, 1975.

USE OF CONSTITUTIVE RELATIONS

Transparency
15-1

- We developed quite general kinematic relations and finite element discretizations, applicable to small or large deformations.
- To use these finite element formulations, appropriate constitutive relations must be employed.
- Schematically

$$\underline{K} = \int_V \underline{B}^T \underline{C} \underline{B} dV, \quad \underline{F} = \int_V \underline{B}^T \underline{\tau} dV$$

constitutive relations enter here

For analysis, it is convenient to use the classifications regarding the magnitude of deformations introduced earlier:

Transparency
15-2

- Infinitesimally small displacements
- Large displacements / large rotations, but small strains
- Large displacements / large rotations, and large strains

The applicability of material descriptions generally falls also into these categories.

**Transparency
15-3****Recall:**

- Materially-nonlinear-only (M.N.O.) analysis assumes (models only) infinitesimally small displacements.
 - The total Lagrangian (T.L.) and updated Lagrangian (U.L.) formulations can be employed for analysis of infinitesimally small displacements, of large displacements and of large strains (considering the analysis of 2-D and 3-D solids).
- All kinematic nonlinearities are fully included.


**Transparency
15-4****We may use various material descriptions:**

Material Model	Examples
Elastic	Almost all materials, for small enough stresses
Hyperelastic	Rubber
Hypoelastic	Concrete
Elastic-plastic	Metals, soils, rocks under high stresses
Creep	Metals at high temperatures
Viscoplastic	Polymers, metals

ELASTIC MATERIAL BEHAVIOR:



In linear, infinitesimal displacement, small strain analysis, we are used to employing

Transparency
15-5



For 1-D nonlinear analysis we can use

Transparency
15-6



Transparency
15-7

We can generalize the elastic material behavior using:

$$^t S_{ij} = {}_0 C_{ijrs} {}_0 \epsilon_{rs}$$

$${}^0 S_{ij} = {}_0 C_{ijrs} {}_0 \epsilon_{rs}$$

This material description is frequently employed with

- the usual constant material moduli used in infinitesimal displacement analysis
- rubber-type materials

Transparency
15-8

Use of constant material moduli, for an isotropic material:

$${}_0 C_{ijrs} = {}_0 C_{ijrs} = \lambda \delta_{ij} \delta_{rs} + \mu (\delta_{ir} \delta_{js} + \delta_{is} \delta_{jr})$$

Lamé constants:

$$\lambda = \frac{E \nu}{(1 + \nu)(1 - 2\nu)} , \quad \mu = \frac{E}{2(1 + \nu)}$$

Kronecker delta:

$$\delta_{ij} = \begin{cases} 0; & i \neq j \\ 1; & i = j \end{cases}$$

Examples:**Transparency
15-9**

2-D plane stress analysis:

$$\underline{\underline{C}} = \frac{E}{1 - \nu^2} \begin{bmatrix} 1 & \nu & 0 \\ \nu & 1 & 0 \\ 0 & 0 & \frac{1 - \nu}{2} \end{bmatrix}$$

corresponds to $\underline{\underline{S}}_{12} = \mu (\underline{\underline{\epsilon}}_{12} + \underline{\underline{\epsilon}}_{21})$

2-D axisymmetric analysis:


**Transparency
15-10**

$$\underline{\underline{C}} = \frac{E(1 - \nu)}{(1 + \nu)(1 - 2\nu)} \begin{bmatrix} 1 & \frac{\nu}{1 - \nu} & 0 & \frac{\nu}{1 - \nu} \\ \frac{\nu}{1 - \nu} & 1 & 0 & \frac{\nu}{1 - \nu} \\ 0 & 0 & \frac{1 - 2\nu}{2(1 - \nu)} & 0 \\ \frac{\nu}{1 - \nu} & \frac{\nu}{1 - \nu} & 0 & 1 \end{bmatrix}$$

Transparency
15-11

For an orthotropic material, we also use the usual constant material moduli:
Example: 2-D plane stress analysis

local coordinate system a-b $\underline{\underline{C}}_{\ell}^{-1} =$




$$\begin{bmatrix} \frac{1}{E_a} & -\frac{\nu_{ab}}{E_b} & 0 \\ 0 & \frac{1}{E_b} & 0 \\ \text{sym.} & & \frac{1}{G_{ab}} \end{bmatrix}$$

$$E_a \neq E_b$$

Transparency
15-12

Sample analysis: One-dimensional problem:

Material constants E, ν




$$\frac{E(1-\nu)}{(1+\nu)(1-2\nu)}$$

$$\text{Constitutive relation: } {}^t S_{11} = \tilde{E} {}^t \epsilon_{11}$$

Sample analysis: One-dimensional problem:

Material constants E, ν

In tension:



$$\text{Constitutive relation: } {}_0^t S_{11} = \tilde{E} {}_0^t \varepsilon_{11}$$


**Transparency
15-13**

Sample analysis: One-dimensional problem:

Material constants E, ν

In tension:

In compression:



$$\text{Constitutive relation: } {}_0^t S_{11} = \tilde{E} {}_0^t \varepsilon_{11}$$

**Transparency
15-14**

Transparency
15-15

We establish the force-displacement relationship:


$$\begin{aligned} {}^t\epsilon_{11} &= \underbrace{{}^0u_{1,1}}_{{}^tL - {}^0L} + \frac{1}{2}({}^0u_{1,1})^2 \\ &\quad \overline{{}^0L} \end{aligned}$$

$$= \frac{1}{2} \left[\left(\frac{{}^tL}{{}^0L} \right)^2 - 1 \right],$$

$$\begin{aligned} {}^tS_{11} &= \frac{{}^0\rho}{{}^t\rho} {}^0x_{1,1} {}^tT_{11} {}^0x_{1,1} \\ &= \frac{{}^tL}{{}^0L} \left(\frac{{}^0L}{{}^tL} \right) \frac{{}^tP}{{}^A} \left(\frac{{}^0L}{{}^tL} \right) = \frac{{}^0L}{{}^tL} \frac{{}^tP}{{}^A} \end{aligned}$$

Transparency
15-16

Using ${}^tL = {}^0L + {}^t\Delta$, ${}^tS_{11} = \tilde{E} {}^t\epsilon_{11}$, we find



This is not a realistic material description for large strains.

- The usual isotropic and orthotropic material relationships (constant E , ν , E_a , etc.) are mostly employed in large displacement/large rotation, but small strain analysis.
- Recall that the components of the 2nd Piola-Kirchhoff stress tensor and of the Green-Lagrange strain tensor are invariant under a rigid body motion (rotation) of the material.

**Transparency
15-17**

- Hence only the actual straining increases the components of the Green-Lagrange strain tensor and, through the material relationship, the components of the 2nd Piola-Kirchhoff stress tensor.
- The effect of rotating the material is included in the T.L. formulation,


$$\underline{\underline{\sigma}} = \int_V \underline{\underline{\delta B_L^T}} \underline{\underline{\delta S}}^0 dV$$

includes rotation invariant under a rigid body rotation

**Transparency
15-18**

Transparency
15-19

Pictorially:

Deformation to state 1
(small strain situation)Rigid rotation from
state 1 to state 2Transparency
15-20

For small strains,

$$\overset{1}{\epsilon}_{11}, \overset{1}{\epsilon}_{22}, \overset{1}{\epsilon}_{12} = \overset{1}{\epsilon}_{21} \ll 1,$$

$$\overset{0}{S}_{ij} = \overset{1}{C}_{ijrs} \overset{1}{\epsilon}_{rs},$$

a function of E, ν

$$\overset{1}{S}_{ij} \doteq \overset{1}{T}_{ij}$$



Also, since state 2 is reached by a
rigid body rotation,

$$\overset{2}{\epsilon}_{ij} = \overset{1}{\epsilon}_{ij}, \quad \overset{2}{S}_{ij} = \overset{1}{S}_{ij},$$

$$\overset{2}{T} = \underbrace{\mathbf{R}}_{\text{rotation matrix}} \overset{1}{T} \mathbf{R}^T$$


Applications:

- Large displacement / large rotation but small strain analysis of beams, plates and shells. These can frequently be modeled using 2-D or 3-D elements. Actual beam and shell elements will be discussed later.
- Linearized buckling analysis of structures.

**Transparency
15-21****Frame analysis:****Transparency
15-22****Axisymmetric shell:**

Transparency
15-23

General shell:

Transparency
15-24Hyperelastic material model:
formulation of rubber-type materials

$${}^t_0S_{ij} = \frac{\partial {}^t_0W}{\partial {}^t_0\varepsilon_{ij}}$$

$\underbrace{{}_0C_{ijrs}} \quad \underbrace{{}^t_0\varepsilon_{rs}}$

$$d_0S_{ij} = \underbrace{{}_0C_{ijrs}} \quad \underbrace{d_0\varepsilon_{rs}} \quad \frac{\partial^2 {}^t_0W}{\partial {}^t_0\varepsilon_{ij} \partial {}^t_0\varepsilon_{rs}}$$

where

t_0W = strain energy density function (per unit original volume)

Rubber is assumed to be an isotropic material, hence

$$\overset{t}{\delta}W = \text{function of } (I_1, I_2, I_3)$$

where the I_i 's are the invariants of the Cauchy-Green deformation tensor (with components $\overset{t}{C}_{ij}$):

$$I_1 = \overset{t}{C}_{ii}$$

$$I_2 = \frac{1}{2} (I_1^2 - \overset{t}{C}_{ij} \overset{t}{C}_{ij})$$

$$I_3 = \det(\overset{t}{C})$$

**Transparency
15-25**

Example: Mooney-Rivlin material law


$$\overset{t}{\delta}W = \underbrace{C_1}_{\text{material constants}} (I_1 - 3) + \underbrace{C_2}_{\text{material constants}} (I_2 - 3)$$

with

$$I_3 = 1 \quad \text{incompressibility constraint}$$

Note, in general, the displacement-based finite element formulations presented above should be extended to include the incompressibility constraint effectively. A special case, however, is the analysis of plane stress problems.

**Transparency
15-26**

Transparency
15-27Special case of Mooney-Rivlin law:
plane stress analysisTransparency
15-28

For this (two-dimensional) problem,

$$\underline{\underline{C}}^t = \begin{bmatrix} {}^tC_{11} & {}^tC_{12} & 0 \\ {}^tC_{21} & {}^tC_{22} & 0 \\ 0 & 0 & {}^tC_{33} \end{bmatrix}$$

Since the rubber is assumed to be incompressible, we set $\det(\underline{\underline{C}}^t)$ to 1 by choosing

$${}^tC_{33} = \frac{1}{({}^tC_{11} \cdot {}^tC_{22} - {}^tC_{12} \cdot {}^tC_{21})}$$

We can now evaluate I_1, I_2 :

$$I_1 = {}^t C_{11} + {}^t C_{22} + \frac{1}{({}^t C_{11} {}^t C_{22} - {}^t C_{12} {}^t C_{21})}$$

$$I_2 = {}^t C_{11} {}^t C_{22} + \frac{{}^t C_{11} + {}^t C_{22}}{({}^t C_{11} {}^t C_{22} - {}^t C_{12} {}^t C_{21})} \\ - \frac{1}{2} ({}^t C_{12})^2 - \frac{1}{2} ({}^t C_{21})^2$$

Transparency
15-29

The 2nd Piola-Kirchhoff stresses are

$$\begin{aligned} {}^t S_{ij} &= \frac{\partial {}^t W}{\partial {}^t \epsilon_{ij}} = 2 \frac{\partial {}^t W}{\partial {}^t C_{ij}} \quad (\text{remember } {}^t C_{ij} = 2 {}^t \epsilon_{ij} + \delta_{ij}) \\ &= 2 \frac{\partial}{\partial {}^t C_{ij}} \left[C_1 (I_1 - 3) + C_2 (I_2 - 3) \right] \\ &= 2 C_1 \frac{\partial I_1}{\partial {}^t C_{ij}} + 2 C_2 \frac{\partial I_2}{\partial {}^t C_{ij}} \end{aligned}$$

Transparency
15-30

Transparency
15-31

Performing the indicated differentiations gives

$$\begin{bmatrix} {}^t\!S_{11} \\ {}^t\!S_{22} \\ {}^t\!S_{12} \end{bmatrix} = 2 C_1 \left\{ \begin{bmatrix} 1 \\ 1 \\ 0 \end{bmatrix} - ({}^t\!C_{33})^2 \begin{bmatrix} {}^t\!C_{22} \\ {}^t\!C_{11} \\ -{}^t\!C_{12} \end{bmatrix} \right\}$$

$$+ 2 C_2 \left\{ {}^t\!C_{33} \begin{bmatrix} 1 \\ 1 \\ 0 \end{bmatrix} + [1 - ({}^t\!C_{33})^2 ({}^t\!C_{11} + {}^t\!C_{22})] \begin{bmatrix} {}^t\!C_{22} \\ {}^t\!C_{11} \\ -{}^t\!C_{12} \end{bmatrix} \right\}$$

This is the stress-strain relationship.

Transparency
15-32

We can also evaluate the tangent constitutive tensor ${}_0\!C_{ijrs}$ using

$$\begin{aligned} {}_0\!C_{ijrs} &= \frac{\partial^2 {}^t\!W}{\partial {}^t\!\epsilon_{ij} \partial {}^t\!\epsilon_{rs}} \\ &= 4 C_1 \frac{\partial^2 I_1}{\partial {}^t\!C_{ij} \partial {}^t\!C_{rs}} + 4 C_2 \frac{\partial^2 I_2}{\partial {}^t\!C_{ij} \partial {}^t\!C_{rs}} \end{aligned}$$

etc. For the Mooney-Rivlin law

Example: Analysis of a tensile test specimen:


Transparency
15-33

Mooney-Rivlin constants:

$$C_1 = .234 \text{ N/mm}^2$$

$$C_2 = .117 \text{ N/mm}^2$$


thickness = 1 mm



All dimensions in millimeters


Finite element mesh: Fourteen 8-node elements

Transparency
15-34




Transparency
15-35


Results: Force – deflection curves




Transparency
15-36

Final deformed mesh (force = 4 N):




Slide
15-1

Analysis of rubber sheet with hole

Slide
15-2


Finite element mesh

**Slide
15-3**




Static load-deflection curve for rubber sheet with hole

**Slide
15-4**



Deformed configuration drawn to scale of
rubber sheet with hole (static analysis)

**Slide
15-5**



Displacements versus time for rubber sheet with hole, T.L. solution

Topic 16

Use of Elastic Constitutive Relations in Updated Lagrangian Formulation

Contents:

- Use of updated Lagrangian (U.L.) formulation
- Detailed comparison of expressions used in total Lagrangian (T.L.) and U.L. formulations; strains, stresses, and constitutive relations
- Study of conditions to obtain in a general incremental analysis the same results as in the T.L. formulation, and vice versa
- The special case of elasticity
- The Almansi strain tensor
- One-dimensional example involving large strains
- Analysis of large displacement/small strain problems
- Example analysis: Large displacement solution of frame using updated and total Lagrangian formulations

Textbook:

6.4, 6.4.1

Example:

6.19

SO FAR THE USE OF
THE T.L. FORMULATION
WAS IMPLIED


Transparency
16-1

Now suppose that we wish to use the U.L. formulation in the analysis. We ask

- Is it possible to obtain, using the U.L. formulation, identically the same numerical results (for each iteration) as are obtained using the T.L. formulation?

In other words, the situation is

Program 1
<ul style="list-style-type: none"> • Only T.L. formulation is implemented <ul style="list-style-type: none"> — Constitutive relations are $\overset{t}{S}_{ij} = \text{function of displacements}$ $d\overset{t}{S}_{ij} = \overset{o}{C}_{ijrs} d\overset{o}{\epsilon}_{rs}$
Information obtained from physical laboratory experiments.



Transparency
16-2

Transparency
16-3

Program 2

- Only U.L. formulation is implemented
- Constitutive relations are
 $\overset{t}{T}_{ij} = \dots \rightarrow \textcircled{1}$
 $d_t S_{ij} = \dots \rightarrow \textcircled{2}$

Question:

How can we obtain with program 2 identically the same results as are obtained from program 1?

Transparency
16-4

To answer, we consider the linearized equations of motion:

$$\left. \int_{\partial V} {}^0 C_{ijrs} {}^0 e_{rs} \delta {}^0 e_{ij} {}^0 dV + \int_V {}^0 S_{ij} \delta {}^0 \eta_{ij} {}^0 dV \right]_{T.L.} \\ = {}^{t+\Delta t} \mathcal{R} - \int_V {}^0 S_{ij} \delta {}^0 e_{ij} {}^0 dV$$

$$\left. \int_V {}^t C_{ijrs} {}^t e_{rs} \delta {}^t e_{ij} {}^t dV + \int_V {}^t T_{ij} \delta {}^t \eta_{ij} {}^t dV \right]_{U.L.} \\ = {}^{t+\Delta t} \mathcal{R} - \int_V {}^t T_{ij} \delta {}^t e_{ij} {}^t dV$$

Terms used in the formulations:

T.L. formulation	U.L. formulation	Transformation
$\int_{^0V} ^0dV$	$\int_{^tV} ^t dV$	$^0dV = \frac{^t\rho}{\rho} ^t dV$
$^0e_{ij}, ^0\eta_{ij}$	$^t e_{ij}, ^t \eta_{ij}$	$^0e_{ij} = \frac{^tX_{r,i}}{^0X_{r,i}} \frac{^tX_{s,j}}{^0X_{s,j}} ^t e_{rs}$ $^0\eta_{ij} = \frac{^tX_{r,i}}{^0X_{r,i}} \frac{^tX_{s,j}}{^0X_{s,j}} ^t \eta_{rs}$
$\delta^0e_{ij}, \delta^0\eta_{ij}$	$\delta^t e_{ij}, \delta^t \eta_{ij}$	$\delta^0e_{ij} = \frac{^tX_{r,i}}{^0X_{r,i}} \frac{^tX_{s,j}}{^0X_{s,j}} \delta^t e_{rs}$ $\delta^0\eta_{ij} = \frac{^tX_{r,i}}{^0X_{r,i}} \frac{^tX_{s,j}}{^0X_{s,j}} \delta^t \eta_{rs}$

Transparency
16-5

Derivation of these kinematic relationships:

A fundamental property of ${}^0\varepsilon_{ij}$ is that

$${}^0\varepsilon_{ij} d^0x_i d^0x_j = \frac{1}{2} (({}^t ds)^2 - ({}^0 ds)^2)$$


Similarly,

$${}^{t+\Delta t} {}^0\varepsilon_{ij} d^0x_i d^0x_j = \frac{1}{2} (({}^{t+\Delta t} ds)^2 - ({}^0 ds)^2)$$

and

$${}^t \varepsilon_{rs} d^t x_r d^t x_s = \frac{1}{2} (({}^{t+\Delta t} ds)^2 - ({}^t ds)^2)$$

Transparency
16-6

Transparency
16-7

Fiber $d^0 \underline{x}$ of length $d^0 s$ moves to become $d^t \underline{x}$ of length $d^t s$.

Transparency
16-8

Hence, by subtraction, we obtain

$${}^0 \varepsilon_{ij} d^0 x_i d^0 x_j = {}^t \varepsilon_{rs} d^t x_r d^t x_s$$

Using $d^t \underline{x} = {}^0 \underline{X} d^0 \underline{x}$, we obtain

$${}^0 \varepsilon_{ij} d^0 x_i d^0 x_j = {}^t \varepsilon_{rs} {}^0 x_{r,i} {}^0 x_{s,j} d^0 x_i d^0 x_j$$

Since this relationship holds for arbitrary material fibers, we have

$${}^0 \varepsilon_{ij} = {}^0 x_{r,i} {}^0 x_{s,j} {}^t \varepsilon_{rs}$$

**Transparency
16-9**

Now we see that

$$\delta e_{ij} + \delta \eta_{ij} = \overset{t}{\delta}x_{r,i} \overset{t}{\delta}x_{s,j} t e_{rs} + \overset{t}{\delta}x_{r,i} \overset{t}{\delta}x_{s,j} t \eta_{rs}$$

Since the factors $\overset{t}{\delta}x_{r,i} \overset{t}{\delta}x_{s,j}$ do not contain the incremental displacements u_i , we have

$$\delta e_{ij} = \overset{t}{\delta}x_{r,i} \overset{t}{\delta}x_{s,j} t e_{rs} \leftarrow \text{linear in } u_i$$

$$\delta \eta_{ij} = \overset{t}{\delta}x_{r,i} \overset{t}{\delta}x_{s,j} t \eta_{rs} \leftarrow \text{quadratic in } u_i$$

In addition, we have

$$\delta_0 e_{ij} = \overset{t}{\delta}x_{r,i} \overset{t}{\delta}x_{s,j} \delta_t e_{rs}$$

$$\delta_0 \eta_{ij} = \overset{t}{\delta}x_{r,i} \overset{t}{\delta}x_{s,j} \delta_t \eta_{rs}$$

These follow because the variation is taken on the configuration $t + \Delta t$ and hence the factors $\overset{t}{\delta}x_{r,i} \overset{t}{\delta}x_{s,j}$ are taken as constant during the variation.

**Transparency
16-10**

Transparency
16-11

We also have

T.L. formulation	U.L. formulation	Transformation
${}^0S_{ij}$	${}^tT_{ij}$	${}^0S_{ij} = \frac{{}^0\rho}{{}^t\rho} {}^0x_{i,m} {}^tT_{mn} {}^0x_{j,n}$
${}^0C_{ijrs}$	${}^tC_{ijrs}$	${}^0C_{ijrs} = \frac{{}^0\rho}{{}^t\rho} {}^0x_{i,a} {}^0x_{j,b} {}^tC_{abpq} {}^0x_{r,p} {}^0x_{s,q}$ (To be derived below)

Transparency
16-12Consider the tangent constitutive tensors ${}^0C_{ijrs}$ and ${}^tC_{ijrs}$:

Recall that

$$\begin{aligned} d_0 S_{ij} &= {}^0C_{ijrs} d_0 \varepsilon_{rs} \\ d_t S_{ij} &= {}^tC_{ijrs} d_t \varepsilon_{rs} \end{aligned} \quad \text{differential increments}$$

Now we note that

$$\begin{aligned} d_0 S_{ij} &= \frac{{}^0\rho}{{}^t\rho} {}^0x_{i,a} {}^0x_{j,b} d_t S_{ab} \\ d_0 \varepsilon_{rs} &= {}^0x_{p,r} {}^0x_{q,s} d_t \varepsilon_{pq} \end{aligned}$$

Hence

$$\underbrace{\left(\frac{^0\rho}{^t\rho} \frac{^0x_{i,a}}{^0x_{j,b}} d_t S_{ab} \right)}_{d_0 S_{ij}} = \underbrace{^0C_{ijrs} \left(\frac{^tx_{p,r}}{^0x_{q,s}} d_t \epsilon_{pq} \right)}_{d_0 \epsilon_{rs}}$$

Solving for $d_t S_{ab}$ gives

$$d_t S_{ab} = \underbrace{\left(\frac{^t\rho}{^0\rho} \frac{^tx_{a,i}}{^0x_{b,j}} ^0C_{ijrs} \frac{^tx_{p,r}}{^0x_{q,s}} \right) d_t \epsilon_{pq}}_{^tC_{abpq}}$$

**Transparency
16-13**

And we therefore observe that the tangent material relationship to be used is

$$^tC_{abpq} = \frac{^t\rho}{^0\rho} \frac{^tx_{a,i}}{^0x_{b,j}} ^0C_{ijrs} \frac{^tx_{p,r}}{^0x_{q,s}}$$

**Transparency
16-14**

**Transparency
16-15**

Now compare each of the integrals appearing in the T.L. and U.L. equations of motion:

$$1) \int_{\text{0V}}^{\text{tV}} \overset{0}{\delta S_{ij}} \delta_0 e_{ij}^0 dV = \int_{\text{tV}}^{\text{tV}} \overset{t}{T_{ij}} \delta_t e_{ij}^t dV \quad ?$$

True, as we verify by substituting the established transformations:

$$\begin{aligned} & \int_{\text{0V}}^{\text{tV}} \left(\frac{0\rho}{\tau\rho} \overset{0}{x_{i,m}} \overset{t}{T}_{mn} \overset{0}{x_{j,n}} \right) (\overset{t}{x_{r,i}} \overset{0}{x_{s,j}} \delta_t e_{rs})^0 dV \\ &= \int_{\text{0V}}^{\text{tV}} \overset{t}{T}_{mn} \delta_t e_{rs} \left(\frac{0}{\tau} \overset{0}{x_{i,m}} \overset{t}{x_{r,i}} \right) \left(\frac{0}{\tau} \overset{0}{x_{j,n}} \overset{t}{x_{s,j}} \right) \frac{0\rho}{\tau\rho} \overset{0}{dV} \\ &= \int_{\text{tV}}^{\text{tV}} \overset{t}{T}_{mn} \delta_t e_{mn}^t dV \end{aligned}$$

**Transparency
16-16**

$$2) \int_{\text{0V}}^{\text{tV}} \overset{0}{\delta S_{ij}} \delta_0 \eta_{ij}^0 dV = \int_{\text{tV}}^{\text{tV}} \overset{t}{T_{ij}} \delta_t \eta_{ij}^t dV \quad ?$$

True, as we verify by substituting the established transformations:

$$\begin{aligned} & \int_{\text{0V}}^{\text{tV}} \left(\frac{0\rho}{\tau\rho} \overset{0}{x_{i,m}} \overset{t}{T}_{mn} \overset{0}{x_{j,n}} \right) (\overset{t}{x_{r,i}} \overset{0}{x_{s,j}} \delta_t \eta_{rs})^0 dV \\ &= \int_{\text{0V}}^{\text{tV}} \overset{t}{T}_{mn} \delta_t \eta_{rs} \left(\frac{0}{\tau} \overset{0}{x_{i,m}} \overset{t}{x_{r,i}} \right) \left(\frac{0}{\tau} \overset{0}{x_{j,n}} \overset{t}{x_{s,j}} \right) \frac{0\rho}{\tau\rho} \overset{0}{dV} \\ &= \int_{\text{tV}}^{\text{tV}} \overset{t}{T}_{mn} \delta_t \eta_{mn}^t dV \end{aligned}$$

$$3) \int_V {}^0C_{ijrs} {}^0e_{rs} \delta {}^0e_{ij} {}^0dV = \int_V {}^tC_{ijrs} {}^t e_{rs} \delta {}^t e_{ij} {}^t dV ?$$

True, as we verify by substituting the established transformations:

$$\begin{aligned} & \int_V \underbrace{\left(\frac{{}^0p}{{}^tp} {}^0x_{i,a} {}^0x_{j,b} {}^t C_{abpq} {}^0x_{r,p} {}^0x_{s,q} \right)}_{{}^0C_{ijrs}} \times \\ & \quad \underbrace{({}^tx_{k,r} {}^tx_{\ell,s} {}^t e_{k\ell})}_{{}^0e_{rs}} \underbrace{({}^tx_{m,i} {}^tx_{n,j} \delta {}^t e_{mn})}_{\delta {}^0e_{ij}} {}^0dV \\ & = \int_V {}^tC_{abpq} {}^t e_{pq} \delta {}^t e_{ab} {}^t dV \end{aligned}$$

**Transparency
16-17**

Provided the established transformations are used, the three integrals are identical. Therefore the resulting finite element discretizations will also be identical.

$$({}^t\underline{K}_L + {}^0\underline{K}_{NL}) \Delta \underline{U} = {}^{t+\Delta t} \underline{R} - {}^0\underline{F}$$

$$({}^t\underline{K}_L + {}^t\underline{K}_{NL}) \Delta \underline{U} = {}^{t+\Delta t} \underline{R} - {}^t\underline{F}$$

${}^0\underline{K}_L = {}^t\underline{K}_L$
${}^0\underline{K}_{NL} = {}^t\underline{K}_{NL}$
${}^0\underline{F} = {}^t\underline{F}$

The same holds for each equilibrium iteration.

**Transparency
16-18**

Transparency
16-19

Hence, to summarize once more, program 2 gives the same results as program 1, provided

- ① → The Cauchy stresses are calculated from

$${}^t T_{ij} = \frac{{}^t \rho}{\sigma} {}^t x_{i,m} {}^t S_{mn} {}^t x_{j,n}$$

- ② → The tangent stress-strain law is calculated from

$${}^t C_{ijrs} = \frac{{}^t \rho}{\sigma} {}^t x_{i,a} {}^t x_{j,b} {}^t C_{abpq} {}^t x_{r,p} {}^t x_{s,q}$$

Transparency
16-20

Conversely, assume that the material relationships for program 2 are given, hence, from laboratory experimental information, ${}^t T_{ij}$ and ${}^t C_{ijrs}$ for the U.L. formulation are given.

Then we can show that, provided the appropriate transformations

$${}^0 S_{ij} = \frac{{}^0 \rho}{\sigma} {}^0 x_{i,m} {}^t T_{mn} {}^0 x_{j,n}$$

$${}^0 C_{ijrs} = \frac{{}^0 \rho}{\sigma} {}^0 x_{i,a} {}^0 x_{j,b} {}^t C_{abpq} {}^0 x_{r,p} {}^0 x_{s,q}$$

are used in program 1 with the T.L. formulation, again the same numerical results are generated.

Hence the choice of formulation (T.L. vs. U.L.) is based solely on the numerical effectiveness of the methods:

- The \mathbf{B}_L^t matrix (U.L. formulation) contains less entries than the \mathbf{B}_L^0 matrix (T.L. formulation).
- The matrix product $\mathbf{B}^T \mathbf{C} \mathbf{B}$ is less expensive using the U.L. formulation.

Transparency
16-21

- If the stress-strain law is available in terms of \mathbf{S}^0 , then the T.L. formulation will be in general most effective.
 - Mooney-Rivlin material law
 - Inelastic analysis allowing for large displacements / large rotations, but small strains

Transparency
16-22

Transparency
16-23

THE SPECIAL CASE OF ELASTICITY

Consider that the components ${}^0C_{ijrs}$ are given:

$${}^0S_{ij} = {}^0C_{ijrs} {}^0\epsilon_{rs}$$

From the above discussion, to obtain the same numerical results with the U.L. formulation, we would employ

$${}^tT_{ij} = \frac{p}{\rho} {}^tX_{i,m} ({}^0C_{mnrs} {}^0\epsilon_{rs}) {}^tX_{j,n}$$

$${}^tC_{ijrs} = \frac{p}{\rho} {}^tX_{i,a} {}^tX_{j,b} {}^0C_{abpq} {}^tX_{r,p} {}^tX_{s,q}$$

Transparency
16-24

We see that in the above equation, the Cauchy stresses are related to the Green-Lagrange strains by a transformation acting only on the m and n components of ${}^0C_{mnrs}$.

However, we can write the total stress-strain law using a tensor, ${}^tC_{ijrs}^a$, by introducing another strain measure, namely the Almansi strain tensor,

$${}^tT_{ij} = {}^tC_{ijrs}^a \underbrace{{}^t\epsilon_{rs}^a}_{\text{Almansi strain tensor}}$$

$${}^tC_{ijrs}^a = \frac{p}{\rho} {}^tX_{i,a} {}^tX_{j,b} {}^tC_{abpq} {}^tX_{r,p} {}^tX_{s,q}$$

Transparency
16-25

Definitions of the Almansi strain tensor:

$${}^t\epsilon_{mn}^a = {}^0x_{i,m} {}^0x_{j,n} {}^0\epsilon_{ij}$$


$$\underline{{}^t\epsilon^a} = \frac{1}{2} (\mathbf{I} - {}^0X^T {}^0X)$$

$${}^t\epsilon_{ij}^a = \frac{1}{2} ({}^t u_{i,j} + {}^t u_{j,i} - \underbrace{{}^t u_{k,i}}_{{}^t u_{k,j}})$$

$$\frac{\partial {}^t u_k}{\partial {}^t x_j}$$


Transparency
16-26

- A symmetric strain tensor, ${}^t\epsilon_{ij}^a = {}^t\epsilon_{ji}^a$
- The components of $\underline{{}^t\epsilon^a}$ are not invariant under a rigid body rotation of the material.
- Hence, $\underline{{}^t\epsilon^a}$ is not a very useful strain measure, but we wanted to introduce it here briefly.

Transparency
16-27Example: Uniaxial strain

$$\delta^t \epsilon_{11} = \frac{t\Delta}{\delta L} + \frac{1}{2} \left(\frac{t\Delta}{\delta L} \right)^2$$

$$t^t \epsilon_{11}^a = \frac{t\Delta}{t L} - \frac{1}{2} \left(\frac{t\Delta}{t L} \right)^2$$

Transparency
16-28

It turns out that the use of $t^t C_{ijrs}^a$ with the Almansi strain tensor is effective when the U.L. formulation is used with a linear isotropic material law for large displacement / large rotation but small strain analysis.


- In this case, ${}^tC_{ijrs}^a$ may be taken as

$$\begin{aligned} {}^tC_{ijrs}^a &= \lambda \underbrace{\delta_{ij} \delta_{rs}} + \mu (\underbrace{\delta_{ir} \delta_{js} + \delta_{is} \delta_{jr}}) \\ &= {}^tC_{ijrs} \quad \text{constants} \end{aligned}$$

Practically the same response is calculated using the T.L. formulation with

$$\begin{aligned} {}^0C_{ijrs}^a &= \lambda \underbrace{\delta_{ij} \delta_{rs}} + \mu (\underbrace{\delta_{ir} \delta_{js} + \delta_{is} \delta_{jr}}) \\ &= {}^0C_{ijrs} \quad \text{constants} \end{aligned}$$

**Transparency
16-29**



Load-deflection curve for a shallow arch under concentrated load

**Slide
16-1**

Transparency
16-30

The reason that practically the same response is calculated is that the required transformations to obtain exactly the same response reduce to mere rotations:

Namely, in the transformations from ${}^tC_{ijrs}^a$ to ${}^0C_{abpq}$, and in the relation between ${}^0C_{ijrs}$ and ${}^tC_{ijrs}$,

$$\frac{{}^0\rho}{{}^t\rho} \doteq 1, [{}^0x_{i,j}] = {}^0X = {}^0R {}^tU \\ \doteq {}^0R$$

Transparency
16-31

However, when using constant material moduli (E, ν) for large strain analysis, with


$${}^tT_{ij} = \underbrace{{}^tC_{ijrs}^a} {}^t\epsilon_{rs}^a$$

and $\underbrace{\quad}_{\delta_{ij}\delta_{rs}} = \lambda \delta_{ij}\delta_{rs} + \mu (\delta_{ir}\delta_{is} + \delta_{is}\delta_{jr})$

$${}^tS_{ij} = \underbrace{{}^0C_{ijrs}} {}^0\epsilon_{rs}$$

totally different results are obtained.

Consider the 1-D problem already solved earlier:



Transparency
16-32

$$\tilde{E} = \frac{E(1-\nu)}{(1+\nu)(1-2\nu)}$$

Before, we used ${}^0S_{11} = \tilde{E} {}^0\epsilon_{11}$.

Now, we consider ${}^tT_{11} = \tilde{E} {}^t\epsilon_{11}^a$.

Here, we have


$${}^t\epsilon_{11}^a = \underbrace{{}^t u_{1,1}}_{\frac{{}^t L - {}^0 L}{{}^t L}} - \frac{1}{2}({}^t u_{1,1})^2 = \frac{1}{2} \left[1 - \left(\frac{{}^0 L}{{}^t L} \right)^2 \right]$$

Transparency
16-33

$${}^t T_{11} = \frac{{}^t P}{A}$$


Using ${}^t L = {}^0 L + {}^t \Delta$, ${}^t T_{11} = \tilde{E} {}^t \epsilon_{11}^a$, we obtain the force-displacement relationship.

Transparency
16-34



Transparency
16-35

Example: Corner under tip load




$$\begin{aligned} L &= 10.0 \text{ m} \\ h &= 0.2 \text{ m} \\ b &= 1.0 \text{ m} \\ E &= 207000 \text{ MPa} \\ \nu &= 0.3 \end{aligned}$$

$$\left. \begin{aligned} h \\ L \end{aligned} \right\} \frac{h}{L} = \frac{1}{50}$$

Finite element mesh: 51 two-dimensional
8-node elements

Transparency
16-36



Consider a nonlinear elastic analysis.
For what loads will the T.L. and U.L.
formulations give similar results?

Transparency
16-37


Transparency
16-38

- For large displacement/large rotation, but small strain conditions, the T.L. and U.L. formulations will give similar results.
- For large displacement/large rotation and large strain conditions, the T.L. and U.L. formulations will give different results, because different constitutive relations are assumed.

Transparency
16-39


Results: Force-deflection curve

- Over the range of loads shown, the T.L. and U.L. formulations give practically identical results
- The force-deflection curve obtained with two 4-node isoparametric beam elements is also shown.



**Deformed configuration for a load of 5 MN
(2-D elements are used):**

**Transparency
16-40**



Numerically, for a load of 5 MN, we have,
using the 2-D elements,

**Transparency
16-41**

	T.L. formulation	U.L. formulation
vertical tip displacement	15.289 m	15.282 m

The displacements and rotations are large.
However, the strains are small – they can
be estimated using strength of materials
formulas:

$$\epsilon_{\text{base}} = \frac{M(h/2)}{E I} \quad \text{where } M \doteq (5 \text{ MN})(7.5 \text{ m}) \\ \doteq 3\%$$

Topic 17

Modeling of Elasto-Plastic and Creep Response—Part I

Contents:

- Basic considerations in modeling inelastic response
 - A schematic review of laboratory test results, effects of stress level, temperature, strain rate
 - One-dimensional stress-strain laws for elasto-plasticity, creep, and viscoplasticity
 - Isotropic and kinematic hardening in plasticity
 - General equations of multiaxial plasticity based on a yield condition, flow rule, and hardening rule
 - Example of von Mises yield condition and isotropic hardening, evaluation of stress-strain law for general analysis
 - Use of plastic work, effective stress, effective plastic strain
 - Integration of stresses with subincrementation
 - Example analysis: Plane strain punch problem
 - Example analysis: Elasto-plastic response up to ultimate load of a plate with a hole
 - Computer-plotted animation: Plate with a hole
-

Textbook:

Section 6.4.2

Example:

6.20

References:

The plasticity computations are discussed in

Bathe, K. J., M. D. Snyder, A. P. Cimento, and W. D. Rolph III, "On Some Current Procedures and Difficulties in Finite Element Analysis of Elasto-Plastic Response," *Computers & Structures*, 12, 607–624, 1980.

References:
(continued)

Snyder, M. D., and K. J. Bathe, "A Solution Procedure for Thermo-Elastic-Plastic and Creep Problems," *Nuclear Engineering and Design*, 64, 49–80, 1981.

The plane strain punch problem is also considered in
Sussman, T., and K. J. Bathe, "Finite Elements Based on Mixed Interpolation for Incompressible Elastic and Inelastic Analysis," *Computers & Structures*, to appear.

- WE DISCUSSED IN THE PREVIOUS LECTURES THE MODELING OF ELASTIC MATERIALS
 - LINEAR STRESS - STRAIN LAW
 - NONLINEAR STRESS - STRAIN LAW
- THE T.L. AND U.L. FORMULATIONS
- WE NOW WANT TO DISCUSS THE MODELING OF INELASTIC MATERIALS
 - ELASTO-PLASTICITY AND CREEP
- WE PROCEED AS FOLLOWS :
 - WE DISCUSS BRIEFLY INELASTIC MATERIAL BEHAVIORS, AS OBSERVED IN LABORATORY TESTS
 - WE DISCUSS BRIEFLY MODELING OF SUCH RESPONSE IN 1-D ANALYSIS
 - WE GENERALIZE OUR MODELING CONSIDERATIONS TO 2-D AND 3-D STRESS SITUATIONS

Transparency
17-1

MODELING OF INELASTIC RESPONSE: ELASTO-PLASTICITY, CREEP AND VISCOPLASTICITY

- The total stress is not uniquely related to the current total strain. Hence, to calculate the response history, stress increments must be evaluated for each time (load) step and added to the previous total stress.

Transparency
17-2

- The differential stress increment is obtained as – assuming infinitesimally small displacement conditions –

$$d\sigma_{ij} = C_{ijrs}^E (de_{rs} - de_{rs}^{IN})$$

where

C_{ijrs}^E = components of the elasticity tensor

de_{rs} = total differential strain increment

de_{rs}^{IN} = inelastic differential strain increment

The inelastic response may occur rapidly or slowly in time, depending on the problem of nature considered.

Modeling:

- In plasticity, the model assumes that δ_{rs}^{IN} occurs instantaneously with the load application.
- In creep, the model assumes that δ_{rs}^{IN} occurs as a function of time.
- The actual response in nature can be modeled using plasticity and creep together, or alternatively using a viscoplastic material model.

Transparency
17-3

— In the following discussion we assume small strain conditions, hence

- we have either a materially-nonlinear-only analysis
- or a large displacement/large rotation but small strain analysis

Transparency
17-4

Transparency
17-5

- As pointed out earlier, for the large displacement solution we would use the total Lagrangian formulation and in the evaluation of the stress-strain laws simply use
 - Green-Lagrange strain component for the engineering strain components
 - and
 - 2nd Piola-Kirchhoff stress components for the engineering stress components

Transparency
17-6


Consider a brief summary of some observations regarding material response measured in the laboratory

- We only consider schematically what approximate response is observed; no details are given.
- Note that, regarding the notation, no time, t, superscript is used on the stress and strain variables describing the material behavior.

MATERIAL BEHAVIOR, “INSTANTANEOUS” RESPONSE

Transparency
17-7

Tensile Test: Assume




- small strain conditions
- behavior in compression is the same as in tension

Hence

$$e = \frac{\ell - \ell_0}{\ell_0}$$


$$\sigma = \frac{P}{A_0}$$

Transparency
17-8




Transparency
17-9

Effect of strain rate:



Transparency
17-10

Effect of temperature




MATERIAL BEHAVIOR, TIME-DEPENDENT RESPONSE

Transparency
17-11

- Now, at constant stress, inelastic strains develop.
- Important effect for materials when temperatures are high


Typical creep curve

Transparency
17-12




Transparency
17-13

Effect of stress level on creep strain



Transparency
17-14


Effect of temperature on creep strain




MODELING OF RESPONSE

Transparency
17-15



Consider a one-dimensional situation:



- We assume that the load is increased monotonically to its final value, P^* .
- We assume that the time is "long" so that inertia effects are negligible (static analysis).



Transparency
17-16

Transparency
17-17**Plasticity, uniaxial, bilinear material model**Transparency
17-18**Creep, power law material model:**

- The elastic strain is the same as in the plastic analysis (this follows from equilibrium).
- The inelastic strain is time-dependent and time is now an actual variable.

Viscoplasticity:

- Time-dependent response is modeled using a fluidity parameter γ :



$$\dot{\epsilon} = \frac{\dot{\sigma}}{E} + \underbrace{\gamma \left\langle \frac{\sigma}{\sigma_y} - 1 \right\rangle}_{\dot{\epsilon}^{VP}}$$

where

$$\langle \sigma - \sigma_y \rangle = \begin{cases} 0 & , \sigma \leq \sigma_y \\ \sigma - \sigma_y & , \sigma > \sigma_y \end{cases}$$

Transparency
17-19

Typical solutions (1-D specimen):



Transparency
17-20


Transparency
17-21

PLASTICITY


- So far we considered only loading conditions.
- Before we discuss more general multiaxial plasticity relations, consider unloading and cyclic loading assuming uniaxial stress conditions.

Transparency
17-22

- Consider that the load increases in tension, causes plastic deformation, reverses elastically, and again causes plastic deformation in compression.




Bilinear material assumption, isotropic hardening



Transparency
17-23

Bilinear material assumption, kinematic hardening



Transparency
17-24

Transparency
17-25

MULTIAXIAL PLASTICITY

To describe the plastic behavior in multiaxial stress conditions, we use

- A yield condition
- A flow rule
- A hardening rule

In the following, we consider isothermal (constant temperature) conditions.

Transparency
17-26

These conditions are expressed using a stress function ' F '.

Two widely used stress functions are the

von Mises function

Drucker-Prager function

von Mises

$$^tF = \frac{1}{2} ^tS_{ij} ^tS_{ij} - ^tK$$

$$^tS_{ij} = ^t\sigma_{ij} - \frac{^t\sigma_{mm}}{3} \delta_{ij}; \quad ^tK = \frac{1}{3} ^t\sigma_y^2$$

Transparency
17-27

Drucker-Prager

$$^tF = 3\alpha ^t\sigma_m + ^t\bar{\sigma} - k$$

$$^t\sigma_m = \frac{^t\sigma_{ii}}{3}; \quad ^t\bar{\sigma} = \sqrt{\frac{1}{2} ^tS_{ij} ^tS_{ij}}$$

We use both matrix notation and index notation:

Transparency
17-28

$$\underline{de^P} = \begin{bmatrix} de_{11}^P \\ de_{22}^P \\ de_{33}^P \\ de_{12}^P + de_{21}^P \\ de_{23}^P + de_{32}^P \\ de_{13}^P + de_{31}^P \end{bmatrix}, \quad \underline{d\sigma} = \begin{bmatrix} d\sigma_{11} \\ d\sigma_{22} \\ d\sigma_{33} \\ d\sigma_{12} \\ d\sigma_{23} \\ d\sigma_{31} \end{bmatrix}$$

matrix notation

note that both de_{12}^P
and de_{21}^P are added

Transparency
17-29

$$d\epsilon_{ij}^P = \left[\begin{array}{ccc} d\epsilon_{11}^P & d\epsilon_{12}^P & d\epsilon_{13}^P \\ d\epsilon_{21}^P & d\epsilon_{22}^P & d\epsilon_{23}^P \\ d\epsilon_{31}^P & d\epsilon_{32}^P & d\epsilon_{33}^P \end{array} \right] \quad \left. \right\} \text{index notation}$$

$$d\sigma_{ij} = \left[\begin{array}{ccc} d\sigma_{11} & d\sigma_{12} & d\sigma_{13} \\ d\sigma_{21} & d\sigma_{22} & d\sigma_{23} \\ d\sigma_{31} & d\sigma_{32} & d\sigma_{33} \end{array} \right]$$

Transparency
17-30The basic equations are then (von Mises tF):

1) Yield condition

$${}^tF ({}^t\sigma_{ij}, {}^t\kappa) = 0$$

↗ current stresses ↗ function of
 ↗ plastic strains

 tF is zero throughout the plastic response

- 1-D equivalent: $\frac{1}{3} ({}^t\sigma^2 - {}^t\sigma_y^2) = 0$
- ↗ uniaxial stress ↗ current stresses ↗ function of
 ↗ plastic strains.

2) Flow rule (associated rule):

$$d\mathbf{e}_{ij}^P = {}^t \lambda \frac{\partial {}^t F}{\partial {}^t \sigma_{ij}}$$

where ${}^t \lambda$ is a positive scalar.

- 1-D equivalent:

$$d\mathbf{e}_{11}^P = \frac{2}{3} {}^t \lambda {}^t \sigma$$

$$d\mathbf{e}_{22}^P = -\frac{1}{3} {}^t \lambda {}^t \sigma$$

$$d\mathbf{e}_{33}^P = -\frac{1}{3} {}^t \lambda {}^t \sigma$$

**Transparency
17-31**

3) Stress-strain relationship:

$$d\sigma = \underline{C}^E (\underline{de} - \underline{de}^P)$$

- 1-D equivalent:

$$d\sigma = E (d\mathbf{e}_{11} - d\mathbf{e}_{11}^P)$$

**Transparency
17-32**

Transparency
17-33Our goal is to determine \underline{C}^{EP} such that

$$d\underline{\sigma} = \underline{\underline{C}}^{EP} d\underline{e}$$

instantaneous elastic-plastic stress-strain matrix

Transparency
17-34General derivation of \underline{C}^{EP} :Define

$${}^t q_{ij} = \left. \frac{\partial {}^t F}{\partial {}^t \sigma_{ij}} \right|_{{}^t e_{ij}^P \text{ fixed}}$$

$${}^t p_{ij} = - \left. \frac{\partial {}^t F}{\partial {}^t e_{ij}^P} \right|_{{}^t \sigma_{ij} \text{ fixed}}$$

Transparency
17-35

Using matrix notation,

results from our
definition of the plastic
strain and stress
increment vectors

$$\underline{\underline{q}}^T = [{}^T q_{11} \mid {}^T q_{22} \mid {}^T q_{33} \mid \underline{\underline{2}} {}^T q_{12} \mid \underline{\underline{2}} {}^T q_{23} \mid \underline{\underline{2}} {}^T q_{31}]$$

$$\underline{\underline{p}}^T = [{}^T p_{11} \mid {}^T p_{22} \mid {}^T p_{33} \mid {}^T p_{12} \mid {}^T p_{23} \mid {}^T p_{31}]$$

Transparency
17-36

We now determine ${}^t\lambda$ in terms of $\underline{\underline{de}}$:

Using ${}^tF = 0$ during plastic deformations,

$$\begin{aligned} d^tF &= \frac{\partial {}^tF}{\partial {}^t\sigma_{ij}} d\sigma_{ij} + \frac{\partial {}^tF}{\partial {}^t\epsilon_{ij}^P} d\epsilon_{ij}^P \\ &= \underline{\underline{q}}^T d\underline{\sigma} - \underline{\underline{p}}^T \underbrace{d\underline{\epsilon}^P}_{{}^t\lambda \underline{\underline{q}}} \\ &= 0 \end{aligned}$$

Transparency
17-37

Also

$$\underline{\underline{q}}^T \underline{\underline{d}\sigma} = \underline{\underline{q}}^T (\underline{\underline{C}}^E (\underline{\underline{d}\epsilon} - \underline{\underline{d}\epsilon}^P))$$

The flow rule assumption may be written as

$$\underline{\underline{d}\epsilon}^P = {}^t\lambda \underline{\underline{q}}$$

Hence

$$\underline{\underline{q}}^T \underline{\underline{d}\sigma} = \boxed{\underline{\underline{q}}^T (\underline{\underline{C}}^E (\underline{\underline{d}\epsilon} - {}^t\lambda \underline{\underline{q}})) = {}^t\lambda \underline{\underline{p}}^T \underline{\underline{q}}}$$

from $d^tF = 0$

Transparency
17-38Solving the boxed equation for ${}^t\lambda$ gives

$${}^t\lambda = \frac{\underline{\underline{q}}^T \underline{\underline{C}}^E \underline{\underline{d}\epsilon}}{\underline{\underline{p}}^T \underline{\underline{q}} + \underline{\underline{q}}^T \underline{\underline{C}}^E \underline{\underline{q}}}$$

Hence we can determine the plastic strain increment from the total strain increment:

$$\underline{\underline{d}\epsilon}^P = \left(\frac{\underline{\underline{q}}^T \underline{\underline{C}}^E \underline{\underline{d}\epsilon}}{\underline{\underline{p}}^T \underline{\underline{q}} + \underline{\underline{q}}^T \underline{\underline{C}}^E \underline{\underline{q}}} \right) \underline{\underline{q}}$$

total strain increment

plastic strain increment

We can now solve for \underline{C}^{EP} :

$$d\underline{\sigma} = \underline{C}^E (\underline{de} - \underline{de}^P) \quad \begin{matrix} \text{function of } \underline{de} \\ \text{from above} \end{matrix}$$

$$\underline{C}^{EP} = \underline{C}^E - \frac{\underline{C}^E {}^t q (\underline{C}^E {}^t q)^T}{{}^t p^T {}^t q + {}^t q^T \underline{C}^E {}^t q}$$

Transparency
17-39

Example: Von Mises yield condition,
isotropic hardening

Two equivalent equations:

$${}^t \sigma_y = \frac{\sqrt{2}}{2} \sqrt{({}^t \sigma_1 - {}^t \sigma_2)^2 + ({}^t \sigma_2 - {}^t \sigma_3)^2 + ({}^t \sigma_3 - {}^t \sigma_1)^2}$$



principal stresses

$${}^t F = \frac{1}{2} {}^t s_{ij} {}^t s_{ij} - {}^t k ; \quad {}^t k = \frac{1}{3} {}^t \sigma_y^2$$

$\overbrace{s_{ij}}$

deviatoric stresses: ${}^t s_{ij} = {}^t \sigma_{ij} - \frac{{}^t \sigma_{mm}}{3} \delta_{ij}$

Transparency
17-40

Transparency
17-41Yield surface
for plane stressEnd view of
yield surfaceTransparency
17-42

We now compute the derivatives of the yield function.

First consider ${}^t p_{ij}$:

$${}^t p_{ij} = - \frac{\partial {}^t F}{\partial {}^t e_{ij}} \Big|_{\sigma_{ij} \text{ fixed}} = - \frac{\partial {}^t F}{\partial {}^t e_{ij}} \left(\frac{1}{2} {}^t s_{ij} {}^t s_{ij} - \frac{1}{3} {}^t \sigma_y^2 \right)$$

$$= \frac{2}{3} {}^t \sigma_y \frac{\partial {}^t \sigma_y}{\partial {}^t e_{ij}} \quad ({}^t \sigma_{ij} \text{ fixed implies } {}^t s_{ij} \text{ is fixed})$$


What is the relationship between $t\sigma_y$ and the plastic strains?

We answer this question using the concept of "plastic work".

- The plastic work (per unit volume) is the amount of energy that is unrecoverable when the material is unloaded.
- This energy has been used in creating the plastic deformations within the material.

Transparency
17-43

- Pictorially: 1-D example




Transparency
17-44

- In general, $tW_P = \int_0^{t e_P^t} \tau \sigma_{ij} de_{ij}^P$

Transparency
17-45

Consider 1-D test results: the current yield stress may be written in terms of the plastic work.

Transparency
17-46

We can now evaluate $t\sigma_{ij}$ — which corresponds to a generalization of the 1-D test results to multiaxial conditions.

$$\begin{aligned}
 t\sigma_{ij} &= \frac{2}{3} t\sigma_y \underbrace{\left(\frac{d^t\sigma_y}{d^tW_P} \frac{\partial^t W_P}{\partial^t e_{ij}^P} \right)}_{\frac{\partial^t \sigma_y}{\partial^t e_{ij}^P}} \\
 &= \frac{2}{3} t\sigma_y \left(\left(\frac{E E_T}{E - E_T} \right) \frac{1}{t\sigma_y} \right) (t\sigma_{ij}) \\
 &= \boxed{\frac{2}{3} \left(\frac{E E_T}{E - E_T} \right) t\sigma_{ij}}
 \end{aligned}$$

Alternatively, we could have used that

$$d^t W_P = {}^t \bar{\sigma} d^t \bar{e}^P$$

where

$${}^t \bar{\sigma} = \sqrt{\frac{3}{2} {}^t S_{ij} {}^t S_{ij}} \quad (\text{effective stress})$$

$$d^t \bar{e}^P = \sqrt{\frac{2}{3} d e_{ij}^P d e_{ij}^P} \quad (\text{increment in effective plastic strain})$$

and then the same result is obtained using

$${}^t p_{ij} = \frac{2}{3} {}^t \sigma_y \left(\frac{d^t \sigma_y}{d^t \bar{e}^P} \frac{\partial^t \bar{e}^P}{\partial^t e_{ij}^P} \right)$$

Transparency
17-47

Next consider ${}^t q_{ij}$:

Transparency
17-48

$$\begin{aligned} {}^t q_{ij} &= \frac{\partial^t F}{\partial^t \sigma_{ij}} \Big|_{e_{ij}^P \text{ fixed}} = \frac{\partial}{\partial^t \sigma_{ij}} \left(\frac{1}{2} {}^t S_{kl} {}^t S_{kl} - \frac{1}{3} {}^t \sigma_y^2 \right) \\ &= {}^t S_{kl} \frac{\partial^t S_{kl}}{\partial^t \sigma_{ij}} = {}^t S_{kl} \frac{\partial}{\partial^t \sigma_{ij}} \left({}^t \sigma_{kl} - \frac{{}^t \sigma_{mm}}{3} \delta_{kl} \right) \\ &= {}^t S_{kl} \left(\delta_{ik} \delta_{jl} - \frac{\delta_{ij} \delta_{kl}}{3} \right) \\ &= {}^t S_{ij} \quad (\text{note that } {}^t S_{kl} \delta_{kl} = {}^t S_{kk} = 0) \end{aligned}$$

Transparency
17-49We can now evaluate \underline{C}^{EP} :


$$\underline{C}^{EP} = \frac{E}{1 + \nu} \begin{bmatrix} de_{11} & de_{22} & 2de_{12} \\ \frac{1 - \nu}{1 - 2\nu} - \beta(t's_{11})^2 & \frac{\nu}{1 - 2\nu} - \beta t's_{11} t's_{22} & \dots - \beta t's_{11} t's_{12} \\ \dots & \dots & \dots \\ \frac{1 - \nu}{1 - 2\nu} - \beta(t's_{22})^2 & \dots - \beta t's_{22} t's_{12} & \dots \\ \dots & \dots & \dots \\ \frac{1}{2} - \beta(t's_{12})^2 & \dots & \dots \end{bmatrix}$$

symmetric

$$\text{where } \beta = \frac{3}{2} \frac{1}{t' \sigma_y^2} \left(\frac{1}{1 + \frac{2}{3} \frac{E E_T}{E - E_T} \frac{1 + \nu}{E}} \right)$$

Transparency
17-50Evaluation of the stresses at time $t + \Delta t$:

$$\begin{aligned} t + \Delta t \underline{\sigma} &= t \underline{\sigma} + \int_t^{t + \Delta t} d\underline{\sigma} \\ &= t \underline{\sigma} + \int_{t_e}^{t + \Delta t} \underline{C}^{EP} d\underline{e} \end{aligned}$$



The stress integration must be performed at each Gauss integration point.

**Transparency
17-51**

We can approximate the evaluation of this integral using the Euler forward method.

- Without subincrementation:

$$\int_{t_e}^{t+\Delta t_e} \underline{C}^{\text{EP}} \, d\underline{e} \doteq \underline{C}^{\text{EP}} \Big|_t \underbrace{\Delta \underline{e}}_{\Delta t_e} = \underline{C}^{\text{EP}} \Big|_t \frac{t+\Delta t_e - t_e}{\Delta t_e}$$


- With n subincrements:

$$\begin{aligned} \int_{t_e}^{t+\Delta t_e} \underline{C}^{\text{EP}} \, d\underline{e} &\doteq \underline{C}^{\text{EP}} \Big|_t \frac{\Delta \underline{e}}{n} \\ &+ \underline{C}^{\text{EP}} \Big|_{t+\Delta \tau} \frac{\Delta \underline{e}}{n} - \frac{\Delta t}{n} \\ &+ \dots \\ &+ \underline{C}^{\text{EP}} \Big|_{t+(n-1)\Delta \tau} \frac{\Delta \underline{e}}{n} \end{aligned}$$

**Transparency
17-52**

Transparency
17-53

Pictorially:

Transparency
17-54

Summary of the procedure used to calculate the total stresses at time $t + \Delta t$.

Given:

STRAIN = Total strains at time $t + \Delta t$

SIG = Total stresses at time t

EPS = Total strains at time t

(a) Calculate the strain increment

DELEPS:

$$\text{DELEPS} = \text{STRAIN} - \text{EPS}$$

- (b) Calculate the stress increment DELSIG, assuming elastic behavior:
- $$\text{DELSIG} = C^E * \text{DELEPS}$$

Transparency
17-55

- (c) Calculate TAU, assuming elastic behavior:

$$\text{TAU} = \text{SIG} + \text{DELSIG}$$

- (d) With TAU as the state of stress, calculate the value of the yield function F.

- (e) If $F(\text{TAU}) \leq 0$, the strain increment is elastic. In this case, TAU is correct; we return.

- (f) If the previous state of stress was plastic, set RATIO to zero and go to (g). Otherwise, there is a transition from elastic to plastic and RATIO (the portion of incremental strain taken elastically) has to be determined. RATIO is determined from

$$F(\text{SIG} + \text{RATIO} * \text{DELSIG}) = 0$$

since $F = 0$ signals the initiation of yielding.

Transparency
17-56

Transparency
17-57


- (g) Redefine TAU as the stress at start of yield

$\text{TAU} = \text{SIG} + \text{RATIO} * \text{DELSIG}$
and calculate the elastic-plastic strain increment

$$\text{DEPS} = (1 - \text{RATIO}) * \text{DELEPS}$$


- (h) Divide DEPS into subincrements DDEPS and calculate

$\text{TAU} \leftarrow \text{TAU} + \underline{\text{C}}^{\text{EP}} * \text{DDEPS}$
for all elastic-plastic strain subincrements.



Slide
17-1


Plane strain punch problem



Slide
17-2


Finite element model of punch problem

Slide
17-3




Solution of Boussinesq problem—2 pt. integration

Slide
17-4



Solution of Boussinesq problem—3 pt. Integration


Slide
17-5



Load-displacement curves for punch problem

Transparency
17-58

Limit load calculations:




- Plate is elasto-plastic.

Transparency
17-59


Elasto-plastic analysis:

Material properties (steel)




- This is an idealization, probably inaccurate for large strain conditions ($e > 2\%$).

TIME = 0
LOAD = 0.0 MPa




Computer Animation
Plate with hole

TIME = 41
LOAD = 512.5 MPa



TIME = 52
LOAD = 650.0 MPa



Topic 18

Modeling of Elasto-Plastic and Creep Response—Part II

Contents:

- Strain formulas to model creep strains
- Assumption of creep strain hardening for varying stress situations
- Creep in multiaxial stress conditions, use of effective stress and effective creep strain
- Explicit and implicit integration of stress
- Selection of size of time step in stress integration
- Thermo-plasticity and creep, temperature-dependency of material constants
- Example analysis: Numerical uniaxial creep results
- Example analysis: Collapse analysis of a column with offset load
- Example analysis: Analysis of cylinder subjected to heat treatment

Textbook:

Section 6.4.2

References:

The computations in thermo-elasto-plastic-creep analysis are described in

Snyder, M. D., and K. J. Bathe, "A Solution Procedure for Thermo-Elasto-Plastic and Creep Problems," *Nuclear Engineering and Design*, 64, 49–80, 1981.

Cesar, F., and K. J. Bathe, "A Finite Element Analysis of Quenching Processes," in *Numerical Methods for Non-Linear Problems*, (Taylor, C., et al. eds.), Pineridge Press, 1984.


References:
(continued)

The effective-stress-function algorithm is presented in
Bathe, K. J., M. Kojić, and R. Slavković, "On Large Strain Elasto-Plastic
and Creep Analysis," in *Finite Element Methods for Nonlinear Prob-*
lems (Bergan, P. G., K. J. Bathe, and W. Wunderlich, eds.), Springer-
Verlag, 1986.

The cylinder subjected to heat treatment is considered in
Rammerstorfer, F. G., D. F. Fischer, W. Mitter, K. J. Bathe, and M. D.
Snyder, "On Thermo-Elastic-Plastic Analysis of Heat-Treatment Pro-
cesses Including Creep and Phase Changes," *Computers & Structures*,
13, 771–779, 1981.

CREEP

We considered already uniaxial constant stress conditions. A typical creep law used is the power creep law
 $e^c = a_0 \sigma^{a_1} t^{a_2}$.



Transparency
18-1

Aside: other possible choices for the creep law are


- $e^c = a_0 \exp(a_1 \sigma) \left[1 - \exp\left(-a_2 \left(\frac{\sigma}{a_3}\right)^{a_4} t\right) \right] + a_5 t \exp(a_6 \sigma)$
- $e^c = (a_0 (\sigma)^{a_1}) (t^{a_2} + a_3 t^{a_4} + a_5 t^{a_6}) \exp\left(\frac{-a_7}{t_0 + 273.16}\right)$
temperature, in degrees C

Transparency
18-2

We will not discuss these choices further.

Transparency
18-3

The creep strain formula $e^c = a_0 \sigma^{a_1} t^{a_2}$ cannot be directly applied to varying stress situations because the stress history does not enter directly into the formula.

Transparency
18-4Example:

The assumption of strain hardening:

- The material creep behavior depends only on the current stress level and the accumulated total creep strain.
- To establish the ensuing creep strain, we solve for the “effective time” using the creep law:

$${}^t e^C = a_0 {}^t \sigma^{a_1} \bar{t}^{a_2} \quad \text{totally unrelated to the physical time}$$

(solve for \bar{t})

**Transparency
18-5**

The effective time is now used in the creep strain rate formula:


$$\begin{aligned} {}^t \dot{e}^C &= a_0 {}^t \sigma^{a_1} a_2 \bar{t}^{a_2-1} \\ &= a_0^{1/a_2} a_2 ({}^t \sigma)^{a_1/a_2} ({}^t e^C)^{\frac{a_2-1}{a_2}} \end{aligned}$$

Now the creep strain rate depends on the current stress level and on the accumulated total creep strain.


**Transparency
18-6**

Transparency
18-7**Pictorially:**


- Decrease in stress



- Increase in stress

Transparency
18-8

- Reverse in stress (cyclic conditions)



**Transparency
18-9**

MULTIAXIAL CREEP

The response is now obtained using

$$\underline{\sigma}^{t+\Delta t} = \underline{\sigma}^t + \int_{t_e}^{t+\Delta t} \underline{C}^E d(\underline{e} - \underline{e}^C)$$

As in plasticity, the creep strains in multiaxial conditions are obtained by a generalization of the 1-D test results.

**Transparency
18-10**

**Transparency
18-11**

We define

$${}^t\bar{\sigma} = \sqrt{\frac{3}{2} {}^t s_{ij} {}^t s_{ij}} \quad (\text{effective stress})$$

$${}^t\bar{e}^C = \sqrt{\frac{2}{3} {}^t e_{ij}^C {}^t e_{ij}^C} \quad (\text{effective strain})$$

and use these in the uniaxial creep law:

$$\dot{e}^C = a_0 \bar{\sigma}^{a_1} t^{a_2}$$

**Transparency
18-12**

The assumption that the creep strain rates are proportional to the current deviatoric stresses gives

$${}^t \dot{e}_{ij}^C = {}^t \gamma {}^t s_{ij} \quad (\text{as in von Mises plasticity})$$

${}^t \gamma$ is evaluated in terms of the effective stress and effective creep strain rate:

$${}^t \gamma = \frac{3}{2} \frac{{}^t \dot{e}^C}{{}^t \bar{\sigma}}$$

$$({}^t \dot{e}^C = a_0 a_2 ({}^t \bar{\sigma})^{a_1} (t)^{a_2-1})$$

Using matrix notation,

$$\underline{d\underline{\epsilon}^C} = (\overset{t}{\gamma}) \underbrace{(\underline{D} \overset{t}{\sigma})}_{\text{deviatoric stresses}} dt$$

Transparency
18-13

For 3-D analysis,

$$\underline{D} = \begin{bmatrix} \frac{2}{3} & -\frac{1}{3} & -\frac{1}{3} \\ -\frac{1}{3} & \frac{2}{3} & -\frac{1}{3} \\ -\frac{1}{3} & -\frac{1}{3} & \frac{2}{3} \end{bmatrix}$$

symmetric

- In creep problems, the time integration is difficult due to the high exponent on the stress.
- Solution instability arises if the Euler forward integration is used and the time step Δt is too large.
 - Rule of thumb:

Transparency
18-14


- Alternatively, we can use implicit integration, using the α -method:

$$\overset{t+\alpha\Delta t}{\underline{\sigma}} = (1 - \alpha) \overset{t}{\underline{\sigma}} + \alpha \overset{t+\Delta t}{\underline{\sigma}}$$

Transparency
18-15**Iteration algorithm:**

$$^{t+\Delta t} \underline{\sigma}_{(k)}^{(i-1)} = ^t \underline{\sigma} +$$

$$\underline{C}^E \left[\underline{\epsilon}^{(i-1)} - \Delta t ^{t+\alpha \Delta t} \gamma_{(k-1)}^{(i-1)} (\underline{D} ^{t+\alpha \Delta t} \underline{\sigma}_{(k-1)}^{(i-1)}) \right]$$


 k = iteration counter at each integration pointTransparency
18-16

- $\alpha \geq 1/2$ gives a stable integration algorithm. We use largely $\alpha = 1.0$.
- In practice, a form of Newton-Raphson iteration to accelerate convergence of the iteration can be used.

- Choice of time step Δt is now governed by need to converge in the iteration and accuracy considerations.
- Subincrementation can be employed.
- Relatively large time steps can be used with the effective-stress-function algorithm.

**Transparency
18-17**

THERMO-PLASTICITY-CREEP



**Transparency
18-18**

**Transparency
18-19**

Now we evaluate the stresses using

$$\underline{\sigma}_{t+\Delta t} = \underline{\sigma}_t + \int_{\underline{e}_t}^{\underline{e}_{t+\Delta t}} \underline{C}^E d(\underline{e} - \underline{e}^P - \underline{e}^C - \underline{e}^{TH})$$

thermal strains

Using the α -method,

$$\begin{aligned} \underline{\sigma}_{t+\Delta t} &= \underline{\sigma}_t + \underline{C}^E \{ [\underline{e} - \underline{e}^P - \underline{e}^C - \underline{e}^{TH}] \\ &\quad + [\underline{e}_t - \underline{e}^P - \underline{e}^C - \underline{e}^{TH}] \} \end{aligned}$$

where

$$\underline{e} = \underline{e}_{t+\Delta t} - \underline{e}_t$$

**Transparency
18-20**

and

$$\begin{aligned} \underline{e}^P &= \Delta t (\underline{\lambda}) (\underline{D}^{t+\alpha\Delta t} \underline{\sigma}_t) \\ \underline{e}^C &= \Delta t (\underline{\gamma}) (\underline{D}^{t+\alpha\Delta t} \underline{\sigma}_t) \\ \underline{e}_{ij}^{TH} &= (\underline{\alpha}^{t+\Delta t} \underline{\theta} - \underline{\alpha}^t \underline{\theta}) \delta_{ij} \end{aligned}$$

where

$\underline{\alpha}$ = coefficient of thermal expansion at time t

$\underline{\theta}$ = temperature at time t


The final iterative equation is

$$\begin{aligned} \underline{\sigma}_{(k)}^{(i-1)} = & \underline{C}^E \Big|_{t+\Delta t} \left[\underline{e}^{(i-1)} - t \underline{e}^P - t \underline{e}^C - t \underline{e}^{TH} \right. \\ & - \Delta t (\underline{\lambda}_{(k-1)}^{(i-1)}) (\underline{D}^{t+\alpha\Delta t} \underline{\sigma}_{(k-1)}^{(i-1)}) \\ & - \Delta t (\underline{\gamma}_{(k-1)}^{(i-1)}) (\underline{D}^{t+\alpha\Delta t} \underline{\sigma}_{(k-1)}^{(i-1)}) \\ & \left. - \underline{e}^{TH} \right] \end{aligned}$$

**Transparency
18-21**

and subincrementation may also be used.

Numerical uniaxial creep results:



**Transparency
18-22**

**Transparency
18-23**

The results are obtained using two solution algorithms:

- $\alpha = 0$, (no subincrementation)
- $\alpha = 1$, effective-stress-function procedure


In all cases, the MNO formulation is employed. Full Newton iterations without line searches are used with

$$\begin{aligned} \text{ETOL} &= 0.001 \\ \text{RTOL} &= 0.01 \\ \text{RNORM} &= 1.0 \text{ MN} \end{aligned}$$


**Transparency
18-24**

1) Constant load of 100 MPa

$$e^C = 4.1 \times 10^{-11} (\sigma)^{3.15} t^{0.8}$$




2) Stress increase from 100 MPa to 200 MPa



Transparency
18-25


Load function employed:



Transparency
18-26


Transparency
18-273) Stress reversal from 100 MPa to
-100 MPa

$$e^C = 4.1 \times 10^{-11} (\sigma)^{3.15} t^{0.8}$$


Transparency
18-28

4) Constant load of 100 MPa

$$e^C = 4.1 \times 10^{-11} (\sigma)^{3.15} t^{0.4}$$




5) Stress increase from 100 MPa to 200 MPa



Transparency
18-29


6) Stress reversal from 100 MPa to -100 MPa




Transparency
18-30

Transparency
18-31

Consider the use of $\alpha = 0$ for the "stress increase from 100 MPa to 200 MPa" problem solved earlier (case #5):


Transparency
18-32

Using $\Delta t = 50 \text{ hr}$, both algorithms converge, although the solution becomes less accurate for $\alpha = 0$.




Using $\Delta t = 100$ hr, $\alpha = 0$ does not converge at $t = 600$ hr. $\alpha = 1$ still gives good results.

Transparency
18-33



Example: Column with offset load

Transparency
18-34



Transparency
18-35

Goal: Determine the collapse response
for different material assumptions:

- Elastic
- Elasto-plastic
- Creep

The total Lagrangian formulation is
employed for all analyses.

Transparency
18-36

Solution procedure:

- The full Newton method without
line searches is employed with


$$\text{ETOL} = 0.001$$

$$\text{RTOL} = 0.01$$

$$\text{RNORM} = 1000 \text{ KN}$$

Mesh used: Ten 8-node quadrilateral elements

Transparency
18-37




Elastic response: We assume that the material law is approximated by

$$^tS_{ij} = ^tC_{ijrs} \ ^t\epsilon_{rs}$$

where the components $^tC_{ijrs}$ are constants determined by E and ν (as previously described).

Transparency
18-38



Transparency
18-39

Elasto-plastic response: Here we use

$$E_T = 0$$

$\sigma_y = 3000 \text{ KPa}$ (von Mises yield criterion)


and

$${}^{t+\Delta t} \underline{\underline{S}} = {}^t \underline{\underline{S}} + \int_0^{t+\Delta t} {}^t \underline{\underline{\varepsilon}} {}^0 \underline{\underline{C}}^{\text{EP}} d {}^t \underline{\underline{\varepsilon}}$$

where ${}^0 \underline{\underline{C}}^{\text{EP}}$ is the incremental elasto-plastic constitutive matrix.

Transparency
18-40

Plastic buckling is observed.



Creep response:

- Creep law: $\dot{\epsilon}^C = 10^{-16}(\bar{\sigma})^3 t$ (t in hours)
No plasticity effects are included.
- We apply a constant load of 2000 KN and determine the time history of the column.
- For the purposes of this problem, the column is considered to have collapsed when a lateral displacement of 2 meters is reached. This corresponds to a total strain of about 2 percent at the base of the column.

**Transparency
18-41**

We investigate the effect of different time integration procedures on the obtained solution:

- Vary Δt ($\Delta t = .5, 1, 2, 5$ hr.)
- Vary α ($\alpha = 0, 0.5, 1$)

**Transparency
18-42**


Transparency
18-43

Collapse times: The table below lists the first time (in hours) for which the lateral displacement of the column exceeds 2 meters.

	$\alpha = 0$	$\alpha = .5$	$\alpha = 1$
$\Delta t = .5$	100.0	100.0	98.5
$\Delta t = 1$	101	101	98
$\Delta t = 2$	102	102	96
$\Delta t = 5$	105	105	90


Transparency
18-44

Pictorially, using $\Delta t = 0.5$ hr., $\alpha = 0.5$, we have



Choose $\Delta t = 0.5$ hr.


- All solution points are connected with straight lines.



Transparency
18-45

Effect of α : Choose $\Delta t = 5$ hr.

- All solution points are connected with straight lines.




Transparency
18-46

Transparency
18-47

We conclude for this problem:


- As the time step is reduced, the collapse times given by $\alpha=0$, $\alpha=.5$, $\alpha=1$ become closer. For $\Delta t=.5$, the difference in collapse times is less than 2 hours.
- For a reasonable choice of time step, solution instability is not a problem.

**Slide
18-1**




Analysis of a cylinder subjected to heat treatment

**Slide
18-2**




Temperature-dependence of the specific heat,
 \hat{c} , and the heat conduction coefficient, k .

Slide
18-3




Temperature-dependence of the Young's modulus, E ,
Poisson's ratio, ν , and hardening modulus, E_T


Slide
18-4



Temperature-dependence of the material yield stress


Slide
18-5

Temperature-dependence of the instantaneous coefficient of thermal expansion (including volume change due to phase transformation), α

Slide
18-6


The calculated transient temperature field

Slide
18-7




Surface and core temperature; comparison between measured and calculated results

Slide
18-8



Measured residual stress field

Slide
18-9



Calculated residual stress field

Topic 19

Beam, Plate, and Shell Elements— Part I

Contents:

- Brief review of major formulation approaches
 - The degeneration of a three-dimensional continuum to beam and shell behavior
 - Basic kinematic and static assumptions used
 - Formulation of isoparametric (degenerate) general shell elements of variable thickness for large displacements and rotations
 - Geometry and displacement interpolations
 - The nodal director vectors
 - Use of five or six nodal point degrees of freedom, theoretical considerations and practical use
 - The stress-strain law in shell analysis, transformations used at shell element integration points
 - Shell transition elements, modeling of transition zones between solids and shells, shell intersections
-

Textbook:

Sections 6.3.4, 6.3.5

References:

The (degenerate) isoparametric shell and beam elements, including the transition elements, are presented and evaluated in

Bathe, K. J., and S. Bolourchi, "A Geometric and Material Nonlinear Plate and Shell Element," *Computers & Structures*, 11, 23–48, 1980.

Bathe, K. J., and L. W. Ho, "Some Results in the Analysis of Thin Shell Structures," in *Nonlinear Finite Element Analysis in Structural Mechanics*, (Wunderlich, W., et al., eds.), Springer-Verlag, 1981.

Bathe, K. J., E. Dvorkin, and L. W. Ho, "Our Discrete Kirchhoff and Isoparametric Shell Elements for Nonlinear Analysis—An Assessment," *Computers & Structures*, 16, 89–98, 1983.

References:
(continued)

The triangular flat plate/shell element is presented and also studied in

Bathe, K. J., and L. W. Ho, "A Simple and Effective Element for Analysis of General Shell Structures," *Computers & Structures*, 13, 673–681, 1981.

STRUCTURAL ELEMENTS

- Beams
- Plates
- Shells

We note that in geometrically nonlinear analysis, a plate (initially “flat shell”) develops shell action, and is analyzed as a shell.

Transparency
19-1


Various solution approaches have been proposed:

- Use of general beam and shell theories that include the desired nonlinearities.
 - With the governing differential equations known, variational formulations can be derived and discretized using finite element procedures.
 - Elegant approach, but difficulties arise in finite element formulations:
 - Lack of generality
 - Large number of nodal degrees of freedom

Transparency
19-2

Transparency
19-3

- Use of simple elements, but a large number of elements can model complex beam and shell structures.
 - An example is the use of 3-node triangular flat plate/membrane elements to model complex shells.
 - Coupling between membrane and bending action is only introduced at the element nodes.
 - Membrane action is not very well modeled.

Transparency
19-4Example:

- Isoparametric (degenerate) beam and shell elements.
 - These are derived from the 3-D continuum mechanics equations that we discussed earlier, but the basic assumptions of beam and shell behavior are imposed.
 - The resulting elements can be used to model quite general beam and shell structures.

Transparency
19-5

We will discuss this approach in some detail.

Basic approach:

- Use the total and updated Lagrangian formulations developed earlier.

Transparency
19-6

Transparency
19-7

We recall, for the T.L. formulation,

$$\int_{\Omega_V} {}^{t+\Delta t} \delta {}^0 S_{ij} {}^0 \epsilon_{ij} {}^0 dV = {}^{t+\Delta t} R$$

Linearization

$$\begin{aligned} & \int_{\Omega_V} {}^0 C_{ijrs} {}^0 e_{rs} \delta {}^0 e_{ij} {}^0 dV + \int_{\Omega_V} {}^0 S_{ij} \delta {}^0 \eta_{ij} {}^0 dV \\ &= {}^{t+\Delta t} R - \int_{\Omega_V} {}^0 S_{ij} \delta {}^0 e_{ij} {}^0 dV \end{aligned}$$

Transparency
19-8

Also, for the U.L. formulation,

$$\int_{\Omega_V} {}^t S_{ij} \delta {}^{t+\Delta t} {}^t \epsilon_{ij} {}^t dV = {}^{t+\Delta t} R$$

Linearization

$$\begin{aligned} & \int_{\Omega_V} {}^t C_{ijrs} {}^t e_{rs} \delta {}^t e_{ij} {}^t dV + \int_{\Omega_V} {}^t T_{ij} \delta {}^t \eta_{ij} {}^t dV \\ &= {}^{t+\Delta t} R - \int_{\Omega_V} {}^t T_{ij} \delta {}^t e_{ij} {}^t dV \end{aligned}$$

- Impose on these equations the basic assumptions of beam and shell action:


- 1) Material particles originally on a straight line normal to the mid-surface of the beam (or shell) remain on that straight line throughout the response history.

**Transparency
19-9**

For beams, “plane sections initially normal to the mid-surface remain plane sections during the response history”.

The effect of transverse shear deformations is included, and hence the lines initially normal to the mid-surface do not remain normal to the mid-surface during the deformations.

**Transparency
19-10**

Transparency
19-11Transparency
19-12

- 2) The stress in the direction “normal” to the beam (or shell) mid-surface is zero throughout the response history.

Note that here the stress along the material fiber that is initially normal to the mid-surface is considered; because of shear deformations, this material fiber does not remain exactly normal to the mid-surface.

- 3) The thickness of the beam (or shell) remains constant (we assume small strain conditions but allow for large displacements and rotations).


FORMULATION OF ISOPARAMETRIC (DEGENERATE) SHELL ELEMENTS

Transparency
19-13

- To incorporate the geometric assumptions of “straight lines normal to the mid-surface remain straight”, and of “the shell thickness remains constant” we use the appropriate geometric and displacement interpolations.
- To incorporate the condition of “zero stress normal to the mid-surface” we use the appropriate stress-strain law.


Shell element geometry Example: 9-node element

Transparency
19-14



Transparency
19-15**Element geometry definition:**

- Input mid-surface nodal point coordinates.
- Input all nodal director vectors at time 0.
- Input thicknesses at nodes.

Transparency
19-16

- Isoparametric coordinate system (r, s, t) :
 - The coordinates r and s are measured in the mid-surface defined by the nodal point coordinates (as for a curved membrane element).
 - The coordinate t is measured in the direction of the director vector at every point in the shell.

Interpolation of geometry at time 0:

$$\underbrace{\mathbf{x}_i^0}_{\begin{array}{l} \text{material} \\ \text{particle} \\ \text{with isoparametric} \\ \text{coordinates } (r, s, t) \end{array}} = \underbrace{\sum_{k=1}^N h_k \mathbf{x}_i^k}_{\begin{array}{l} \text{mid-surface} \\ \text{only} \end{array}} + \frac{t}{2} \underbrace{\sum_{k=1}^N a_k h_k \mathbf{V}_{ni}^k}_{\text{effect of shell thickness}}$$

h_k = 2-D interpolation functions (as for 2-D plane stress, plane strain and axisymmetric elements)

\mathbf{x}_i^k = nodal point coordinates

\mathbf{V}_{ni}^k = components of \mathbf{V}_n^k


Transparency
19-17

Similarly, at time t ,

$$\mathbf{x}_i^t = \sum_{k=1}^N h_k \mathbf{x}_i^k + \frac{t}{2} \sum_{k=1}^N a_k h_k \mathbf{V}_{ni}^k$$

t-coordinate

The nodal point coordinates and director vectors have changed.



Transparency
19-18

**Transparency
19-19**

To obtain the displacements of any material particle,

$${}^t u_i = {}^t x_i - {}^0 x_i$$

Hence

$${}^t u_i = \sum_{k=1}^N h_k {}^t u_i^k + \frac{t}{2} \sum_{k=1}^N a_k h_k ({}^t V_{ni}^k - {}^0 V_{ni}^k)$$

where

$${}^t u_i^k = {}^t x_i^k - {}^0 x_i^k \quad (\text{disp. of nodal point } k)$$

${}^t V_{ni}^k - {}^0 V_{ni}^k$ = change in direction cosines of director vector at node k

**Transparency
19-20**

The incremental displacements from time t to time $t+\Delta t$ are, similarly, for any material particle in the shell element,

$$\begin{aligned} u_i &= {}^{t+\Delta t} x_i - {}^t x_i \\ &= \sum_{k=1}^N h_k u_i^k + \frac{\Delta t}{2} \sum_{k=1}^N a_k h_k V_{ni}^k \end{aligned}$$

where

u_i^k = incremental nodal point displacements

$V_{ni}^k = {}^{t+\Delta t} V_{ni}^k - {}^t V_{ni}^k$ = incremental change in direction cosines of director vector from time t to time $t + \Delta t$


To develop the strain-displacement transformation matrices for the T.L. and U.L. formulations, we need

- the coordinate interpolations for the material particles (0x_i , ${}^t x_i$).
- the interpolation of incremental displacements from the incremental nodal point displacements and rotations.

Hence, express the V_{ni}^k in terms of nodal point rotations.

**Transparency
19-21**

We define at each nodal point k the vectors ${}^0V_1^k$ and ${}^0V_2^k$:



**Transparency
19-22**


$${}^0V_1^k = \frac{{}^0e_2 \times {}^0V_n^k}{\|{}^0e_2 \times {}^0V_n^k\|_2}, \quad {}^0V_2^k = {}^0V_n^k \times {}^0V_1^k$$

The vectors ${}^0V_1^k$, ${}^0V_2^k$ and ${}^0V_n^k$ are therefore mutually perpendicular.

**Transparency
19-23**

Then let α_k and β_k be the rotations about ${}^tV_1^k$ and ${}^tV_2^k$. We have, for small α_k , β_k ,

$$V_n^k = - {}^tV_2^k \alpha_k + {}^tV_1^k \beta_k$$



**Transparency
19-24**

Hence, the incremental displacements of any material point in the shell element are given in terms of incremental nodal point displacements and rotations

$$u_i = \sum_{k=1}^N h_k u_i^k + \frac{t}{2} \sum_{k=1}^N a_k h_k [-{}^tV_{2i}^k \alpha_k + {}^tV_{1i}^k \beta_k]$$

Once the incremental nodal point displacements and rotations have been calculated from the solution of the finite element system equilibrium equations, we calculate the new director vectors using

$${}^{t+\Delta t} \underline{V}_n^k = {}^t \underline{V}_n^k + \int_{\alpha_k, \beta_k} (-{}^t \underline{V}_2^k d\alpha_k + {}^t \underline{V}_1^k d\beta_k)$$

→ and normalize length


**Transparency
19-25**

Nodal point degrees of freedom:

- We have only five degrees of freedom per node:
 - three translations in the Cartesian coordinate directions
 - two rotations referred to the local nodal point vectors ${}^t \underline{V}_1^k$, ${}^t \underline{V}_2^k$
- The nodal point vectors ${}^t \underline{V}_1^k$, ${}^t \underline{V}_2^k$ change directions in a geometrically nonlinear solution.


**Transparency
19-26**

**Transparency
19-27**




— Node k is shared
by four shell elements

**Transparency
19-28**



— Node k is shared
by four shell elements
— One director vector
 \underline{v}_n^k at node k
— No physical stiffness
corresponding to
rotation about \underline{v}_n^k .



**Transparency
19-29**

- If only shell elements connect to node k , and the node is not subjected to boundary prescribed rotations, we only assign five local degrees of freedom to that node.
- We transform the two nodal rotations to the three Cartesian axes in order to
 - connect a beam element (three rotational degrees of freedom) or
 - impose a boundary rotation (other than α_k or β_k) at that node.

**Transparency
19-30**

**Transparency
19-31**

- The above interpolations of 0x_i , ${}^t x_i$, u_i are employed to establish the strain-displacement transformation matrices corresponding to the Cartesian strain components, as in the analysis of 3-D solids.

**Transparency
19-32**

- Using the expression ${}^0e_{ij}$ derived earlier the exact linear strain-displacement matrix 0B_L is obtained.

However, using $\frac{1}{2} {}^0u_{k,i} {}^0u_{k,j}$ to develop the nonlinear strain-displacement matrix ${}^t B_{NL}$, only an approximation to the exact second-order strain-displacement rotation expression is obtained because the internal element displacements depend nonlinearly on the nodal point rotations.


The same conclusion holds for the U.L. formulation.

**Transparency
19-33**

- We still need to impose the condition that the stress in the direction “normal” to the shell mid-surface is zero.

We use the direction of the director vector as the “normal direction.”

**Transparency
19-34**



$$\underline{\bar{e}}_r = \frac{\underline{e}_s \times \underline{e}_t}{\|\underline{e}_s \times \underline{e}_t\|_2}, \quad \underline{\bar{e}}_s = \underline{e}_t \times \underline{\bar{e}}_r$$

We note: \underline{e}_r , \underline{e}_s , \underline{e}_t are not mutually perpendicular in general.

$\underline{\bar{e}}_r$, $\underline{\bar{e}}_s$, \underline{e}_t are constructed to be mutually perpendicular.

Transparency
19-35

Then the stress-strain law used is, for a linear elastic material,

$$\underline{C}_{sh} = \underline{Q}_{sh}^T \left(\frac{E}{1 - \nu^2} \begin{bmatrix} 1 & \nu & 0 & 0 & 0 \\ 1 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 \\ 0 & \frac{1-\nu}{2} & 0 & 0 & 0 \\ \text{symmetric} & k\left(\frac{1-\nu}{2}\right) & 0 & 0 & k\left(\frac{1-\nu}{2}\right) \end{bmatrix} \right) \underline{Q}_{sh}$$

k = shear correction factor

Transparency
19-36

where

$$\underline{Q}_{sh} = \begin{bmatrix} (\ell_1)^2 & (m_1)^2 & (n_1)^2 & \ell_1 m_1 & m_1 n_1 & n_1 \ell_1 \\ \vdots & \vdots & \vdots & \vdots & \vdots & \vdots \\ \text{row 4} & 2\ell_1 \ell_2 & 2m_1 m_2 & 2n_1 n_2 & \ell_1 m_2 + \ell_2 m_1 & m_1 n_2 + m_2 n_1 & n_1 \ell_2 + n_2 \ell_1 \\ \vdots & \vdots & \vdots & \vdots & \vdots & \vdots & \vdots \end{bmatrix}$$

using

$$\begin{array}{l|l|l} \ell_1 = \cos(\underline{e}_1, \underline{\bar{e}}_r) & m_1 = \cos(\underline{e}_2, \underline{\bar{e}}_r) & n_1 = \cos(\underline{e}_3, \underline{\bar{e}}_r) \\ \ell_2 = \cos(\underline{e}_1, \underline{\bar{e}}_s) & m_2 = \cos(\underline{e}_2, \underline{\bar{e}}_s) & n_2 = \cos(\underline{e}_3, \underline{\bar{e}}_s) \\ \ell_3 = \cos(\underline{e}_1, \underline{\bar{e}}_t) & m_3 = \cos(\underline{e}_2, \underline{\bar{e}}_t) & n_3 = \cos(\underline{e}_3, \underline{\bar{e}}_t) \end{array}$$


- The columns and rows 1 to 3 in C_{sh} reflect that the stress “normal” to the shell mid-surface is zero.
- The stress-strain matrix for plasticity and creep solutions is similarly obtained by calculating the stress-strain matrix as in the analysis of 3-D solids, and then imposing the condition that the stress “normal” to the mid-surface is zero.

Transparency
19-37

- Regarding the kinematic description of the shell element, transition elements can also be developed.
- Transition elements are elements with some mid-surface nodes (and associated director vectors and five degrees of freedom per node) and some top and bottom surface nodes (with three translational degrees of freedom per node). These elements are used
 - to model shell-to-solid transitions
 - to model shell intersections


Transparency
19-38

Transparency
19-39




Transparency
19-40

a) Shell intersection



b) Solid-shell intersection



Topic 20

Beam, Plate, and Shell Elements— Part II

Contents:

- Formulation of isoparametric (degenerate) beam elements for large displacements and rotations
- A rectangular cross-section beam element of variable thickness; coordinate and displacement interpolations
- Use of the nodal director vectors
- The stress-strain law
- Introduction of warping displacements
- Example analysis: 180 degrees, large displacement twisting of a ring
- Example analysis: Torsion of an elastic-plastic cross-section
- Recommendations for the use of isoparametric beam and shell elements
- The phenomena of shear and membrane locking as observed for certain elements
- Study of solutions of straight and curved cantilevers modeled using various elements
- An effective 4-node shell element (the MITC4 element) for analysis of general shells
- The patch test, theoretical and practical considerations
- Example analysis: Solution of a three-dimensional spherical shell
- Example analysis: Solution of an open box
- Example analysis: Solution of a square plate, including use of distorted elements
- Example analysis: Solution of a 30-degree skew plate
- Example analysis: Large displacement solution of a cantilever

Contents:
(continued)

- **Example analysis: Collapse analysis of an I-beam in torsion**
 - **Example analysis: Collapse analysis of a cylindrical shell**
-

Textbook:

Sections 6.3.4, 6.3.5

Example:

6.18

References:

The displacement functions to account for warping in the rectangular cross-section beam are introduced in

Bathe, K. J., and A. Chaudhary, "On the Displacement Formulation of Torsion of Shafts with Rectangular Cross-Sections," *International Journal for Numerical Methods in Engineering*, 18, 1565–1568, 1982.

The 4-node and 8-node shell elements based on mixed interpolation (i.e., the MITC4 and MITC8 elements) are developed and discussed in

Dvorkin, E., and K. J. Bathe, "A Continuum Mechanics Based Four-Node Shell Element for General Nonlinear Analysis," *Engineering Computations*, 1, 77–88, 1984.

Bathe, K. J., and E. Dvorkin, "A Four-Node Plate Bending Element Based on Mindlin/Reissner Plate Theory and a Mixed Interpolation," *International Journal for Numerical Methods in Engineering*, 21, 367–383, 1985.

Bathe, K. J., and E. Dvorkin, "A Formulation of General Shell Elements—The Use of Mixed Interpolation of Tensorial Components," *International Journal for Numerical Methods in Engineering*, in press.

The I-beam analysis is reported in

Bathe, K. J., and P. M. Wiener, "On Elastic-Plastic Analysis of I-Beams in Bending and Torsion," *Computers & Structures*, 17, 711–718, 1983.

The beam formulation is extended to a pipe element, including ovalization effects, in

Bathe, K. J., C. A. Almeida, and L. W. Ho, "A Simple and Effective Pipe Elbow Element—Some Nonlinear Capabilities," *Computers & Structures*, 17, 659–667, 1983.

FORMULATION OF ISOPARAMETRIC (DEGENERATE) BEAM ELEMENTS

Transparency
20-1


- The usual Hermitian beam elements (cubic transverse displacements, linear longitudinal displacements) are usually most effective in the linear analysis of beam structures.
- When in the following discussion we refer to a “beam element” we always mean the “isoparametric beam element.”

- The isoparametric formulation can be effective for the analysis of
 - Curved beams
 - Geometrically nonlinear problems
 - Stiffened shell structures
(isoparametric beam and shell elements are coupled compatibly)
- The formulation is analogous to the formulation of the isoparametric (degenerate) shell element.


Transparency
20-2

Transparency
20-3

Consider a beam element with a rectangular cross-section:


Transparency
20-4

Consider a beam element with a rectangular cross-section:




Consider a beam element with a rectangular cross-section:

**Transparency
20-5**



Consider a beam element with a rectangular cross-section:

**Transparency
20-6**



Transparency
20-7

The coordinates of the material particles of the beam are interpolated as

$$\begin{aligned} {}^t x_i = & \sum_{k=1}^N h_k {}^t x_i^k + \frac{t}{2} \sum_{k=1}^N a_k h_k {}^t V_{ti}^k \\ & + \frac{s}{2} \sum_{k=1}^N b_k h_k {}^t V_{si}^k \end{aligned}$$

where

${}^t V_{ti}^k$ = direction cosines of the director vector in the t-direction, of node k at time t

${}^t V_{si}^k$ = direction cosines of the director vector in the s-direction, of node k at time t

Transparency
20-8

Since ${}^t u_i = {}^t x_i - {}^0 x_i$, we have

$$\begin{aligned} {}^t u_i = & \sum_{k=1}^N h_k {}^t u_i^k + \frac{t}{2} \sum_{k=1}^N a_k h_k ({}^t V_{ti}^k - {}^0 V_{ti}^k) \\ & + \frac{s}{2} \sum_{k=1}^N b_k h_k ({}^t V_{si}^k - {}^0 V_{si}^k) \end{aligned}$$

The vectors ${}^0 V_t^k$ and ${}^0 V_s^k$ can be calculated automatically from the initial geometry of the beam element if the element is assumed to lie initially in a plane.

Also

$$\begin{aligned} u_i &= {}^{t+\Delta t}x_i - {}^t x_i \\ &= \sum_{k=1}^N h_k u_i^k + \frac{t}{2} \sum_{k=1}^N a_k h_k v_{ti}^k + \frac{s}{2} \sum_{k=1}^N b_k h_k v_{si}^k \end{aligned}$$


where v_{ti}^k and v_{si}^k are increments in the direction cosines of the vectors ${}^t v_t^k$ and ${}^t v_s^k$. These increments are given in terms of the incremental rotations θ_k , about the Cartesian axes, as

$$v_t^k = \theta_k \times {}^t v_t^k ; \quad v_s^k = \theta_k \times {}^t v_s^k$$

Transparency
20-9

- Using the above displacement and geometry interpolations, we can develop the strain-displacement matrices for the Cartesian strain components. A standard transformation yields the strain-displacement relations corresponding to the beam coordinates η , ξ , ζ .

Transparency
20-10



Transparency
20-11

- The stress-strain relationship used for linear elastic material conditions is

$$\underline{C}_{\text{beam}} = \begin{bmatrix} \eta\eta & \eta\xi & \eta\zeta \\ E & 0 & 0 \\ 0 & Gk & 0 \\ 0 & 0 & Gk \end{bmatrix}$$

components


k = shear correction factor

since only the one normal and two transverse shear stresses are assumed to exist.

Transparency
20-12

- The material stress-strain matrix for analysis of elasto-plasticity or creep would be obtained using also the condition that only the stress components ($\eta\eta$), ($\eta\zeta$) and ($\eta\xi$) are non-zero.

- Note that the kinematic assumptions in the beam element do not allow – so far – for cross-sectional out-of-plane displacements (warping). In torsional loading, allowing for warping is important.
- We therefore amend the displacement assumptions by the following displacements:



Transparency
20-13


Torsion constant k in formula,
 $T = k G \theta a^3 b$

$\frac{b}{a}$	k	
	Analytical value (Timoshenko)	ADINA
1·0	0·141	0·141
2·0	0·229	0·230
4·0	0·281	0·289
10·0	0·312	0·323
100·0	0·333	0·333

Transparency
20-14

Transparency
20-15


Example: Twisting of a ring




All dimensions in inches
thickness = 0.2
 $E = 3 \times 10^5$ psi
 $\nu = 0.3$

Transparency
20-16

Finite element mesh: Twelve 4-node
iso-beam elements






**Demonstration
Photograph
20-1**
Close-up of
ring deformations


Use the T.L. formulation to rotate the ring 180 degrees:


**Transparency
20-17**



**Transparency
20-18**


Pictorially, for a rotation of 180 degrees,
we have



Slide
20-1**MATERIAL DATA:**

GREENBERG et. al.
 $\epsilon = \frac{\sigma}{E} \left[1 + \left(\frac{\sigma}{100} \right)^{2n} \right]$
 $E = 18,600 ; n = 9$

ADINA:
 $E = 18,600 ; \nu = 0.0$
 $\sigma_y = 93.33 ; E_T = 900$

Elastic-plastic analysis of torsion problemSlide
20-2

Solution of torsion problem
 $(k = 100/\sqrt{3}, \theta = \text{rotation per unit length})$

Transparency
20-19


Use of the isoparametric beam and shell elements

- The elements can be programmed for use with different numbers of nodes
 - For the beam,
2, 3 or 4 nodes
 - For the shell,
4, 8, 9, …, 16 nodes
- The elements can be employed for analysis of moderately thick structures (shear deformations are approximately taken into account).

Transparency
20-20

- The elements can be used for analysis of thin structures – but then only certain elements of those mentioned above should be used.

For shells: Use only the 16-node element with 4×4 Gauss integration over the mid-surface.



For beams:

Use 2-node beam element with 1-point Gauss integration along r-direction,

or

Use 3-node beam element with 2-point Gauss integration along r-direction,

or

Use 4-node beam element with 3-point Gauss integration along r-direction.

Transparency
20-21

The reason is that the other elements become overly (and artificially) stiff when used to model thin structures and curved structures.

Transparency
20-22

Two phenomena occur:


- Shear locking
- Membrane locking

**Transparency
20-23**

- The 2-, 3- and 4-node beam elements with 1-, 2- and 3-point Gauss integration along the beam axes do not display these phenomena.
- The 16-node shell element with 4×4 Gauss integration on the shell mid-surface is relatively immune to shear and membrane locking (the element should not be distorted for best predictive capability).

**Transparency
20-24**

- To explain shear locking, consider a 2-node beam element with exact integration (2-point Gauss integration corresponding to the r-direction).



Transverse displacement:


$$w = \frac{1}{2} (1 - r) w_1 + \frac{1}{2} (1 + r) w_2$$

Section rotation:

$$\beta = \frac{1}{2} (1 - r) \theta_1 + \frac{1}{2} (1 + r) \theta_2$$


Hence the transverse shear deformations are given by

$$\gamma = \frac{2}{L} \frac{\partial w}{\partial r} - \beta$$



Transparency
20-25

Consider now the simple case of a cantilever subjected to a tip bending moment, modeled using one 2-node element:



$$\text{Here } \beta = \frac{1}{2} (1 + r) \theta_2$$

$$\gamma = \frac{1}{L} w_2 - \frac{1}{2} (1 + r) \theta_2$$

Transparency
20-26

Transparency
20-27

We observe:

- Clearly, γ cannot be zero at all points along the beam, unless θ_2 and w_2 are zero. But then also β would be zero and there would be no bending of the beam.
- Since for the beam
 - bending strain energy $\propto h^3$
 - shear strain energy $\propto h$
 any error in the shear strains (due to the finite element interpolation functions) becomes increasingly more detrimental as h becomes small.


Transparency
20-28

- For the cantilever example, the shear strain energy should be zero. As h decreases, the relative error in the shear strain increases rapidly and in effect, introduces an artificial stiffness that makes the model “lock.”

h/L $L = 100$	$\theta_{\text{analytical}}$	finite element solution (exact integration)
0.50	9.6×10^{-7}	3.2×10^{-7}
0.10	1.2×10^{-4}	2.4×10^{-6}
0.01	1.2×10^{-1}	2.4×10^{-5}


- Although we considered only one element in the solution, the same conclusion of locking holds for an assemblage of elements.

**Transparency
20-29**



Example: Beam locking study

**Transparency
20-30**




$$L = 10 \text{ m}$$

Square cross-section, height = 0.1 m


Two-node beam elements,
full integration

Transparency
20-31

Plot tip deflection as a function of the number of elements:



Transparency
20-32



A remedy for the 2-node beam element is to use only 1-point Gauss integration (along the beam axis).

This corresponds to assuming a constant transverse shear strain, (since the shear strain is only evaluated at the mid-point of the beam).

The bending energy is still integrated accurately (since $\frac{\partial \beta}{\partial r}$ is correctly evaluated).

h/L $L = 100$	$\theta_{\text{analytical}}$	finite element solution (1-point integration)
0.50	9.6×10^{-7}	9.6×10^{-7}
0.10	1.2×10^{-4}	1.2×10^{-4}
0.01	1.2×10^{-1}	1.2×10^{-1}

Transparency
20-33

- The 3- and 4-node beam elements evaluated using 2- and 3-point integration are similarly effective.
- We should note that these beam elements based on "reduced" integration are reliable because they do not possess any spurious zero energy modes. (They have only 6 zero eigenvalues in 3-D analysis corresponding to the 6 physical rigid body modes).
- The formulation can be interpreted as a mixed interpolation of displacements and transverse shear strains.


Transparency
20-34

Transparency
20-35

- Regarding membrane-locking we note that in addition to not exhibiting erroneous shear strains, the beam model must also not contain erroneous mid-surface membrane strains in the analysis of curved structures.
- The beam elements with reduced integration also do not “membrane-lock”.

Transparency
20-36

Consider the analysis of a curved cantilever:



The exactly integrated 3-node beam element, when curved, does contain erroneous shear strains and erroneous mid-surface membrane strains. As a result, when h becomes small, the element becomes very stiff.

Transparency
20-37

h/R $R = 100$	$\theta_{\text{analytical}}$ ($\alpha = 45^\circ$)	finite element solution: 3-node element, 3-point integration	finite element solution: 3-node element, 2-point integration
0.50	7.5×10^{-7}	6.8×10^{-7}	7.4×10^{-7}
0.10	9.4×10^{-5}	2.9×10^{-5}	9.4×10^{-5}
0.01	9.4×10^{-2}	4.1×10^{-4}	9.4×10^{-2}

- Similarly, we can study the use of the 4-node cubic beam element:

Transparency
20-38

h/R $R = 100$	$\theta_{\text{analytical}}$ ($\alpha = 45^\circ$)	finite element solution: 4-node element, 4-point integration	finite element solution: 4-node element, 3-point integration
0.50	7.5×10^{-7}	7.4×10^{-7}	7.4×10^{-7}
0.10	9.4×10^{-5}	9.4×10^{-5}	9.4×10^{-5}
0.01	9.4×10^{-2}	9.4×10^{-2}	9.4×10^{-2}

We note that the cubic beam element performs well even when using full integration.

**Transparency
20-39**

Considering the analysis of shells, the phenomena of shear and membrane locking are also present, but the difficulty is that simple “reduced” integration (as used for the beam elements) cannot be recommended, because the resulting elements contain spurious zero energy modes.

For example, the 4-node shell element with 1-point integration contains 6 spurious zero energy modes (twelve zero eigenvalues instead of only six).

**Transparency
20-40**


Such spurious zero energy modes can lead to large errors in the solution that – unless a comparison with accurate results is possible – are not known and hence the analysis is unreliable.

- For this reason, only the 16-node shell element with 4×4 Gauss integration on the shell mid-surface can be recommended.
- The 16-node element should, as much as possible, be used with the internal and boundary nodes placed at their $\frac{1}{3}$ rd points (without internal element distortions). This way the element performs best.

Transparency
20-41

- Recently, we have developed elements based on the mixed interpolation of tensorial components.
- The elements do not lock, in shear or membrane action, and also do not contain spurious zero energy modes.
- We will use the 4-node element, referred to as the MITC4 element, in some of our demonstrative sample solutions.

Transparency
20-42

Transparency
20-43**The MITC4 element:**

- For analysis of plates
- For analysis of moderately thick shells and thin shells

Transparency
20-44

- The key step in the formulation is to interpolate the geometry and displacements as earlier described, but
 - To interpolate the transverse shear strain tensor components separately, with judiciously selected shape functions
 - To tie the intensities of these components to the values evaluated using the displacement interpolations

rt transverse shear strain tensor component interpolation



evaluated from
displacement interpolations

st transverse shear strain tensor component interpolation



**Transparency
20-45**

The MITC4 element

- has only six zero eigenvalues (no spurious zero energy modes)
- passes the patch test

What do we mean by the patch test?

The key idea is that any arbitrary patch of elements should be able to represent constant stress conditions.

**Transparency
20-46**

Transparency
20-47


THE PATCH TEST

- We take an arbitrary patch of elements (some of which are geometrically distorted) and subject this patch to
 - the minimum displacement/rotn. boundary conditions to eliminate the physical rigid body modes, and
 - constant boundary tractions, corresponding to the constant stress condition that is tested.


Transparency
20-48

- We calculate all nodal point displacements and element stresses.


The patch test is passed if the calculated element internal stresses and nodal point displacements are correct.

Transparency
20-49


PATCH OF ELEMENTS CONSIDERED

Transparency
20-50

MEMBRANE TESTS




BENDING/TWISTING TESTS

Transparency
20-51Example: Spherical shellTransparency
20-52


Selection of director vectors:

- One director vector is generated for each node.
- The director vector for each node is chosen to be parallel to the radial vector for the node.
- In two dimensions:



Selection of displacement boundary conditions:


- Consider a material fiber that is parallel to a director vector. Then, if this fiber is initially located in the x - z plane, by symmetry this fiber must remain in the x - z plane after the shell has deformed:



**Transparency
20-53**


Finite element mesh: Sixty-four MITC4 elements

**Transparency
20-54**



Transparency
20-55


This condition is applied to each node on the x-z plane as follows:

Transparency
20-56

- A similar condition is applied to nodes initially in the y-z plane.
- These boundary conditions are most easily applied by making each node in the x-z or y-z plane a 6 degree of freedom node. All other nodes are 5 degree of freedom nodes.
- To prevent rigid body translations in the z-direction, the z displacement of one node must be set to zero.

Linear elastic analysis results:


- Displacement at point of load application is 0.0936 (analytical solution is 0.094).
- Pictorially,



Transparency
20-57

Example: Analysis of an open (five-sided) box:

Box is placed open-side-down/Add on a frictionless surface.



Transparency
20-58

Transparency
20-59

Modeling of the box with shell elements:

- Choose initial director vectors.
- Choose 5 or 6 degrees of freedom for each node.
- Choose boundary conditions.


Transparency
20-60

- Instead of input of director vectors, one for each node, it can be more effective to have ADINA generate mid-surface normal vectors.
- If no director vector is input for a node, ADINA generates for each element connected to the node a nodal point mid-surface normal vector at that node (from the element geometry).
- Hence, there will then be as many different nodal point mid-surface normal vectors at that node as there are elements connected to the node (unless the surface is flat).

Nodal point mid-surface normal vectors for the box:


- We use the option of automatic generation of element nodal point mid-surface normal vectors.
- At a node, not on an edge, the result is one mid-surface normal vector (because the surface is flat).
- At an edge where two shell elements meet, two mid-surface normal vectors are generated (one for each element).

**Transparency
20-61**



Degrees of freedom:

**Transparency
20-62**



Note added in preparation of study-guide


In the new version of ADINA (ADINA 84 with an update inserted, or ADINA 86) the use of the 5 or 6 shell degree of freedom option has been considerably automatized:

- The user specifies whether the program is to use 5 or 6 degrees of freedom at each shell mid-surface node N
 - $IGL(N).EQ.0 \rightarrow 6$ d.o.f. with the translations and rotations corresponding to the global (or nodal skew) system
 - $IGL(N).EQ.1 \rightarrow 5$ d.o.f. with the translations corresponding to the global (or nodal skew) system but the rotations corresponding to the vectors V_1 and V_2
- The user (usually) does not input any mid-surface normal or director vectors. The program calculates these automatically from the element mid-surface geometries.
- The user recognizes that a shell element has no nodal stiffness corresponding to the rotation about the mid-surface normal or director vector. Hence, a shell mid-surface node is assigned 5 d.o.f. unless
 - a shell intersection is considered
 - a beam with 6 d.o.f. is coupled to the shell node
 - a rotational boundary condition corresponding to a global (or skew) axis is to be imposed
 - a rigid link is coupled to the shell node

For further explanations, see the ADINA 86 users manual.


Transparency
20-63

**Displacement boundary conditions:
Box is shown open-side-up.**



Consider a linear elastic static analysis of the box when a uniform pressure load is applied to the top.


We use the 128 element mesh shown (note that all hidden lines are removed in the figure):



Transparency
20-64


We obtain the result shown below (again the hidden lines are removed):

- The displacements in this plot are highly magnified.




Transparency
20-65

Slide
20-3




Simply-supported plate under uniform pressure,
 $L/h = 1000$

Slide
20-4




Simply-supported plate under concentrated load
at center, $L/h = 1000$

Slide
20-5




Clamped plate under uniform pressure, $L/h = 1000$


Slide
20-6



Clamped plate under concentrated load at center, $L/h = 1000$

Slide
20-7

Effect of mesh distortion on results in analysis of
a simply-supported plate under uniform pressure
($L/h = 1000$)


Slide
20-8

Analysis of skew plate

Slide
20-9

MESH	w_C^{FEM} / w_C^{MO}	$FEM / MO_{Mmax} / M_{max}$	$FEM / MO_{Mmin} / M_{min}$
4 X 4	0.879	0.873	0.852
8 X 8	0.871	0.928	0.922
16 X 16	0.933	0.961	0.919
32 X 32	0.985	0.989	0.990

Solution of skew plate at point C using uniform skew mesh




2 X 2 MESH

Slide
20-10

MESH	w_C^{FEM} / w_C^{MO}	$FEM / MO_{Mmax} / M_{max}$	$FEM / MO_{Mmin} / M_{min}$
2 X 2	0.984	0.717	0.602
4 X 4	0.994	0.935	0.878


Solution of skew plate using a more effective mesh

**Slide
20-11**





Large displacement analysis of a cantilever

**Slide
20-12**





Response of cantilever




Slide
20-13

Large displacement/rotation analysis of a cantilever




Slide
20-14

**Slide
20-15**




Analysis of I-beam

**Slide
20-16**




Iso-beam model

Slide
20-17




Shell model

Slide
20-18




I-beam

Slide
20-19




Rotation of *I*-beam about *X*-axis for increasing torsional moment.

Slide
20-20



Large deflection elastic-plastic analysis of a cylindrical shell

Slide
20-21

Response of shell

Topic 21

A Demonstrative Computer Session Using ADINA—Linear Analysis

Contents:

- Use of the computer program ADINA for finite element analysis, discussion of data preparation, program solution, and display of results
 - Capabilities of ADINA
 - Computer laboratory demonstration—Part I
 - Linear analysis of a plate with a hole for the stress concentration factor
 - Data input preparation and mesh generation
 - Solution of the model
 - Study and evaluation of results using plots of stresses, stress jumps, and pressure bands
-

Textbook:

Appendix

References:

The use of the ADINA program is described and sample solutions are given in

Bathe, K. J., "Finite Elements in CAD — and ADINA," *Nuclear Engineering and Design*, to appear.

ADINA, ADINAT, ADINA-IN, and ADINA-PLOT Users Manuals, ADINA Verification Manual, and ADINA Theory and Modeling Guide, ADINA Engineering, Inc., Watertown, MA 02172, U.S.A.

Proceedings of the ADINA Conferences, (Bathe, K. J., ed.)
Computers & Structures

13, 5–6, 1981

17, 5–6, 1983

21, 1–2, 1985

References:
(continued)

The use of pressure band plots to evaluate meshes is discussed in Sussman, T., and K. J. Bathe, "Studies of Finite Element Procedures—Stress Band Plots and the Evaluation of Finite Element Meshes," *Engineering Computations*, to appear.

A FINITE ELEMENT ANALYSIS — LINEAR SOLUTION

Transparency
21-1

- We have presented a considerable amount of theory and example solution results in the lectures.
- The objective in the next two lectures is to show how an actual finite element analysis is performed on the computer.

Transparency
21-2

- We cannot discuss in detail all the aspects of the analysis, but shall summarize and demonstrate on the computer the major steps of the analysis, and concentrate on
 - possible difficulties
 - possible pitfalls
 - general recommendations


Transparency
21-3

We will use as the example problem the plate with a hole already considered earlier, and perform linear and nonlinear analyses

- elastic analysis to obtain the stress concentration factor
- elasto-plastic analysis to estimate the limit load
- an analysis to investigate the effect of a shaft in the plate hole

Transparency
21-4

Plate with hole: Schematic drawing




- The first step for a finite element analysis is to select a computer program. We use the ADINA system.

**Transparency
21-5**


ADINA-IN	to prepare, generate the finite element data
ADINA	to solve the finite element model
ADINA-PLOT	to display numerically or graphically the solution results

Schematically:

**Transparency
21-6**




**Transparency
21-7**




- User types into terminal ADINA-IN commands interactively or for batch mode processing. User checks input and generated data on graphics display terminal.

**Transparency
21-8**




- ADINA-IN generates the input data for ADINA.
- The input data is checked internally in ADINA-IN for errors and consistency and is displayed as per request by the user.
- The degree of freedom numbers are generated (for a minimum bandwidth).



**Transparency
21-9**

- User runs ADINA to calculate the response of the finite element model. ADINA writes the model data and calculated results on an output file and stores the model data and calculated results on the porthole file.



**Transparency
21-10**

- User runs ADINA-PLOT to access the output data and display selected results; displacements, stresses, mode shapes, maxima, . . .

Transparency
21-11

A brief overview of ADINA

- Static and dynamic solutions
- Linear and nonlinear analysis
- Small and very large finite element models can be solved.

The formulations, finite elements and numerical procedures used in the program have largely been discussed in this course.

Transparency
21-12

DISPLACEMENT ASSUMPTIONS

- Infinitesimally small displacements
- Large displacements/large rotations but small strains
- Large deformations/large strains

MATERIAL MODELS

- Isotropic Linear Elastic
- Orthotropic Linear Elastic
- Isotropic Thermo-Elastic
- Curve Description Model for Analysis of Geological Materials
- Concrete Model


**Transparency
21-13**

MATERIAL MODELS


- Isothermal Plasticity Models
- Thermo-Elastic-Plastic and Creep Models
- Nonlinear Elastic, Incompressible Models
- User-Supplied Models

**Transparency
21-14**

**Transparency
21-15**




**Transparency
21-16**




Two-Dimensional Solid Element
(variable number of nodes)

**Transparency
21-17**




Three-Dimensional Solid Element
(variable number of nodes)

**Transparency
21-18**




Two-Node Beam Element

**Transparency
21-19**




Isoparametric Beam Element
(2, 3, 4 nodes)

**Transparency
21-20**



Pipe Element with Ovalization



Transparency
21-21

A SUMMARY OF IMPORTANT OBSERVATIONS

- We need to check the finite element data input carefully
 - prior to the actual response solution run, and
 - after the response solution has been obtained by studying whether the desired boundary conditions are satisfied, whether the displacement and stress solution is reasonable (for the desired analysis).


Transparency
21-22

**Transparency
21-23**

- We need to carefully evaluate and interpret the calculated response
 - study in detail the calculated displacements and stresses along certain lines, study stress jumps
 - stress averaging, stress smoothing should only be done after the above careful evaluation


**Transparency
21-24**

**Data for Construction of
64 Element Mesh:**



Finite element mesh to be generated using ADINA-IN:


- Mesh contains 64 elements, 288 nodes.



Transparency
21-25

Demonstration
Photograph
21-1

Finite Element Research
Group Laboratory
computer configuration




**ADINA
Demonstration
21-1
Input data**

```
QUARTER PLATE WITH HOLE - 64 ELEMENTS
2261001110 1 0 1 1 1.0000000
C*** MASTER CONTROL
99999 0 0 1 0 0 1 50 30.
C*** 3 LOAD CONTROL
0 4 0 0 0 0 0 0
C*** 4 MASS AND DAMPING CONTROL
0 0 0 0 .0 .0
C*** 5 EIGENVALUE SOLUTION CONTROL
0 0 0 0 0 0
C*** 6 TIME INTEGRATION METHOD CONTROL
0 20.500000000.25000000 0 0
C*** 7 INCREMENTAL SOLUTION CONTROL
1 1 210 15.001000000.010000000.05
C*** 8 PRINT-OUT CONTROL
1 1 1 1 1 1 0
```

**Transparency
21-26
(Repeat 21-25)**


Finite element mesh to be generated
using ADINA-IN:

- Mesh contains 64 elements,
288 nodes.




Stress vector output: Example

Transparency
21-27




The length of the line is proportional to the magnitude of the stress.



ADINA
Demonstration
21-2
Deformed mesh
plot

Transparency
21-28


Plate with hole: Schematic drawing



Transparency
21-29
(Repeat 21-25)


Finite element mesh to be generated using ADINA-IN:

- Mesh contains 64 elements, 288 nodes.




Stress point numbers and integration point numbers for element 57

Transparency
21-30



Behavior of stresses near the stress concentration:

Transparency
21-31




Transparency
21-32

Maximum principal stress calculation:

$$\sigma_1 = \frac{\sigma_{yy} + \sigma_{zz}}{2} + \sqrt{\frac{(\sigma_{yy} - \sigma_{zz})^2}{4} + \sigma_{yz}^2}$$

Transparency
21-33
(Repeat 21-30)

Stress point numbers and integration point numbers for element 57



**ADINA
Demonstration
21-3**
Close-up of
calculations

```

RESULTANT = SMAX      ARITHMETIC EXPRESSION:
(TYY+TZZ)/TWO+SQRT((TYY-TZZ)*(TYY-TZZ)/FOUR+TYZ*TYZ)


TYY      = YY-STRESS
TZZ      = ZZ-STRESS
TYZ      = YZ-STRESS
TWO     = 2.00000
FOUR    = 4.00000

EXTREME ELEMENT RESULTS PER ELEMENT GROUP FOR WHOLE MODEL
INTERVAL TSTART= 1.0000      TEND= 1.0000      SCANNED FOR ABSOLUTE MAXIMUM
ELEMENT GROUP NO = 1 (2-D SOLID)      LISTED RESULTS ARE MEASURED IN
                                         GLOBAL COORDINATE SYSTEM
                                         RESULTANT SMAX      ELEMENT POINT      TIME      STEP
                                         0.345151E+03      57      4      0.10000E+01      1

```

Finite element mesh to be generated
using ADINA-IN:

- Mesh contains 64 elements,
288 nodes.



**Transparency
21-34**
(Repeat 21-25)


**Transparency
21-35**
(Repeat 2-33)


- To be confident that the stress discontinuities are small everywhere, we should plot stress jumps along each line in the mesh.
- An alternative way of presenting stress discontinuities is by means of a pressure band plot:
 - Plot bands of constant pressure where

$$\text{pressure} = \frac{-(\tau_{xx} + \tau_{yy} + \tau_{zz})}{3}$$

**Transparency
21-36**
(Repeat 2-35)

Sixty-four element mesh: Pressure band plot





**ADINA
Demonstration
21-4**
Close-up of
pressure bands

A SUMMARY OF IMPORTANT OBSERVATIONS

- We need to check the finite element data input carefully
 - prior to the actual response solution run, and
 - after the response solution has been obtained by studying whether the desired boundary conditions are satisfied, whether the displacement and stress solution is reasonable (for the desired analysis).

**Transparency
21-37**
(Repeat 21-22)

Transparency

21-38

(Repeat 21-23)

- We need to carefully evaluate and interpret the calculated response
 - study in detail the calculated displacements and stresses along certain lines, study stress jumps
 - stress averaging, stress smoothing should only be done after the above careful evaluation

Topic 22

A Demonstrative Computer Session Using ADINA—Nonlinear Analysis

Contents:

- Use of ADINA for elastic-plastic analysis of a plate with a hole
 - Computer laboratory demonstration—Part II
 - Selection of solution parameters and input data preparation
 - Study of the effect of using different kinematic assumptions (small or large strains) in the finite element solution
 - Effect of a shaft in the plate hole, assuming frictionless contact
 - Effect of expanding shaft
 - Study and evaluation of solution results
-

Textbook:**Appendix****References:**

The use of the ADINA program is described and sample solutions are given in

Bathe, K. J., "Finite Elements in CAD — and ADINA," *Nuclear Engineering and Design*, to appear.

ADINA, ADINAT, ADINA-IN, and ADINA-PLOT Users Manuals, ADINA Verification Manual, and ADINA Theory and Modeling Guide, ADINA Engineering, Inc., Watertown, MA 02172, U.S.A.

References:
(continued)

Proceedings of the ADINA Conferences, (K. J. Bathe, ed.)
Computers & Structures
13, No. 5–6, 1981
17, No. 5–6, 1983
21, No. 1–2, 1985

The contact solution procedure used in the analysis of the plate with the shaft is described in


Bathe, K. J., and A. Chaudhary, "A Solution Method for Planar and Axisymmetric Contact Problems," *International Journal for Numerical Methods in Engineering*, 21, 65–88, 1985.

A FINITE ELEMENT ANALYSIS — NONLINEAR SOLUTION

- We continue to consider the plate with a hole.
- A nonlinear analysis should only be performed once a linear solution has been obtained.
The linear solution checks the finite element model and yields valuable insight into what nonlinearities might be important.

Transparency
22-1

Plate with hole: Schematic drawing




Transparency
22-2
(Repeat 21-4)

**Transparency
22-3**
(Repeat 21-25)

Finite element mesh to be generated using ADINA-IN:

- Mesh contains 64 elements, 288 nodes.



**Transparency
22-4**

- Some important considerations are now
 - What material model to select
 - What displacement/strain assumption to make
 - What sequence of load application to choose
 - What nonlinear equation solution strategy and convergence criteria to select

- We use the ADINA system to analyse the plate for its elasto-plastic static response.
- We also investigate the effect on the response when a shaft is placed in the plate hole.

Transparency
22-5


Some important observations:

- The recommendations given in the linear analysis are here also applicable (see previous lecture).
- For the nonlinear analysis we need to, in addition, be careful with the
 - sequence and incremental magnitudes of load application
 - choice of convergence tolerances

Transparency
22-6

Transparency
22-7

Limit load calculations:




- Plate is elasto-plastic.


Transparency
22-8

Elasto-plastic analysis:

Material properties (steel)



- This is an idealization, probably inaccurate for large strain conditions ($e > 2\%$).

Load history:**Transparency
22-9**

- Load is increased 50 MPa per load step.
- Load is released in one load step.

USER-SUPPLIED


```
MATERIAL 1 PLASTIC E=207000 NU=0.3 ET=2070 YIELD=740
MATERIAL 1 PLASTIC E=207000 NU=0.3 ET=2070 YIELD=740
DELETE EQUILIBRIUM-ITERATIONS
DELETE EQUILIBRIUM-ITERATIONS
ADINA
ADINA
```

**ADINA
Demonstration
22-1
Input data**

**Transparency
22-10**
(Repeat 21-25)


Finite element mesh to be generated using ADINA-IN:

- Mesh contains 64 elements, 288 nodes.



**Transparency
22-11**

Load history:



- Load is increased 50 MPa per load step.
- Load is released in one load step.
- The BFGS method is employed for each load step.

Convergence criteria:

Energy:


$$\frac{\Delta \underline{U}^{(i)\top} [\underline{R} - \underline{F}^{(i-1)}]}{\Delta \underline{U}^{(1)\top} [\underline{R} - \underline{F}]} \leq ETOL = 0.001$$

Force:

$$\frac{\|\underline{R} - \underline{F}^{(i-1)}\|_2}{RNORM} \leq RTOL = 0.01$$

$$(RNORM = \underbrace{100 \text{ MPa}}_{\text{nominal applied load}} \times \underbrace{0.05 \text{ m}}_{\text{width}} \times \underbrace{0.01 \text{ m}}_{\text{thickness}})$$


**Transparency
22-12**



**ADINA
Demonstration
22-2**
Plot of plasticity
in plate with hole


**Transparency
22-13**

Stress vector output: Example




The length of the line is proportional to the magnitude of the stress.

**ADINA
Demonstration
22-3**
Close-up of stress
vectors around hole



Finite element mesh to be generated using ADINA-IN:

- Mesh contains 64 elements, 288 nodes.



**Transparency
22-14**

(Repeat 21-25)

M.N.O. Materially-Nonlinear-
Only analysis

T.L. Total Lagrangian
formulation


U.L. Updated Lagrangian
formulation

**Transparency
22-15**

**Transparency
22-16**
(Repeat 21-25)

Finite element mesh to be generated using ADINA-IN:

- Mesh contains 64 elements, 288 nodes.



**ADINA
Demonstration
22-4**
Elasto-plastic load
displacement response






Plate with shaft:

Transparency
22-17

- The shaft is initially flush with the hole.
- We assume no friction between the shaft and the hole.

Detail of shaft:

Transparency
22-18

**Transparency
22-19**

Solution procedure: Full Newton iterations without line searches

Convergence criteria:

Energy: ETOL = 0.001

Force: RTOL = 0.01 , RNORM = 0.05 N

Incremental contact force:

$$\frac{\|\Delta \underline{R}^{(i-1)} - \Delta \underline{R}^{(i-2)}\|_2}{\|\Delta \underline{R}^{(i-1)}\|_2} \leq \text{RCTOL} = 0.05$$

**ADINA
Demonstration
22-5**
Deformed mesh






Plate with expanding shaft:



Transparency
22-20

- The shaft now uniformly expands.



ADINA
Demonstration
22-6
Close-up of
deformations at
contact

Glossary

Glossary of Symbols

Contents:

- Glossary of Roman Symbols
- Glossary of Greek Symbols

Glossary of Roman Symbols

$\ \cdot \ _2$	The Euclidean norm or "two-norm." For a vector \underline{a}	C_1, C_2	The Mooney-Rivlin material constants (for rubberlike materials).
$\underline{\underline{a}}$	$\ \underline{a} \ _2 = \sqrt{\sum_k (a_k)^2}$	${}^0C_{ij}$	Components of the Cauchy-Green deformation tensor (basic concepts of Lagrangian continuum mechanics).
$\underline{\underline{a}}$	When used above a symbol, denotes "in the rotated coordinate system."	\underline{C}_t	Matrix containing components of the constitutive tensor referred to a local coordinate system.
a_k, b_k	Cross-sectional dimensions of a beam at nodal point k .	\underline{C}	Matrix containing components of the constitutive tensor, used in linear and M.N.O. analysis.
tA	Cross-sectional area at time t .	0C	Matrix containing components of the constitutive tensor ${}^0C_{ijrs}$, used in the T.L. formulation.
$A^{(i)}$	A square matrix used in the BFGS method.	tC	Matrix containing components of the constitutive tensor ${}^tC_{ijrs}$, used in the U.L. formulation.
\underline{B}_L	Linear strain-displacement matrix used in linear or M.N.O. analysis.	C_{ijrs}^E	Components of elastic constitutive tensor relating $d\sigma_{ij}$ to de_{rs}^E
${}^0\underline{B}_L$	Linear strain-displacement matrix used in the T.L. formulation.	C_{ijrs}^{EP}	Components of elasto-plastic constitutive tensor relating $d\sigma_{ij}$ to de_{rs}
${}^t\underline{B}_L$	Linear strain-displacement matrix used in the U.L. formulation.	${}^0C_{ijrs}$	Components of tangent constitutive tensor relating d_0S_{ij} to $d_0\epsilon_{rs}$
${}^0\underline{B}_{LO}, {}^0\underline{B}_{L1}$	Intermediate matrices used to compute ${}^t\underline{B}_L$; ${}^0\underline{B}_{L1}$ contains the "initial displacement effect."	${}^tC_{ijrs}$	Components of tangent constitutive tensor relating d_tS_{ij} to $d_t\epsilon_{rs}$
${}^0\underline{B}_{NL}$	Nonlinear strain-displacement matrix used in the T.L. formulation.	DNORM	Reference displacement used with displacement convergence tolerance DTOL (solution of nonlinear equations).
${}^t\underline{B}_{NL}$	Nonlinear strain-displacement matrix used in the U.L. formulation.	DMNORM	DMNORM is the reference rotation used when rotational degrees of freedom are present.
c	The wave speed of a stress wave (dynamic analysis).	DTOL	Convergence tolerance used to measure convergence of the displacements and rotations (solution of nonlinear equations).
c_{ii}	Diagonal element corresponding to the i th degree of freedom in the damping matrix (dynamic analysis).		
\underline{C}	The damping matrix (dynamic analysis).		

\det	The determinant function, for example, $\det \mathbf{X}$.	E_T	Strain hardening modulus (elasto-plastic analysis).
${}^t dV$	A differential element of volume evaluated at time t .	ETOL	Convergence tolerance used to measure convergence in energy (solution of nonlinear equations).
${}^0 dV$	A differential element of volume evaluated at time 0.	$f(\mathbf{x})$	A function that depends on \mathbf{x} (solution of nonlinear equations).
$d^t \mathbf{x}$	Vector describing the orientation and length of a differential material fiber at time t (basic concepts of Lagrangian continuum mechanics).	$f(\mathbf{U})$	A vector function that depends on the column vector \mathbf{U} (solution of nonlinear equations).
$d^0 \mathbf{x}$	Vector describing the orientation and length of a differential material fiber at time 0 (basic concepts of Lagrangian continuum mechanics).	t_f^B, t_f^S	Components of externally applied forces per unit current volume and unit current surface area.
${}^t \bar{\epsilon}^C$	Effective creep strain, evaluated at time t (creep analysis).	\mathbf{f}	Yield function (elasto-plastic analysis).
ϵ_{ij}	Components of infinitesimal strain tensor (linear and M.N.O. analysis).	\mathbf{f}	Vector of nodal point forces equivalent to the internal element stresses.
${}^0 \epsilon_{ij}$	Linear (in the incremental displacements) part of ${}^0 \epsilon_{ij}$ (T.L. formulation)	$\delta \mathbf{f}$	Vector of nodal point forces equivalent to the internal element stresses (T.L. formulation).
${}^t \epsilon_{ij}$	Linear (in the incremental displacements) part of ${}^t \epsilon_{ij}$ (U.L. formulation).	\mathbf{f}	Vector of nodal point forces equivalent to the internal element stresses (U.L. formulation).
${}^t \epsilon_{ij}^{IN}, {}^t \epsilon_{ij}^C, {}^t \epsilon_{ij}^P, {}^t \epsilon_{ij}^{TH}, {}^t \epsilon_{ij}^{VP}$	Various types of inelastic strains evaluated at time t (inelastic analysis): IN inelastic C creep P plastic TH thermal VP viscoplastic	$\mathbf{F}_I(t)$	Column vector containing the inertia forces for all degrees of freedom (dynamic analysis).
$\mathbf{e}_r, \mathbf{e}_s, \mathbf{e}_t$	Unit vectors in the r , s , and t directions (shell analysis).	$\mathbf{F}_D(t)$	Column vector containing the damping forces for all degrees of freedom (dynamic analysis).
$\bar{\mathbf{e}}_r, \bar{\mathbf{e}}_s$	Unit vectors constructed so that $\bar{\mathbf{e}}_r, \bar{\mathbf{e}}_s, \bar{\mathbf{e}}_t$ are mutually orthogonal (shell analysis).	$\mathbf{F}_E(t)$	Column vector containing the elastic forces (nodal point forces equivalent to element stresses) for all degrees of freedom (dynamic analysis).
E	Young's modulus.	g	Acceleration due to gravity.
E_a, E_b	Young's moduli in the a and b directions (orthotropic analysis).	G_{ab}	Shear modulus measured in the local coordinate system $a-b$ (orthotropic analysis).
		h	Cross-sectional height (beam element).
		h_k	Interpolation function corresponding to nodal point k .

\underline{H}	Displacement interpolation matrix (derivation of element matrices).	$\hat{\underline{K}}$	Effective stiffness matrix, including inertia effects and nonlinear effects (dynamic substructure analysis).
\underline{H}^S	Displacement interpolation matrix for surfaces with externally applied tractions (derivation of element matrices).	$\hat{\underline{K}}_c$	$\hat{\underline{K}}$ after static condensation (dynamic substructure analysis).
I_1, I_2, I_3	The invariants of the Cauchy-Green deformation tensor (analysis of rubberlike materials).	$\hat{\underline{K}}_c$	$\hat{\underline{K}}$ after static condensation (dynamic substructure analysis).
\underline{J}	The Jacobian matrix relating the x_i coordinates to the isoparametric coordinates (two- and three-dimensional solid elements).	$\underline{tK}_{\text{nonlinear}}$	Nonlinear stiffness effects due to geometric and material nonlinearities (dynamic substructure analysis).
\underline{tJ}	The Jacobian matrix relating the \underline{x}_i coordinates to the isoparametric coordinates (two- and three-dimensional solid elements in geometrically nonlinear analysis).	tL	Length, evaluated at time t .
k	Shear factor (beam and shell analysis).	L_e	Element length, chosen using the relation $L_e = c \Delta t$ (dynamic analysis).
\underline{tK}	The tangent stiffness matrix, including all geometric and material nonlinearities.	L_w	Wave length of a stress wave (dynamic analysis).
\underline{oK}	The tangent stiffness matrix, including all geometric and material nonlinearities (T.L. formulation).	m_{ii}	Lumped mass associated with degree of freedom i (dynamic analysis).
\underline{tK}	The tangent stiffness matrix, including all geometric and material nonlinearities (U.L. formulation).	M	The mass matrix (dynamic analysis).
$\underline{oK}_L, \underline{tK}_L$	The contribution to the total tangent stiffness matrix arising from the linear part of the Green-Lagrange strain tensor.	\underline{tP}_{ij}	Quantities used in elasto-plastic analysis, defined as $\underline{tP}_{ij} = - \frac{\partial \underline{F}}{\partial \underline{e}_{ij}^P} \Big _{\sigma_{ij} \text{ fixed}}$
	\underline{oK}_L - T.L. formulation	\underline{tq}_{ij}	Quantities used in elasto-plastic analysis defined as $\underline{tq}_{ij} = \frac{\partial \underline{F}}{\partial \sigma_{ij}} \Big _{\underline{e}_{ij}^P \text{ fixed}}$
	\underline{tK}_L - U.L. formulation	r, s, t	Isoparametric coordinates (two- and three-dimensional solid elements, shell elements).
$\underline{oK}_{NL}, \underline{tK}_{NL}$	The contribution to the total tangent stiffness matrix arising from the nonlinear part of the Green-Lagrange strain tensor.	\underline{oR}	Rotation matrix (polar decomposition of \underline{oC}).
	\underline{oK}_{NL} - T.L. formulation	\underline{R}	Reference load vector (automatic load step incrementation).
	\underline{tK}_{NL} - U.L. formulation	\underline{tR}	Applied loads vector, corresponding to time t .
$\underline{\hat{K}}$	Effective stiffness matrix, including inertia effects but no nonlinear effects (dynamic substructure analysis).		

\mathcal{R}	Virtual work associated with the applied loads, evaluated at time t .	T_n	Smallest period in finite element assemblage (dynamic analysis).
RNORM,	Reference load used with force tolerance RTOL (solution of nonlinear equations).	$^t u_i$	Total displacement of a point in the i th direction.
RMNORM	Reference moment used when rotational degrees of freedom are present.	$^t \ddot{u}_i$	Total acceleration of a point in the i th direction (dynamic analysis).
RTOL	Convergence tolerance used to measure convergence of the out-of-balance loads (solution of nonlinear equations).	u_i	Incremental displacement of a point in the i th direction.
$^t S_{ij}$	Deviatoric stress evaluated at time t (elasto-plastic analysis).	u_i^s	Components of displacement of a point upon which a traction is applied.
$^t S$	Surface area, evaluated at time t .	$^t \partial u_{i,j}$	Derivatives of the total displacements with respect to the original coordinates (T.L. formulation).
$^t \delta S_{ij}$	Components of 2nd Piola-Kirchhoff stress tensor, evaluated at time t and referred to the original configuration (basic Lagrangian continuum mechanics).	$^0 \partial u_{i,j}$	Derivatives of the incremental displacements with respect to the original coordinates (T.L. formulation).
$^0 S_{ij}$, $^t S_{ij}$	Components of increments in the 2nd Piola-Kirchhoff stress tensors: $^0 S_{ij} = ^{t+\Delta t} \delta S_{ij} - ^0 \delta S_{ij}$ $^t S_{ij} = ^{t+\Delta t} S_{ij} - ^t T_{ij}$	$^t u_{i,j}$	Derivatives of the incremental displacements with respect to the current coordinates (U.L. formulation).
$^t S$	Matrix containing the components of the 2nd Piola-Kirchhoff stress tensor (T.L. formulation).	u_i^k	Incremental displacement of nodal point k in the i th direction.
$^t \delta S$	Vector containing the components of the 2nd Piola-Kirchhoff stress tensor (T.L. formulation).	$^t u_i^k$	Total displacement of nodal point k in the i th direction at time t .
t , $t+\Delta t$	Times for which a solution is to be obtained in incremental or dynamic analysis. The solution is presumed known at time t and is to be determined for time $t+\Delta t$.	\underline{u}	A vector containing incremental nodal point displacements.
\bar{t}	"Effective" time (creep analysis).	\underline{u}	A vector containing total nodal point displacements at time t .
T	Displacement transformation matrix (truss element).	$\underline{\dot{u}}$	Vector of nodal point accelerations, evaluated at time t .
T_{co}	Cut-off period (the smallest period to be accurately integrated in dynamic analysis).	$\underline{\dot{u}}$	Vector of nodal point velocities, evaluated at time t .
		\underline{u}	Vector of nodal point displacements, evaluated at time t .
		\underline{U}	Stretch matrix (polar decomposition of $\underline{\dot{C}}$).
		$v^{(i)}$	Column vector used in the BFGS method (solution of nonlinear equations).

tV	Volume evaluated at time t .
${}^tV_n^k$, ${}^tV_{ni}^k$	Director vector at node k evaluated at time t (shell analysis).
V_n^k	Increment in the director vector at node k (shell analysis).
${}^tV_1^k$, ${}^tV_2^k$	Vectors constructed so that ${}^tV_1^k$, ${}^tV_2^k$ and ${}^tV_n^k$ are mutually perpendicular (shell analysis).
${}^tV_s^k$, ${}^tV_t^k$	Director vectors in the s and t directions at node k , evaluated at time t (beam analysis).
V_s^k , V_t^k	Increments in the director vectors in the s and t directions at node k (beam analysis).
$\underline{w}^{(i)}$	Vector used in the BFGS method (solution of nonlinear equations).
W	Preselected increment in external work (automatic load step incrementation).
${}^t\delta W$	Strain energy density per unit original volume, evaluated at time t (analysis of rubberlike materials).
tW_P	Plastic work per unit volume (elasto-plastic analysis).
tX_i	Coordinate of a material particle in the i th direction at time t .
${}^tX_i^k$	Coordinate of node k in the i th direction at time t .
${}^t\delta X_{i,j}$, ${}^t\delta X_{ij}$	Components of the deformation gradient tensor, evaluated at time t and referred to the configuration at time 0.
${}^0\delta X_{i,j}$, ${}^0\delta X_{ij}$	Components of the inverse deformation gradient tensor.

Glossary of Greek Symbols

α	Parameter used in the α -method of time integration. $\alpha = 0$ - Euler forward method $\alpha = 1/2$ - Trapezoidal rule $\alpha = 1$ - Euler backward method	$\frac{\partial f}{\partial \bar{U}}$	A square coefficient matrix with entries $\left[\frac{\partial f_i}{\partial \bar{U}_j} \right]_{ij} = \frac{\partial f_i}{\partial \bar{U}_j}$ (solution of nonlinear equations).
α_k	Incremental nodal point rotation for node k about the \underline{V}_1^k vector (shell analysis).	δ	When used before a symbol, this denotes "variation in."
α_t	Coefficient of thermal expansion (thermo-elasto-plastic and creep analysis).	δ_{ij}	Kronecker delta; $\delta_{ij} = \begin{cases} 0; & i \neq j \\ 1; & i = j \end{cases}$
β	Line search parameter (used in the solution of nonlinear equations).	$\underline{\delta}^{(i)}$	Displacement vector in the BFGS method.
β	Section rotation of a beam element.	$\Delta\ell$	"Length" used in the constant arc-length constraint equation (automatic load step incrementation).
β_k	Incremental nodal point rotation for node k about the \underline{V}_2^k vector (shell analysis).	Δt	Time step used in incremental or dynamic analysis.
γ	Transverse shear strain in a beam element.	Δt_{cr}	Critical time step (dynamic analysis).
γ	Fluidity parameter used in viscoplastic analysis.	$\Delta \underline{U}^{(i)}$	Increment in the nodal point displacements during equilibrium iterations $\Delta \underline{U}^{(i)} = {}^{t+\Delta t} \underline{U}^{(i)} - {}^{t+\Delta t} \underline{U}^{(i-1)}$
γ	Related to the buckling load factor λ through the relationship $\gamma = \frac{\lambda - 1}{\lambda}$	$\Delta \bar{U}$	Vector giving the direction used for line searches (solution of nonlinear equations).
γ	Proportionality coefficient between the creep strain rates and the total deviatoric stresses (creep analysis).	$\Delta \bar{U}^{(i)}, \Delta \bar{U}$	Intermediate displacement vectors used during automatic load step incrementation.
$\gamma^{(i)}$	Force vector in the BFGS method.		

$\Delta X^{(k)}$	Increment in the modal displacements (mode superposition analysis).	λ	Proportionality coefficient in calculation of the plastic strain increments (plastic analysis).
ΔT	A time step corresponding to a subdivision of the time step Δt (plastic analysis).	μ	Lamé constant (elastic analysis). $\mu = \frac{E}{2(1 + \nu)}$
${}^t\epsilon_{ij}^0$	Components of Green-Lagrange strain tensor, evaluated at time t and referred to time 0.	ν	Poisson's ratio.
${}^0\epsilon_{ij}$	Components of increment in the Green-Lagrange strain tensor: ${}^0\epsilon_{ij} = {}^{t+\Delta t}{}^0\epsilon_{ij} - {}^0\epsilon_{ij}$	ν_{ab}	Poisson's ratio referred to the local coordinate system $a-b$ (orthotropic analysis).
${}^t\epsilon_{ij}^a$	Components of Almansi strain tensor.	Π	Total potential energy (fracture mechanics analysis).
η, ξ, ζ	Convected coordinate system (used in beam analysis).	${}^t\rho$	Mass density, evaluated at time t .
${}^0\eta_{ij}$	The "nonlinear" part of the increment in the Green-Lagrange strain tensor.	${}^t\sigma_{ij}$	Components of stress tensor evaluated at time t in M.N.O. analysis.
θ_k	Nodal point rotation for node k (two-dimensional beam analysis).	${}^t\bar{\sigma}$	Effective stress (used in creep analysis) ${}^t\bar{\sigma} = \sqrt{\frac{3}{2} {}^t\sigma_{ij} {}^t\sigma_{ij}}$
θ_i^k	Nodal point rotation for node k about the x_i axis (beam analysis).	${}^t\sigma_y$	Yield stress at time t (plastic analysis).
${}^t\theta$	Temperature at time t (thermo-elasto-plastic and creep analysis).	σ_y	Initial yield stress (plastic analysis).
t_k	Variable in plastic analysis.	\sum_m	Denotes "sum over all elements."
λ	Lamé constant (elastic analysis). $\lambda = \frac{E\nu}{(1 + \nu)(1 - 2\nu)}$	$\underline{{}^t\sigma}$	Vector containing the components of the stress tensor in M.N.O. analysis.
λ	Scaling factor used to scale the stiffness matrix and load vector in linearized buckling analysis.	T	(as a left superscript)—Denotes a time.
${}^t\lambda$	Load factor used to obtain the current loads from the reference load vector: ${}^tR = {}^t\lambda R$ (automatic load step incrementation).	Examples	${}^tK, {}^tR$ - linearized buckling analysis tK - solution of nonlinear equations
		${}^tT_{ij}$	Components of Cauchy stress tensor, evaluated at time t .
		tT	Matrix containing the components of the Cauchy stress tensor (U.L. formulation).

$\hat{\underline{T}}$	Vector containing the components of the Cauchy stress tensor (U.L. formulation).
$\underline{\Phi}$	A vector containing the nodal point displacements corresponding to a buckling mode shape.
$\underline{\Phi}_i$	A vector containing the nodal point displacements corresponding to the i th mode shape.
ω_i	Natural frequency of the i th mode shape.
$\omega_n^{(m)}$	Largest natural frequency of element m .
$(\omega_n^{(m)})_{\max}$	Largest natural frequency of all individual elements.

MIT OpenCourseWare
<http://ocw.mit.edu>

Resource: Finite Element Procedures for Solids and Structures
Klaus-Jürgen Bathe

The following may not correspond to a particular course on MIT OpenCourseWare, but has been provided by the author as an individual learning resource.

For information about citing these materials or our Terms of Use, visit: <http://ocw.mit.edu/terms>.