

GhostTint Installation Guide

Everything you need to install your SPD smart tint film and wireless remote, from cleaning the glass to wiring the control box into your vehicle's ACC circuit.

STEP 01

Clean the Window

Use a microfiber cloth to clean the glass thoroughly for best adhesion.

STEP 02

Measurement

Measure the window and position the tint film accurately before cutting.

STEP 03

Trim Excess Tint Film

Trim the film carefully to match your window shape for a perfect fit.

STEP 04

Remove the Release Liner

Peel off the liner to expose the adhesive side of the tint film.

STEP 05

Position the Tint Film

Place the film onto the glass and adjust it into the correct position.

STEP 06

Scrape & Remove Bubbles

Use a squeegee to push out any air bubbles for a smooth finish.

STEP 07

Remove Door Panel

Carefully remove the door panel to access the power supply and wiring.

STEP 08

Connect Tint to ACC Power Supply

Connect the tint system's wiring to the ACC circuit for power.

STEP 09

Install Door Panel Back

Screw the panel back on securely after completing wiring.

STEP 10

Smart Tint Ready to Use

Your smart tint is now installed — test with remote/ACC to confirm smooth operation.

Need help partway through? Visit theghosttint.com/pages/installation for the video walkthrough and troubleshooting, or theghosttint.com/pages/contact to reach us directly.