

# MPLAB® XC16 USER'S GUIDE FOR EMBEDDED ENGINEERS

# MPLAB® XC16 User's Guide for Embedded Engineers

### INTRODUCTION

This document presents five code examples for 16-bit devices and the MPLAB® XC16 C compiler. Some knowledge of microcontrollers and the C programming language is necessary to use them.

- 1. Turn LEDs On or Off
- 2. Flash LEDs Using delay() Function
- 3. Count Up on LEDs Using Interrupts as Delay
- 4. Display Potentiometer Values on LEDs Using an ADC
- 5. Display EEPROM Data Values on LEDs
- A Run Code in MPLAB X IDE
- B Get Software and Hardware

### 1. TURN LEDS ON OR OFF

This example will light alternate LEDs on the Explorer 16/32 Development Board with a PIC24FJ128GA010 Plug-In Module (PIM). For more information, see Section B. "Get Software and Hardware".

```
#include <xc.h> ← see Section 1.1
// PIC24FJ128GA010 Configuration Bit Settings
                            see Section 1.2
// For more on Configuration Bits, ◀─
// consult your device data sheet
// CONFIG2
#pragma config OSCIOFNC = ON // OSC2/CLKO/RC15 as port I/O (RC15)
#pragma config FCKSM = CSDCMD // Clock Switching and Monitor disabled
// CONFIG1
#pragma config WDTPS = PS32768 // Watchdog Timer Postscaler (1:32,768)
#pragma config FWPSA = PR128  // WDT Prescaler (1:128)
int main(void) {
  // Port A access ← see Section 1.4
  AD1PCFG = 0xFFFF; // set to digital I/O (not analog)
  TRISA = 0x0000; // set all port bits to be output
  LATA = LEDS ON OFF; // write to port latch
  return 0;
```

### 1.1 Header File <xc.h>

This header file allows code in the source file to access compiler- or device-specific features. This and other header files may be found in the MPLAB XC16 installation directory, in the support subdirectory.

Based on the selected device, the compiler will set macros that allow xc.h to vector to the correct device-specific header file. Do not include a device-specific header in your code or your code will not be portable.

### 1.2 Configuration Bits

Microchip devices have configuration registers with bits that enable and/or set up device features.

**Note:** If you do not set Configuration bits correctly, your device will not operate at all, or at least not as expected.

### 1.2.1 WHICH CONFIGURATION BITS TO SET

In particular, you need to look at:

Oscillator selection – this must match your hardware's oscillator circuitry. If this
is not correct, the device clock may not run. Typically, development boards use
high-speed crystal oscillators. From the example code:

```
#pragma config FNOSC = PRI
#pragma config POSCMOD = XT
```

• **Watchdog timer** – it is recommended that you disable this timer until it is required. This prevents *unexpected resets*. From the example code:

```
#pragma config FWDTEN = OFF
```

• **Code protection** – turn off code protection until it is required. This ensures that *device memory is fully accessible*. From the example code:

```
#pragma config GCP = OFF
```

Different configuration bits might need to be set up to use another 16-bit device (rather than the MCU used in this example). See your device data sheet for the number and function of corresponding configuration bits. Use the part number to search <a href="http://www.microchip.com">http://www.microchip.com</a> for the appropriate data sheet.


For more about configuration bits that are available for each device, see the following file in the location where MPLAB XC16 was installed:

MPLAB XC16 Installation Directory/docs/config\_index.html

### 1.2.2 HOW TO SET CONFIGURATION BITS

In MPLAB X IDE, you can use the Configuration Bits window to view and set these bits. Select *Window>PIC Memory Views>Configuration Bits* to open this window.

### FIGURE 1: CONFIGURATION BITS WINDOW



After you have selected your settings, click into your code at the location you want the pragma directives placed and click the **Insert Source Code in Editor** icon.

Alternately you can click **Generate Source Code to Output** and copy the pragma directives from the Output window into your code.

### 1.3 Define Macro for LED Values

The value to be written to the LEDs, as explained in the next section, has been assigned to a descriptive macro (LEDS\_ON\_OFF), i.e., LEDs D3, D5, D7, and D9 will be on, and LEDs D4, D6, D8 and D10 will be off. See Section B. "Get Software and Hardware" for the demo board schematic location.

### 1.4 Port Access

Digital I/O device pins may be multiplexed with peripheral I/O pins. To ensure that you are using digital I/O only, disable the other peripheral(s). Do this by using the predefined C variables that represent the peripheral registers and bits. These variables are listed in the device-specific header file in the compiler include directory. To determine which peripherals share which pins, refer to your device data sheet.

For the example in this section, Port A pins are multiplexed with peripherals that are disabled by default. The only issue is that the pins default to analog; so, you will need to set them to digital I/O:

```
AD1PCFG = 0xFFFF; // set to digital I/O (not analog)
```

A device pin is connected to either a digital I/O port (PORT) or latch (LAT) register in the device. For the example, LATA is used. The macro LEDS\_ON\_OFF is assigned to the latch:

```
LATA = LEDS ON OFF; // write to port latch
```

In addition, there is a register for specifying the directionality of the pin – either input or output – called a TRIS register. For the example in this section, TRISD and TRISB are used. Setting a bit to 0 makes the pin an output, and setting a bit to 1 makes the pin an input. For this example:

TRISA = 0x0000; // set all port bits to be output

### 2. FLASH LEDs USING delay() FUNCTION

This example is a modification of the previous code. Instead of just turning on LEDs, this code will flash alternating LEDs.

```
#include <xc.h>
#include de <le>de <le>de
// PIC24FJ128GA010 Configuration Bit Settings
// For more on Configuration Bits, consult your device data sheet
// CONFIG2
#pragma config POSCMOD = XT // XT Oscillator mode selected
#pragma config OSCIOFNC = ON // OSC2/CLKO/RC15 as port I/O (RC15)
#pragma config FCKSM = CSDCMD // Clock Switching and Monitor disabled
#pragma config FNOSC = PRI // Primary Oscillator (XT, HS, EC)
// CONFIG1
#pragma config WDTPS = PS32768 // Watchdog Timer Postscaler (1:32,768)
#pragma config FWPSA = PR128 // WDT Prescaler (1:128)
#define LEDS ON OFF 0x55
#define LEDS OFF ON 0xAA
#define IC DELAY 1500000
int main(void) {
         // Port A access
        AD1PCFG = 0xffff; // set to digital I/O (not analog)
        TRISA = 0x0000; // set all port bits to be output
        while (1) { ◀──── see Section 2.2
                 LATA = LEDS ON OFF; // write to port latch
                  // delay value change ← see Section 2.3
                  delay32(IC DELAY); // delay in instruction cycles
                 LATA = LEDS OFF ON; // write to port latch
                  delay32(IC DELAY); // delay in instruction cycles
         return -1;
}
```

### 2.1 Library Header File

In this example, the delay32 function from the libpic30 compiler library is used. To access this library, libpic30.h must be included.

### 2.2 The while () Loop and Variable Values

To make the LEDs on Port A change, the macro  $LEDS_ON_OFF$  is assigned in the first part of the loop and a complementary macro,  $LEDS_OFF_ON$ , is assigned in the second part of the loop. To perform the loop, while(1) { } was used.

If the main function returns, it means there was an error, as the while loop should not normally end. There, a -1 is returned.

### 2.3 The delay() Function

Because the speed of execution will, in most cases, cause the LEDs to flash faster than the eye can see, execution needs to be slowed. \_\_delay32() is a library function that can be used by compiler.

For more details on the delay function, see the *16-Bit Language Tools Libraries Reference Manual* (DS50001456).

### 3. COUNT UP ON LEDS USING INTERRUPTS AS DELAY

This example is a modification of the previous code. Although the delay function in the previous example was useful in slowing down loop execution, it created dead time in the program. To avoid this, a timer interrupt can be used.

```
#include <xc.h>
// PIC24FJ128GA010 Configuration Bit Settings
// For more on Configuration Bits, consult your device data sheet
// CONFIG2
#pragma config POSCMOD = XT // XT Oscillator mode selected
#pragma config OSCIOFNC = ON // OSC2/CLKO/RC15 as port I/O (RC15)
#pragma config FCKSM = CSDCMD // Clock Switching and Monitor disabled
// CONFIG1
#pragma config WDTPS = PS32768 // Watchdog Timer Postscaler (1:32,768)
#pragma config FWPSA = PR128 // WDT Prescaler (1:128)
// Interrupt function ← see Section 3.1
void __attribute__((interrupt, no auto psv)) T1Interrupt(void){
  // static variable for permanent storage duration
  static unsigned char portValue = 0;
  // write to port latch
  LATA = portValue++;
  // clear this interrupt condition
  _{T1IF} = 0;
int main(void) {
  // Port A access
  AD1PCFG = 0xFFFF; // set to digital I/O (not analog)
  TRISA = 0x0000; // set all port bits to be output
  T1CON = 0x8010; // timer 1 on, prescaler 1:8, internal clock
  _T1IE = 1; // enable interrupts for timer 1
  T1IP = 0x001; // set interrupt priority (lowest)
  while(1);
  return -1;
```

### 3.1 The Interrupt Function isr()

Functions are made into interrupt functions by using the interrupt attribute. Program Space Visibility (PSV) should be specified also, and for this simple example no PSV is used. For more on PSV, see the "MPLAB XC16 C Compiler User's Guide" (DS50002071).

The primary interrupt vector specific to Timer 1 is used, \_\_T1Interrupt. Interrupt Vector Tables for each device are provided in the compiler install docs directory.

Within the interrupt function, the counter portValue is incremented when Timer1 generates an interrupt.

### 3.2 Timer1 Setup

Code also needs to be added to the main routine to turn on and set up the timer, enable timer interrupts, and change the latch assignment, now that the variable value changes are performed in the interrupt service routine.

### 4 DISPLAY POTENTIOMETER VALUES ON LEDS USING AN ADC

This example uses the same device and Port A LEDs as the previous example. However, in this example, values from a potentiometer (slider) on the demo board provide Analog-to-Digital Converter (ADC) input through Port B that is converted and displayed on the LEDs.

Instead of generating code by hand, the MPLAB Code Configurator (MCC) is used. The MCC is a plug-in available for installation under the MPLAB X IDE menu <u>Tools>Plugins</u>, **Available Plugins** tab. See MPLAB X IDE Help for more on how to install plugins.

For MCC installation information and the *MPLAB*<sup>®</sup> *Code Configurator User's Guide* (DS40001725), go to the MPLAB Code Configurator web page at the following URL:

http://www.microchip.com/mplab/mplab-code-configurator

For this example, the MCC was set up as shown in the following figures.

Projects Files Classes Resource Management [MCC] 

Project Resources Generate

▼ System


Interrupt Module

Pin Module

System Module

FIGURE 2: ADC PROJECT RESOURCES - SYSTEM MODULE

### FIGURE 3: ADC PROJECT SYSTEM MODULE CONFIGURATION







FIGURE 5: ADC PROJECT ADC1 CONFIGURATION



### FIGURE 6: ADC PROJECT ADC1 PIN RESOURCE






FIGURE 7: ADC PROJECT RESOURCES - PIN MODULE




### FIGURE 8: ADC PROJECT I/O PIN CONFIGURATION



### FIGURE 9: ADC PROJECT I/O PIN RESOURCES

Package:	TQFP100 ▼	Pin No:	17	38	58	59	60	61	91	92	28	29	66	67	25	24	23	22	21	20	26	27	32
				-				Port	A V			-		-			-			-		Port	В
Module	Function	Direction	0	1	2	3	4	5	6	7	9	10	14	15	0	1	2	3	4	5	6	7	8
	ANx	input													B B '	î.	î.	î.	a	Ъ	î.	æ	
ADC1 ▼	VREF+	input										æ											
	VREF-	input									æ												
	PGCx	input														Ъ					â		
ICD ▼	PGDx	input													æ							â	
OSC	CLKO	output																					
Pin Module ▼	GPIO	input	ì	î.	în.	îa.	î.	în e	æ	în.	î.	îa	æ	æ	ì	æ	æ	æ	Ъ	æ	Ъ	æ	æ
	GPIO	output	A	A	â	â	A	A	A	â	)ia	æ	æ	î.	æ	æ	î.	æ	î.	æ	î.	æ	æ




When the code is configured as shown in the previous figures, click the **Generate** button in the "Project Resources" window (Figure 7). Code generated by the MCC is modular. Therefore main, system and peripheral code are all in individual files. Also, each peripheral has its own header file.

Traps files are generated to catch potential errors. Although no interrupts will be used in this application, interrupt manager files are generated for future use.

Editing of main.c is always required to add functionality to your program. Review the generated files to find any functions or macros you may need in your code.

FIGURE 11: ADC PROJECT TREE FOR CODE GENERATED BY MCC



### 4.1 main.c Modified Code

The main.c template file has been edited as shown below. Some comments have been removed as described in < >. Code added to main() is in red.

```
Generated Main Source File
<See generated main.c file for file information.>
/*
(c) 2016 Microchip Technology Inc. and its subsidiaries. You may use
this software and any derivatives exclusively with Microchip products.
<See generated main.c file for additional copyright information.>
*/
#include "mcc generated files/mcc.h"
unsigned int value = 0;
/*
                        Main application
* /
int main(void) {
   // initialize the device
   SYSTEM Initialize();
    while (1) {
       // Wait for conversion ← see Section 4.2
        // and then get result
       while(!ADC1 IsConversionComplete());
       value = ADC1 ConversionResultGet();
       // Shift for MSb
       value = value >> 2;
       // Write to Port Latch/LEDs See Section 4.3
       LATA = value;
   return -1;
End of File
* /
```

### 4.2 ADC Conversion and Result

MCC sets AD1CON1 bits to turn on the ADC, use automatic sample acquisition, and use an internal counter to end sampling and start conversion. Therefore main() code only needs to wait for the conversion to end and get the result.

From the adc1.c module, use the functions:

```
bool ADC1_IsConversionComplete(void)
uint16 t ADC1 ConversionResultGet(void)
```

For information on setting up other ADC features, see the *dsPIC33/PIC24 Family Reference Manual*, "Section 17. 10-bit Analog-to-Digital Converter (ADC)" (DS61104).

Since only 8 LEDs are available, and the ADC conversion result is 10-bit, the conversion result in the variable value is shifted to display the most significant bits. Some resolution will be lost.

### 4.3 Write to Port Latch and LEDs

The ADC conversion result value is displayed on the Port A LEDs.

### 5. DISPLAY EEPROM DATA VALUES ON LEDS

This example uses another Microchip device, the PIC24F32KA304 MCU, with the Explorer 16/32 board, to demonstrate how to write to and read from EEPROM Data (EEData). Read values are displayed on LEDs accessed from three ports.

MPLAB Code Configurator (MCC) is used to generate some of the code. To find out how to install and get the user's guide for MCC, see: Section 4 "Display Potentiometer Values on LEDs Using an ADC".

For this example, the MCC GUI was used to set up the System (oscillator speed, configuration bits, etc.) and the General Purpose I/O (GPIO) for Ports A, B, and C (Figure 12). However, at this time, there is no EEData device resource available for 16-bit devices.

Code for using the EEData module is found in the device data sheet and the dsPIC33/PIC24 Family Reference Manual, "Section 5. "Data EEPROM", both located on the device web page:

http://www.microchip.com/PIC24F32KA304






FIGURE 12: EEDATA PROJECT RESOURCES - SYSTEM MODULE

FIGURE 13: **EEDATA PROJECT SYSTEM MODULE CONFIGURATION** Start Page 🔞 🧺 MPLAB X Store 🕸 💯 MPLAB® Code Configurator 💸 System Module 👸 Easy Setup 🗏 Registers 🚹 Notifications : 0 ▼ INTERNAL OSCILLATOR 8000000 FRC Oscillator (8.0 MHz) Clock Source ▼ ✓ FRC Postscaler 8 MHz Postscaler PLL Enable 8 MHz Fosc 4 MHz Fosc/2 Clock Output Pin Configuration CLKO output disabled Use Secondary Oscillator (31 - 33) kHz **Enable Clock Switching** Enable Fail-Safe Monitor ▼ ICD Emulator Pin Placement | EMUC/EMUD share PGC3/PGD3 **▼** WATCHDOG WDT disabled in hardware; SWDTEN bit disabled Enable Clock Settings Mode Standard WDT selected(windowed WDT disabled) Timer Prescaler WDT prescaler ratio of 1:128 Timer Postscaler 1:32768 Time-out Period | 131.072s

FIGURE 14: EEDATA PROJECT RESOURCES - PIN MODULE



### FIGURE 15: EEDATA PROJECT I/O PIN CONFIGURATION



Pins RA9:11, RB2:3, RB12 and RC8:9 will appear in the window above when they are selected in Figure 16. RB6 and RB7 are preselected for debug communication.

Once visible in the window, pin configurations may be viewed or selected for each pin.

FIGURE 16: EEDATA PROJECT I/O PIN RESOURCES





FIGURE 17: EEDATA PROJECT PIN PACKAGE



After your code is configured (as shown in the previous figures), click the **Generate** button on the "Project Resources" window. Code generated by the MCC is modular. Therefore main, system, and peripheral code are all in individual files. Also, each peripheral has its own header file.

Traps files are generated to catch potential errors. Although no interrupts will be used in this application, interrupt manager files are generated for future use.

FIGURE 18: EEDATA PROJECT TREE FOR CODE GENERATED BY MCC Projects % Files Resource Manag... Classes Example 5 in Header Files i MCC Generated Files ---- 🖭 interrupt\_manager.h mcc.h pin\_manager.h traps.h Important Files · 🔁 Makefile MyConfig.mc3 Linker Files .... 🖭 main.c i → A MCC Generated Files · 🏰 interrupt\_manager.c · 🖭 mcc.c pin\_manager.c traps.c Libraries Loadables


The GPIO-generated files default to analog input, so they must be changed to digital input in the pin manager.c file (Section 5.1).

In addition, because LED connections are not to one port but spread across three, an additional type definition and code to assign the port pins to the correct LED values are needed. A header file, LEDs.h (Section 5.2), and a C file, LEDs.c (Section 5.3), have been added to the project.

As previously mentioned, there is no EEData device resource currently available in MCC for 16-bit devices, so code needs to be added by hand. A header file eedata.h (Section 5.4) and a C file, eedata.c (Section 5.5), have been added to the project.

The final project tree will appear as shown in Figure 19.





Editing of main.c is always required to add functionality to your program (Section 5.6). Review the generated files and additional files to find any functions or macros you may need in your code.

### 5.1 pin manager.c Modified Code

The main.c template file has been edited as shown below. Some comments and generated content have been removed as described in < >. Code that is changed is shown in red.

```
System Interrupts Generated Driver File
<See generated pin manager.c for file information.>
Copyright (c) 2013 - 2015 released Microchip Technology Inc. All
rights reserved.
<See generated pin manager.c for additional copyright information.>
   Section: Includes
#include <xc.h>
#include "pin manager.h"
   void PIN MANAGER Initialize(void)
void PIN MANAGER Initialize(void) {
<See generated pin_manager.c for port setup information.>
/***********************
 * Setting the Analog/Digital Configuration SFR(s)
   ANSA = 0x0;
   ANSB = 0x0;
   ANSC = 0x0;
```

### 5.2 LEDs.h Code

Some comments have been removed as described in < >.

```
* PICF32KA304 LEDs header
* (c) Copyright 1999-2015 Microchip Technology, All rights reserved
<See generated header files for additional copyright information.>
/************************
 * Union of structures to hold value for display on LEDs
* LAT LEDx - bit fields of value
* w - entire value
*******************
typedef union {
   struct {
    unsigned LAT LED0:1;
    unsigned LAT LED1:1;
    unsigned LAT LED2:1;
    unsigned LAT LED3:1;
    unsigned LAT LED4:1;
     unsigned LAT LED5:1;
     unsigned LAT LED6:1;
    unsigned LAT LED7:1;
   };
   struct {
    unsigned w:16;
   };
} LAT LEDSBITS;
extern volatile LAT LEDSBITS LAT LEDSbits;
/* LAT LEDSBITS */
#define LEDO LAT LEDSbits.LAT LEDO
       LED1 LAT LEDSbits.LAT LED1
#define |
#define _LED2 LAT_LEDSbits.LAT_LED2
#define _LED3 LAT_LEDSbits.LAT_LED3
#define _LED4 LAT_LEDSbits.LAT_LED4
#define _LED5 LAT_LEDSbits.LAT LED5
#define _LED6 LAT_LEDSbits.LAT_LED6
#define _LED7 LAT LEDSbits.LAT LED7
#define LEDS LAT LEDSbits.w
* Function: DisplayValueOnLEDs
* Precondition: None.
* Overview: Display input value on Explorer 16 LEDs
* Input: Value to display
* Output: None.
         *************************
void DisplayValueOnLEDs(unsigned int value);
End of File
* /
```

### 5.3 LEDs.c Code

```
Some comments have been removed as described in < >.
 Display on LEDs Source File
<See LEDs.c for file description information.>
* /
Copyright (c) 2013 - 2015 released Microchip Technology Inc. All
rights reserved.
<See generated header files for additional copyright information.>
#include "mcc generated files/mcc.h"
#include "LEDs.h"
volatile LAT LEDSBITS LAT LEDSbits;
* Function: DisplayValueOnLEDs
 * Precondition: None.
 * Overview: Display input value on Explorer 16 LEDs
 * Input: Value to display
 * Output: None.
 void DisplayValueOnLEDs(unsigned int value) {
   LEDS = value;
    \_LATA9 = \_LED0;
    \_LATA10 = \_LED1;
    _LATA11 = _LED2;
_LATC8 = _LED3;
    _
_LATC9 = _LED4;
   _LATB12 = _LED5;
_LATB2 = _LED6;
   LATB3 = LED7;
End of File
```

### 5.4 eedata.h Code

Some comments have been removed as described in < >. \* PICF32KA304 Data EEPROM header \* (c) Copyright 1999-2015 Microchip Technology, All rights reserved <See generated header files for additional copyright information.> /\* \* Function: EEData WTL \* Precondition: None. \* Overview: Write one word of EEData \* Input: Action to take: Erase or Write, Data to write \* Output: None. \*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\* void EEData WTL(unsigned int action, unsigned int data); /\* \* Function: EEData\_Erase \* Precondition: None. \* Overview: Set up erase of one word of EEData \* Input: None. \* Output: None. \* void EEData Erase(void); /\* \* Function: EEData Write \* Precondition: None. \* Overview: Set up write of one word of EEData \* Input: Data to write \* Output: None. \* void EEData Write (unsigned int data); \* Function: EEData Read \* Precondition: None. \* Overview: Read one word of EEData \* Input: None. \* Output: Value read from EEData \*\*\*\*\*\*\*\*\*\*\* unsigned int EEData Read(void); End of File

### 5.5 eedata.c Code

```
Some comments have been removed as described in < >.
 Data EEPROM Write and Read
<See eedata.c for file description information.>
* /
Copyright (c) 2013 - 2015 released Microchip Technology Inc. All
rights reserved.
<See generated header files for additional copyright information.>
#include <xc.h>
#include "eedata.h"
#define ERASE EEWORD 0x4058
#define WRITE EEWORD 0x4004
int attribute ((space(eedata))) eeData = 0x0;
unsigned int offset = 0x0;
/******************************
 * Function: EEData WTL
* Precondition: None.
* Overview: Write one word of EEData
* Input: Action to take: Erase or Write, Data to write
* Output: None.
 void EEData WTL(unsigned int action, unsigned int data) {
   // Set up NVMCON to write one word of data EEPROM
   NVMCON = action;
   // Set up a pointer to the EEPROM location to be written
   TBLPAG = __builtin_tblpage(&eeData);
   offset = builtin tbloffset(&eeData);
   builtin tblwtl(offset, data);
   // Issue Unlock Sequence & Start Write Cycle
   __builtin_write_NVM();
   // Wait for completion
   while (NVMCONbits.WR);
/***********************
* Function: EEData Erase
* Precondition: None.
* Overview: Set up erase of one word of EEData
* Input: None.
* Output: None.
**************************************
void EEData Erase(void) {
   EEData WTL(ERASE EEWORD, 0);
```

```
/************************
* Function: EEData_Write
* Precondition: None.
* Overview: Set up write of one word of EEData
* Input: Data to write
* Output: None.
******************************
void EEData Write(unsigned int data) {
   EEData WTL(WRITE EEWORD, data);
/***************************
* Function: EEData_Read
* Precondition: None.
* Overview: Read one word of EEData
* Input: None.
* Output: Value read from EEData
******************************
unsigned int EEData Read(void) {
   // Set up a pointer to the EEPROM location to be read
   TBLPAG = __builtin_tblpage(&eeData);
   offset = __builtin_tbloffset(&eeData);
   // Read the EEPROM data
   return __builtin_tblrdl(offset);
/**
End of File
```

### 5.6 main.c Modified Code

The main.c template file has been edited as shown below. Some comments have been removed as described in < >. Code that has been added is shown in red.

```
Generated Main Source File
<See generated main.c for file information.>
/*
(c) 2016 Microchip Technology Inc. and its subsidiaries. You may use
this software and any derivatives exclusively with Microchip products.
<See generated main.c for additional copyright information.>
#include "mcc generated files/mcc.h"
#include "eedata.h"
#include "LEDs.h"
#include "libpic30.h"
#define IC DELAY 1000000
unsigned int data write = 0x0;
unsigned int data read = 0x0;
/*
                        Main application
* /
int main(void) {
    // initialize the device
    SYSTEM Initialize();
    while (1) {
       data write++;
        // Erase one word of data EEPROM ← see Section 5.7
       EEData Erase();
        // Write one word of data EEPROM
        EEData Write(data write);
        // Read one word of data EEPROM ← See Section 5.8
        data read = EEData Read();
                                         see Section 5.9
        // Display result on LEDs
        DisplayValueOnLEDs(data read);
        // Delay change on LEDs so visible
        delay32(IC DELAY); // delay in instruction cycles
    }
    return -1;
 End of File
 */
```

### 5.7 Erase and Write to EEData

To write a single word in the EEData, the following sequence must be followed:

- Erase one data EEPROM word.
- 2. Write the data word into the data EEPROM latch.
- 3. Program the data word into the EEPROM.

The code to erase and write one word to EEData is found in eedata.c (Section 5.5).

For a PIC24F32KA304 device, a key sequence needs to be written to NVMKEY (in NVMCON) before EEData can be erased or written.

Built-in functions are used to simplify coding:

```
unsigned int __builtin_tblpage(const void *p);
unsigned int __builtin_tbloffset(const void *p);
void __builtin_tblwtl(unsigned int offset, unsigned int data);
void __builtin_write NVM(void);
```

Details on these functions may be found in the *MPLAB XC16 C Compiler User's Guide* (DS50002071), Appendix G. "Built-in Functions".

### 5.8 Read from EEData

For this example, after EEData is written, the word of EEData is read.

The code to read one word to EEData is found in eedata.c (Section 5.5).

Again, built-in functions are used to simplify coding:

```
    unsigned int __builtin_tblpage(const void *p);
    unsigned int __builtin_tbloffset(const void *p);
    unsigned int __builtin_tblrdl(unsigned int offset);
```

Details on these functions may be found in the *MPLAB XC16 C Compiler User's Guide* (DS50002071), Appendix G. "Built-in Functions".

### 5.9 Display Data on LEDs and Delay

Displaying the data on the demo board LEDs is more involved for this device, as three ports provide connections to the LEDs. Therefore, union and structure data types are used so that the whole data value can be assigned ( $LAT\_LEDSbits.w$ ), and then individual bits may be accessed so they can be assigned to the correct port pins for display (e.g., LATAbits.LATA9 = LAT LEDSbits.LAT LED0).

The code creating the union and structures is found in LEDs.h (Section 5.2).

The code assigning the port pins to LED values is found in LEDs.c (Section 5.5).

Because the speed of execution will, in most cases, cause the LEDs to flash faster than the eye can see, the \_delay() function is used again (as in Section 2.) to slow execution.

### A. RUN CODE IN MPLAB X IDE

First, create a project:

- 1. Launch MPLAB X IDE.
- 2. From the IDE, launch the New Project Wizard (File>New Project).
- 3. Follow the screens to create a new project:
  - a) **Choose Project:** Select "Microchip Embedded", and then select "Standalone Project".
  - b) Select Device: Select the example device.
  - c) Select Header: None.
  - d) Select Tool: Select your hardware debug tool by serial number (SN), SNxxxxxx. If you do not see an SN under your debug tool name, ensure that your debug tool is correctly installed. See your debug tool documentation for details.
  - e) Select Plugin Board: None.
  - f) **Select Compiler:** Select XC16 (*latest version number*) [bin location]. If you do not see a compiler under XC16, ensure the compiler is correctly installed and that MPLAB X IDE can find the executable. Select <u>Tools>Options</u>, click the **Embedded** button on the **Build Tools** tab, and look for your compiler. See MPLAB XC16 and MPLAB X IDE documentation for details
  - g) Select Project Name and Folder: Name the project.

Now, create a file to hold the example code (unless you have used MCC):

- Right click on the project name in the Projects window. Select <u>New>Empty File</u>.
   The New Empty File dialog will open.
- 2. Under "File name", enter a name.
- 3. Click Finish.
- 4. Cut and paste the example code from this user's guide into the empty editor window and select *File>Save*.

Build, download to a device, and execute the code by selecting to Debug Run your code. You will see every other LED lit on the demo board. Click Halt to end execution.

# FIGURE 20: TOOLBAR ICONS Debug Main Project DEBUG RUN HALT

### **B. GET SOFTWARE AND HARDWARE**

For the MPLAB XC16 projects in this document, the Explorer 16/32 board with a PIC24F PIM is powered from a 9V external power supply and uses standard (ICSP™) communications. MPLAB X IDE was used for development.

### B.1 Get MPLAB X IDE and MPLAB XC16 C Compiler

MPLAB X IDE v3.45 and later can be found at:

http://www.microchip.com/mplab/mplab-x-ide

The MPLAB XC16 C Compiler v1.26 and later can be found at:

http://www.microchip.com/mplab/compilers

### **B.2** Get the MPLAB Code Configurator (MCC)

The MCC v3.25 and later can be found at:

http://www.microchip.com/mplab/mplab-code-configurator

### B.3 Get PIC® MCU Plug-in Module (PIM)

The PIC MCU PIMs used in the examples are available at the following locations on the Microchip Technology web site:

PIC24FJ128GA010: http://www.microchip.com/MA240011

PIC24F32KA304: http://www.microchip.com/MA240022

### B.4 Get and Set Up the Explorer 16/32 Board

The Explorer 16/32 development board, schematic and documentation are available on the web site:

http://www.microchip.com/dm240001-2

Jumpers and switches were set up as shown in the following table.

TABLE 1-1: JUMPER/SWITCH SELECTS FOR PROJECTS

Jumper/Switch	Selection	Jumper/Switch	Selection				
JP2	Closed	J37	Open				
J19	Open	J38	Open				
J22	Open	J39	Default				
J23	Default	J41	Open				
J25	Closed	J42	Open				
J26	Closed	J43	Default				
J27	Open	J44	Default				
J28	Open	J45	Default				
J29	Open	J50	Closed				
J33	Open						

### **B.5** Get Microchip Debug Tools

Emulators and debuggers may be found on the Development Tools web page:

http://www.microchip.com/development-tools

### Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

# QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV = ISO/TS 16949=

### **Trademarks**

The Microchip name and logo, the Microchip logo, AnyRate, AVR, AVR logo, AVR Freaks, BeaconThings, BitCloud, CryptoMemory, CryptoRF, dsPIC, FlashFlex, flexPWR, Heldo, JukeBlox, KEELOQ, KEELOQ logo, Kleer, LANCheck, LINK MD, maXStylus, maXTouch, MediaLB, megaAVR, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, Prochip Designer, QTouch, RightTouch, SAM-BA, SpyNIC, SST, SST Logo, SuperFlash, tinyAVR, UNI/O, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

ClockWorks, The Embedded Control Solutions Company, EtherSynch, Hyper Speed Control, HyperLight Load, IntelliMOS, mTouch, Precision Edge, and Quiet-Wire are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, Anyln, AnyOut, BodyCom, chipKIT, chipKIT logo, CodeGuard, CryptoAuthentication, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, EtherGREEN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, JitterBlocker, KleerNet, KleerNet logo, Mindi, MiWi, motorBench, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, PureSilicon, QMatrix, RightTouch logo, REAL ICE, Ripple Blocker, SAM-ICE, Serial Quad I/O, SMART-I.S., SQI, SuperSwitcher, SuperSwitcher II, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

 $\ensuremath{\mathsf{SQTP}}$  is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2015-2016, Microchip Technology Incorporated, All Rights Reserved.

ISBN: 978-1-5224-1152-9



### Worldwide Sales and Service

### **AMERICAS**

**Corporate Office** 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277

**Technical Support:** 

http://www.microchip.com/ support

Web Address: www.microchip.com

Atlanta Duluth, GA

Tel: 678-957-9614 Fax: 678-957-1455

Austin, TX Tel: 512-257-3370

**Boston** 

Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL

Tel: 630-285-0071 Fax: 630-285-0075

**Dallas** 

Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

**Detroit** Novi, MI

Tel: 248-848-4000

Houston, TX

Tel: 281-894-5983 Indianapolis

Noblesville, IN Tel: 317-773-8323 Fax: 317-773-5453 Tel: 317-536-2380

Los Angeles

Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608 Tel: 951-273-7800

Raleigh, NC Tel: 919-844-7510

New York NY

Tel: 631-435-6000

San Jose, CA Tel: 408-735-9110 Tel: 408-436-4270

Canada - Toronto Tel: 905-695-1980 Fax: 905-695-2078

### ASIA/PACIFIC

**Asia Pacific Office** Suites 3707-14, 37th Floor Tower 6, The Gateway

Harbour City, Kowloon Hong Kong

Tel: 852-2943-5100 Fax: 852-2401-3431

Australia - Sydney Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing Tel: 86-10-8569-7000

Fax: 86-10-8528-2104 China - Chengdu

Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

China - Chongqing Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

China - Dongguan Tel: 86-769-8702-9880

China - Guangzhou Tel: 86-20-8755-8029

China - Hangzhou Tel: 86-571-8792-8115 Fax: 86-571-8792-8116

China - Hong Kong SAR Tel: 852-2943-5100 Fax: 852-2401-3431

China - Nanjing Tel: 86-25-8473-2460

Fax: 86-25-8473-2470 China - Qingdao Tel: 86-532-8502-7355

Fax: 86-532-8502-7205 China - Shanghai

Tel: 86-21-3326-8000 Fax: 86-21-3326-8021

China - Shenyang Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

China - Shenzhen Tel: 86-755-8864-2200 Fax: 86-755-8203-1760

China - Wuhan Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

China - Xian Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

### ASIA/PACIFIC

China - Xiamen Tel: 86-592-2388138 Fax: 86-592-2388130

China - Zhuhai Tel: 86-756-3210040 Fax: 86-756-3210049

India - Bangalore Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

India - New Delhi Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune Tel: 91-20-3019-1500

Japan - Osaka Tel: 81-6-6152-7160 Fax: 81-6-6152-9310

Japan - Tokyo Tel: 81-3-6880- 3770 Fax: 81-3-6880-3771

Korea - Daegu Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur Tel: 60-3-6201-9857 Fax: 60-3-6201-9859

Malaysia - Penang Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila Tel: 63-2-634-9065 Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu Tel: 886-3-5778-366 Fax: 886-3-5770-955

Taiwan - Kaohsiung Tel: 886-7-213-7830

Taiwan - Taipei Tel: 886-2-2508-8600 Fax: 886-2-2508-0102

Thailand - Bangkok Tel: 66-2-694-1351 Fax: 66-2-694-1350

### **EUROPE**

Austria - Wels Tel: 43-7242-2244-39 Fax: 43-7242-2244-393

Denmark - Copenhagen Tel: 45-4450-2828 Fax: 45-4485-2829

Finland - Espoo Tel: 358-9-4520-820

France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

France - Saint Cloud Tel: 33-1-30-60-70-00

Germany - Garching Tel: 49-8931-9700 Germany - Haan Tel: 49-2129-3766400

Germany - Heilbronn Tel: 49-7131-67-3636

Germany - Karlsruhe Tel: 49-721-625370

Germany - Munich Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Germany - Rosenheim Tel: 49-8031-354-560

Israel - Ra'anana Tel: 972-9-744-7705

Italy - Milan Tel: 39-0331-742611 Fax: 39-0331-466781

Italy - Padova Tel: 39-049-7625286

Netherlands - Drunen Tel: 31-416-690399 Fax: 31-416-690340

Norway - Trondheim Tel: 47-7289-7561

Poland - Warsaw Tel: 48-22-3325737

Romania - Bucharest Tel: 40-21-407-87-50

Spain - Madrid Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

Sweden - Gothenberg Tel: 46-31-704-60-40

Sweden - Stockholm Tel: 46-8-5090-4654

UK - Wokingham Tel: 44-118-921-5800 Fax: 44-118-921-5820