

- To get the specified scale, select 100% in print settings. Drill location tolerance:  $\pm 0.1$  [ $\pm 5$ ]. Board edge tolerance:  $\pm 0.3$  [ $\pm 10$ ]. 1.
- 2.

