

User's Guide 2760342 **Ultrasonic Range Sensor**



Thank you for purchasing your Ultrasonic Ranger Sensor from **RadioShack**. Please read this user's guide before setting up and using your new sensor.

Attention: Observe precautions for handling Electrostatic Sensitive Devices (ESD).

Package Contents

• Ultrasonic Range Sensor

• User's Guide

Features

- Compatible with Arduino and other types of microprocessors
- Ideal for autopiloting projects, security applications, and more
- · Pulse in/pulse out communication

Specifications

| Detection angle | 30° |
|--|-------------------------------|
| Supply voltage | 5 V |
| Current | 15 mA |
| Detecting range | . 1.2 in – 13 ft (3 cm – 4 m) |
| Ultrasonic frequency | 40 kHz |
| Operating temp. range | 32 – 58°F (0 – 70°C) |
| Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document. | |

Connect to Your Arduino


- 1. Connect the Range Sensor to your Arduino:
- SIG to pin D7 VCC to pin 5V GND to pin GND
- Use a USB cable (not included) to connect your Arduino to your computer.

Programming the Sensor

- Go to <u>shack.net/sensor0342</u>. At the end of the blog post, click RadioShack Ultrasonic Range Sensor Support Files, and extract the contents of the folder onto your computer.
- Open UltrasonicRangeSensor.ino in the Arduino programming environment. Verify and upload the program.
- In the Arduino programming environment, open Serial Monitor (9600) to observe output. The output reading will change according to the distance between the sensor and an object placed in front of the sensor.

Required:

- Arduino Board
- Jumper Wires (3)



FCC Information

This equipment has been tested and found to comply with the limits for an ISM (industrial, scientific, medical) device limit, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment.

IMPORTANT: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Limited Warranty

RadioShack warrants this product against defects in materials and workmanship under normal use by the original purchaser for ninety (90) days after the date of purchase from a RadioShack-owned store or an authorized RadioShack franchisee or dealer. RADIOSHACK MAKES NO OTHER EXPRESS WARRANTIES.

This warranty does not cover: (a) damage or failure caused by or attributable to abuse, misuse, failure to follow instructions, improper installation or maintenance, alteration, accident, Acts of God (such as floods or lightning), or excess voltage or current; (b) improper or incorrectly performed repairs by persons who are not a *RadioShack* Authorized Service Facility; (c) consumables such as fuses or batteries; (d) ordinary wear and tear or cosmetic damage; (e) transportation, shipping or insurance costs; (f) costs of product removal, installation, set-up service, adjustment or reinstallation; and (g) claims by persons other than the original purchaser.

Should a problem occur that is covered by this warranty, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store in the U.S. RadioShack will, at its option, unless otherwise provided by law: (a) repair the product without charge for parts and labor; (b) replace the product with the same or a comparable product; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

RADIOSHACK EXPRESSLY DISCLAIMS ALL WARRANTIES AND CONDITIONS NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND, IF APPLICABLE,

THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, SHALL EXPIRE ON THE EXPIRATION OF THE STATED WARRANTY PERIOD.

EXCEPT AS DESCRIBED ABOVE. RADIOSHACK SHALL HAVE NOTIABILITY OF RESPONSIBILITY TO THE PURCHASER OF THE PRODUCT OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE AND ANY LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT AND ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RADIOSHACK HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above

limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. You may contact *RadioShack* at:

RadioShack Customer Relations 300 RadioShack Circle Fort Worth, TX 76102

04/08

www.RadioShack.com



Complies with the European Union's "Restriction of Hazardous Substances Directive," which protects the environment by restricting specific hazardous materials and products.

©2013. **RadioShack** Corporation. All rights reserved. **RadioShack** is a registered trademark used by **RadioShack** Corporation.

Printed 05A13 in China 2760342