```
0001 defaultevents = [0]; // main event
0002
0003 // set-up schematic by calling the user defined
0004 // function "schematic_fn"
0005 insizes = [1,1]; outsizes=[1];
0006 [sim_container_irpar, sim]=<u>libdyn_setup_schematic</u>(schematic_fn, ...
0007
                                 insizes, outsizes);
0008
0009 // Initialise a new parameter set
0010 parlist = new_irparam_set();
0011
0012 // pack simulations into irpar container with id = 901
0013 parlist = new_irparam_container(parlist, sim_container_irpar, 901);
0014
0015 // irparam set is complete convert to vectors
0016 par = combine_irparam(parlist);
0017
0018 // save vectors to a file
0019 save_irparam(par, 'simple_demo.ipar', 'simple_demo.rpar');
```