Programmer's Guide to the MUT Facility

A Facility Which Provides Motif Utility Functions

Stephen M. Moore

Mallinckrodt Institute of Radiology Electronic Radiology Laboratory 510 South Kingshighway Boulevard St. Louis, Missouri 63110 314/362-6965 (Voice) 314/362-6971 (FAX)

Version 2.10.0

August 3, 1998

Copyright (c) 1995, 1998 RSNA, Washington University

1 Introduction

The Motif toolkit provides a number of widgets for developing user interfaces. This facility provides some convenience functions for loading values into widgets and extracting values from widgets.

2 Data Structures

3 Include Files

To use MUT functions, applications need to include these files in the order given below:

```
#include "dicom.h"
#include "condition.h"
#include "mut.h"
```

4 Return Values

The following returns are possible from the MUT facility:

MUT_NORMAL Normal return from MUT facility.

MUT SCANFAILURE Function failed to scan an ASCII fie

Function failed to scan an ASCII field. For example, caller was scanning for an integer and the value to be

scanned was "abc".

5 MUT Routines

This section provides detailed documentation for each MUT facility routine.

Name

MUT_LoadList - load a Motif scrolled list with a set of items.

Synopsis

void MUT_LoadList(Widget w, LST_HEAD *lst, void (*format)(), char *buf)

w The MOTIF scrolled list widget which will be loaded with text items.

lst A list of user items to be placed in the scrolled list.

format A callback function which is invoked for each item in the caller's lst. This function is

expected to fill in a text buffer with the ASCII data to be placed in the widget.

buf A scratch buffer which will be passed to the format function. This buffer should be large

enough to hold the ASCII data created by format.

Description

MUT_LoadList is used to provide a uniform mechanism for loading text items into a Motif scrolled list widget. For each item in the caller's lst, MUT_LoadList invokes the caller's format function with the arguments:

node The node in the list.

i The index of the node in the list (0 - N-1). buffer The ASCII buffer to be filled by format.

format is expected to examine the data in node and create a line of text to be placed in the scrolled list widget. This line of text should be written into *buffer*.

For each line of text it receives from *format*, *MUT_LoadList* creates the appropriate XmString variable and loads it into the list widget.

Notes

The user's *callback* function should know what type of structure to expect. The current implementation uses XmSTRING_DEFAULT_CHARSET as the character set when creating the XmString variable.

It is assumed the caller has knowledge of the structure to be formatted and how the output of the *format* function, allowing the caller to allocate sufficient space in buf.

Return Values

None

Name

MUT_ScanWidget - scan a Motif text widget for data in one of several formats (text, int, float)

Synopsis

CONDITION MUT_ScanWidget(Widget w, MUT_DATATYPE type, CTNBOOLEAN *nullFlag, void *d)

w The widget containing text to be scanned.

type An enumerated type that indicates the format of the data expected by the user.

nullFlag Will be set by this function to indicate if the data in widget w is null.

d Address of caller's data.

Description

MUT_ScanWidget reads the text from a text widget, w, and converts the text into a format that is easily used by the caller. The caller indicates the type of data expected to be in the text widget:

MUT_TEXT Text
MUT_INT Integer
MUT_FLOAT Float

MUT_US Unsigned short

MUT_ScanWidget expects the caller to have allocated enough space to hold the return data. This could be a problem for text data.

Return Values

MUT_NORMAL
MUT_SCANFAILURE