

- 1. Clear wall-board counter to the corner
- 2. Cut in new headers and attach to rafters and external shear
- 3. Cut in new studs, electrical and HVC Vent
- 4. Test fit / check new door and adjust exterior siding
- 5. Cut out exterior shear, install new door, trim exterior
- 6. Clean-up / patch indoor drywall, HVC and electrical