At a glance

Seven swappable back panels for the Any% handheld. Each one is a Bambu Studio project (two colours; four for the ETHGlobal Mumbai panels) that is **already set up and sliced**. The logo is part of the panel and prints fused to its face, so nothing needs gluing.

Item	Detail
Printer	Bambu Lab P2S with AMS
Nozzle	0.4 mm hardened steel (the P2S stock nozzle)
Plate	Textured PEI Plate
Filament	PLA (Bambu PLA Basic profile): 2 colours per panel, 4 for both ETHGlobal Mumbai panels
Per panel	About **2 h**, about **80 g** panel colour and **1 to 2.5 g** logo colour
All seven	About **15 h** and 575 g, one panel per plate
Part size	202 x 124 x 4.8 mm
Supports	None

The files

#	File	AMS slot 1: panel	Logo slots
16	`..._panel_world_...3mf`	White	2: Black
17	`..._panel_arkiv_...3mf`	Blue	2: White
18	`..._panel_arc_...3mf`	Black	2: White
19	`..._panel_chainlink_...3mf`	Blue	2: White
20	`..._panel_ethglobal_mumbai_...3mf`	Black	2: Orange, 3: Red, 4: Green
21	`..._panel_ethglobal_mumbai_lockup_...3mf`	White	2: Orange, 3: Red, 4: Green
22	`..._panel_hedera_...3mf`	Black	2: White

All colours are standard PLA spools already on this printer (Bambu PLA Basic colour codes). Do not use the ABS red or the translucent PETG for panels: they do not bond to PLA in a multi-colour print.



World



Arkiv



Arc



Chainlink



ETHGlobal Mumbai



Mumbai lockup



Hedera

Settings baked into every file

You do not need to change anything. This is what the files contain, so you can check it.

Setting	Value
Printer preset	Bambu Lab P2S 0.4 nozzle
Process preset	0.20mm Standard @BBL P2S
Layer height	0.20 mm, 24 layers: 20 for the panel, 4 for the logo
Walls	4
Top and bottom layers	5 and 5
Infill	25 % gyroid
Brim	5 mm, outer only
Supports	Off
Prime tower	Off. There is only one colour change, and the purge goes to the chute
Plate temperature	55 C (PLA Basic on Textured PEI)
Nozzle temperature	220 C

Printing, step by step

1. **Clean the plate.** Wash the Textured PEI Plate with warm water and dish soap, or wipe it with isopropyl alcohol. Do not touch the print surface afterwards. No glue is needed.
2. **Load the AMS.** Put the panel colour in any slot and the logo colour in another. Let the AMS read the spools, or set their type (PLA) and colour on the printer.
3. **Open the file** in Bambu Studio (File > Open Project, or double-click the .3mf). Say **yes** if it asks to load the project's presets.
4. **Check the top bar.** It should show printer *Bambu Lab P2S 0.4 nozzle* and plate *Textured PEI Plate*. If Bambu Studio asks to sync the nozzle with the printer, accept: the printer reports its 0.4 mm hardened steel nozzle.
5. **Slice.** Click **Slice plate** (the file is pre-sliced, but slicing again is quick and picks up any sync changes). Check the preview: a flat panel with a thin logo on top, and a 5 mm brim round the edge.
6. **Print.** Click **Print plate**. In the send dialog, **map filament 1 to the panel colour spool and filament 2 to the logo colour spool**. For ETHGlobal Mumbai, map all four: 1 black, 2 orange, 3 red, 4 green. For the lockup, map all four: 1 white, 2 orange, 3 red, 4 green. Leave *Bed levelling* ticked and select the Textured PEI Plate.
7. **Wait for it to cool.** When it finishes, let the plate cool for about 5 minutes. Then take it off and flex it gently: the panel pops off.
8. **Trim the brim** with a deburring tool or a craft knife, cutting along the panel's edge.

Repeat for the other files, one panel per plate.

What to expect

- The printer changes colour **once**, after layer 20, at a height of 4.0 mm. From there it prints only the logo, in four layers.
- **The lockup** changes colour several times per logo layer: about 2 h 25 min.
- **ETHGlobal Mumbai** changes colour on each of the four logo layers, cycling orange, pink and green, about a dozen changes. It takes about 20 minutes longer and purges a few extra grams into the chute.
- The flat side on the bed is the **inside** of the panel. It has small magnet pockets, a groove, and the panel's name in mirrored text. That is correct: do not flip the part.
- The logo stands 0.8 mm proud of the panel face.

Quality check

- ☐ Logo edges are crisp, with no panel colour showing on top of the logo
- ☐ The panel is flat. Lay it on a table: the corners should not rock
- ☐ The magnet pockets on the inside are clean round holes, with no stringing inside them
- ☐ The inner groove along the edge is open and not filled with brim or blobs

If something goes wrong

Problem	Fix
The first logo layer looks tinted with the panel colour (dark to light changes, such as navy to light blue or blue to white)	Before slicing, click **Flushing volumes** on the Prepare tab and raise the value from the panel colour to the logo colour, e.g. to 600. Only four layers use it, so little extra is purged
The corners lift	Clean the plate again with soap and water. Raise the plate to 60 C for PLA if it keeps happening
"Filament type or colour mismatch" when sending	Check that both AMS slots are set to PLA, then map each filament to the right slot by hand
No AMS available	Print the single-colour STLs instead (files 12 to 15, 20, 22 and 24 in the main print package) and add a colour change at 4.0 mm in the slicer
The logo is on the wrong colour	Filaments 1 and 2 were swapped in the send dialog. Filament 1 is always the panel colour, filament 2 the logo