# **CHILTON**LIBRARY



## **Removal & Installation**

#### **REMOVAL AND INSTALLATION**

#### **REMOVAL**



- 1. Open the glove box.
- 2. Using a trim stick, remove the switch bank pod assembly (1).
- 3. Remove the screw located in the media hub bezel (3) opening.
- 4. Open the bin (2), and using a trim stick remove the media hub bezel.

### NOTE

Start removing from the center of vehicle and rotate the part outward to release the end from the right side A-pillar extension.

5. Using a trim stick or equivalent, remove the instrument panel center trim panel (4) and disconnect the wire harness connector.

#### **INSTALLATION**



- 1. Insert the outboard end behind the A-pillar extension, then position the instrument panel center trim panel (4) and hand tap to engage the retaining clips.
- 2. Position the media hub bezel (3) and hand tap to engage the retaining clips.
- 3. Install the screw located in the media hub bezel opening, and tighten securely.
- 4. Install the switch bank pod assembly (1).