CHILTONLIBRARY



Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL



- 1. Using a small flat bladed tool, remove the cap (1) from the side of the armrest (2).
- 2. Remove the bolt and the armrest

INSTALLATION



- 1. Position the armrest (2) onto the seat.
- 2. Install the bolt and tighten the second row stow-n-go armrest bolt to the proper (Torque Specifications).
- 3. Install the cap (1).